

Agile

Operating Instructions
Frequency inverter 230 V / 400
0.09 kW ... 11 kW







Content

COI	NTEN	Т	3
1	GENI	ERAL INFORMATION ABOUT THE DOCUMENTATION	.11
1.1	Thi	s document	12
1.2	Wa	rranty and liability	12
1.3	Ob	ligation	13
1.4	Cor	pyright	13
1.5	•	rage	
2		ERAL SAFETY INSTRUCTIONS AND INFORMATION ON USE	
2.1	Ter	minology	14
2.2	Des	signated use	15
2.3		suse	
	3.1	Explosion protection	
2.4	Res	sidual risks	16
2.5	Saf	ety and warning signs at frequency inverter	16
2.6		rning information and symbols used in the user manual	
	6.1	Hazard classes	
	6.2	Hazard symbols	
	6.3	Prohibition signs	
	6.4	Personal safety equipment	
	6.5	Recycling	
	6.6	Grounding symbol	
	6.7	ESD symbol	
2.	6.8	Information signs	. 18
2.7	Dir	ectives and guidelines to be adhered to by the operator	19
2.8	Ор	erator's general plant documentation	19
2.9		erator's/operating staff's responsibilities	
	9.1	Selection and qualification of staff	
2.	9.2	General work safety	. 19
2.10		Organizational measures	
	10.1	General	
	10.2	Use in combination with third-party products	
	10.3	Transport and Storage	
	10.4	Handling and installation	
2.	10.5	Electrical connections	
_	2.10.5	,	
	10.6	Safe operation	
	10.7 10.8	Maintenance and service/troubleshootingFinal decommissioning	
۷.	TO.0	1 III al accollii ii i i i i i i i i i i i i i i i i	. ۷۷



3	DI	EVICE OVERVIEW2	23
3.1		Inverter type and warning signs on the device	23
3.2		Type designation	24
3.3		Software Version Identification	25
3.4		Overview of components and connection terminals	26
3.5		Number of control terminals	26
4	М	ECHANICAL INSTALLATION	27
4.1		Safety	27
4. 1	•	Safety	21
4.2		Installation	27
4	.2.1	Size 1 (3~:0.18 kW to 2.2 kW; 1~: 0.09 kW to 1.1 kW)	28
4	.2.2		
4	.2.3		
5	EL	ECTRICAL INSTALLATION	31
- 4		Cafala.	24
5.1		Safety	
5.2		Electrical connections overview	32
5.3		EMC Information	32
5.4		Dimensioning of conductor cross-section	
5	.4.1	Typical cross-sections	35
5.5		Mains Connection	36
5.6		Motor Connection	38
	.6.1		
_	.6.2	2 Motor cable length, with output filter du/dt	<u>عر</u>
	.6.3	5 , , ,	
	.6.4	5 ,	
	.6.5	· ·	
,	.0.5	blake resistor	
5.7		Control terminals Standard connection	43
5	.7.1	Circuit for control via control terminals	46
5	.7.2	2 Circuit for control via operator panel	46
5	.7.3	B Further setting options for control terminals	47
5	.7.4	Evaluation logic of digital inputs	48
5	.7.5	Overview of voltage inputs and outputs	49
5	.7.6		
5	.7.7	Installation notes according to UL508c	50
6	C	DMMISSIONING	51
6.1		Operator panel	
6	.1.1		
	• • • •	1.1.1 Selection of Data sets	
	_	1.1.2 Menu for communication setup	
_	.1.2		
_	.1.3		
6	.1.4	Restrict the scope of operation	60



	First commissioning	
6.2		
6.2		
6.2	.3 Start first commissioning of a synchronous motor	65
6.2		68
6.2		68
6.2		70
6.2		71
6.2		
6.2	• • •	
6.2	3	
	5.2.10.1 Speed Controller: Softer set up	
	5.2.10.2 Speed Controller: Stronger set up	
	5.2.10.3 Voltage Constant	
	5.2.10.4 Insufficient Torque during Start of FOC and SYNCH	
	5.2.10.5 Cross coupling compensation	
	2 h. sara	
6.3	Commissioning of a communication interface	74
6.4	After first commissioning	80
6.5	Typical functions	01
	.	
6.6	Error Acknowledgment via keypad	98
6.7	Applications	99
6.7		
6.7	·	
6.7		
6.7		
6.7		
6.7	, , ,	
6.7	· ·	
6.7	··	
0.7	•	
6.8	Set-up via the Communication Interface	108
7 F	PARAMETER DESCRIPTIONS	110
, ,	ARAIVILTER DESCRIPTIONS	110
7.1	Inverter Data	
7.1	.1 Control level	110
7.1	J	111
7.1	.3 Set password	112
7.1	.4 Programming	113
7.2	Machine data	113
7.2		
7.2	•	
7.2	·	
	2.2.3.1 Earth fault and short circuit test (Test 1)	
	7.2.3.2 Load test (Test 2)	
	'.2.3.3 Start device test via operator panel	
	2.2.3.4 Start device test via operator pariet	
	2.2.3.5 Automatic device test after error switch-off	
	7.2.3.6 Fan test	
7 2	Operational Behavior	122
7.3 7.3	<u>-</u>	
7.3 7.3		
	.3 Stopping behavior	



7.3.4	Auto start	129
7.3.5	Flying Start	
7.3.6	Direct current brake	
7.3.7	Positioning	
7.4 Erro	or and warning behavior	135
7.4.1	Overload Ixt	
7.4.2	Temperature	
7.4.3	Controller status	
7.4.4	Frequency switch-off limit	
7.4.5	External error	
7.4.6	Motor temperature	
7.4.6.1	· ·	
7.4.7	Phase failure	
7.4.8	Automatic Error Acknowledgment	142
7.1.0	Additionable Error Acknowledgment	1 12
7.5 Ref	erence Values	142
7.5.1	Reference frequency channel	
7.5.1.1	·	
7.5.1.2		
7.5.1.2	•	
7.5.1.4	· ·	
7.5.1.5	· ·	
7.5.1.6		
7.5.2	Reference percentage channel	
7.5.2.1		
7.5.2.2		
7.5.2.3	, ,	
7.5.2.4	·	
7.5.3	Motor potentiometer	
7.5.3.1	· · · · · · · · · · · · · · · · · · ·	
7.5.3.2	· F · · · · · · · · · · · · · · · · · ·	
7.5.3.3	5 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
7.5.3.4	-7F F F	
7.5.4	Electronic gear	
7.5.4.1	 	
7.5.4.2	- p	
7.5.4.3	Gear factor	165
7.5.4.4	1 Offset	166
7.5.4.5	5 Actual values	166
7.5.4.6	5 Adjustment Options	166
7.6 Con	trol inputs and outputs	168
7.6.1	Multifunction input MFI1	168
7.6.1.1	Multifunction input set as analog input MFI1A	169
7.6.1.2	Multifunction input set as digital input MFI1D	174
7.6.2	Multifunction input MFI2	
7.6.2.1	·	
7.6.2.2		
7.6.3	Multifunction output MFO1	
7.6.4	Digital input/output IN3D/OUT3D	
7.6.5	Digital outputs	
7.6.5.1		
7.6.5.2		
7.6.5.3	9 ' '	
7.6.5.4		
7.6.5. ² 7.6.5. ⁵	5	
7.6.5.6 7.6.5.6		
7.6.5.7		
7.6.5.8		192
7.6.5.9	Warning mask, application	195



	jital inputs	196
7.6.6.1	List of control signals	
7.6.6.2	Start command	
7.6.6.3	3-Wire Control	
7.6.6.4	Motor potentiometer	
7.6.6.5	Fixed frequency changeover	
7.6.6.6	Fixed percentage changeover	
7.6.6.7	Jog Start	
7.6.6.8	Error Acknowledgment	
7.6.6.9	Thermal contact	
7.6.6.10	n-/T-control changeover	
7.6.6.11	Dataset changeover	
7.6.6.12	Handshake Traverse	
7.6.6.13	Brake chopper release	
7.6.6.14	User warning	
7.6.6.15	External error	
7.6.6.16	PLC	
7.6.6.17	Multiplexer/demultiplexer	
	out PWM/repetition frequency/pulse train	
7.6.7.1	PWM input	
7.6.7.2	Repetition frequency input	
7.6.7.3	Pulse train	
7.6.7.4	Further setting options	211
7.7 V/f ch	aracteristic	211
	V/f characteristic	
7.8.1 Dy	namic voltage pre-control	213
	l functions	
	elligent current limits	
	Itage controller	
	O controller (technology controller)	
	nctions of sensorless control	
7.9.4.1	Slip compensation	
7.9.4.2	Current limit value controller	
	nctions of field-orientated control	
	Current controller	
7.9.5.2	Torque controller	
7.9.5.3	Speed controller	
7.9.5.4	Acceleration pre-control	
7.9.5.5	Field controller	
7.9.5.6	Modulation controller	
7.9.6 Re	al-time tuning (optimizing motor parameters in operation)	239
7.10 Spec	ial functions	240
	ial functions	
	lse width modulation	
	1	
	andby mode and energy saving function	
	ake chopper and brake resistor	
7.10.4.1	Dimensioning of brake resistor	
	tor chopper	
	tor Protection	
7.10.6.1	Motor protection by Motor Circuit Breaker	
7.10.6.2	Motor Protection by I ² t- monitoring	
	pelt monitoring	250
	pelt monitoringaverse function	250 250
	pelt monitoring	250 250 253
7.10.10	pelt monitoring	250 250 253 253
7.10.10 S 7.10.11 C	pelt monitoring	



	.10.11.2 Copying using the PC control software	
8 E	NERGY SAVING	257
0 1	Energy saving function	257
8.1	Energy saving function	. 257
8.2	Quadratic V/f characteristic	. 259
8.3	Standby mode	. 260
8.4	Further energy saving options	263
9 A	CTUAL VALUES	265
9.1	Actual values of frequency inverter	265
9.1.	1 STO Status	267
9.2	Actual values of machine	267
9.3 9.3.	Actual values of the system	
	, and the second se	
9.4	Actual value memory	268
9.5	Actual values of the CAN system bus	. 270
9.6	Actual values CANopen	270
9.7	Actual values Modbus and VABus	270
9.8	Actual values Ethernet	270
10	SERVICE	271
10.1	Safety	. 271
10.2	Regular service work	271
10.3	Monitoring of service interval	
10.3 10.3		
10.3		
11	TECHNICAL DATA	.277
11.1	General technical data	277
11.2	Device data	279
11.2		
11.2		
11.2		
11.2		
11.2		
11.2		
11.2		
11 2	Control electronics	201
11.3	Control electronics	∠୪6



11.4	Operation diagrams	288
12 (OPTIONS	290
12.1	Safety	290
12.2	Chiefel about	200
12.2	Shield sheets	290
12.2.		
	2.1.1 Dimensions	
	2 Shield sheet for motor cables	293
	2.2.1 Size 1 and 2 (3~: 0.18 kW to 5.5 kW; 1~: 0.09 kW to 2.2 kW)	
12.3	Brake resistor	205
12.3		
12.3.		
12.3.		
12.4	Line choke	
12.4.		
12.4.		
12.4.		
12.4.	4 Dimensions	299
12.5	Input filter	300
12.5.	1 Footprint filter	300
12.5.	2 Booktype filter	302
12.5.	3 Interference suppression class	303
12.	5.3.1 AC 3x400 V	303
12.	5.3.2 AC 3x230 V	305
12.	5.3.3 AC 1x230 V	306
12.6	Communication module	307
12.7	USB adaptor	307
12.8	Resource pack	307
12.0	Accomplete contains	200
12.9	Assembly variants	
12.9.		
	3 1 3/ 1	
	9.1.2 Size 1 (3~: 0.18 kW to 2.2 kW; 1~: 0.09 kW to 1.1 kW)	
	9.1.3 Size 2 (3~: 3.0 kW to 5.5 kW; 1~: 1.5 kW to 2.2 kW)	
	9.1.4 Size 3 (5.5 kW to 11.0 kW)	
	2 Cold Plate (This assembly set is not included in delivery.)	
	9.2.1 Range of application	
	9.2.2 Required thermal properties of the external heat sink	
	9.2.3 Additional fan or liquid cooling	
	9.2.4 Application notes	
	9.2.5 Assembly	
	3 Vibration-proof (This assembly set is not included in delivery.)	
	9.3.1 Size 1 (3~: 0.18 kW to 2.2 kW; 1~: 0.09 kW to 1.1 kW)	
	9.3.2 Size 2 (3~: 3.0 kW to 5.5 kW; 1.5 kW to 2.2 kW)	
	9.3.3 Size 3 (3~: 5.5 kW to 11.0 kW)	323
	4 DIN rail (This assembly set is not included in delivery.)	
12.	9.4.1 Size 1 (3~: 0.18 kW to 2.2 kW; 1~: 0.09 kW to 1.1 kW)	324
13 E	RROR PROTOCOL	325
121	Error list	225



13.1	1.1 Error messages	326
13.2	Error environment	329
13.3	Troubleshooting	331
14	OPERATIONAL AND ERROR DIAGNOSIS	335
14.1	Status of digital signals	335
14.2	Controller status	335
14.3	Warning status and warning status application	336
15	PARAMETER LIST	339
15.1	Actual values (Menu Actual)	339
15.2	Parameters (Menu PARA)	343
INDE	EX	354



1 General information about the documentation



For the series of devices AGL (Agile) is for the safety-related commissioning and operation to be complied with the following documentation:

- This Operating instructions
- Application manual "Functional Safety Agile"

For better clarity, the documentation is structured according to the customer-specific requirements made on the frequency inverter.

Quick start guide

The Quick Start Guide describes the basic steps required for mechanical and electrical installation of the frequency inverter. The guided commissioning supports you in the selection of necessary parameters and the configuration of the frequency inverter by the software.

Operating instructions

The Operating Instructions describe and document all functions of the frequency inverter. The parameters required for adapting the frequency inverter to specific applications as well as the wide range of additional functions are described in detail.

Application manual

The application manual supplements the documentation for purposeful installation and commissioning of the frequency inverter. Information on various subjects connected with the use of the frequency inverter is described specific to the application.

Installation instructions

The installation manual describes the installation and use of devices, complementing the "Quick Start Guide" and the user manual.

The following instructions are available for the *Agile* series:

Operating Instructions Agile	Functions of the frequency inverter.
Quick Start Guide Agile	Installation and commissioning. Delivered with the device.
Application manual "Functional Safety".	Description of the Functions and usage of the integrated Functional Safety.
Application manuals Communication	Communication via the RS485 interface at terminal X21: Manuals Modbus and VABus.
	Communication via the control terminals X12.5 and X12.6: system bus and CANopen®.
	CM-232/CM-485: Manuals Modbus and VABus. CM-CAN: Manuals system bus and CANopen®. CM-PDPV1: Manual Profibus-DP-V1.
	CM-VABus/TCP: Manual for Ethernet Module CM-VABus/TCP (i.P.)
	CM-ModbusTCP: Manual for Ethernet Module CM-Modbus/TCP (i.P.)
	CM-EtherCAT®: Manual for Ethernet Module CM-EtherCAT® (i.P.)
	CM-ProfiNet: Manual for Ethernet Module CM-ProfiNet (i.P.)
	CM-EtherNet-I/P: Manual for Ethernet Module CM-EtherNet-I/P (i.P.)
Application manual PLC	Logic linking of digital signals. Functions for analog signals such as comparisons and mathematical functions. Graphic functional block programming.

The products for CANopen® communication comply with the specifications of the user organization CiA® (CAN in Automation).

The products for EtherCAT® communication comply with the specifications of the user organization ETG (EtherCAT Technology Group).



1.1 This document

The present user manual complements the "Quick Start Guide" for the frequency inverters of the AGL 202 and ACU 402 device series.

The user manual contains important information on the installation and use in its specified application range. Compliance with this user manual contributes to avoiding risks, minimizing repair cost and downtimes and increasing the reliability and service live of the frequency inverter.

For this reason, make sure you read the user manual carefully.

⚠ WARNING



Compliance with the documentation is required to ensure safe operation of the frequency inverter. BONFIGLIOLI VECTRON GmbH shall not be held liable for any damage caused by any non-compliance with the documentation.



In case any problems occur which are not covered by the documentation sufficiently, please contact the manufacturer.

1.2 Warranty and liability

BONFIGLIOLI VECTRON GmbH would like to point out that the contents of this user manual do not form part of any previous or existing agreement, assurance or legal relationship. Neither are they intended to supplement or replace such agreements, assurances or legal relationships. Any obligations of the manufacturer shall solely be based on the relevant purchase agreement which also includes the complete and solely valid warranty stipulations. These contractual warranty provisions are neither extended nor limited by the specifications contained in this documentation.

The manufacturer reserves the right to correct or amend the specifications, product information and omissions in these operating instructions without notice. The manufacturer shall not be liable for any damage, injuries or costs which may be caused by the aforementioned reasons.

In addition to that, BONFIGLIOLI VECTRON GmbH excludes any warranty/liability claims for any personal and/or material damage if such damage is due to one or more of the following causes:

- inappropriate use of the frequency inverter,
- non-compliance with the instructions, warnings and prohibitions contained in the documentation,
- · unauthorized modifications of the solar inverter,
- insufficient monitoring of parts of the machine/plant which are subject to wear,
- repair work at the machine/plant not carried out properly or in time,
- catastrophes by external impact and Force Majeure.



1.3 Obligation

This user manual must be read before commissioning and complied with. Anybody entrusted with tasks in connection with the

- transport,
- assembly,
- · installation of the frequency inverter and
- operation of the frequency inverter

must have read and understood the user manual and, in particular, the safety instructions in order to prevent personal and material losses.

1.4 Copyright

In accordance with applicable law against unfair competition, this user manual is a certificate. Any copyrights relating to it shall remain with

BONFIGLIOLI VECTRON GmbH Europark Fichtenhain B6 47807 Krefeld Germany

These user manual is intended for the operator of the frequency inverter. Any disclosure or copying of this document, exploitation and communication of its contents (as hardcopy or electronically) shall be forbidden, unless permitted expressly.

Any non-compliance will constitute an offense against the copyright law dated 09 September 1965, the law against unfair competition and the Civil Code and may result in claims for damages. All rights relating to patent, utility model or design registration reserved.

1.5 Storage

The documentation form an integral part of the frequency inverter. It must be stored such that it is accessible to operating staff at all times. In case the frequency inverter is sold to other users, this user manual must also be handed over.



2 General safety instructions and information on use

The chapter "General safety instructions and information on use" contains general safety instructions for the Operator and the Operating Staff. At the beginning of certain main chapters, some safety instructions are included which apply to all work described in the relevant chapter. Special work-specific safety instructions are provided before each safety-relevant work step.

2.1 Terminology

According to the documentation, different activities must be performed by certain persons with certain qualifications.

The groups of persons with the required qualification are defined as follows:

Operator

This is the entrepreneur/company who/which operates the frequency inverter and uses it as per the specifications or has it operated by qualified and instructed staff.

Operating staff

The term Operating Staff covers persons instructed by the Operator of the frequency inverter and assigned the task of operating the frequency inverter.

Qualified staff

The term Qualified Staff covers staff who is assigned special tasks by the Operator of the frequency inverter, e.g. installation, maintenance and service/repair and troubleshooting. Based on their qualification and/or know-how, qualified staff must be capable of identifying defects and assessing functions.

Qualified electrician

The term Qualified Electrician covers qualified and trained staff who has special technical know-how and experience with electrical installations. In addition, Qualified Electricians must be familiar with the applicable standards and regulations, they must be able to assess the assigned tasks properly and identify and eliminate potential hazards.

Instructed person

The term Instructed Person covers staff who was instructed and trained about/in the assigned tasks and the potential hazards that might result from inappropriate behavior. In addition, instructed persons must have been instructed in the required protection provisions, protective measures, the applicable directives, accident prevention regulations as well as the operating conditions and verified their qualification.

Expert

The term Expert covers qualified and trained staff who has special technical know-how and experience relating to frequency inverter. Experts must be familiar with the applicable government work safety directives, accident prevention regulations, guidelines and generally accepted rules of technology in order to assess the operationally safe condition of the frequency inverter.



2.2 Designated use

The frequency inverter is designed according to the state of the art and recognized safety regulations.

The frequency inverters are electrical drive components intended for installation in industrial plants or machines. Commissioning and start of operation is not allowed until it has been verified that the machine meets the requirements of the EC Machinery Directive 2006/42/EC and DIN EN 60204-1.

The frequency inverters meet the requirements of the low voltage directive 2006/95/EEC and DIN EN 61800-5-1. CE-labeling is based on these standards. Responsibility for compliance with the EMC Directive 2004/108/EC lies with the operator. Frequency inverters are only available at specialized dealers and are exclusively intended for commercial use as per EN 61000-3-2.

No capacitive loads may be connected to the frequency inverter.

The technical data, connection specifications and information on ambient conditions are indicated on the rating plate and in the documentation and must be complied with in any case.

2.3 Misuse

Any use other than that described in "Designated use" shall not be permissible and shall be considered as misuse.

For example, the machine/plant must not be operated

- by uninstructed staff,
- while it is not in perfect condition,
- without protection enclosure (e.g. covers),
- without safety equipment or with safety equipment deactivated.

The manufacturer shall not be held liable for any damage resulting from such misuse. The sole risk shall be borne by the operator.

2.3.1 Explosion protection

The frequency inverter is an IP 20 protection class device. For this reason, use of the device in explosive atmospheres is not permitted.



2.4 Residual risks

Residual risks are special hazards involved in handling of the frequency inverter which cannot be eliminated despite the safety-compliant design of the device. Residual risks are not obviously identifiable and can be a potential source of injury or health hazard.

Typical residual hazards include:

Electrical hazard

Danger of contact with energized components due to a defect, opened covers or enclosures or improper working on electrical equipment.

Danger of contact with energized components inside of the frequency inverter if no external disconnection device was installed by the operator.

Electrostatic charging

Touching electronic components bears the risk of electrostatic discharges.

Thermal hazards

Risk of accidents by hot machine/plant surfaces, e.g. heat sink, transformer, fuse or sine filter.

Charged capacitors in DC link

The DC link may have dangerous voltage levels even up to three minutes after shutdown.

Danger of equipment falling down/over, e.g. during transport

Center of gravity is not the middle of the electric cabinet modules.

2.5 Safety and warning signs at frequency inverter

- Comply with all safety instructions and danger information provided on the frequency inverter.
- Safety information and warnings on the frequency inverter must not be removed.



2.6 Warning information and symbols used in the user manual

2.6.1 Hazard classes

The following hazard identifications and symbols are used to mark particularly important information:



⚠ DANGER

Identification of immediate threat holding a **high** risk of death or serious injury if not avoided.



⚠ WARNING

Identification of immediate threat holding a **medium** risk of death or serious injury if not avoided.



⚠ CAUTION

Identification of immediate threat holding a **low** risk of minor or moderate physical injury if not avoided.

NOTE

Identification of a threat holding a risk of material damage if not avoided.

2.6.2 Hazard symbols

Symbol	Meaning	Symbol	Meaning
<u>^</u>	General hazard		Suspended load
4	Electrical voltage	<u>\$\$</u>	Hot surfaces

2.6.3 Prohibition signs

Symbol	Meaning
	No switching; it is forbidden to switch the machine/plant, assembly on



2.6.4 Personal safety equipment

Symbol	Meaning
	Wear body protection

2.6.5 Recycling

Symbol	Meaning
	Recycling, to avoid waste, collect all materials for reuse

2.6.6 Grounding symbol

Symbol	Meaning
<u>_</u>	Ground connection

2.6.7 ESD symbol

Symbol	Meaning				
	ESD: Electrostatic Discharge (can damage components and assemblies)				

2.6.8 Information signs

Symbol	Meaning
i	Tips and information making using the frequency inverter easier.



2.7 Directives and guidelines to be adhered to by the operator

The operator must follow the following directives and regulations:

- Ensure that the applicable workplace-related accident prevention regulations as well as other applicable national regulation are accessible to the staff.
- An authorized person must ensure, before using the frequency inverter, that the device is used in compliance with its designated use and that all safety requirements are met.
- Additionally, comply with the applicable laws, regulations and directives of the country in which the frequency inverter is used.
- Any additional guidelines and directives that may be required additionally shall be defined by the operator of the machine/plant considering the operating environment.

2.8 Operator's general plant documentation

• In addition to the user manual, the operator should issue separate internal operating instructions for the frequency inverter. The user manual of the frequency inverter must be included in the user manual of the whole plant.

2.9 Operator's/operating staff's responsibilities

2.9.1 Selection and qualification of staff

- Any work on the frequency inverter may only be carried out by qualified technical staff. The staff must not be under the influence of any drugs. Note the minimum age required by law. Define the staff's responsibility in connection with all work on the frequency inverter clearly.
- Work on the electrical components may only be performed by a qualified electrician according to the applicable rules of electrical engineering.
- The operating staff must be trained for the relevant work to be performed.

2.9.2 General work safety

- In addition to the user manual of the machine/plant, any applicable legal or other regulations relating to accident prevention and environmental protection must be complied with. The staff must be instructed accordingly.
 - Such regulations and/or requirements may include, for example, handling of hazardous media and materials or provision/use of personal protective equipment.
- In addition to this user manual, issue any additional directives that may be required to meet specific operating requirements, including supervision and reporting requirements, e.g. directives relating to work organization, workflow and employed staff.
- Unless approved of expressly by the manufacturer, do not modify the frequency inverter in any way, including addition of attachments or retrofits.
- Only use the frequency inverter if the rated connection and setup values specified by the manufacturer are met.
- Provide appropriate tools as may be required for performing all work on the frequency inverter properly.



2.10 Organizational measures

2.10.1 General

- Train your staff in the handling and use of the frequency inverter and the machine/plant as well as the risks involved.
- Use of any individual parts or components of the frequency inverter in other parts of the operator's machine/plant is prohibited.
- Optional components for the frequency inverter must be used in accordance with their designated use and in compliance with the relevant documentation.

2.10.2 Use in combination with third-party products

- Please note that BONFIGLIOLI VECTRON GmbH will not accept any responsibility for compatibility with third-party products (e.g. motors, cables or filters).
- In order to enable optimum system compatibility, BONFIGLIOLI VECTRON GmbH office components facilitating commissioning and providing optimum synchronization of the machine/plant parts in operation.
- If you use the frequency inverter in combination with third-party products, you do this at your own risk.

2.10.3 Transport and Storage

- The frequency inverters must be transported and stored in an appropriate way. During transport and storage the devices must remain in their original packaging.
- The units may only be stored in dry rooms which are protected against dust and moisture and are exposed to little temperature deviations only. The requirements of DIN EN 60721-3-1 for storage, DIN EN 60721-3-2 for transport and labeling on the packaging must be met.
- The duration of storage without connection to the permissible nominal voltage may not exceed one year.

2.10.4 Handling and installation

- Do not commission any damaged or destroyed components.
- Prevent any mechanical overloading of the frequency inverter. Do not bend any components and never change the isolation distances.
- Do not touch any electronic construction elements and contacts. The frequency inverter is
 equipped with components which are sensitive to electrostatic energy and can be damaged if
 handled improperly. Any use of damaged or destroyed components will endanger the machine/plant safety and shall be considered as a non-compliance with the applicable standards.
- Only install the frequency inverter in a suitable operating environment. The frequency inverter is exclusively designed for installation in industrial environments.
- If seals are removed from the case, this can result in the warranty becoming null and void.

2.10.5 Electrical connections

- The five safety rules must be complied with.
- Never touch live terminals. The DC link may have dangerous voltage levels even up to three minutes after shutdown.
- When performing any work on/with the frequency inverter, always comply with the applicable
 national and international regulations/laws on work on electrical equipment/plants of the country
 when the frequency inverter is used.
- The cables connected to the frequency inverters may not be subjected to high-voltage insulation tests unless appropriate circuitry measures are taken before.
- Only connect the frequency inverter to suitable supply mains.



2.10.5.1 The five safety rules

When working on/in electrical plants, always follow the five safety rules:

- 1. Isolate
- 2. Secure to prevent restarting
- Check isolation
- 4. Earth and short-circuit,
- 5. Cover or shield neighboring live parts.

2.10.6 Safe operation

- During operation of the frequency inverter, always comply with the applicable national and international regulations/laws on work on electrical equipment/plants.
- Before commissioning and the start of the operation, make sure to fix all covers and check the terminals. Check the additional monitoring and protective devices according to the applicable national and international safety directives.
- During operation, never open the machine/plant
- Do not connect/disconnect any components/equipment during operation.
- The machine/plant holds high voltage levels during operation, is equipped with rotating parts (fan) and has hot surfaces. Any unauthorized removal of covers, improper use, wrong installation or operation may result in serious injuries or material damage.
- Some components, e.g. the heat sink or brake resistor, may be hot even some time after the machine/plant was shut down. Don't touch any surfaces directly after shutdown. Wear safety gloves where necessary.
- The frequency inverter may hold dangerous voltage levels until the capacitor in the DC link is discharged. Wait for at least 3 minutes after shutdown before starting electrical or mechanical work on the frequency inverter. Even after this waiting time, make sure that the equipment is deenergized in accordance with the safety rules before starting the work.
- In order to avoid accidents or damage, only qualified staff and electricians may carry out the work such as installation, commissioning or setup.
- In the case of a defect of terminals and/or cables, immediately disconnect the frequency inverter from mains supply.
- Persons not familiar with the operation of frequency inverters must not have access to the frequency inverter. Do not bypass nor decommission any protective facilities.
- The frequency inverter may be connected to power supply every 60 s. This must be considered when operating a mains contactor in jog operation mode. For commissioning or after an emergency stop, a non-recurrent, direct restart is permissible.
- After a failure and restoration of the power supply, the motor may start unexpectedly if the Auto Start function is activated.
 - If staff is endangered, a restart of the motor must be prevented by means of external circuitry.
- Before commissioning and the start of the operation, make sure to fix all covers and check the terminals. Check the additional monitoring and protective devices according to EN 60204 and applicable the safety directives (e.g., Working Machines Act or Accident Prevention Directives).



2.10.7 Maintenance and service/troubleshooting

- Visually inspect the frequency inverter when carrying out the required maintenance work and inspections at the machine/plant.
- Perform the maintenance work and inspections prescribed for the machine carefully, including the specifications on parts/equipment replacement.
- Work on the electrical components may only be performed by a qualified electrician according to the applicable rules of electrical engineering. Only use original spare parts.
- Unauthorized opening and improper interventions in the machine/plant can lead to personal injury
 or material damage. Repairs on the frequency inverters may only be carried out by the manufacturer or persons authorized by the manufacturer. Check protective equipment regularly.
- Before performing any maintenance work, the machine/plant must be disconnected from mains supply and secured against restarting. The five safety rules must be complied with.

2.10.8 Final decommissioning

Unless separate return or disposal agreements were made, recycle the disassembled frequency inverter components:

- Scrap metal materials
- Recycle plastic elements
- Sort and dispose of other component materials



Electric scrap, electronic components, lubricants and other utility materials must be treated as special waste and may only be disposed of by specialized companies.



In any case, comply with any applicable national disposal regulations as regards environmentally compatible disposal of the frequency inverter. For more details, contact the competent local authorities.




3 Device overview

This chapter describes the characteristic of the Agile series.

3.1 Inverter type and warning signs on the device

- Determine the type of frequency inverter.
- Verify that the rated input voltage corresponds to the local power supply.
- Verify that the recommended motor shaft power of the frequency inverter corresponds to the rated power of the motor.




- [1] Labeling for Functional Safety (if applicable). Please check the Application manual "Functional Safety".
- [2] Labeling for UL508c (if applicable)

		Recommended motor shaft power at specified power supply		
Specifier	Frame size	AGL 402: AC 3x400 V	AGL 202: AC 3x230 V	AGL 202: AC 1x230 V
-01 1			0,18 kW	0,09 kW
-02 1		0,25 kW	0,25 kW	0,12 kW
-03 1		0,37 kW	0,37 kW	0,18 kW
-05 1	1	0,55 kW	0,55 kW	0,25 kW
-07 1	1	0,75 kW	0,75 kW	0,37 kW
-09 1		1,1 kW	1,1 kW	0,55 kW
-11 1		1,5 kW	1,5 kW	0,75 kW
-13 1		2,2 kW	2,2 kW	1,1 kW
-15 2		3,0 kW	3,0 kW	1,5 kW
-18 2	2	4,0 kW	4,0 kW	2,2 kW
-19 2		5,5 kW		
-19 3		5,5 kW	5,5 kW	3,0 kW
-21 3	3	7,5 kW	7,5 kW	3,0 kW
-22 3	3	9,2 kW		
-23 3		11,0 kW		



3.2 Type designation



Basic	c Type designation
1	Series:
	AGL 202 : inverter Agile 1xAC 200 – 15 %240 V + 10 %
	3xAC 200 – 15 %240 V + 10 %
	AGL 402 : inverter Agile 3xAC 360480 V +/- 10 %
2	Size (Power)
	Coding see previous chapter
3	Size (mechanical size)
	1 = Size 1
	2 = Size 2
	3 = Size 3
4	EMC Filter
	F = integrated (default)
5	Design Version
	A = standard cooling (default)
	C = Cold Plate (optional)

Optional-Type designation						
A	Mounting:					
, ,	(blank)					
	MPSV	= feed-through no fan				
	MDIN	= DIN rail (size 1 only)				
	MNVIB	= vibration proof mounting				
В	Communication m					
	(blank)	= no module (default)				
	CM-CAN	= CANopen interface				
	CM-PDPV1	= Profibus DP-V1 interface				
	CM-232	= RS232 interface				
	CM-485	= 2nd RS485 interface (VABus & Modbus)				
	CM-VABus/TCP	= Ethernet Protocol VABus/TCP				
	CM-Modbus/TCP	= Ethernet Protocol Modbus/TCP = EtherCAT® Protocol				
	CM-EtherCAT®	= EtherCAT [®] Protocol				
	CM-ProfiNet					
	CM-EtherNet-I/P	= EtherNet-I/P Protocol				
С	Memory Extension					
	(blank)	= no memory card (default)				
	RP	= Resource Pack (MMC memory card)				
D	Software Version	,				
	(blank)	= Standard (default)				
		,				



The name plate shows the options at delivery.


Most of the options (with the exception of the Software Version) can be refitted by the user. Also the later modification (in example removing a CM module) is possible.



Devices with Functional Safety are marked accordingly. For information regarding the marking please comply with the application manual "Functional Safety".




3.3 Software Version Identification



The Software version plate is situated right from the memory card slot and left from the Control terminals.



3.4 Overview of components and connection terminals



	See
Mains voltage connection	Chapter 5.5
The safety instructions must be complied with strictly.	Chapter 5.1
Motor Connection	Chapter 5.6
The safety instructions must be complied with strictly.	Chapter 5.1
Control terminals and relay output	Chapter 5.7
The safety instructions must be complied with strictly.	Chapter 5.1
CAN connection terminals	Separate instructions on System bus or
	CANopen® ¹ .
Operator panel	Chapter 6.1
Port for memory card (MMC)	Chapter 7.10.11 and 12.8
Communication interface X21 ²	Separate instructions on VABus or Mod-
	bus.
Port for one of the optional communication modules (see	Separate instructions on the protocols.
previous chapter for list)	

3.5 Number of control terminals

4 digital inputs	1 input for external voltage supply DC 24 V		
2 digital inputs for enable	1 reference voltage output DC 10 V		
1 digital input/output	1 voltage output DC 24 V		
2 multifunction inputs: digital/analog input	1 relay output, potential-free		
1 digital output	Control terminals for system bus or protocol		
1 multifunction output: digital/analog/frequency	CANopen®		

26

¹ The products for CANopen® communication comply with the specifications of the user organization CiA® (CAN in Automation).

Install an interface adapter for connection of a PC. This enables configuration and monitoring using the PC software VPlus.



4 Mechanical Installation

The frequency inverters of degree of protection IP20 are designed, as a standard, for installation in electrical cabinets.

During installation, both the installation and the safety instructions as well as the device specifications must be complied with.

4.1 Safety



△ WARNING

To avoid serious physical injury or considerable damage to property, only qualified staff may work on the devices.

$oldsymbol{\Lambda}$ warning



During assembly, make sure that no foreign particles (e.g. chips, dust, wires, screws, tools) can get inside the frequency inverter. Otherwise there is the risk of short circuits and fire.

The frequency inverter complies with protection class IP20 only if the covers, components and terminals are mounted properly.

Overhead Installation or installation in horizontal position is not permissible.


NOTE

Mount the devices with sufficient clearance to other components so that the cooling air can circulate freely. Avoid soiling by grease and air pollution by dust, aggressive gases, etc.

Suction intakes of fans may not be covered.

4.2 Installation

Mounting distance






4.2.1 Size 1 (3~:0.18 kW to 2.2 kW; 1~: 0.09 kW to 1.1 kW)


Valid for the following devices

Frequency inverter				
Type	<i>Agile</i> 202		<i>Agile</i> 402	
Mains supply	1ph.	3ph.	3ph.	
Power	kW	kW	kW	
-01 1	0.09	0.18		
-02 1	0.12	0.25	0.25	
-03 1	0.18	0.37	0.37	
-05 1	0.25	0.55	0.55	
-07 1	0.37	0.75	0.75	
-09 1	0.55	1.1	1.1	
-11 1	0.75	1.5	1.5	
-13 1	1.1	2.2	2.2	

Dimensions



Assembly



Use screws M6.




4.2.2 Size 2 (3~: 3.0 kW to 5.5 kW; 1~: 1.5 kW to 2.2 kW)


Valid for the following devices

Frequency inverter				
Type	Agile	202	<i>Agile</i> 402	
Mains supply	1ph.	3ph.	3ph.	
Power	kW	kW	kW	
-15 2	1.5	3.0	3.0	
-18 2	2.2	4.0	4.0	
-19 2			5.5	

Dimensions



Assembly



Use screws M6.




4.2.3 Size 3 (5.5 kW to 11.0 kW)


Valid for the following devices

Frequency inverter			
Type	<i>Agile</i> 202		<i>Agile</i> 402
Mains supply	1ph.	3ph.	3ph.
Power	kW	kW	kW
-19 3	3.0	5.5	5.5
-21 3	3.0	7.5	7.5
-22 3	-		9.2
-23 3	1		11

Dimensions



Assembly



30



5 Electrical Installation

This chapter describes the electrical installation of the Agile series.

5.1 Safety

⚠ WARNING

The electrical installation must be carried out by qualified electricians according to the general and regional safety and installation directives.

The documentation and device specification must be complied with during installation.

Before any assembly or connection work, discharge the frequency inverter. Verify that the frequency inverter is discharged.



Do not touch the terminals because the capacitors may still be charged.

Only connect suitable voltage sources. The nominal voltage of the frequency inverter must correspond to the supply voltage.

The frequency inverter must be connected to ground potential.

If voltage supply is switched on, no covers of the frequency inverter may be removed.

The connecting cables must be protected externally, considering the maximum voltage and current values of the fuses. The mains fuses and cable cross-sections are to be selected according to EN 60204-1 and DIN VDE 0298 Part 4 for the nominal operating point of the frequency inverter. According to UL/CSA, the frequency inverter is suitable for operation at a supply network of a maximum of 480 VAC which delivers a maximum symmetrical current of 5000 A (effective value) if protected by fuses of class RK5. Only use copper cables with a temperature range of 60/75 °C.

In the case of special applications, you may also have to comply with further guidelines and instructions.

The frequency inverters are to be grounded properly, i.e. large connection area and with good conductivity. The leakage current of the frequency inverters may be > 3.5 mA. According to EN 50178 a stationary installation must be provided. The protective con-ductor cross-section required for grounding the fixing plate must be selected according to the size of the unit. In these applications, the cross-section must correspond to the recommended cross-section of the wire. Refer to chapter 5.4 "Dimensioning of conductor cross-section".



⚠ CAUTION

Degree of protection IP20 is only achieved with terminals plugged and properly mounted covers.

Connection conditions

- The frequency inverter is suited for connection to the public or industrial supply mains according to the technical data.
- It must be checked, based on the specifications of EN 61000-3-2, if the devices can be connected
 to the public supply means without taking additional measures. Increased requirements in connection with the specific application of the fre-quency inverter are to be met by means of optional
 components. Commutating chokes and EMC filters are optionally available.
- Operation on unearthed mains (IT mains) is admissible after pulling out the IT mains plug-in jumper.


Interference-free operation with residual current device is guaranteed at a tripping current \geq 30 mA if the following points are observed:

- All-current sensitive residual current devices (Type B to EN 50178)
- Use EMC filters with reduced leakage current or, if possible, do not use EMC filters at all.
- The length of the shielded motor cable is ≤ 10 m and there are no additional capacitive components between the mains or motor cables and PE.

For connection to IT mains, refer to chapter 5.5 "Mains Connection".



5.2 Electrical connections overview



For connection refer to the corresponding chapter.


5.3 EMC Information

The frequency inverters are designed according to the requirements and limit values of product norm EN 61800-3 with an interference immunity factor (EMI) for operation in industrial applications. Electromagnetic interference is to be avoided by expert installation and observation of the specific product information.

Measures

- Install the frequency inverters on a metal mounting panel that is connected to the equipotential bonding. Ideally, the mounting panel should be galvanized, not painted.
- Provide proper equipotential bonding within the plant. Plant components such as control cabinets, control panels, machine frames must be connected to the equipotential bonding by means of low inductive wire mesh.
- Connect the shields of the cables on both sides to the mounting panel that is not painted and connected to the equipotential bonding.
- Connect the shield of analog control cables to the equipotential bonding only on one side near to the frequency inverter.
- Connect the frequency inverter and other components, e.g. external filters and other components to the equipotential bonding via short cables.
- Keep the cables as short as possible; make sure that cables are installed properly using appropriate cable clamps, etc.
- Contactors, relays and solenoids in the electrical cabinet are to be provided with suitable interference suppression components.





Optional shield sheets can be used for the cable shielding. Refer to chapter 12.2 "Shield sheets".

Mains Connection

Install the mains supply cable separate from the control and data cables and the motor cable.

DC link connection

The frequency inverter may be connected via the terminals "-" and "+" of terminal block X10 to further *Agile*- or ACTIVE-devices or to a common direct voltage source. Cables longer than 300 mm are to be shielded. The shield must be connected across a wide area contact on both sides to the unpainted conductive mounting panel.

Control connection

Control and signal cables must be kept physically separate from the power cables.

Analog signal lines must be shielded. The shield is to be connected to the unpainted conductive mounting panel that is connected to equipotential bonding. An optional shield sheet can be used for shielding. Refer to chapter 12.2.1 "Shield sheet for control cables".

Motor and brake resistor

Connect the shield of the motor cable to the unpainted conductive mounting panel that is connected to equipotential bonding.

An optional shield sheet can be used for shielding. Refer to chapter 12.2.2 "Shield sheet for motor cables".

The signal cable used for monitoring the motor temperature must be kept separate from the motor cable. Connect the shield of this line on both sides.

If a brake resistor is used, the connection cable must be shielded. Connect the shield in consideration of EMC.



Line choke

Line chokes reduce mains harmonics and reactive power. Additional the increase of product life is possible. Consider the reduction of the maximum output voltage if a line choke is installed.

The line choke must be installed between mains connection and input filter.

BONFIGLIOLI provides applicable line chokes. Refer to chapter 12.4 "Line choke".

Input filter

Input filters reduce the conducted radio-frequency interference voltage. The input filter must be installed upstream on mains side of the frequency inverter.

⚠ CAUTION



The frequency inverters meet the requirements of the low-voltage direc-tive 2006/95/EC and the requirements of the EMC directive 2004/108/EC. The EMC product standard EN 61800-3 relates to the drive system. The documentation provides information on how the applicable standards can be complied if the frequency inverter is a component of the drive system. The declaration of conformity is to be issued by the supplier of the drive system.

5.4 Dimensioning of conductor cross-section

- The cable dimensions must be selected according to the current load and voltage drop to be expected.
- Select the cable cross-section of the cables such that the voltage drop is as small as possible. If the voltage drop is too great, the motor will not reach its full torque.
- Comply with any additional national and application-specific regulations and the separate UL instructions. For typical mains fuses, refer to chapter 11 "Technical data".

Select cross-sections of PE conductor according to EN61800-5-1:

Mains cable	Protective conductor
Mains cable up to 10 mm ²	Install two protective conductors of the same size as the mains
	cable, or one protective conductor of a size of 10 mm ² .
Mains cable 1016 mm ²	Install one protective conductor of the same size as the mains cable.
Mains cable 1635 mm ²	Install one protective conductor with a cross-section of 16 mm ² .
Mains cable > 35 mm ²	Install one protective conductor of half the size of the mains cable.



5.4.1 Typical cross-sections

The following table provides an overview of typical cable cross-sections (copper cable with PVC insulation, 30 °C ambient temperature, continuous mains current max. 100% rated input current). Actual cable cross-section requirements may deviate from these values due to actual operating conditions.

Single-phase connection (L1/N), 230 V

-	Гуре	Mains cable	PE-conductor	Motor cable
-01	0.09kW			
-02	0.12 kW			
-03	0.18 kW			
-05	0.25 kW			
-07	0.37 kW	1.5 mm ²	2x1.5 mm ² or 1x10 mm ² 1)	1.5 mm ²
-09	0.55 kW			
-11	0.75 kW			
-13	1.1 kW			
-15	1.5 kW			
-18	2.2 kW	2.5 mm ²	2x2.5 mm ² or 1x10 mm ² 1)	1.5 mm ²
-19	3.0 kW	1 mm?	2x4 mm ² or 1x10 mm ² 1)	1 F mm?
-21	3.0 kW	4 mm ²	2X4 1111112 OF 1X10 1111112 /	1.5 mm ²

¹⁾ Connection on protective earth on mounting plate.

Three-phase connection (L1/L2/L3), 230 V

	Гуре	Mains cable	PE-conductor	Motor cable
-01	0.18 kW			
-02	0.25 kW			
-03	0.37 kW			
-05	0.55 kW			
-07	0.75 kW	1.5 mm ²	2x1.5 mm ² or 1x10 mm ² 1)	1.5 mm ²
-09	1.1 kW			
-11	1.5 kW			
-13	2.2 kW			
-15	3.0 kW			
-18	4. kW	2.5 mm ²	2x2.5 mm ² or 1x10 mm ² 1)	1.5 mm ²
-19	5.5 kW	4 mm ²	2x4 mm ² or 1x10 mm ² 1)	4 mm ²
-21	7.5 kW	6 mm ²	2x6 mm ² or 1x10 mm ² 1)	4 mm ²

¹⁾ Connection on protective earth on mounting plate.

Three-phase connection (L1/L2/L3), 400 V

	Туре	Mains cable	PE-conductor	Motor cable
-03	0,25 kW			
-02	0,37 kW			
-05	0.55 kW			
-07	0.75 kW			
-09	1.1 kW	1.5 mm ²	2x1.5 mm ² or 1x10 mm ² 1)	1.5 mm ²
-11	1.5 kW			
-13	2.2 kW			
-15	3.0 kW			
-18	4.0 kW			
-19	5.5 kW			
-21	7.5 kW	2.5 mm ²	2x2.5 mm ² or 1x10 mm ² 1)	2.5 mm ²
-22	9.2 kW			
-23	11.0 kW	4 mm ²	2x4 mm ² or 1x10 mm ² 1)	4 mm ²

¹⁾ Connection on protective earth on mounting plate.

Please note, that the mentioned typical cross sections do not consider other factors like fuses. Comply with applying local standards and applying branch standards.



5.5 Mains Connection

⚠ DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.



Verify that the frequency inverter is discharged.

Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.


When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

The mains fuses and cable cross-sections are to be selected according to EN 60204-1 and DIN VDE 0298 Part 4 for the nominal operating point of the frequency inverter. According to UL/CSA, approved Class 1 copper lines with a temperature range of 60/75°C and matching mains fuses are to be used for the power cables. The electrical installation is to be done according to the device specifications and the applicable standards and directives.

⚠ CAUTION



The control, mains and motor lines must be kept physically separate from one another. The cables connected to the frequency inverters may not be subjected to high-voltage insulation tests unless appropriate circuitry measures are taken before.





Minimum Torque to tighten the screws: **0.5 Nm** (4.6 lb-in) Maximum Torque to tighten the screws: **0.6 Nm** (5,3 lb-in)

Recommended sizes of Mains fuses F1 are described in the technical data chapter 11.2 "Device data".


⇒ : Only for in DC link connections.

Comply with the notes on cable cross-sections in chapter 5.4 "Dimensioning of conductor cross-section".

Cab	le cross-sections mm ²
Mains terminals: $\begin{bmatrix} 0,2\\0,2 \end{bmatrix}$	4 (flexible cable with sleeve) 6 (rigid cable)



Connection to IT mains



For connection to IT mains, pull out the plug-type jumper.

NOTE

Removing the jumper reduces interference immunity and increases the emitted interference. Interference immunity can be increased by means of external filters.

Additional work for EMC conformity may be possible. Comply with the EMC information.



5.6 Motor Connection

⚠ DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify that the frequency inverter is discharged.



Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

When using pluggable terminals: Do not switch on the device while the plugs are disconnected, the IP protection is only warranted with plugged terminals.


BONFIGLIOLI recommends connecting the motor to the frequency inverter using shielded cables.

- Connect the cable shield to PE potential properly, i.e. with good conductivity, on both sides.
- The motor cables must be kept physically separate from the control and network cables.


The user must comply with the applicable limits stipulated in the relevant national and international directives as regards the application, the length of the motor cable and the switching frequency.

Connect in delta connection or star connection according to the motor data.

Delta connection



Star connection





Minimum Torque to tighten the screws: **0.5 Nm** (4.6 lb-in) **Maximum** Torque to tighten the screws: **0,6 Nm** (5,3 lb-in)

Comply with the notes on cable cross-sections in chapter 5.4 "Dimensioning of conductor cross-section"

	Cable cross-sections mm ²
Motor terminals	0.2 4 (flexible cable with sleeve)
Motor terminais.	0.2 4 (flexible cable with sleeve) 0.2 6 (rigid cable)



5.6.1 Length of motor cables, without filter

	Permissik	ole length	of motor ca	ble without output	filter
Type	Agile	202	Agile 402		
Mains supply	1ph.	3ph.	3ph.	unshielded cable	shielded cable
Power	kW	kW	kW		
-01 1	0.09	0.18			
-02 1	0.12	0.25	0.25		
-03 1	0.18	0.37	0.37		
-05 1	0.25	0.55	0.55	50 m	25 m
-07 1	0.37	0.75	0.75	30 111	
-09 1	0.55	1.1	1.1		
-11 1	0.75	1.5	1.5		
-13 1	1.1	2.2	2.2		
-15 2	1.5	3.0	3.0		
-18 2	2.2	4.0	4.0	100 m	50 m
-19 2			5.5		
-19 3	3.0	5.5	5.5		
-21 3	3.0	7.5	7.5	100 m	E0 m
-22 3			9.2	100 111	50 m
-23 3			11		

The specified lengths of the motor cables must not be exceeded if no output filter is installed.



5.6.2 Motor cable length, with output filter du/dt

Longer motor cables can be used after taking appropriate measures, e.g. use of low-capacitance cables and output filters. The following table contains recommended values for the use of output filters.

		Motor cal	ole length wi	th output filter	
Type	Agile	202	Agile 402		
Mains supply	1ph.	3ph.	3ph.	unshielded cable	shielded cable
Power	kW	kW	kW		
-01 1	0.09	0.18			
-02 1	0.12	0.25	0.25		
-03 1	0.18	0.37	0.37		
-05 1	0.25	0.55	0.55	150 m	100 m
-07 1	0.37	0.75	0.75	130 111	100 111
-09 1	0.55	1.1	1.1		
-11 1	0.75	1.5	1.5		
-13 1	1.1	2.2	2.2		
-15 2	1.5	3.0	3.0		
-18 2	2.2	4.0	4.0	300 m	200 m
-19 2			5.5		
-19 3	3.0	5.5	5.5		
-21 3	3.0	7.5	7.5	300 m	200 m
-22 3			9.2	300 111	200 111
-23 3			11		

5.6.3 Motor cable length, with sinus filter

Motor cables can be longer if sinus filters are used. By conversion in sinus-shaped currents, high-frequency portions which might limit the cable length are filtered out. Consider the voltage drop across the cable length and the resulting voltage drop at the sinus filter. The voltage drop results in an increase of the output current. The frequency inverter must be suitable for the higher output current. This must be considered in the projecting phase.

In the case of motor cable lengths exceeding 300 m, contact BONFIGLIOLI service.

5.6.4 Group drive

In the case of a group drive (several motors at one frequency inverter), the total length must be divided across the individual motors according to the value given in the table. See chapters 5.6.1 and 0. Use a thermal monitoring element on each motor (e.g. PTC resistor) in order to avoid damage.

A group drive with synchronous server motors is not possible.




5.6.5 Brake resistor

Installing a brake resistor if feedback of generator energy is expected. Overvoltage shutdowns can be avoided by this.

⚠ DANGER

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.





Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time.

⚠ WARNING



During operation, the surface of the brake resistor can reach high temperatures. The surface can keep high temperatures after operation for a certain time. Do not touch the brake resistor during operation or operational readiness of the frequency inverter. Non-compliance may result in skin burn.

Install a safeguard for protection against contact or fix warning labels.

Do not install the brake resistor in the proximity to flammable or heat-sensitive materials.

Do not cover the brake resistor.

⚠ CAUTION




Bonfiglioli Vectron recommends using a temperature switch. Depending on the selected resistor the temperature switch is integrated as a standard or optional available. A detailed list is included in Chapter 12.3 "Brake resistor". The temperature switch disconnects the frequency inverter from mains supply if the brake resistor is overloaded.

Using Brake resistors without temperature switches can result in critical states.



Minimize cable lengths.





Minimum Torque to tighten the screws: **0.5 Nm** (4.6 lb-in) Maximum Torque to tighten the screws: **0.6 Nm** (5,3 lb-in)

NOTE

BONFIGLIOLI provides suitable brake resistors. Refer to chapter 12.3 "Brake resistor". For calculation of brake resistance refer to chapter 7.10.4.1 "Dimensioning of brake resistor".

NOTE

DC-connection requires a power estimation of the complete system. The brake resistor is operational dependent on the enable of the frequency inverter. The contactor K1 must disconnect all plant components from the mains.



5.7 Control terminals Standard connection

A CAUTION




The unit may only be connected with the power supply switched off.

Verify that the frequency inverter is discharged.

Switch off power supply before connecting or disconnecting the control inputs and outputs. Verify that the keyed control inputs and outputs are deenergized before connecting or disconnecting them. Otherwise, components may be damaged.

Factory settings




Comply with the technical data of control terminals: See chapter 11.3 "Control electronics".

For evaluation of the motor thermo contact, parameter *Operation Mode Motor-PTC* **570** must be set. See Chapter 7.4.6 "Motor temperature".

Via parameters *Digital inputs PNP/NPN* **559**, the logic evaluation at IN1D, IN2D, IN4D and IN5D is changed.







Factory settings

Digital inputs:

Termina	l	Sign	al for functions	Function
X11.4	IN1D	71	IN1D	Start Clockwise 68
X11.5	IN2D	72	IN2D	Start Anticlockwise 69
X12.1	IN4D	74	IN4D	Fixed Frequency Change-Over 1 66
X12.2	IN5D	75	IN5D	Error Acknowledgment 103
X11.3	STOA	70	Enable (fixed assignment)	Enable
X13.3	STOB	70	Enable (fixed assignment)	Lilable

Changeover of evaluation at digital inputs:

Termina	l	Operation modes		
X11.4	IN1D		_	NDN (active) 0 \/)
X11.5	IN2D	Digital inputs	U	NPN (active: 0 V)
X12.1	IN4D	<i>PNP/NPN</i> 559	1	DND (active) 24 V
X12.2	IN5D		1	PNP (active: 24 V)

Multifunction inputs (analog input/digital input):

Termina	l	Operation modes				Function
X12.3	Analog: MF11A	1 voltage 010 V	Operation Mode	1	voltage	Reference Frequency Source 1 475 , Refer-
X12.3	Digital: MF1D	2 current 020 mA 3 digital NPN (active: 0V)	<i>MFI1</i> 452	1	0 10V	ence Percentage Source 1 476
	Analog: MFI2A	4 digital PNP (active: 24V) 5 current 420 mA	Operation		digital	Thermo contact for P570 204 ,
X12.4	Digital: MFI2D	6 voltage, characteristic 7 current, characteristic	Mode MFI2 562	3	PNP (active: 0V)	Set <i>Operation Mode Motor Temp.</i> 570 to 1, 2 or 3

Digital output:

Termina	l	Function		
X13.5	OUT1D	Operation mode OUT1D (X13.5) 531	2	Run Signal

Multifunction output (analog output/digital output):

Termina	I	Operation	mode	S		Fι	unction
	MFO1D	Onava	1	Digital MFO1D	Digital: Source MFO1D 554	4	Setting Fre- quency
	MFO1A	Opera- tion Mode	10	Analog (PWM) MFO1A	Analog: Source MFO1A 553	7	Abs. value of actual frequency
X13.6	MFO1F	MFO1 (X13.6)	20	Repetition fre- quency (RF) MFO1F	RF/PT:Output Val- ue MFO1F 555	1	Actual Frequen- cy
	MFO1F	550	30	Pulse Train (PT) MFO1F	PT: Scaling Frequen	cy :	557

Relay output:

Termina		Function		
X10	OUT2D	Operation Mode OUT2D (X10/Relay) 532	103	Inv. error signal

Digital input/output:

Termina	l	Operation mo	odes			Function
X11.6	IN3D	Operation Mode Ter- minal	0 Input IN3D	Digital inputs PNP/NPN 559	0 NPN (ac- tive: 0 V) 1 PNP (ac- tive: 24 V)	Data Set Change- Over 1 70
	OUT3D	X11.6 558	1 Output OUT3D	<i>Op.Mode OU</i> 533	VT3D (X11.6)	103 Inv. error signal


IN: input, OUT: output, MFI: Multi-function input MFO: Multi-function output,

D: digital, A: analog, F: frequency, PT: pulse train, RF: Repetition frequency, Op. Mode: Operation Mode



5.7.1 Circuit for control via control terminals

The motor is started via start signals on the control terminals. The circuit shows the input signals required as a minimum and the control terminals in factory settings.



 $\varnothing \Longrightarrow 1.5 \text{ mm}^2 \text{ max. } 2.5 \text{ mm}^2$


Start cw: Start clockwise operation Start ccw: Start anticlockwise operation

VDC out: Voltage output

n: Speed E: Enable

5.7.2 Circuit for control via operator panel

The motor is started via the operator panel. The circuit shows the input signals required as a minimum and the control terminals in factory settings.




Ø == 1.5 mm² max. 2.5 mm²

VDC out: Voltage output

E: Enable



5.7.3 Further setting options for control terminals



The block diagram only shows a selection of possible uses of the inputs and outputs.




5.7.4 Evaluation logic of digital inputs


The evaluation logic of the digital inputs and multifunction inputs - in digital operation mode - can be changed over via parameter settings.

• Select "0 - NPN (active: 0 V)" or "1 - PNP (active: 24 V)" for parameter *Digital inputs PNP/NPN* **559**.

Digital inputs


Terminal	Input	Digit	tal inputs PNP/NPN 559
X11.4	IN1D	0 - NPN (active: 0 V)	Low-switching (with negative signal).
X11.5	IN2D	1 - PNP (active: 24 V)	High-switching (with positive signal). Factory setting.
X11.6	IN3D		
X12.1	IN4D		
X12.2	IN5D		






Multifunction inputs


Terminal	Input	Operati	on Mode MFI1 452
X12.3	MFI1	3 digital NPN (active: 0 V)	Low-switching (with negative signal).
Λ12.3	IVITI	4 digital PNP (active: 24 V)	High-switching (with positive signal).
Terminal	Input	Operati	on Mode MFI2 562
			Love quitabing (with pogetive sig
X12.4	MFI2	3 digital NPN (active: 0 V)	Low-switching (with negative sig- nal).Factory setting.







5.7.5 Overview of voltage inputs and outputs



5.7.6 External DC 24 V power supply

An external power supply DC 24 V can be connected to control terminals X13.1/X13.2. The external power supply enables parameter configuration, maintenance of input/output functions and communication, even while the mains voltage is switched off.

Requirements to be met by external power supply		
Input voltage range	DC 24 V ±10%	
Rated input current	Max. 1.0 A (typically 0.45 A)	
Peak inrush current	Typically: < 15 A (max. 100 μs)	
External fuse	Via standard fuse elements for rated current, characteristic: slow	
Safety	Safety extra low voltage (SELV) according to EN 61800-5-1	

NOTE

The digital inputs and the DC 24 V terminal of the electronic control equipment can withstand external voltage up to DC 30 V. Higher voltages may destroy the unit.

Use suitable external power supply units with a maximum output current of DC 30 V or use appropriate fuses to protect the unit.

Operation of the frequency inverter is not affected if the mains voltage is switched on and the external power supply is switched off.

Exceptions:

Mains voltage must be switched on for the following functions. The function is not enabled if only an external power supply is applied.

- The relay output X10 is controlled only if mains voltage is switched on.
- The heat sink fan and the internal fan are controlled only if mains voltage is switched on.



5.7.7 Installation notes according to UL508c

For an installation according to UL508c the motor must be supervised regarding the thermal behavior. The connection and the parameter settings for the temperature motor supervision is described in chapter 5.7 "Control terminals Standard connection".

For an installation according to UL508c only allowed fuses can be used for mains protection. The allowed fuses are described in chapter 11.2 "Device data".

For an installation according to UL508c the in chapter 11.2 "Device data" described maximum temperatures must not be exceeded.

For an installation according to UL508c only 60/75°C copper conductors are allowed to be used.

For an installation according to UL508c the devices are only allowed to be used in environments according to Pollution Degree 2.

According to UL508c Warn- or Marking labels are not allowed to be removed.



6 Commissioning

The unit may also be commissioned as described in the Quick Start Guide. This guide is supplied with the device.

In this chapter, first commissioning and commissioning for typical applications are described.






The frequency inverter may only be commissioned by qualified staff.


Prior to commissioning, all covers must be fixed, all standard equipment components of the frequency inverter must be installed, and the terminals must be checked.

Procedure:





6.1 Operator panel



Press arrow key for a short time to set a value in discrete steps.

Keep arrow key pressed for a quick value changing.

When setting a parameter value the default value can be selected by pressing both arrow keys at the same time.


The access to the parameter menu and setup menu can be locked with a password. Please refer to the notes in chapter 7.1.3 "Set password".

The RUN and STOP key can be locked by parameter *Local/Remote* **412**. Please refer to chapter 7.3.1 "Control" and chapter 7.5.3.4.1 "Control via reference frequency channel".

6.1.1 Menus

Menu	Functions			
Actual	Shows actual values. An actual value for permanent display during operation can be selected.			
Para	ameters. The following selection limits the number of visible and adjustable param-			
		For elementary applications and quick commissioning. Setting options for about 40 50 parameters (dependent on <i>Configuration</i> 30).		
	Std	For standard applications. Setting options for about 180 parameters.		
	Pro	For higher requirements. Setting options for about 380 parameters.		
	The limitation of the number of parameters can also be set via parameter <i>Control</i>			
	Il actual values are displayed, independent of the control level.			
Local Control the motor by means of the operator pane		the motor by means of the operator panel.		
	Poti F	Set output frequency (drive speed).		
Poti P Set percentage v		Set percentage values. For example in torque control or PID-control.		
	Jog	Keep pressed RUN-key: The drive operates with fixed set frequency.		
	Test	For finding errors and defects at the frequency inverter, sensors, the load and the electrical connections.		
Setup	Guided	commissioning. Select control method and motor type. Enter motor data.		
•	Guided commissioning also for the available communication interfaces.			
	Full	For first commissioning. Entry and measurement of motor data.		
	Motor	Only motor data measurement.		
	Buscon	For commissioning of a communication interface.		
Сору	Copy parameters by means of a memory card.			







6.1.1.1 Selection of Data sets

The 4 data sets can be set up differently if required. By default all 4 data sets are set up identically.

By default the parameter number is shown. If a dot and a digit is shown in extension to the Parameter number, a data set was already selected or changed individually before.

For the Selection comply with the following steps:

- To change all data sets:
 - o Move in the parameter menu to the requested parameter (Up/Down).
 - o Check if the parameter number is shown without following dot and digit.
 - o Press 1x ENT.
- To change a single data set:
 - o Move in the parameter menu to the requested parameter (Up/Down).
 - To select a data set, press and hold ENT and select with Up/Down the requested data set. Release ENT.
 - Press 1x ENT.




Not all parameters are data set changeable. The parameter list in this manual contains all information concerning data sets.



Contains a parameter different values in the data set, the selection of the parameter will automatically show data set 1. If the data sets differ they can only be be changed individually via Keypad.



6.1.1.2 Menu for communication setup





6.1.2 Motor control with operator panel

Poti F - variable frequency

The function Poti F is applicable for variable speed operation.

Select one of the following settings for parameter *Local/Remote* **412**:

- 3 Control via keypad
- 4 Control via keypad or contacts(factory setting)
- Select "5 Keypad motor potentiometer" for parameter *Reference frequency source 1* **475** or *Reference frequency source 2* **492**.
- Switch on enable signals at digital inputs STOA (terminal X11.3) and STOB (terminal X13.3).
- Select Lo[AL via arrow keys. Confirm by pressing ENT.

Confirm Pot , F by	pressing ENT.		., -
Start drive	RUN		ccelerates to the sum of <i>Reference frequency source 1</i> 475 and <i>irequency source 2</i> 492 . The displayed value is the totalized refer-
		Operation	0 - Off: 0 Hz.
		<i>mode</i> 493 ² :	1 - The reference frequency can be both positive and negative.
			2 - Positive only.
			3 - Inverted.
Set speed		Increase sp	eed.
	\bigcirc	Decrease sp	peed.
		Press for	r a short time to change the frequency by increments of 0.1 Hz.
			essed to change the frequency ³ by <i>Ramp Frequency-Motorpoti</i> ctory setting 2 Hz/s).
		Attention! The change set to 0 Hz.	of direction of rotation can occur if <i>Minimum Frequency</i> 418 is
		Minimum F range.	Trequency 418 and Maximum Frequency 419 limit the setting
Stop drive	STOP	The drive st wise) 423 is	cops. Deceleration (clockwise) 421 or Deceleration (anticlocks applied.
Status	(ESC)	Keep presse	ed for 1 second. The drive status is displayed.
Change direction of rotation	RUN)+(E	The direction	ection of rotation changes.
Change sign	STOP +		versal of the reference value. The direction of rotation is reversed next start.

_

¹ Factory setting of parameter *Reference frequency source 2* **492**. In the factory setting the reference frequency value can be set via operator panel (keypad).

² In the factory setting the reference frequency value can be positive (clockwise rotation) or negative (anticlockwise rotation).

³ Value "0" cannot be set if parameter *Minimum Frequency* **418** (factory setting 3.50 Hz) limits the setting range.



⚠ WARNING



The key RUN starts the drive, if the enable signals at digital inputs STOA (terminal X11.3) and STOB (terminal X13.3) are switched on. The start or stop of the drive is possible, even if menu Poti F is currently not selected. For example the start of the drive is possible if menu PARA for parameter settings or menu ACTUAL for actual value display is selected.

Display of drive status:



The drive rotates at the reference frequency value. The reference frequency value is the sum of *Reference frequency source 1* **475** and *Reference frequency source 2* **492**.



The drive is stopped. The alternating display shows the reference frequency value and the message STOP.



The selection Poti F is only available if the parameter *Local/Remote* **412** was set like described above.



Poti P - variable percentage reference value

The function Poti P is applicable for operation with variable percentage values, in example this is used with the technology controller and the direct torque control.

Select one of the following settings for parameter *Local/Remote* **412**:

- 3 Control via keypad
- 4 Control via keypad or contacts (factory setting)
- Select "5 Keypad motor potentiometer" for parameter *Reference percentage source 1* **476** or *Reference percentage source 2* **494**.
- Switch on enable signals at digital inputs STOA (terminal X11.3) and STOB (terminal X13.3).
- Select LoEAL via arrow keys. Confirm by pressing ENT.
- Select Pot P via arrow keys. Confirm by pressing ENT.

Start drive	RUN		d reference value is the sum of <i>Reference percentage source 1</i> erence percentage source 2 494 .
		Operation	0 - Off: 0%.
		<i>mode</i> 495 ² :	1 - The reference value can be both positive and negative.
			2 - Positive only.
			3 - Inverted.
Set per- centage		Increase per	centage value.
value	\bigcirc	Decrease per	centage value.
		- Press for	a short time to change the frequency by increments of 0.1%.
			sed to change the percentage value by <i>Ramp Percentage</i> : 509 (factory setting: 10%/s).
		The change of	of sign can occur if Minimum Frequency 418 is set to 0 Hz.
		Minimum ref	rerence percentage 518 and <i>Maximum reference percentage</i> 519 ng range.
Change sign RUN+ENT			on of the reference percentage value changes. Only possible for control (parameter n-/T-Control Change-Over 164).

Display of drive status:



The reference percentage value at rotating drive. The reference percentage value is the sum of *Reference percentage source 1* **476** and *Reference percentage source 2* **494**.



The drive is stopped. The alternating display shows the reference percentage value and the message STOP.

58

¹ Factory setting of parameter *Reference frequency source 2492*. In the factory setting the reference frequency value can be set via operator panel (keypad).

² In the factory setting the reference percentage value can be positive or negative.





The selection Poti P is only available if the parameter *Local/Remote* **412** was set like described above.

JOG

The function JOG is applicable for fixed speed operation.

- Switch on enable signals at digital inputs STOA (terminal X11.3) and STOB (terminal X13.3).
- If digital inputs are intended for start-signals: Switch off the signals of the parameters *Start clockwise* **68** and *Start anticlockwise* **69**¹.
- Select LoEAL via arrow keys. Confirm by pressing ENT.
- Select Jog via arrow keys. Confirm by pressing ENT.

Start drive	RUN	Keep pressed: The drive accelerates to the $JOG\ frequency\ 489$ (factory setting 5 Hz).
		For clockwise rotation: Set the <i>JOG frequency</i> 489 to positive values. For anticlockwise rotation: Set the <i>JOG frequency</i> 489 to negative values.
		Set the acceleration value for clockwise rotation in parameter <i>Acceleration</i> (<i>clockwise</i>) 420 . Set the acceleration value for anticlockwise rotation in parameter <i>Acceleration anticlockwise</i> 422 .
		Parameter Maximum frequency 419 limits the adjustable frequency range.
Stop drive	RUN	Release the key: The drive decelerates and comes to a standstill. Set the deceleration value for clockwise rotation in parameter <i>Deceleration</i> (clockwise) 421 . Set the deceleration value for anticlockwise rotation in parameter <i>Deceleration</i> anticlockwise 423 .
Change direction of rotation	ENT	The direction of rotation changes. The direction of rotation can be changed while the drive rotates or at standstill.

Display of drive status:



The drive rotates at *JOG frequency* **489**.



The drive is stopped.

The alternating display shows the Jog frequency value and the message STOP.



The function JOG can also be activated via a digital input. Refer to chapter 7.5.1.6 "JOG frequency" and 7.6.6.7 "Jog Start".

The selection JOG is available independent of the setting of parameter Lo-cal/Remote 412.

¹ The commands Start clockwise and Start anticlockwise have a higher priority than the start of the function JOG.



6.1.3 Set a parameter to the factory setting

Select the parameter number in menu "Para". Confirm by pressing ENT.

	Press simultaneously. The parameter shows now the value of the factory setting.
ENT	Press ENT to confirm this value as the new value for the parameter.

6.1.4 Restrict the scope of operation

The scope of operation can be restricted.

Lock the functions start, stop and change direction of rotation at the operator panel: Refer to chapter 7.5.3.4.1 "Control via reference frequency channel".

Lock the setting of the reference frequency: Refer to chapter 7.5.1 "Reference frequency channel". Lock the setting of the reference percentage: Refer to chapter 7.5.2 "Reference percentage channel".

6.2 First commissioning


During commissioning with "Setup/Full" a control method (according to V/f-characteristic or field-orientated control) and the connected motor type (asynchronous or synchronous motor) can be selected. The motor data must be entered according to the motor type-plate. Further motor data is measured automatically. The prompt of basic parameter entries like maximum frequency or acceleration is displayed. After Setup the drive is operational.

Select "Full" setup if the frequency inverter is commissioned for the first time.

Select "Motor" setup if only the motor data are to be measured and other settings are not to be changed.



6.2.1 Overview



Note: The overview shows the sequence for an asynchronous motor. When commissioning synchronous servo motors, the motor type (BCR, BTD, "Other") has to be selected additionally and the order of the entry of the motor parameters is adjusted.

6.2.2 Start first commissioning of an asynchronous motor

- Switch on enable at STOA (X11.3) and STOB (X13.3).
- Switch off enable at IN1D (X11.4) and IN2D (X11.5), if a circuit for control via control terminals is installed.
- Switch on the power supply.
- Start commissioning (Setup) on operator panel.



If the unit is in "as-delivered" condition or after resetting the unit to the factory settings, the guided commissioning procedure is started automatically. The operator panel displays the menu item "Setup". Guided commissioning can also be opened by selecting the "Setup" menu.



Setup

Parameter		Display
	Start commissioning.	SE LUP ENT
	Using arrow keys, select:	
	 Complete commissioning or 	FULL or
	 Measure motor data only. 	ñobor
	 Commissioning of a communication interface Refer to chapter " 	bU5C0n
	Note	
	 Select "Full" setup if the frequency inverter is commissioned for the first time. 	
	 Select "Motor" setup if only the motor data are to be measured and other settings are not to be changed. 	
		ENT
	Select data set 0. Select another data set for commissioning of several motors or for different operating points.	dSEL O
		ENT
P30	Configuration (control method).	ctrL (ENT)
	Using arrow keys, select:	\bigcirc
	 110 - IM¹: sensor-less control(SLC) or 	⊔F or
	 410 - IM²: sensor-less field-orientated control or 	Foc or
	 610 - PMSM³: sensor-less field-orientated control 	5ynch
		ENT
	Please note: If you changed the configuration, the device resets. Please execute the before mentioned steps anew.	

¹ For simple applications (e.g. fans, pumps). Control according to V/f-characteristic. In the case of control via operator panel: Select "UF". IM: Induction machine (asynchronous motor).

² Control of an induction machine (asynchronous motor). For higher demands on speed or torque accuracy. In the case of control via operator panel: Select "Foc".

³ Control of a synchronous motor, for higher demands on speed or torque accuracy. In the case of control via operator panel: Select "Synch". PMSM: Permanently magnetized synchronous motor.



Parameter Display Enter motor data according to motor rating plate: $V \triangle/Y Hz kW A \triangle/Y$ min⁻¹ cos φ 230/400 50 0.25 1.32-0.76 1375 0.77 P out SPEEd uoLE (Example of rating plate) F-E9 RTPERE coSPh i P376 Rated mechanical power P out (ENT) Set the value using the arrow keys. Note Press the arrow keys for 1 s to set each figure individually. The following rated values are automatically preset if the last set value of rated mechanical power corresponds to a BONFIGLIOLI motor. If a BONFIGLIOLI motor is connected check and confirm the values. P370 uoLE Rated voltage in V. (ENT) ATPERE P371 Rated current in A. (ENT) SPEEd P372 Rated speed in rpm. (ENT) coSPh i P374 Rated Cos-Phi (Enter if 110 "UF" or 410 "FOC" was selected for P30.) (ENT) Fr E9 P375 Rated frequency in Hz. (ENT) 5±0 If "STO" is displayed, enable must be switched on via STOA (X11.3) and STOB (X13.3). Auto-tuning (auto set-up). Confirm to start the measurement of fur-LunE ther motor parameters. Consider the following note for another set-(ENT) ting option. Note CALC If a BONFIGLIOLI motor is connected and the rated values have been confirmed, "Calc" instead of "tune" is displayed. In this case further motor parameters are not measured. The data is loaded and stored. If instead an auto-tuning should be done, use the arrow keys to switch from "Calc" to "tune". Auto-tuning (auto set-up). Further motor parameters are measured Eun ing automatically if "tune" was selected. Wait until the auto-tuning operation is complete and the next parameter prompt is displayed. If "Motor" (measurement of motor data only) was selected at the beginning of the setup procedure, "ready" is displayed.

Ramp gradient. Change rate [Hz/s] of output frequency after a change of the reference value or after a start command.

Acceleration (clockwise) in Hz/s.

Deceleration (clockwise) in Hz/s.

P420

P421

Ac c

(ENT)

dE C



Parameter		Display
	Ramp gradient. Change rate [Hz/s] of output frequency after a change of the reference value or after a stop or brake command.	ENT
P418	Minimum Frequency in Hz. Minimum motor speed [Hz]. The frequency will not drop below this value even if a lower reference frequency is selected.	Fr E9Lo
		ENT
P419	Maximum Frequency in Hz. Maximum motor speed [Hz]. The frequency will not rise above this value even if a higher reference frequency is selected.	FrE9Hı
	Commissioning (Setup) complete and ready for operation. Finish the guided commissioning. The device executes a reset. 2 seconds after the message "done" is visible, the reset is done automatically.	dan E (ENT)
	Drive enabled.	r ERdY
	 For further setting options, select "Para" menu or 	△ PA-A
	 start the drive. Via the operator panel or via signals at control terminals. 	
	Start motor via operator panel:	
	Select "local" menu for manual operation.	L oc AL ENT)
	Select "Poti F" (motor potentiometer) menu.	Pot , F (ENT) 350 H
	Switch on STOA (X11.3) and STOB (X13.3). Press RUN button.	(RUN)
	The motor is accelerated to the value of P418 (minimum frequency). Factory setting 3.50 Hz.	
	Using the arrow keys, set the speed.	△✓

Start the drive via signals at control terminals:

Switch on Start clockwise at IN1D (X11.4) or Start anticlockwise at IN2D (X11.5).

The motor is accelerated to the value of P418 (minimum frequency).

Factory setting 3.50 Hz.

By means of a voltage 0 ... 10 V on MFI1 (X12.3) set the speed. For potentiometer connection refer to chapter 5.7.1 "Circuit for control via control terminals".

Optional optimization of motor characteristics

The motor characteristics are set correctly for most of the applications with the default settings. In some cases optimization of the motor characteristics can be necessary or improve the performance significantly. The optimization possibilities are described in chapter 6.2.10.



6.2.3 Start first commissioning of a synchronous motor

- Switch on enable at STOA (X11.3) and STOB (X13.3).
- Switch off enable at IN1D (X11.4) and IN2D (X11.5), if a circuit for control via control terminals is installed.
- Switch on the power supply.
- Start commissioning (Setup) on operator panel.

If the unit is in "as-delivered" condition or after resetting the unit to the factory settings, the guided commissioning procedure is started automatically. The operator panel displays the menu item "Setup". Guided commissioning can also be opened by selecting the "Setup" menu.



Setup

Parameter		Display
	Start commissioning.	SELUP ENT
	Using arrow keys, select:	\bigcirc
	 Complete commissioning or 	FULL or
	 Measure motor data only. 	otor
	 Commissioning of a communication interface Refer to chapter " 	6U5COn
	Note	
	 Select "Full" setup if the frequency inverter is commissioned for the first time. 	
	 Select "Motor" setup if only the motor data are to be measured and other settings are not to be changed. 	
		ENT
	Select data set 0. Select another data set for commissioning of several motors or for different operating points.	d5EE 0
		ENT
P30	Configuration (control method).	ENT)
	Using arrow keys, select:	△
	 110 - IM¹: sensor-less control(SLC) or 	UF or
	 410 - IM²: sensor-less field-orientated control or 	Foc or
	 610 - PMSM¹: sensor-less field-orientated control 	5Ynch

¹ For simple applications (e.g. fans, pumps). Control according to V/f-characteristic. In the case of control via operator panel: Select "UF". IM: Induction machine (asynchronous motor).

² Control of an induction machine (asynchronous motor). For higher demands on speed or torque accuracy. In the case of control via operator panel: Select "Foc".



Parameter		Display ENT
	Please note: If you changed the configuration, the device resets. Please execute the before mentioned steps anew.	
	BCR-motor series of Bonfiglioli Vectron	bcr oder
	 BTD- motor series of Bonfiglioli Vectron 	btd oder
	Other synchronous servo motor	othEr (ENT)
	Enter motor data according to the name plate:	
	Standstill Torque M0 in Nm	EOT)
	Set the value using the arrow keys.	∅∅
i	Note Press the arrow keys for 1 s to set each figure individually.	∅ √ 1 s
P371	Rated current in A	ATPERE ENT
	If a BCR or BTD motor of Bonfiglioli Vectron was selected, the following data are preselected based on the standstill torque and the rated current. If a BONFIGLIOLI motor is connected check and confirm the values. If a motor of another manufacturer was connected, please enter the values manually.	
P370	Rated voltage in V The real AC rated voltage of the motor has to be set up (marked bold in the following). This results in entering: AC 330 V Motor = DC 560 V Motor = AC 400 V FI System voltage AC 200 V Motor = DC 320 V Motor = AC 230 V FI System voltage	uolt (ENT)
P376	Rated mechanical power in kW. For the BCR and BTD motors, the rated mechanical power is listed in the motor catalogue.	P out
		ENT
P372	Rated speed in rpm.	5 PE E d
P373	No. of pole pairs	Pol.Pr5 (ENT)
P375	Rated frequency in Hz	FrE9
	If "STO" is displayed, enable must be switched on via STOA (X11.3) and STOB (X13.3).	5±0
	Auto-tuning (auto set-up). Confirm to start the measurement of further motor parameters. Consider the following note for another set-	EunE

¹ Control of a synchronous motor, for higher demands on speed or torque accuracy. In the case of control via operator panel: Select "Synch". PMSM: Permanently magnetized synchronous motor.



Parameter		Display
	ting option.	ENT
i	Note If a BONFIGLIOLI motor is connected and the rated values have been confirmed, "Calc" instead of "tune" is displayed. If "calc" is selected, no further motor parameters are measured. The data is loaded and stored.	ENT)
	If instead an auto-tuning should be done, use the arrow keys to switch from "Calc" to "tune".	
	Auto-tuning (auto set-up). Further motor parameters are measured automatically if "tune" was selected. Wait until the auto-tuning operation is complete and the next prompt is displayed.	tun in9
D202	Té Matau Wolfe auf una calacte d'at the le crimine af the catur muse	11 51
P383	If Motor "Other" was selected at the beginning of the setup procedure, the determined Voltage constant is displayed. Correct this setting, if the value is known from the motor data sheet. For Bonfiglioli motors, this step is not necessary and the Voltage constant is set automatically.	U.con5t ENT)
	If the Voltage constant is unknown, set the value to Zero. The Setup will determine the Voltage constant automatically if the value is set to zero.	
	If "Motor" (measurement of motor data only) was selected at the	rEAdy
	beginning of the setup procedure, "ready" is displayed.	1 61103
P420	Acceleration (clockwise) in Hz/s Ramp gradient. Change rate [Hz/s] of output frequency after a	Ясс
	change of the reference value or after a start command.	ENT
P421	Deceleration (clockwise) in Hz/s Ramp gradient. Change rate [Hz/s] of output frequency after a change of the reference value or after a stop or brake command.	dE C
		ENT
P418	Minimum Frequency in Hz. Minimum motor speed [Hz]. The frequency will not drop below this value even if a lower reference frequency is selected.	FrE9Lo
		ENT
P419	Maximum Frequency in Hz. Maximum motor speed [Hz]. The frequency will not rise above this value even if a higher reference frequency is selected.	FrE9Hı
		ENT
	Commissioning (Setup) complete and ready for operation. Finish the guided commissioning. The device executes a reset. 2 seconds after the message "done" is visible, the reset is done automatically.	don E (ENT)
	Drive enabled.	r EAdY
	 For further setting options, select "Para" menu or 	
	- For further setting options, select Fara menu of	PA-A
	 start the drive. Via the operator panel or via signals at control terminals. 	
	Start motor via operator panel:	



Parameter		Display
	Select "local" menu for manual operation.	L oc AL (ENT)
	Select "Poti F" (motor potentiometer) menu.	Pot , F (ENT) 350 H
	Switch on STOA (X11.3) and STOB (X13.3). Press RUN button. The motor is accelerated to the value of P418 (minimum frequency). Factory setting 3.50 Hz. Using the arrow keys, set the speed.	RUN)

Start the drive via signals at control terminals:

Switch on Start clockwise at IN1D (X11.4) or

Start anticlockwise at IN2D (X11.5).

The motor is accelerated to the value of P418 (minimum frequency).

Factory setting 3.50 Hz.

By means of a voltage 0 ... 10 V on MFI1 (X12.3) set the speed. For potentiometer connection refer to chapter 5.7.1 "Circuit for control via control terminals".

Optional optimization of motor characteristics

The motor characteristics are set correctly for most of the applications with the default settings. In some cases optimization of the motor characteristics can be necessary or improve the performance significantly. The optimization possibilities are described in chapter 6.2.10.

6.2.4 Status messages during commissioning (SS...)

The following status messages are possible during commissioning (setup):

Status message		Meaning
SS000	OK	Auto setup routine has been carried out.
SS001	PC Phase 1	The plausibility check (PC) of the motor data is active.
SS002	PC Phase 2	The calculation of dependent parameters is active.
SS003	STO	The parameter identification demands enable on digital input STOA and STOB.
SS004	Parameter identifica- tion	The rated motor values are checked by the parameter identification feature.
SS010	Setup already active	The setup routine via the operator panel is being carried out.
SS030	No Release	No enable signal. The parameter identification demands enable on digital input STOA and STOB.
SS031	Error	Error during the auto set-up routine. Check the value of <i>Actual error</i> 259 .
SS032	Warning Phase Asymmetry	The parameter identification feature diagnosed an unbalance during the measurements in the three motor phases.
SS099	Setup not carried out	The setup is not carried out until now.

6.2.5 Warnings during commissioning (SA...)

If an error or a warning is signaled during commissioning, the following causes are possible.

Warning Messages					
Code	Message	Meaning			
SA001	Rated voltage	The value of the parameter <i>Rated Voltage</i> 370 is out of the rated voltage range of the frequency inverter. The maximum reference voltage is indicated on the nameplate of the frequency inverter.			
SA002	Efficiency	For an asynchronous motor, the calculated efficiency is in the limit range. Check <i>Rated Voltage</i> 370 , <i>Rated Current</i> 371 and <i>Rated Power</i> 376 .			



Warning Messages				
SA003	Rated cos-phi	The value entered for parameter <i>Rated Cosine Phi</i> 374 is outside of the normal range (0.6 to 0.95). Correct the value.		
SA004	Slip frequen- cy	For an asynchronous motor, the calculated slip is in the limit range. Check <i>Rated Speed</i> 372 and <i>Rated Frequency</i> 375 .		
SA021	Stator re- sistance high value	The following causes are possible: The motor cable cross-section is not sufficient. The motor cable is too long. The motor cable is connected incorrectly.		
SA022	Rotor re- sistance high value	The following causes are possible: The motor cable cross-section is not sufficient. The motor cable is too long. The motor cable is connected incorrectly.		
SA041	Rated Slip Correction Factor low value	Check Rated Speed 372 and Rated Frequency 375.		
SA042	Rated Slip Correction Factor high value	Check Rated Speed 372 and Rated Frequency 375 .		
SA051	Check motor connection	The motor data for star connection were entered, the motor, however, is connected in delta. Change motor cable connections for star connection. Check motor data entered for delta connection. Repeat commissioning (Setup) via operator panel.		
SA052	Check motor connection	The machine data for delta connection were entered, the motor, however, is connected in star. Change motor cable connections for delta connection. Check motor data entered for star connection. Repeat commissioning (Setup) via operator panel.		
SA053	Check motor connection	Check connections at frequency inverter and motor.		

If an error or a warning is signaled:

- Press ESC to correct a parameter value after an error message or warning.
- Press ENT to suppress a warning message. Setup is continued. It is recommended that the entered data be checked.

In the case of problems not triggering an error message, you can try to find an appropriate measure, following the instructions in chapter 13.3 "Troubleshooting".

If errors or warning messages occur during operation, proceed according to the instructions in chapters 13.1.1 "Error messages" and 14.3 "Warning status and warning status application".



6.2.6 Error messages during commissioning (SF...)

If an error or a warning is signaled during commissioning, the following causes are possible.

Error messages				
Code	Message	Meaning		
SF001	Rated current too low	The value entered for parameter <i>Rated Current</i> 371 is too low. Correct the value.		
SF002	Rated current too high	The value for parameter <i>Rated Current</i> 371 is too high, referred to parameters <i>Rated Power</i> 376 and <i>Rated Voltage</i> 370 . Correct the values.		
SF003	Rated cos-phi	The value entered for parameter <i>Rated Cosine Phi</i> 374 is wrong (greater than 1 or smaller than 0.3). Correct the value.		
SF004	Negative slip frequency	The calculated slip frequency is negative. Check and, if necessary, correct the values entered for parameters <i>Rated Speed</i> 372 and <i>Rated Frequency</i> 375 .		
SF005	Slip frequen- cy too high	The calculated slip frequency is too high. Check and, if necessary, correct the values entered for parameters <i>Rated Speed</i> 372 and <i>Rated Frequency</i> 375 .		
SF006	Power bal- ance	The calculated total output of the drive is lower than the rated power. Correct and check, if necessary, the value entered for parameter <i>Rated Power</i> 376 .		
SF007	Config. not supported	The set configuration is not supported by the set-up routine.		
SF011	Inductance measurement failed	The main inductance measurement has failed because the motor has a high slip. Correct the rated motor values in parameters 370 , 371 , 372 , 374 , 375 and 376 . Carry out the set-up routine again. In case an error message is displayed again, enter the value 110 for parameter <i>Configuration</i> 30 (sensorless control according to V/f-characteristic) if value 410 was set so far. Carry out the set-up routine again.		
SF012	Inductance measurement failed	The leakage inductance measurement has failed because the motor has a high slip. Correct the rated motor values in parameters 370 , 371 , 372 , 374 , 375 and 376 . Carry out the set-up routine again. In case an error message is displayed again, enter the value 110 for parameter <i>Configuration</i> 30 (sensorless control according to V/f-characteristic) if value 410 was set so far. Carry out the set-up routine again.		
SF021	Resistance measurement failed	The measurement of the stator resistance did not deliver a plausible value. Check the cables at the terminals of the motor and the frequency inverter for proper connection and check the contacts for corrosion and safe contact. Carry out the set-up routine again.		
SF022	Resistance measurement failed	The measurement of the rotor resistance did not deliver a plausible value. Check the cables at the terminals of the motor and the frequency inverter for proper connection and check the contacts for corrosion and safe contact. Carry out the set-up routine again.		
SF026	Setup abort- ed	The setup-routine is aborted.		

If an error or a warning is signaled:

- Press ESC to correct a parameter value after an error message or warning.
- Press ENT to suppress a warning message. Setup is continued. It is recommended that the entered data be checked.

In the case of problems not triggering an error message, you can try to find an appropriate measure, following the instructions in chapter 13.3 "Troubleshooting".

If errors or warning messages occur during operation, proceed according to the instructions in chapters 13.1.1 "Error messages" and 14.3 "Warning status and warning status application".



6.2.7 Check direction of rotation

MARNING

The unit may only be connected with the power supply switched off.

Make sure that the frequency inverter is discharged.



Dangerous voltage may be present at the motor terminals and the terminals of the brake resistor even after the frequency inverter has been disconnected from power supply. Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.

To check if the reference value and the actual direction of rotation of the drive correspond to one another, proceed as follows:

- Operate the drive at low speed, i.e. specify a reference value of approx. 10%.
- Switch on frequency inverter enable briefly: signal at digital inputs STOA and STOB as well as IN1D (Start clockwise) or signal at digital inputs STOA and STOB as well as IN2D (Start anticlockwise).
- Check if the motor shaft turns in the required direction.

In case the sense of rotation is wrong, exchange two motor phases, e.g. U and V at the terminals of the frequency inverter. The mains-side connection of the frequency inverter does not affect the sense of rotation of the drive. In addition to checking the drive, the corresponding actual values and operating messages can be read out by means of the operator panel.

NOTE

When using a synchronous motor (in example BCR-, BTD-motor from BONFIGLIOLI) the correct phase sequence must be complied with. A mix up of the phases leads to the loss of the correct motor control and typically a fault message.

6.2.8 Selection of actual value display


During drive operation the display of the operator panel indicates the actual frequency (factory setting). This is the value of parameter *Actual Frequency* **241**.

The actual value for permanent display during operation can be selected:

- Select menu "Actual". Confirm by pressing ENT.
- By means of the arrow keys select the number of the parameter the value of which is to be displayed. Confirm by pressing ENT. The value is displayed.
- Press ENT for at least 1 second. The display flashes.

The selected value is displayed permanently during drive operation.

Example: Select the working hours (operating hours in which the output stage of the inverter is active) for permanent display.





6.2.9 Commissioning without Setup

After electrical connection, the motor (that is selected according to the technical data of the frequency inverter) is ready for operation. The parameters of the frequency inverter must be set to the factory setting. Commissioning by means of Setup with the operator panel is not necessary.

After first switch-on the Setup message is displayed automatically. Select an actual value (for example *Actual Frequency* **241**) in menu "Actual" to hide this message.

If the operation should be changed between asynchronous motor (setting 110 or 410 of *Configuration* **30**) and synchronous motor (setting 610 of *Configuration* **30**) the frequency inverter must be reset to the factory setting. This enables commissioning without Setup via operator panel.

6.2.10 Optional Optimization of motor characteristics

The motor characteristics are set correctly for most of the applications with the default settings. In some cases optimization of the motor characteristics can be necessary or improve the performance significantly.

The following optimizations usually result from the described behavior:

Objectionable or faulty behavior:	Controller	Chapter
Overfrequency or Overcurrent error switch off	Speed Controller	6.2.10.1
Motorspeed swings	Speed Controller	6.2.10.1
Motor hums audible	Speed Controller	6.2.10.1
Motor doesn't follow fast enough to a Reference value	Speed Controller	6.2.10.2
step		
Vibration response at low speeds (often occurs with	Voltage Constant	6.2.10.3
unknown or inexact motor data)		
Jerky or oscillating behavior at approx. 5 % of the rated	Voltage Constant	6.2.10.3
frequency (Transition from current impression to Field		
oriented control)		
Unsufficient Torque during Start of FOC and SYNCH	Starting behavior	6.2.10.4

6.2.10.1 Speed Controller: Softer set up

If regularly a fault "Overfrequency" or "Overcurrent" occurs or the connected motor hums (even at zero speed) or the motor speed oscillated, then the Speed controller is typically set to dynamic.

Set Amplification 1 (|f| < P738) **721** lower and Integral Time 1 (|f| < P738) **722** higher.

Please note, that *Speed Control Switch-Over Limit* **738** offers different settings of the speed controller for different speed ranges. Above the Switch-Over threshold the parameters *Amplification 2* (|f|>P738) **723** and *Integral Time 2* (|f|>P738) **724** are effective for the speed controller.



With setting *Speed Control Switch-Over Limit* **738** = 0, *Amplification* 1 (|f| < P738) **721** and *Integral Time* 1 (|f| < P738) **722** are effective over the complete frequency range.

Comply with chapter 7.9.5.3.

6.2.10.2 Speed Controller: Stronger set up

If the motor doesn't follow dynamic enough a reference value step ("load step"), more dynamic settings of the speed controller can enhance the dynamic behavior.

Set $Amplification \ 1 \ (|f| < P738)$ **721** higher and $Integral \ Time \ 1 \ (|f| < P738)$ **722** lower. Please note, that $Speed \ Control \ Switch-Over \ Limit$ **738** offers different settings of the speed controller for



different speed ranges. Above the Switch-Over threshold the parameters $Amplification\ 2\ (|f|>P738)$ **723** and $Integral\ Time\ 2\ (|f|>P738)$ **724** are effective for the speed controller.

Comply with chapter 7.9.5.3.

In different applications the Acceleration Pre-Control can enhance additionally the dynamic behavior, please comply with the notes in chapter 7.9.5.4.



Depending on the application (inverter power, motor power, gear power, driven load) and its load the frequency inverter might not be able to supply physically the requested power. In this case the dynamic behavior has to be adjusted to the environmental conditions or the project planning has to be checked.

6.2.10.3 Voltage Constant

After the Setup was completed including the motor tuning, the Voltage constant can be changed manually. If the Voltage Constant is not set optimum, the result might be a jerky or oscillating behavior at approx. 5 % of the rated frequency (transition from starting current impression to Field Oriented Control, the exact transition point is defined via *Frequency limit* **624**).

Proceed with the Optimization of the Voltage Constant as follows:

- Rotate the motor at approx 50 % of the rated speed without load.
- Check the Actual value *Rotor flux* **225**.
- Change the *Voltage constant* **383** until the *Rotor flux* **225** equals 101 %.



With Motors with a high pole pair number it can occur, that the Voltage constant cannot be entered in the valid value range up to 6500.00 mVmin. In this case you can enter the value with factor 10 smaller. In the device the ratio input voltage/rated speed is validated and the factor 10 is corrected automatically (if necessary).

Comply with chapter 7.2.2 "Further motor parameters".

6.2.10.4 Insufficient Torque during Start of FOC and SYNCH

In the sensorless control the motor rotation is controlled below the $Frequency\ limit\ 624$ via a current impression with $Starting\ current\ 623$. Both parameters are set up during the Autotuning. $Frequency\ limit\ 624$ is set to approx. 5 % of the Rated frequency. The value can be reduced in most applications. Bonfiglioli Vectron recommends to set up the $Frequency\ limit\ 624$ always > 2.5 % of the rated frequency and at least 1 Hz. Check your changes via the Scope function.

Starting current **623** affects the Torque during the Start. If the Torque during the Start should be increased, increase *Starting current* **623**.





Please note, that a continuous operation with a high Starting current can overload the motor thermally and eventually even destruct the motor. Always check the thermal stability of the motor after increasing the Starting current.

Comply with chapter 7.3.2 "Starting behavior".

6.2.10.5 Cross coupling compensation

Using permanent excited synchronous motors can require a cross coupling compensation in individual cases for high stator frequencies. This is typically necessary if changes in the speed controller do not result in further improvements in the control behavior and the control behavior shows small oscillations at high stator frequencies.

• Rotate the motor at approx 66 % of the rated speed without load.



- Check the Actual value *Isd* **215**.
- Change the Cross-Coupling Factor **746** until the oscillations are minimal in Isq **225**.

NOTE

Too high values set as *Cross-Coupling Factor* **746** can result in Overcurrent switch-offs. Change the value in small steps (max. 5 % per step).

6.3 Commissioning of a communication interface

The communication interfaces can be put into operation by means of the menu "Setup" at the operator panel. Even without the knowledge of the parameter number(s) a communication interface can be set up quick and easy. Further communication parameters can be set in the menu "Para". The communication manuals describe the setting options and protocols in detail.

Protocol selection

	Display
Use the arrow keys to select menu "Setup".	SELUP (ENT)
Use the arrow keys to select:	△▽
Commissioning of a communication interface(bus configuration)	bUSEOn (ENT)
Use the arrow keys to select a protocol:	△▽
CANopen	[AnoPn
Profibus ¹	PrOF! b
Systembus	595605
Modbus	ñodbU5
VABus	∪AbUS
TCP/IP (Ethernet-Interfaces without EtherCAT®)	ECP-1P
	ENT




EtherCAT® doesn't require parameterization at the frequency inverter. The settings are done for EtherCAT® completely via the PLC.

¹Selection is possible only if an optional communication module CM-PDPV1 is installed.




CANopen

Parameter		Display
387	CAN Node Number	nodE id
385	CAN Baudrate	ьяиа
276	CAN interface setting(CM-CAN/X12).	if SEE
	 Set the terminals X12.5 and X12.6 to protocol CANopen. Or: 	2
	 Set an optional communication module CM-CAN to CANopen. 	1




Profibus





Systembus


Parameter		Display
900	Node-ID	nodE id
903	Baudrate	ьяиа
276	CAN interface setting (CM-CAN/X12).	IF SEL
	 Set the terminals X12.5 and X12.6 to system bus. Or: 	1
	 Set an optional communication module CM-CAN to system bus. 	2





Modbus


Parameter		Display
1376	Modbus Address (Node-ID).	nodE id
1504	Modbus Baudrate	ьяиа
1503	Modbus Mode (RTU or ASCII)	ñodE
1375	Modbus Parity	PAr 169
395	Interface setting. Protocol (CM/X21).	IF SEL
	 Set the service interface X21 to Modbus. Or: 	1
	 Set an optional communication module CM-232 or CM- 485 to Modbus. 	2





VABus


Parameter		Display
	Select the interface for settings of VABus parameters. (Service interface X21 or communication module).	IntErF
	 Select service interface X21 for VABus communication. Or: 	55רט וכ
	 Select an optional communication module CM-232 or CM- 485 for VABus communication. The menu item is only displayed if a communication module is installed. 	Eñ-ñod
394	CM: VABus Node-ID. An optional communication module CM-232 or CM-485 was selected.	nodE id
1501	X21: VABus Node-ID. The service interface X21 was selected.	nodE id
10	Baudrate. An optional communication module CM-232 or CM-485 was selected.	ьяиа
1500	Baudrate. The service interface X21 was selected.	ьЯUd
395	Interface setting. Protocol (CM/X21).	IF SEL
	 Set the service interface X21 to VABus. Or: 	2
	 Set an optional communication module CM-232 or CM- 485 to VABus. Or: 	1
	 Set the service interface X21 and an optional communication module CM-232 or CM-485 to VABus. 	0





■ TCP/IP

Parameter		Display
1432	Set up the IP address. This is done in 4 steps. The dots mark the current position.	AddrES
1433	Set up the Subnet mask. This is done in 4 steps. The dots mark the current position.	SUbnEt
1434	Set up the Gateway address. This is done in 4 steps. The dots mark the current position.	9ALE
1435	Set up the DNS server address. This is done in 4 steps. The dots mark the current position.	dn5
1436	If a DHCP Server should and can be used, this setting is used. 0 = Off/Disabled 1 = On/Enabled When the DHCP is enabled, the above settings are not required.	dhCP
	APPLY: Must be used after the configuration of the above settings. Only if the settings are applied, they are taken over. If this was not successful, an error or timeout message might occur.	APPLY
	RELOAD: Reload can be used to reload the default values. If this was not successful, an error or timeout message might occur.	rELoAd





6.4 After first commissioning

After execution of the "Setup" function, the device can be adjusted to the relevant application via the following parameters. Not all setting options are listed. The parameters can be set in the menu "Para".

Control level


Parar	neter		(Factory setting)
P28	1	Easy: Parameters for quick commissioning.	
	2	Standard: The most common parameters can be set.	
	3	Professional: Extended access to parameters.	

Local/Remote, control via contacts or keypad

P412	0	The commands start, stop and direction of rotation (parameters <i>Start Clockwise</i> 68 , <i>Start Anticlockwise</i> 69) can be entered via digital inputs.
	3	The commands start, stop and direction of rotation can be entered via the operator panel.
	4	The commands start, stop and direction of rotation can be entered via the operator panel or via digital inputs. Factory setting.
	5	Control of direction of rotation (parameter <i>Start Clockwise</i> 68 , <i>Start Anticlockwise</i> 69) and signal <i>Start 3-Wire Ctrl.</i> 87 via digital inputs. Further settings are applicable for control via bus system.



Selection of reference frequency





Ramp rise time

(Factory setting) P430

Accelerated and uniform acceleration and deceleration via S-curve. Thereby the jerk during acceleration and deceleration is reduced. The value is used both for clockwise

and anticlockwise operation. (0 ms)

Torque control

					(Factory setting)
			Refere	nce to	orque
P164	6	On	P476	1	Analog Value MFI1A
	7	Off		2	Analog Value MFI2A
	71	Changeover via		3	Fixed Percentage
		digital inputs		4	Motorpot. via Digital Inputs
				5	Keypad-Motorpot.
	Spee	ed control is switched o	ff when torg	ue co	ontrol is switched on.
					r) or 610 (synchronous motor).

Speed control

				(Factory setting)
			Optimiz	re speed controller
P720	0 9	Speed controller off	P721	Amplification 1 (f <p738) (10)<="" td=""></p738)>
	1 5	Switched on	P722	Integral Time 1 (f <p738) (104="" ms)<="" td=""></p738)>
	Limits			
	P728 C	Current limit		
	P730 T	Torque limit		
		Power limit		
	. ,		mited by t	the Minimum Frequency (P418) and Maximum
	•	cy (P419).	iniced by	are i minimani i requeste, (i 110) una i laximani
	•	, ,	hronouci	motor) or 610 (synchronous motor).



Digital inputs


- Digita	ai inputs			(Factor (cotting)
	Evaluation logic			(Factory setting)
	3	Terminal	NPN	PNP
P559	0 NPN (active: 0 V) 1 PNP (active: 24 V)	X11.4 X11.5 X12.1 X12.2 X11.6	GND IN1D X11.4 IN2D X11.5 IN4D X12.1	24 VDC IN1D X11.4 IN2D X11.5 IN4D X12.1
P452	Multi-function MFI1 3 digital NPN (active: 0 V) 4 digital PNP (active: 24 V)	X12.3	IN5D X12.2 IN3D P558=0 X11.6	IN5D X12.2 IN3D P558=0 X11.6
P562	Multi-function MFI2 3 digital NPN (active: 0 V) 4 digital PNP (active: 24 V)	X12.4	MFI1 X12.3 MFI2 X12.4	MFI1 X112.3 MFI2 X12.4
	Franchica		High: ≤ DC 5 V	High: ≥ DC 10 V
	Function			
P[]	72 IN2D P69 (Start 73 IN3D P70 (Data 74 IN4D P66 (Fixed 75 IN5D P103 (Erro 76 MFI1D - 77 MFI2D -	clockwise) anticlockwise Set Change-C I Frequency C or Acknowledg	Over 1) (P558 = (hange-Over 1) gement)) - Input IN3D)
	Other possible functions P62 Frequency Motorpoti U P63 Frequency Motorpoti D P67 Fixed Frequency Chang P71 Data Set Change-Over P72 Percent Motorpoti Up P73 Percent Motorpoti Dow P75 Fixed Percent Change-Over P76 Fixed Percent Change-Over	own P pe-Over 2 P 2 P (I n Over 1	87 Start 3-Wire C 95 Brake Choppe 164 n-/T-Control C 183 External Error Not all functions are I	r Release hange-Over
	Assign a function to a digital in Select the parameter of the fur Set the parameter to the digita	nction.	,	

Digital outputs

					(Factory setting)
	Func	tion	Terminal	Othe	r possible functions
P531	2	Run Signal	X13.5	0	Off
P532	103	Inverted Error Signal	X10	3	Ready or Standby Signal Error Signal
1 332	103	inverted Error Signal	X10	5	Reference Frequency reached
P533	103	Inverted Error Signal	X11.6	6	Reference Percentage reached
		P558 = 1 (output)		7	Ixt-Warning (overload)
				8	Warning Heat Sink Temperature
P554	4	Setting Frequency	X13.6	9	Warning Inside Temperature
		P550 = 1 (digital)		10	Warning Motor Temperature
				11	Warning, General
				(Not	all functions are listed.)



Analog inputs




Analog outputs

	outputs	
P550	Multi-function output MFO1 Terminal 10 Analog (PWM) MFO1A X13.6	(Factory setting) U [V] 24
P551 P552	Analog: Voltage 100% (10 V) Analog: Voltage 0% (0 V)	P551 10 P552 0 0% 100%
P553	7 Abs. Actual Frequency(0 HzP419)	P553=7 0 Hz P419 (f _{max})
	Other possible output values 0 Off 10 Abs. Reference Percentage (P476+P494) 20 Abs. Iactive (active current) 30 Abs. Pactive (active power)	 32 Abs. Inside Temperature 33 Abs. Heat Sink Temperature 51 DC-Link Voltage 52 V (output voltage)
	30 Abs. Pactive (active power) 31 Abs. T (torque)	52 V (output voltage) (Not all functions are listed.)
	Via multifunction output (MFO1), output and Set MFO1 as analog output. Set the voltage range (022 V) for output. Select the value to be output.	alog value:



Motor potentiometer

Control via digital inputs or operator panel.






Fixed Frequencies

				(Fac	ctory setting)
P480	Fixed Frequency 1 (0.00 Hz)				
P481	Fixed Frequency 2 (10.00 Hz)				
P482	Fixed Frequency 3 (25.00 Hz)				
P483	Fixed Frequency 4 (50.00 Hz)				
P485	Fixed Frequency 5 (5.00 Hz)				
P486	Fixed Frequency 6 (10.00 Hz)				
P487	Fixed Frequency 7 (25.00 Hz)				
P488	Fixed Frequency 8 (50.00 Hz)				
P66	7 Off	P66	P67	P131	Selection
P67	71 IN1D	0	0	0	P480
P131	72 IN2D	1	0	0	P481
	73 IN3D (P558: 0 - Input)	1	1	0	P482
	74 IN4D	0	1	0	P483
	75 IN5D	0	1	1	P485
	76 MFI1D(P452: 3 - NPN or 4 - PNP)	1	1	1	P486
	77 MFI2D (P562: 3 - NPN or 4 - PNP)	1	0	1	P487
	other signal sources	0	0	1	P488
	Via the signal states at the digital inputs, the fixe	ed frequenc	ies can	be seled	cted.
	P475 or P492: 3 - Fixed Frequency.				
	The Speed Control is always limited by the Minir Frequency (P419).	mum Freque	ency (P4	18) and	Maximum

Blocking Frequencies



PWM input

A PWM signal at input IN2D (X11.5) can be used as reference value.

P496

10 PWM, 0 ... 100% of P419 (maximum frequency) or of P519 (maximum 11 PWM, -100 ... 100% reference percentage)

P652 and P653; for scaling

P476 or P494: 10 Repetition percentage

The Speed Control is always limited by the Minimum Frequency (P418) and Maximum Frequency (P419).



Repetition frequency input

A frequency signal at input IN2D (X11.5) can be used as reference value.

Evaluation

P496 20 RF (Repetition frequency) single evaluation: One signal edge

21 RF (Repetition frequency) double evaluation: Both signal edges

P497 (Divider); for scaling

P475 or P492: 10 Repetition Frequency Input

The Speed Control is always limited by the Minimum Frequency (P418) and Maximum Frequency (P419).

Pulse train input

A pulse train signal at input IN2D (X11.5) can be used for specification of the reference value. The frequency of the pulse train signal on the input can be modified via a scaling factor.

P496 30 Pulse train


P654 (scaling frequency)

P475 or P492: 10 Repetition

frequency

P476 or P494: 10 Repetition

percentage



The Speed Control is always limited by the Minimum Frequency (P418) and Maximum Frequency (P419).



Startin	g behaviour (V/f)	
	if P30: 110 - IM: ser	(Factory setting) asor-less control (SLC), V/f characteristic
	The motor is magnetized (flux-formation, P781 (P623) is impressed. The IxR compensation coresistor.	
P620	Operation Mode	
	0 Off	Control according to V/f characteristic.
	1 Magnetization	Set P780 and P781.
	2 Magnetization +Current Impression	Set P623, P624, P780 and P781.
	3 Magnetization + IxR-Compensation	Set P624, P780 and P781.
	4 Magnetization + Current Impression + IxR-Compensation	Set P623, P624, P780 and P781.
	12 Magnetization +Current Impression	Set P623, P624, P780 and P781.
	with Ramp Stop	For high start torque.
	14 Magnetization + Current Impression	Set P623, P624, P780 and P781.
	with Ramp Stop + IxR-Compensation	For high start torque.
P623	Starting Current (value: I_{FIN}) ¹	PI controller for start current
		P621 P part (2.00)
	For sufficient torque if a high start torque is re quired. The start current is impressed until the output frequency reaches the value of P624.	
	output frequency reacties the value of 1 024.	
P624	Frequency Limit (2.60 Hz) The starting current is impressed up to this out	tput frequency.
P780	Max. Flux-Formation Time (300 ms) The current during flux-formation (value of P75 time.	81) is not impressed longer than this
5704		
P781	Current during Flux-Formation (value: I _{FIN}) Upon startup, this current value is impressed. by P780.	The time for current impression is limited

¹ Nominal value of frequency inverter



Starting behaviour (field-oriented)

	(Factory setting)
	if P30: 410 - IM: sensor-less field-oriented control" P30: 610 - PMSM: sensor-less field-oriented control"
P623	Starting Current (value: I _{FIN}) ¹
	For sufficient torque if a high start torque is required. The start current is impressed until the output frequency reaches the value of P624.
P624	Frequency Limit (2.60 Hz) The starting current is impressed up to this output frequency.
779	Min. Flux-Formation Time The current during flux-formation (P781) is impressed at least for this time.
P780	Max. Flux-Formation Time (P30=410: 1000 ms), (P30=610: 50 ms) The current during flux-formation (P781) is impressed not longer than this time.
P781	Current during flux-formation (value: I_{FIN}) Upon startup, this current value is impressed. The time for current impression is limited by P780.

Stopping behaviour

		(Factory setting)
P630	0 P68 and P69 = 1: Coast to Stop, P68 and P69 = 0: Coast to P68 and P69 = 1: Coast to Stop, P68 and P69 = 0: Stop and	
	P68 and P69 = 1: Stop and Switch Off, P68 and P69 = 0: Stop	op and Switch Off
	P68 and P69 = 1: Emergency Stop and Switch Off, P68 and DC brake DC brake (only if P30 = 110): As from standstill, the direct c ing current) is impressed for the time of P632 (braking time)	urrent P631 (brak-
	Via P68 (Start Clockwise) and P69 (Start Anticlockwise) the motor store controlled. For state P68 and P69 = logic 1, a stopping behavior must state P68 and P69 = logic 0, a stopping behavior must be selected.	

¹ Nominal value of frequency inverter



V/f characteristic

		(Factory setting)
	if P30: 110 - IM: sensorle	
606	Type V/f characteristic 1 Linear Linear characteristic. 2 Quadratic For applications where the speed. Suitable for energy	e torque increases quadratically to the y saving.
600	Starting Voltage (5.0 V) Output voltage at output frequency of 0 Hz.	U [V]♠
601	Voltage Rise (10%) Increase of output voltage deviating from linear characteristic.	P601
602	Rise Frequency (20%) Increase of output voltage deviating from line- ar characteristic.	P600
603	Cut-Off Voltage (230,0 or 400.0 V) Coordinate for setting of V/f characteristic.	P602 P604 f [Hz] P418 (f _{min}) P419 (f _{max})
604	Cut-Off Frequency (50 Hz) Coordinate for setting of V/f characteristic.	Quadratic P603
		P601 P600 P602 P418 (f _{min}) P419 (f _{max})
	The working range is between P418 (minimum fimum frequency 50 Hz).	requency 3.50 Hz) and P419 (maxi-

Motor temperature monitoring

	Evaluate thermo contact at MFI1 (X12.4):
570	1 Thermo contact, P204: Warning only
	2 Thermo contact, P204: Error Switch-Off
	3 Thermo contact, P204: Error Switch-Off 1 minute delayed
	Further evaluations: PTC, KTY, PT1000.



6.5 Typical functions

The tables show a selection of setting options.

Control type and motor type

Control type and motor type can also be selected during commissioning via operator panel (Setup). If the control type is changed, a device reset is executed immediately.

	(Factory settir	ng) Chapter
V/f characteris-	Set P30 to "110 - IM: sensor-less control (SLC)"1.	7.1.2
tic, asynchro-	For P606, select "1 - linear" or "2 - quadratic".	7.7, 8.2
nous motor	P600 P605: Set V/f characteristic.	7.7
	P620: Set start behavior.	7.3.2
	P630: Set stop behavior.	7.3.3
Field-orientated	Set P30 to "410 - IM: sensor-less field-oriented control ² ".	7.1.2
control,	P780, P781: Set start behavior.	7.3.2
asynchronous	P630: Set stop behavior.	7.3.3
motor	Set functions of field-orientated control.	7.9.5
Field-orientated	Set P30 to "610 - PMSM: sensor-less field-oriented control ³ ".	7.1.2
control,	P780, P781: Set start behavior.	7.3.2
synchronous	P630: Set stop behavior.	7.3.2
motor	Set functions of field-oriented control.	7.9.5

Set motor speed (reference frequency)

	(Factory setting)	Chapter
Operator panel	Set P492 to "5 - Keypad motorpoti".	7.5.1
	In "Local" menu, select function "Poti F".	
	Using the arrow keys, set the output frequency (motor speed).	
Analog input	Set P475 to "1 - analog value MFI1A".	7.5.1
	Voltage input at MFI1 (terminal X12.3). The motor speed is proportional to the voltage at MFI1.	
Fixed Frequen-	Set P475 or P492 to "3 - Keypad motorpoti".	7.5.1
cies	In P480 P488, set frequency values.	7.5.1.3
	For P66, P67, P131, select digital inputs.	7.6.6.5
	Select a frequency value via these digital inputs.	
Digital signals	Set P475 or P492 to "4 - Motorpoti via digital inputs".	7.5.1
	For P473, set an acceleration value.	7.5.3.3.1
	For P62 (Motorpoti up) and P63 (Motorpoti down), select digital inputs.	7.6.6.4
	Signals at the chosen digital inputs increase the output frequency (motor speed).	
Communication	The reference frequency is transmitted via a bus system.	Protocol ⁴
interface	Set P475 or P492 to "20 - Fieldbus Reference Value".	

_

¹ For simple applications (e.g. fans, pumps). In the case of control via operator panel: Select "UF".

² Control of an induction machine (asynchronous motor). For higher demands on speed or torque accuracy. In the case of control via operator panel: Select "Foc".

³ Control of a synchronous motor. For higher demands on speed or torque accuracy. In the case of control via operator panel: Select "Synch".

⁴ Instructions on relevant protocol.



Acceleration and deceleration

		(Factory setting)	Chapter
Accelerate	Can be set separa	ately for clockwise and anticlockwise operation.	7.5.1.4
clockwise and Clockwise: Define how fast the output frequency of			
anticlockwise			
	Anticlockwise:	startup, stops, or braking operations.	
	P422 and P423		
S-curve	P430: The drive is	s accelerated and decelerated more uniformly and	7.5.1.4
	load surges are a	voided.	

Reference torque

	(Factory setting)	Chapter
	Set P30 to 410 (asynchronous motor) or 610 (synchronous motor). Set P164 to "6 -On" or to a signal source (e.g. digital input). Via the	7.1.2 7.9.5.2
	signal source the changeover to torque control can be effected.	7.6.6.10
Setting via:		
Operator panel	Set P494 to "5 - Keypad-Motorpot.". In "Local" menu, select function "Poti P". Using the arrow keys, set the reference torque (percentage referred	7.5.3.4.2
	to the nominal motor torque).	
Analog input	Set P476 to "1 - Analog Value MFI1A" (terminal X12.3).	7.5.2
	Set P452 to "1 - Voltage 010 V".	7.6.1
	The reference torque is proportional to the voltage at MFI1.	
Limitation via:		
Limits	P418 Minimum Frequency (only in current impression phase)	7.5.1.1
	P419 Maximum Frequency	
Speed Controller	P767 Frequency Upper Limit	7.9.5.3.1
	P768 Frequency Lower Limit	

Setting inputsand outputs

		(Facto	ry setting)	Chapter
IN1D (X11.4)	Assign signal "71 - IN1D" to a function. (P68)			7.6.6
IN2D (X11.5)	Assign sign	al "72 - IN2D" to a function (P69) or		7.6.6
	set as input	for PWM, repetition frequency or pulse train v	ria P496.	7.6.7
IN4D (X12.1)	Assign sign	al "74 - IN4D" to a function. (P71)		7.6.6
IN5D (X12.2)	Assign sign	al "75 - IN5D" to a function. (P103)		7.6.6
Evaluation logic	P559: Select PNP (active 24 V) or NPN (active: 0 V) for IN1D			7.6.6
	IN5D.			
IN3D/OUT3D	P558: Set a	s input or output.		7.6.4,
(X11.6) Input: Assign signal "73 - IN3D" to a function. (P70))	7.6.6	
	Output:	Select a function via P533.		7.6.5
Evaluation logic	P559: PNP (active 24 V) or NPN (active: 0 V).			



		(Factory setting)	Chapter
MFI1 ¹ (X12.3)	P452: Sele	ct analog (voltage/current) or digital (PNP/NPN).	7.6.1
	Analog:	For setting of reference frequency:	
		Set P475 or P492 to "1 - Analog Value MFI1A".	7.5.1
		Setting range: P418 P419.	7.5.1.1
		For setting of reference percentage ² :	
		Set P476 or P494 to "1 - Analog Value MFI1A".	7.5.2
		Setting range: P518 P519.	7.5.2.1
		Adjustable characteristic if P452 = 6 or 7.	7.6.1.1.2
	Digital:	Assign signal "76 - MFI1D" to a function.	7.6.6
MFI2 ³ (X12.4)	P562: Sele	ct analog (voltage/current) or digital (PNP/NPN).	7.6.2
	Analog:	For setting of reference frequency:	
		Set P475 or P492 to "2 - analog value MFI2A".	7.5.1
		Setting range: P418 P419.	7.5.1.1
		For setting of reference percentage ⁴ :	
		Set P476 or P494 to "2 - analog value MFI2A".	7.5.2
		Setting range: P518 P519.	7.5.2.1
		Adjustable characteristic if P462 = 6 or 7.	7.6.2.1.2
	Digital:	Assign signal "77 - MFI2D" to a function.	7.6.6
		Temperature monitoring with thermo contact:	
		Set P204 to "532 - MFI2D (Hardware)".	7.6.6.9
		Set P570 to 1, 2 or 3 (motor temperature: warning or	7.4.6
		error switch-off).	
MFO1 ⁵ (X13.6)	P550: Sele	ct analog, digital, repetition frequency or pulse train out-	7.6.3
- ()	put.		
	Digital:	Select a function via P554.	7.6.3
	Analog:	Via P553, select a signal for the output. (7 - Abs. Actu-	7.6.3
		al Frequency).	
	Repetition	Via P555, select a frequency value for the output.	7.6.3
	frequency	Set P556 for representation of incremental encoder.	
	Pulse	Scale delivered frequency value via P557.	7.6.3
	train	The value is referred to P419 (maximum frequency).	7.5.1.1
OUT1D (X13.5)	Select a fu	nction via P531. (2 - Run Signal)	7.6.5
OUT2D (X10)		nction via P531. (2 Run signal)	7.6.5
Relay	20.000 4 14		

 $^{^1}$ Multifunction input 1: 2 e.g. for PID controller (P475/P492 = 30 - technology controller") or for the torque controller (P164). 3 Multifunction input 2: 4 e.g. for PID controller (P475/P492 = 30 - technology controller") or for the torque controller (P164). 5 Multifunction output



Data set for parameter values and motor data

-	(Factory setting)	Chapter
	For motor data of different motors or adjustment to different operating points.	
Data set for setup	Select "Setup" menu. Press ENT. The data set selection is displayed. Select the data set where the entered and measured motor data and parameter values are to be saved.	-
	 Select data set 0 if all data sets are to contain the same parameter values. 	
	 Select one of the data sets 1 4 for commissioning of several motors or for different operating points. 	
	Example: For auto set-up (auto-tuning) and motor data, select data set 1.	
	(d5EL 4)	
	SELUP (ENT) Data set	
Change pa- rameter val- ue	Set parameter values in a certain data set: In menu "Para", select the parameter to be set. Keeping ENT pressed, press arrow key. The last digit shows the data set. Release ENT and press again. Now, you can set the parameter value using the arrow buttons.	
	Example: Set nominal motor voltage P370 in data set 2.	
	P 3702 ENT 4005 U P 370 ENT 4005 U Value of P370 in data set 2 Keep pressed Data set	
Switch over data set	Select digital inputs for P70 (73 - IN3D) and P71 (74 - IN4D). Select a data set value via these digital inputs.	7.6.6.11

PID controller (technology controller)

	(Factory setting)	Chapter
	Process control (e.g. pressure, flow rate, temperature).	
Switch on	Set P475 or P492 to "30 - Technology controller".	7.5.1
Reference Value	For P476 or P494, select the source specifying the reference value.	7.5.2
Actual value	For P478, select the input where the actual value is applied. The actual value can also be received via a communication interface.	7.9.3
Control be- haviour	P444 proportional component (amplification), P445 integral component (integral time), P446 differential component (derivative time).	7.9.3
Start	P68 (71 - IN1D) or P69 (72 - IN2D).	7.6.6.2



Electronic gear

		(Factory setting)	Chapter
	Synchroni	zation of drives.	
Reference value for slave drive	etition fre input.	to "20 - repetition frequency single evaluation:" or "21 - Repquency double evaluation". IN2D (X11.5) is the frequency	7.6.7
	Set P497	(typically identical to P556 of the master drive).	7.6.7.2
Switch on	Set P475	or P492 to "40 - electr. gear".	7.5.1
Gear factor	Fixed	Set P689 to "1 - (P. 685 Numerator)/(P. 686 Denominator)". Set P685 and P686.	7.5.4.3.1
	Variable	Set P689 to "2 - (Analog Numerator)/(P. 686 Denominator)" or "3 - (P. 685 Numerator)/(Analog Denominator)". Set the range via P687 and P688.	7.5.4.3.2
		For P476 or P494, select a signal source. Via the signal source the gear factor can be changed during operation.	7.5.2
Master drive	Output M	FO1: Set P550 to "20 - Repetition Frequency MFO1F".	7.6.3
		select a frequency source (1- Actual Frequency). Via P556, itput frequency.	

Positioning

	Chapter
P458 to "1 - Reference positioning". The reference point is detected via	7.3.7
digital input IN1D (terminal X11.4).	
In P460, enter the travel distance in motor revolutions.	

PLC: Logic functions and functions with analog quantities

	Chapter/ instruc-
	tion
Via graphic functional block programming or via entries in a table, analog quantities can be influences and logic links to digital signals can be created.	7.6.6.16, PLC ¹

¹ Application manual "PLC".



Monitoring and protective functions

	(Factory setting)	Chapter
Motor Tem-	Temperature monitoring with thermo contact at MFI2.	
perature	Set P204 to "532 - MFI2D (Hardware)".	7.6.6.9
	Set P562 to "3 - Digital NPN (active: 0 V)" or "4 - Digital PNP (active:	7.6.2
	24 V)".	7.4.6
	Set P570 (0 - off) to 1 (warning only), 2 (immediate error switch-off), or 3 (error switch-off 1 minute delayed).	7.4.0
	Temperature measurement at MFI2, temperature monitoring and dis-	7.4.6
	play with KTY measuring resistor or resistor PT1000.	71110
	Set P617 to a temperature value. If the value is reached, a warning	7.4.6
	message will be effected or the frequency inverter will be switched off	
	(depending on setting of P570).	
	Set P562 to voltage input or current input.	7.6.2
	PTC Set P570 to 11 (warning), 12 (immediate error switch-off), or 13 (error switch-off 1 minute delayed).	7.4.6
	KTY Set P570 to 21 (warning), 22 (immediate error switch-off),	7.4.6
	or 23 (error switch-off 1 minute delayed).	
	PT1000 Set P570 to 31 (warning), 32 (immediate error switch-off),	7.4.6
	or 33 (error switch-off 1 minute delayed).	
	P226 shows the measured motor temperature.	9.2
	PTC resistor (motor PTC) does not enable temperature measurement.	
	P617 is inoperable for this evaluation. The evaluation is dependent on	
	the used resistor.	
Motor circuit breaker	The motor ratings are monitored. If the motor is overloaded an error switch-off or a warning message will be effected.	7.10.6
	Set P571 for single motor operation or multiple motor operation and	7.10.6
	choose if an error switch-off or a warning message is to be effected.	
Mains failure	Short mains failures are bridged.	7.9.2
	Via P670 select mains support. Set P671 and P672. If the voltage	
	drops below the value set in P671, the DC link voltage is controlled to	
DC Link	the value set in P672.	702
DC –Link	Via P670, set U _d limitation. Set P680. The DC link voltage is limited to	7.9.2
Voltage	the value of P680 if it increases in generator operation mode or during braking operations.	
Phase failure	The frequency inverter is shut down if a mains or motor phase fails.	7.4.7
	Via P576, select error switch-off or shutdown.	

Control mechanical brake

		Chapter
Activation	For addressing a brake via a digital output: Select "41 - Brake release"	7.6.5.5
	for one of the parameters 531 (OUT1D), 532 (OUT2D relay), 533	
	(OUT3D) or 554 (MFO1).	
Delayed start	Set P625. When the brake release time has elapsed the drive acceler-	7.3.2
-	ates. This protects the brake against damage.	
Shutdown	Via P630, select the stopping behavior of the drive.	7.3.3



Energy saving

		Chapter
Switch off display	Set a time in P1510. If no key is pressed on the operator panel during this time, the display will be switched off.	8
Switch off functions	Via P1511, select which functions are to be switched off: Operator panel, digital inputs and outputs, communication or fan. The frequency inverter switches the functions off thus reducing power consumption if enable is switched off via digital inputs STOA and STOB.	8
Energy sav- ing function	For P30, "110 - IM sensor-less control (SLC)" or "410 - IM: sensor-less field-oriented control" must be selected. Via P1550, select if the possible energy savings are to be determined automatically or specified via an entered value (P1551). Via P1551, select which digital input or logic signal is to be used for starting the energy saving function.	8.1
Quadratic V/f characteristic	For load behavior with torque increasing quadratically to speed (e.g. fan). For control according to V/f characteristic. For P30, "110 - IM sensor-less control (SLC)" must be selected. Via P606, set the characteristic to "2 - quadratic". Set up the V/f characteristic using parameters 600 604.	8.2
Other	E.g. temperature-controlled fans, automatic switch frequency change- over, energy-optimized braking.	8.4

Service

				Chapter
Service inter-	The time remaining until service of DC link (F	P1530) and fan (P:	1531)	10.3
val	can be displayed.			
	If the time is expired, a message in P1533	DC-Link:	P1534	10.3.1
	or a warning will be output. The reaction	Fan:	P1535	10.3.2
	can be set up.			

Test functions

			Chapter
	_	rrors and defects at the frequency inverter, sensors, the electrical connections.	
Earth fault/ short circuit test	Test for eart	n fault or short-circuit with DC link potential.	7.2.3.1
Load test	Test of IGBT	s, the load (e.g. for short circuit), current measurement en cables.	7.2.3.2
Start test	With operator panel	Switch on enable at inputs STOA and STOB. Select menu item "Test" in "Local" menu. Select test 1. Comply with the instructions in chapter 7.2.3.1 "Earth fault and short circuit test (Test 1)". Then, select test 2.	7.2.3.3
	With PC software VPlus	Via P1540, select "11 - Start Test 1" or "12 - Start Test 2".	7.2.3.4
Automatic test	Via P1542, se switch-off.	elect which test is to be started each time after an error	7.2.3.5
			Kapitel
Test of fan	The function	of the fans is tested	•
Start test	With opera- tor panel	Switch on enable at inputs STOA and STOB. Select menu item "Test" in "Local" menu. Select Test 3. Press ENT. The fans must rotate. Press ESC.	7.2.3.6



Communication

	(Factory setting)	Instruc- tions
CAN System bus	Interface at terminals X12.5 and X12.6.	System bus
CANopen®	 Protocol via terminals X12.5 and X12.6 or Interface at optional communication module CM-CAN. 	CANopen
	For parameter <i>CAN Interface (CM-CAN/X12)</i> 276 , select the protocol for terminals X12.5/X12.6 or for the communication module. You can choose either CAN system bus or CANopen®.	
Modbus (RTU/ASCII)	Interface at connection X21 (RJ45 socket) oroptional communication module CM-232 or CM-485.	Modbus
VABus	Interface at connection X21 (RJ45 socket) oroptional communication module CM-232 or CM-485.	VABus
	Via parameter <i>Protocol</i> (<i>CM/X21</i>) 395 , select the protocol for terminal X21 or for the communication module. You can choose either Modbus or VABus. If Modbus is selected, choose either RTU or ASCII via parameter <i>Modbus Mode</i> 1503 .	
Profibus-DP	Optional communication module CM-PDPV1.	PDP-V1
TCP/IP	Optional communication module with Ethernet communication TCP/IP	Ethernet module

6.6 Error Acknowledgment via keypad

If a fault occurs, a device reset can be executed via the STOP key. A reset via the STOP key can only be executed, if Parameter *Local/Remote* **412** allows the control via keypad (see chapter 7.3.1 "Control").

Further possibilities to execute a fault reset are described in chapter 7.6.6.8 "Error Acknowledgment".



6.7 Applications


The parameters required for typical applications are listed. Selecting an application makes commissioning easier. Depending on the application, additional settings may be required.

Note

The PC software VPlus provides application masks for easy commissioning of applications.

6.7.1 Pump


	Parameters	Recommenced setting
30	Configuration	110 IM: sensorless control (V/f characteristic)
420	Acceleration (clockwise)	10 Hz/s
421	Deceleration (clockwise)	-0.01 Hz
492	Reference frequency source 2	0 - Zero
493	Operation mode (reference frequency source)	1 - (+/- reference)
418	Minimum frequency	10 Hz
419	Maximum frequency	53 Hz
420	Acceleration (clockwise)	10 Hz/s
447	1st Blocking frequency	0 Hz
449	Frequency Hysteresis	0 Hz
475	Reference frequency source 1	1 - Analog Value MFI1A
606	Type V/f characteristic	2 - quadratic
630	Operation mode (P68&P69=1 P68&P69=0) (stopping behavior)	11 - (Stop, Off Stop, Off)
651	Operation mode (auto start)	0 - Off
1550	Operation mode energy saving function	2 - Automatic
1552	Energy saving function on	163 - Reference Frequency reached
68	Start Clockwise	71 - IN1D
69	Start Anticlockwise	7 - Off
531	Operation mode OUT1D (X13.5) (digital output)	2 - Run signal
532	Operation mode OUT2D (X10/relay)	103 - Inv. error signal





6.7.2 Fan

	Parameters	Recommenced setting
30	Configuration	110 IM: sensorless control (V/f characteristic)
68	Start Clockwise	71 - IN1D
421	Deceleration (clockwise)	-0.01 Hz
492	Reference frequency source 2	0 - Zero
493	Operation mode (reference frequency source)	1 - (+/- reference)
418	Minimum frequency	10 Hz
419	Maximum frequency	53 Hz
420	Acceleration (clockwise)	50 Hz/s
447	1st Blocking frequency	0 Hz
475	Reference frequency source 1	1 - Analog Value MFI1A
606	Type V/f characteristic	2 - quadratic
630	Operation mode (P68&P69=1 P68&P69=0) (stopping behavior)	0 - (Coast to Stop Coast to Stop)
645	Operation mode Flying Start	2 - On, according to reference
651	Operation mode (auto start)	0 - Off
1550	Operation mode energy saving function	2 - Automatic
1552	Energy saving function on	163 - Reference Frequency reached
68	Start Clockwise	71 - IN1D
69	Start Anticlockwise	7 - Off
531	Operation mode OUT1D (X13.5) (digital output)	2 - Run signal
532	Operation mode OUT2D (X10/relay)	103 - Inv. error signal






6.7.3 Fan or pump with closed control loop

Decembers Decembers destring		
30	Parameters Configuration	Recommenced setting 110 IM: sensorless control (V/f characteristic)
	Fixed frequency 1	0 Hz
	Minimum frequency	10 Hz
	Maximum frequency	53 Hz
	Acceleration (clockwise)	5 Hz/s
	Deceleration (clockwise)	-0.01 Hz
	Operation mode actual value failure	1 - active, fixed frequency 1
	Max. I component	50 Hz
	Maximum frequency	53 Hz
	Minimum frequency	0 Hz
	Amplification	1
	Integral time	1000 ms
	Derivative time	0 ms
	1st Blocking frequency	0 Hz
	Frequency Hysteresis	0 Hz
	Reference frequency source 1	30 - Technology Controller (PID controller)
	Reference percentage source 1	2 - Analog Value MFI2A
	Actual percentage source	1 - Analog Value MFI1A
480	Fixed frequency 1 (in case of actual value failure)	0 Hz
492		0 - zero
493	Operation mode (reference frequency source)	1 - (+/- reference)
494	Reference percentage source 2	0 - zero
495	Operation mode (reference percentage source)	2 - positive only
606	Type V/f characteristic	2 - quadratic
618	Backlash	0%
630	Operation mode (P68&P69=1 P68&P69=0) (stopping behavior)	0 - (Coast to Stop Coast to Stop)
651	Operation mode (auto start)	0 - Off
	Operation mode energy saving function	Automatic
	Energy saving function on	163 - Reference Frequency reached
68	Start Clockwise	71 - IN1D
	Start Anticlockwise	72 - IN2D
531	Operation mode OUT1D (X13.5) (digital output)	
532	Operation mode OUT2D (X10/relay)	103 - Inv. error signal








6.7.4 Fan for heating, ventilation, air conditioning system


	Parameters	Recommenced setting
30	Configuration	110 IM: sensorless control (V/f characteristic)
418	Minimum frequency	10 Hz
	Maximum frequency	50 Hz
420	Acceleration (clockwise)	10 Hz/s
421	Deceleration (clockwise)	-0.01 Hz
447	1st Blocking frequency	0 Hz
	Frequency Hysteresis	0 Hz
475	Reference frequency source 1	1 - analog value MFI1A
492	Reference frequency source 2	0 - zero
493	Operation mode (reference frequency source)	1 - (+/- reference)
558	Operation mode terminal X11.6 (digital input/output)	1 - Output OUT3D
573	Operation mode (intelligent current limits)	11 - Ixt + Tc (limitation to overload and max. heat sink temperature)
606	Type V/f characteristic	2 - quadratic
630	Operation mode (P68&P69=1 P68&P69=0) (stopping behavior)	0 - (Coast to Stop Coast to Stop)
645	Operation Mode Flying Start	2 - On, according to reference
651	Operation mode (auto start)	1 - On
1550	Operation mode energy saving function	Automatic
1552	Energy saving function on	163 - Reference Frequency reached
68	Start Clockwise	71 - IN1D
69	Start Anticlockwise	7 - Off
531	Operation mode OUT1D (X13.5) (digital output)	2 - Run signal
532	Operation mode OUT2D (X10/relay)	103 - Inv. error signal
533	Operation mode OUT3D (X11.6) (digital input/output)	25 - Warning Mask





6.7.5 Conveying plant


	Parameters	Recommenced setting
30	Configuration	110 IM: sensorless control (V/f characteristic)
418	Minimum frequency	10 Hz
419	Maximum frequency	53 Hz
420	Acceleration (clockwise)	5 Hz/s
421	Deceleration (clockwise)	5 Hz/s
447	1st Blocking frequency	0 Hz
449	Frequency Hysteresis	0 Hz
475	Reference frequency source 1	1 - Analog Value MFI1A
492	Reference frequency source 2	0 - zero
493	Operation mode (reference frequency source)	1 - (+/- reference)
630	Operation mode (P68&P69=1 P68&P69=0) (stopping behavior)	0 - (Coast to Stop Coast to Stop)
645	Operation Mode Flying Start	2 - On, according to reference
68	Start Clockwise	71 - IN1D
69	Start Anticlockwise	7 - Off
531	Operation mode OUT1D (X13.5) (digital output)	2 - Run signal
532	Operation mode OUT2D (X10/relay)	103 - Inv. error signal





6.7.6 Compressor


	Parameters	Recommenced setting
30	Configuration	110 IM: sensorless control (V/f characteristic)
418	Minimum frequency	10 Hz
419	Maximum frequency	50 Hz
420	Acceleration (clockwise)	12.5 Hz/s
421	Deceleration (clockwise)	-0.01 Hz
447	1st Blocking frequency	0 Hz
449	Frequency Hysteresis	0 Hz
475	Reference frequency source 1	1 - Analog Value MFI1A
492	Reference frequency source 2	0 - zero
493	Operation mode (reference frequency source)	1 - (+/- reference)
630	Operation mode (P68&P69=1 P68&P69=0) (stopping behavior)	0 - (Coast to Stop Coast to Stop)
670	Operation mode (voltage controller)	3 - Ud limitation and mains support active (Ud: DC link voltage)
68	Start Clockwise	71 - IN1D
69	Start Anticlockwise	7 - Off
531	Operation mode OUT1D (X13.5) (digital output)	2 - Run signal
532	Operation mode OUT2D (X10/relay)	103 - Inv. error signal





6.7.7 Travel applications

	Parameters	Recommenced setting
30	Configuration	110 IM: sensorless control (V/f characteristic)
418	Minimum frequency	10 Hz
419	Maximum frequency	50 Hz
420	Acceleration (clockwise)	15 Hz/s
421	Deceleration (clockwise)	15 Hz/s
475	Reference frequency source 1	1 - Analog Value MFI1A
480	Fixed frequency 1	10 Hz
481	Fixed frequency 2	25 Hz
482	Fixed frequency 3	40 Hz
483	Fixed frequency 4	50 Hz
492	Reference frequency source 2	3 - Fixed frequency
493	Operation mode (reference frequency source)	1 - (+/- reference)
558	Operation mode terminal X11.6 (digital input/output)	0 - Input IN3D
630	Operation mode (P68&P69=1 P68&P69=0) (stopping behavior)	11 - (Stop, Off Stop, Off)
68	Start Clockwise	71 - IN1D
69	Start Anticlockwise	7 - Off
66	Fixed frequency Change-Over 1	73 - IN3D
67	Fixed frequency Change-Over 2	74 - IN4D
531	Operation mode OUT1D (X13.5) (digital output)	2 - Run signal
532	Operation mode OUT2D (X10/relay)	103 - Inv. error signal





6.7.8 Torque control

The Torque control can be used in applications where a torque should be used as reference value instead of a frequency.

Via parameter n/T Control Change-Over **164** a jerk less switch over from Speed Control to Torque Control is possible.


100 % Torque refer to the calculated Torque from *Rated Mech. Power* **376** (Motor power) and *Rated Speed* **372** (Motor nominal speed).

The Torque control is only available in configurations 410 FOC and 610 SYNC.

	Parameters	Recommenced setting
164	n-/T-Control Change-Over	74 - IN4D
	Minimum frequency	0 Hz ²⁾
	Maximum frequency	53 Hz
	Acceleration (clockwise)	5 Hz/s
	Deceleration (clockwise)	-0.01 Hz ¹⁾
	1st Blocking frequency	0 Hz
	Frequency Hysteresis	0 Hz
	Reference frequency source 1	1 - Analog Value MFI1A
	Reference percentage source 1	2 - Analog Value MFI2A
	Gradient percentage ramp	100%/s
	Reference frequency source 2	0 – zero
493	Operation mode (reference frequency source)	1 - (+/- reference)
494	Reference percentage source 2	0 – zero
495	Operation mode (reference percentage source)	2 - positive only
518	Minimum reference percentage	0%
519	Maximum reference percentage	100%
520	Fixed percentage 1	0%
521	Fixed percentage 2	20%
562	Operation Mode MFI2 (Multifunction input 2)	1 - Voltage 010 V
630	Operation mode (P68&P69=1 P68&P69=0) (stopping behavior)	0 - (Coast to Stop Coast to Stop)
651	Operation mode (auto start)	0 – Off
767	Frequency Upper limit	50 Hz
768	Frequency Lower limit	-50 Hz
66	Fixed frequency Change-Over 1	7 – Off
	Fixed frequency Change-Over 2	7 – Off
	Start Clockwise	71 - IN1D
	Start Anticlockwise	7 – Off
	Data set Change-Over 1	7 – Off
	Data set Change-Over 2	7 – Off
	Fixed percent Change-Over 1	7 – Off
	Fixed percent Change-Over 2	7 – Off
531	Operation mode OUT1D (X13.5) (digital output)	2 - Run signal
532	Operation mode OUT2D (X10/relay)	103 - Inv. error signal

- 1) The setting -0.01 Hz effects the usage of the same ramp like stated in Parameters *Acceleration Clockwise* **420**.
- 1) Bonfiglioli Vectron recommends to set *Minimum frequency* **418** > *Frequency limit* **624**. Comply with the notes in chapter 7.9.5.2 "Torque controller".





6.8 Set-up via the Communication Interface

796 SETUP Selection

Parameter-setting and commissioning of the frequency inverter via one of the communication interfaces include the plausibility check and the parameter identification functions. The parameter selection during the guided commissioning procedure includes the basic parameters. These are based on standard applications and support commissioning.

⚠ CAUTION



Parameter settings may only be changed by qualified staff. Before starting the commissioning process, read the documentation and comply with the safety instructions.

At the beginning of the auto set-up of a synchronous motor, the motor shaft will be aligned when enable is switched on. It must be ensured that, personal or material damage is excluded.

For parameter *SETUP Selection* **796**, choose a function.

The function will be executed as soon as enable is switched on at digital inputs STOA and STOB.

The functions are also carried out automatically one after the other during the guided commissioning procedure.

SETUP Selection 796	Function
0 - Clear Status	The auto set-up routine does not perform a function.
1 - Continue	The warning message is acknowledged and the auto set-up routine is continued.
2 - Abort	The auto set-up routine is stopped and a RESET of the frequency inverter is performed.
10 - Complete Setup, DS0	The auto set-up routine is performed in data set 0 and the parameter values are stored in all of the four data sets identically (recommended).
11 - Complete Setup, DS1	The parameter values of the auto set-up are stored in data set 1.
12 - Complete Setup, DS2	The parameter values of the auto set-up are stored in data set 2.
13 - Complete Setup, DS3	The parameter values of the auto set-up are stored in data set 3.
14 - Complete Setup, DS4	The parameter values of the auto set-up are stored in data set 4.
20 - PlausCheck Machine Data, DS0	The auto set-up routine checks the rated motor parameters in the four data sets (plausibility check).



SETUP Selection 796	Function
21 - PlausCheck Machine Data, DS1	The rated motor parameters in data set 1 are checked for plausibility.
22 - PlausCheck Machine Data, DS2	The rated motor parameters in data set 2 are checked for plausibility.
23 - PlausCheck Machine Data, DS3	The rated motor parameters in data set 3 are checked for plausibility.
24 - PlausCheck Machine Data, DS4	The rated motor parameters in data set 4 are checked for plausibility.
30 - Calculation and Para- Ident., DS0	The auto set-up routine determines extended motor data via the parameter identification feature, calculates depend-ent parameters and stores the parameter values in all of the four data sets identically.
31 - Calculation and Para- Ident., DS1	Further motor data are measured, dependent pa-rameters are calculated and the parameter values are saved in data set 1
32 - Calculation and Para- Ident., DS2	Further motor data are measured, dependent pa-rameters are calculated and the parameter values are saved in data set 2
33 - Calculation and Para- Ident., DS3	Further motor data are measured, dependent pa-rameters are calculated and the parameter values are saved in data set 3
34 - Calculation and Para- Ident., DS4	Further motor data are measured, dependent pa-rameters are calculated and the parameter values are saved in data set 4
40 - Para-Ident. Machine Data only, DS0	Extended motor data are measured and saved identically in all data sets. Other parameter values already set are maintained.
41 - Para-Ident. Machine Data only, DS1	Extended motor data are measured and saved data set 1. Other parameter values already set are maintained.
42 - Para-Ident. Machine Data only, DS2	Extended motor data are measured and saved data set 2. Other parameter values already set are maintained.
43 - Para-Ident. Machine Data only, DS3	Extended motor data are measured and saved data set 3.
44 - Para-Ident. Machine Data only, DS4	Extended motor data are measured and saved data set 4. Other parameter values already set are maintained.

797 Setup Status

The individual steps of the auto set-up routine can be monitored and checked via parameter *SETUP Status* **797**. The setup routine via the communication interface continuously updates the status parameter which can be read out via the interface.

Status messages				
Message	Meaning			
OK	Auto set-up routine has been carried out.			
PC Phase 1	The plausibility check of the motor data is active.			
PC Phase 2	The calculation of dependent parameters is active.			
STO	The parameter identification demands enable on digital input STOA and STOB.			
Parameter identifica- tion	The rated motor values are checked by the parameter identification feature.			
Setup already active	The setup routine via the operator panel is being carried out.			
No Release	No enable signal. The parameter identification demands enable on digital input STOA and STOB.			
Error	Error during the auto set-up routine.			
Warning Phase Asym- metry	The parameter identification feature diagnosed an unbalance during the measurements in the three motor phases.			
Setup not carried out	The setup is not carried out until now.			

If a warning message is output or an error occurs during Setup, refer to chapter 6.2.5 "Warnings during commissioning".



7 Parameter descriptions

This chapter contains the parameter descriptions. Please note, that some parameters are described more in detail in additional documentations. These are the parameters of the communication interfaces and the PLC function.

7.1 Inverter Data

Parameters can be set via the operator panel or the optional PC software VPlus (Version 6.0.1 or higher).

O Serial Number

The *Serial Number* **0** is entered on the type plate during the production of the frequency inverter. Information on the device type and the production data with 8-digit number are displayed. In addition, the serial number is printed on the rating plate.

Serial Number 0:

For example: 9120801234 (serial no.)

1 Optional modules

Modular extension of the hardware is possible via the plug-in slot. The communication module detected by the frequency inverter (Parameter *Optional module* 1) and the corresponding designations are displayed on the operator panel and in the optional control software VPlus after initialization. For the parameters which can be set for the communication module, refer to the corresponding operating instructions.

For example: CM-485

12 Inverter Software Version

The firmware stored in the frequency inverter defines the available parameters and functions of the software. The software version is indicated in parameter *Inverter Software Version* **12**. In addition, the 9-digit software key is printed on the rating plate of the frequency inverter.

For example: Inverter Software Version 12: 6.1.4

On the rating plate: Version: 6.1.4; Software: 152 800 011

15 Copyright

(c) 2012 BONFIGLIOLI VECTRON

16 Power Module Software Version

The power module of the frequency inverter features its own processor. The firmware of the power module is output via parameter *Power Module Software Version* **16**.

29 User Name

The *User Name* **29** can be entered via the optional control software VPlus. The name can be made up of 32 alphanumerical characters.

7.1.1 Control level

28 Control level

The *Control level* **28** defines the scope of the functions to be parameterized. These operating instructions describe the parameters on the third control level. These parameters should only be set by qualified users.

	Parameters Setting			
No.	Identification	Min.	Max.	Fact. sett.
28	Control level	1	3	1



Control level 28	Selection on operator panel
1 - Parameters for quick commissioning.	Easy
2 - The parameters most used can be set.	Standard
3 - All parameters can be set.	Professional

7.1.2 Configuration

30 Configuration

The *Configuration* **30** determines the control behavior with which the electric motor is controlled. The operating instructions describe the following configurations and the relevant parameters in the third *Control level* **28** (adjustment of parameter *Control level* **28** to value 3).

Configuration 110, IM1: sensor-less control

Configuration 110 contains the functions for variable-speed control of an asynchronous motor in a wide range of standard applications (e.g. for control of fans and pumps). The motor speed is set according to the V/f characteristic in accordance with the voltage/frequency ratio.

Configuration 410, IM: sensor-less field-orientated control (DMC)²

Configuration 410 contains the functions for sensor-less, field-orientated control of an asynchronous motor. The current motor speed is determined from the present cur-rents and voltages in combination with the motor parameters. Separate control of torque and flux-forming current enables high drive dynamism at a high load moment. In this configuration, parallel connection of several 3-phase motors is possible to a limited extent only.

Configuration 610, PMSM³: sensor-less field-orientated control (DMC)

Configuration 610 contains the functions for sensor-less, field-orientated control of a synchronous motor. The current motor speed is determined from the present cur-rents and voltages in combination with the motor parameters. Separate control of torque and flux-forming current enables high drive dynamism at a high load moment. This configuration is intended for the connection of a single motor. Parallel connection of several synchronous motors is not intended and possible to a very limited extent only.

		Configuration		
		Asynchronous motor Synchron motor		Synchronous motor
		V/f character- istic	Field-orient	ated control
Function	Chapter	110	410	610
Speed control	7.9.5.3	x	X	X
Torque control	7.9.5.2		Х	Х
Switch-over speed/torque control	7.6.6.10		Х	Х
Dynamic voltage pre-control	7.8.1	х		
Intelligent current limits	7.9.1	x	X	x
Voltage controller	7.9.2	х	Х	Х
PID controller (technology controller)	7.9.3	Х	Х	Х
Slip compensation	7.9.4.1	х		
Current limit value controller	7.9.4.2	х		
Current controller	7.9.5.1	х	Х	Х
Acceleration pre-control	7.9.5.4		Х	Х
Field controller	7.9.5.5		X	X

¹ Asynchronous motor

² Direct moment control

³ Permanently excited synchronous motor.



		Configuration		
		Asynchron	ous motor	Synchronous motor
		V/f character- istic	Field-orient	tated control
Function	Chapter	110	410	610
Modulation controller	7.9.5.6		X	X
Starting behavior	7.3.2	x	X	X
Starting current impression	7.3.2	x	X	X
Flux-formation	7.3.2	x	X	X
Stopping behavior	7.3.3	X	X	X
Direct current brake	7.3.6	x		
Auto start	7.3.4	х	X	х
Flying Start	7.3.5	х	x	х
Energy saving	8	х	Х	х
Energy saving function (Flux reduction)	8.1	х	X	
Reference point positioning	7.3.7	x	X	X
PLC function	7.6.6.16	x	X	X
Frequency reference channel	7.5.1	х	X	х
Reference percentage channel	7.5.1.3	x	X	x
Fixed frequencies	7.5.1.3	х	X	х
Fixed percentages	7.5.2	х	X	х
Blocking frequencies	7.5.1.5	х	Х	х
Input PWM/repetition frequency/pulse train	7.5.4	x	Х	х
Brake chopper	7.10.4	x	X	x
Motor circuit breaker	7.10.6	х	Х	х
V-belt monitoring	7.10.7	х	Х	х
Motor chopper	7.10.5		Х	х
Real-time tuning	7.9.6		Х	х

7.1.3 Set password

27 Set password

As a protection against unauthorized access, the parameter *Set password* **27** can be set such that anyone who wants to change parameters must enter this password before. A change of parameter is only possible if the password is entered correctly. If the *Set password* **27** parameter is set to zero, no password is required for access to the parameters. The previous password is deleted.

	Parameters	Setting		
No.	Identification	Min.	Max.	Fact. sett.
27	Set password	0	999	0

If a password is set the password entry is necessary for

- modification of parameter values
- start of Setup
- upload of parameter values from memory card to frequency inverter

The correct entered password unlocks all functions for 10 minutes. After 10 minutes the password protection is switched on again automatically.

The modification of a password is possible in control level 3 (parameter *Control level* **28**).



The control facilities of the operator panel are not locked. For the restriction of control facilities refer to chapter 7.5.1 "Reference frequency channel", 7.5.2 "Reference percentage channel" and 7.3.1 "Control".

7.1.4 Programming

34 Program(ming)

The parameter Program(ming) 34 enables acknowledgment of a fault message and resetting to the factory settings.

Program(ming) 34	Function
123 - Reset	A hardware reset is done (Behavior like Mains-Off/Mains-On).
4444 - Default	The parameters of the selected configuration, except for a few exceptions, are reset to the default settings. The display of the control unit reads "dEFLt".



Parameters $Control\ level\ 28$ and $Configuration\ 30$ are not changed during resetting to factory settings $(Program(ing)\ 34 = 4444)$.



With Keypad Parameter default settings:

Select P34 in Menu Para. Press both arrow keys to jump to value 4443. Set P34 to 4444 and confirm with ENT. This sets all parameters to the default values.

7.2 Machine data

The input of the machine data is the foundation for the functionality of the control functions and methods. You will have to enter the motor ratings during the guided commissioning (setup).

7.2.1 Rated motor parameters

370 Rated voltage

371 Rated current

372 Rated speed

373 No. of pole pairs

374 Rated cosine Phi

375 Rated frequency

376 Rated mechanical power

Parameterize the rated motor data according to the rating plate of the motor of the motor data sheet. The default settings of the machine parameters are based on the nominal data of the frequency inverter and a four-pole asynchronous motor. The machine data required for the control functions and methods are checked for plausibility and calculated in the course of the commissioning.



Parameter *Rated cosine Phi* **374** is not available in configuration 610 (synchronous motors).

	Parameters	Setting		
No.	Description	Min.	Max.	Fact. sett.
370	Rated voltage	$0.17 \cdot U_{FIN}$	2·U _{FIN}	U_{FIN}
371	Rated current	$0.01{\cdot}I_{\text{FIN}}$	$10\cdot o_c \cdot I_{FIN}$	${ m I}_{\sf FIN}$
372	Rated speed	30 min ⁻¹	60000 min ⁻¹	n_N
373	No. of pole pairs	1	24	2
374	Rated cosine Phi	0.01	1.00	$cos(\phi)_N$
375	Rated frequency	10.00 Hz	1000.00 Hz	50.00 Hz
376	Rated mechanical power	$0.01 \cdot P_{FIN}$	10-P _{FIN}	P_{FIN}



U_{FIN} = Nominal Frequency inverter voltage, usually 400 V or 230 V

 I_{FIN} = Nominal Frequency inverter output current

P_{FIN} = Nominal Frequency inverter power

o_c: Overload capacity of frequency inverter.

In the case of asynchronous machines, the speed can be increased at a constant torque if the motor winding can be switched over from star to delta connection. The changeover leads to a modification of the dependent rated figures by a square root of three.

NOTE

The rated data of the motor are to be entered according to the specifications on the rating plate for the motor connection type used (star or delta connection). If the data entered deviate from the rating plate, the parameters will not be identified correctly. Parameterize the rated data according to the rating plate of the motor for the wiring of the motor winding. Consider the increased rated current of the connected asynchronous motor.

Input via operator panel

- The motor ratings must be entered when the "Setup" menu is selected on the operator panel.
- The motor ratings can be entered in menu "Para" for parameters 370 ... 376.

7.2.2 Further motor parameters

In particular the field-orientated control requires the determination of further data which cannot be read off the rating plate of the asynchronous or synchronous motor for the precise calculation of the machine model. In the course of the guided commissioning (setup), the parameter identification is carried out to measure the further motor parameters.

The values of the following parameters will not be measured by the frequency inverter during the guided commissioning (setup). Changing the measured values is normally not required.

Configuration $30 = 110$	Configuration $30 = 410$
Asynchronous motor	Asynchronous motor
Stator resistance 377	Rated voltage correction factor 368
Leakage coefficient 378	Stator resistance 377
	Leakage coefficient 378
	Rated magnetising current 716
	Rated slip correction factor 718

<i>Configuration</i> 30 = 610
Synchronous motor
Stator resistance 1190
Voltage constant 383, if no input before
Stator inductance 384

377 Stator resistance (asynchronous motor) 1190 Stator resistance (synchronous motor)

The resistance of the stator winding is measured during the guided commissioning. The measured value is saved as a phase value in parameter *Stator resistance* **377** and is 3 times smaller than the winding resistance in delta connection.

By default, the stator resistance of a standard motor is entered to match the reference output of the frequency inverter.



Parameters		Setting		
No. Description		Min.	Max.	Fact. sett.
377	Stator resistance 1)	0 mΩ	65535 mΩ	R _{sN}
1190	Stator resistance 2)	0.001 Ω	100.000 Ω	$10.000~\Omega$

¹⁾ In settings 110 and 410 of parameter Configuration 30.

Stator resistance asynchronous motor:

For sensorless control according to V/f characteristic (setting 110 for *Configuration* **30**): The stator resistance of an asynchronous motor can be optimized while the machine is in no-load operation. At the stationary operating point, the torque-forming current *Isq* **216** and/or the estimated *Active current* **214** should be zero. Due to the temperature-dependent of the stator resistance, the adjustment should be done at a winding temperature which is also reached during normal operation.

A correct measurement will optimize the control functions.

For sensorless field-orientated control according to V/f characteristic (setting 410 for *Configuration* **30**): The stator resistance value determined during the guided commissioning procedure is suitable for most applications and does not have to be optimized.

Stator resistance synchronous motor:

The stator resistance value of a synchronous motor is entered during commissioning. The stator resistance is needed particular of operation at low speeds and should be available and entered as exactly as possible for this reason. The *Stator resistance* **1190** refers to the quantity between two motor phases and can typically be taken from the data sheet of the motor.

The stator resistance value determined during the guided commissioning procedure is suitable for most applications and does not have to be optimized.

378 Leakage Coefficient (asynchronous motor)

The leakage coefficient of the motor defines the ratio of the leakage inductivity to the main inductivity. The torque and flux-forming current components are thus coupled via the leakage coefficient. Optimization of the leakage coefficient within the field-orientated control systems demands acceleration to various operating points of the drive. Unlike the torque-forming current *Isq* **216**, the flow-forming current *Isd* **215** should be largely independent of the load torque. The flow-forming current component is inversely proportional to the leakage coefficient. If the leakage coefficient is increased, the torque-forming current increases and the flux-forming component drops. The adjustment should result in a relatively constant actual current *Isd* **215**, matching the set *Rated magnetizing current* **716**, regardless of the load on the drive.

The sensor-less control system uses the parameter *Leakage Coefficient* **378** in order to optimize the synchronization to one drive.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
378	Leakage Coefficient	1.0%	20.0%	7.0%

716 Rated magnetising current (asynchronous motor, field-orientated control)

The *Rated magnetising current* **716** is a measure for the current in the motor. The motor voltage will build up accordingly in no-load operation (depending on speed). The guided commissioning determines this value at approx. 30% to 50% of the *Rated current* **371**. This current can be compared to the field current of an externally excited direct current machine.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
716	Rated magnetising current	$0.01 \cdot I_{\text{FIN}}$	$o_c{\cdot}I_{\text{FIN}}$	$0.3 \cdot I_{FIN}$

I_{FIN}: Nominal value of frequency inverter o_c: Overload capacity of frequency inverter

²⁾ In setting 610 of parameter *Configuration* **30**.



The rated magnetizing current determined during the guided commissioning procedure is set to an optimized value and does not have to be adjusted.

718 Rated slip correction factor (asynchronous motor, field-orientated control)

The rotor time constant results from the inductivity of the rotor circuit and the rotor resistance. Due to the temperature-dependence of the rotor resistance and the satura-tion effects of the iron, the rotor time constant is also dependent on temperature and current. The load behavior and thus the rated slip depend on the rotor time constant. The guided commissioning determines the machine data during the parameter identification and sets the parameter *Rated slip correction factor* **718** accordingly. The value calculated by the rotor time constants can be read out via the actual value *Current rotor time constant* **227**. Parameter identification (during guided commissioning "Setup") should be done while the motor is cold.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
718	Rated slip correction factor	0.01%	300.00%	100.00%

383 Voltage constant (synchronous motor)

In Configuration 610 (parameter *Configuration* **30**) for control of synchronous motors, the control behavior should be optimized by setting parameter *Voltage constant* **383**.

The auto-setup during the guided commissioning (setup) identifies the voltage constant of the synchronous motor. If a value > 0 mV was entered before manually, the voltage constant will not be determined during auto-setup. The entered value is maintained.

For the voltage constant, refer to the motor data sheet. In the motor data sheet, the value may be indicated in $\frac{V}{1000 \frac{U}{min}}$. This value can be taken over for Parameter *Voltage constant* 383.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
383	Voltage constant	0.0 mVmin	6500.0 mVmin	0.0 mVmin

If the guided commissioning (Setup) is not carried out, the auto-setup should be carried out via parameter *SETUP selection* **796** in order to improve the drive behavior, particularly for small speeds. Select one of the settings 10 ... 14 for *SETUP selection* **796**.

During the guided commissioning (via keypad and VPlus) for Bonfiglioli motors the voltage constant is pre-allocated.

For Non-Bonfiglioli motors the voltage constant should be entered if it is known. If the voltage constant is unknown, set *Voltage constant* **383** to 0 mV before the commissioning to ensure the automatic calculation and measurement.

The voltage constant should be optimized after the guided commissioning procedure: In no-load operation, set 50% of the rated speed. Change the voltage constant in small steps until parameter Rotor flux **225** displays the value 101% ($\pm 0.5\%$).



In the case of motors with a very high number of pole pairs (e.g. higher than 20), it is possible that the maximum setting range of the parameter is not sufficient. In this case, divide the voltage constant by 10 and enter the value. The division by 10 is considered internally.

384 Stator inductance (synchronous motor)

In configuration 610 for the control of synchronous machines, the control behavior can be improved for high dynamic requirements by setting the parameter *Stator inductance* **384**.



The value of parameter *Stator inductance* **384** refers to the quantity between two motor phases and can typically be taken from the data sheet of the motor.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
384	Stator inductance	0.1 mH	500.0 mH	1.0 mH

1192 Peak current (synchronous motor)

The parameter *Peak current* **1192** is used during commissioning of the motor to set the limit for the reference Isq value in the frequency inverter. This is to protect the connected synchronous motor. The value can be taken from the motor rating plate or the motor data sheet. Exceeding the value specified by the manufacturer may result in motor damage.

Parameters			Setting	
No.	Description	Min.	Max.	Fact. sett.
1192	Peak current	0.01% I _{FIN}	100000% o _c ·I _{FIN}	100% I _{FIN}

I_{FIN}: Nominal value of frequency inverter

o_c: Overload capacity of frequency inverter.

7.2.3 Device test

For easier troubleshooting in the device or in a plant, the internal and externally connected hardware can be tested. Errors in the frequency inverter, external sensors, the load (motor) and electrical connections will be identified.

In order to be able to test individual components separately, the device test is split up in individual tests which can be activated separately.

7.2.3.1 Earth fault and short circuit test (Test 1)



⚠ WARNING




Synchronous motors may move briefly while the test is performed. It must be checked if there is a potential risk of personal injury or material damage. If necessary, access to hazard areas must be safely prevented.

If a synchronous motor is connected: The test must not be started while the synchronous motor runs.

Test 1 checks if there is an earth fault or a short-circuit against DC-link potential in the load (motor) or in the frequency inverter. This test can be carried out with or without load.

In this test, all six IGBTs (transistors) will be switched on briefly individually. No current may flow in this process even if the load is connected.





If, for example, there is a short-circuit between the positive DC-link potential (P or +) and branch U (see illustration), the test would be stopped and error "T0104 earth /P-U fault" would be displayed. This may either be a "hard" short-circuit or a "soft" short-circuit, i.e. a short-circuit with a relatively high resistance. Short-circuits which don't trigger a hardware overcurrent circuit break, but cause a current which is 10 % greater than the rated current peak value are signaled as earth faults.

If an error is signaled during a test with connected load, the test should be repeated without connected load, in order to find out if the device or the load is defective.

If an error is only signaled while the load is connected, it is an earth fault in the load or - if the DC-link terminals are assigned - possibly a short-circuit between a load branch and a DC-link potential.

If an error is also signaled while the load terminals are not assigned, there is a short-circuit in the device or an IGBT is defective. In the case of a defective IGBT or a short-circuit in the device, the error will be signaled in several branches while the load is connected, as the current can also flow via the load. In this case, only the messages generated while the load is not connected may be considered.

Non-switching IGBTs or non-functioning current measurements will not be detected by this test (but by Test 2). In this case existing errors which would normally be identified by this test might not be detected.

Message	Meaning
T0001	Stop. Test stopped by user.
T0002	Permanent error. Non-acknowledgeable error present. No (further) test possible.
T0003	Signals on digitals inputs STOA and STOB for enable missing. No enable.
T0010	At the beginning of the test an inadmissible current flows.
T0101	Earth /N-U fault. Short-circuit between branch U and the negative DC-link potential or PE.
T0102	Earth /N-V fault. Short-circuit between branch V and the negative DC-link potential or PE.
T0103	Earth /N-W fault. Short-circuit between branch W and the negative DC-link potential or PE.
T0104	Earth /P-U fault. Short-circuit between branch U and the positive DC-link potential or PE.
T0105	Earth /P-V fault. Short-circuit between branch V and the positive DC-link potential or PE.
T0106	Earth /P-W fault. Short-circuit between branch W and the positive DC-link potential or PE.
T0114	Soft earth /P-U fault. Short-circuit between branch U and the positive DC-link potential or PE.
T0115	Soft earth /P-V fault. Short-circuit between branch V and the positive DC-link potential or PE.
T0116	Soft earth /P-W fault. Short-circuit between branch W and the positive DC-link potential or PE.
Err.S41	Internal error. Abort and restart the test.

7.2.3.2 Load test (Test 2)

⚠ WARNING



If a synchronous motor is connected: The test must not be started while the synchronous motor runs.

Synchronous motors may move briefly while the test is performed. It must be checked if there is a potential risk of personal injury or material damage. If necessary, access to hazard areas must be safely prevented.

Test 2 checks if a direct current can be impressed in the connected load (motor) in both directions. Test 1 should be carried out before without any error messages.

For Test 2, a three-phase choke or a three-phase motor must be connected as the load. The load may be star or delta connected. The star point must not be connected, if applicable.

Test 2 impresses a positive and a negative direct current in each branch one after the other. If no current can be impressed in any direction, an error will be signaled. IGBTs, the load and the current measurement are checked.



If an error is signaled in a branch both for positive and negative current, the relevant load branch circuit is open (e.g. broken wire) or the relevant current measurement is defective. If an error is signaled in a branch for one polarity only, an IGBT or driver is defective or a connection in the device is interrupted.

The impressed direct current is 25% of the peak value of the rated current. The rated current must be set with parameter *Rated Current* **371** in data set 1.

In order to prevent damage of the device and the load, the output voltage is limited. If the set current (see above) cannot be reached with this voltage due to a high ohmic resistance of the load, an open-circuit error is identified in each branch. In this case, the current to be impressed must be reduced by changing parameter *Rated Current* **371**.

Message	Meaning
T0001	Stop. Test stopped by user.
T0002	Permanent error. Non-acknowledgeable error present. No (further) test possible.
T0003	Signals on digitals inputs STOA and STOB for enable missing. No enable.
T0010	At the beginning of the test an inadmissible current flows.
T0201	U open. It was not possible to impress a positive current in branch U.
T0202	V open. It was not possible to impress a positive current in branch V.
T0203	W open. It was not possible to impress a positive current in branch W.
T0204	-U open. It was not possible to impress a negative current in branch U.
T0205	-V open. It was not possible to impress a negative current in branch V.
T0206	-W open. It was not possible to impress a negative current in branch W.
T0211	U short-circuit. Short-circuit cutoff during impression of positive current in branch U.
T0212	V short-circuit. Short-circuit cutoff during impression of positive current in branch V.
T0213	W short-circuit. Short-circuit cutoff during impression of positive current in branch W.
T0214	-U short-circuit. Short-circuit cutoff during impression of negative current in branch U.
T0215	-V short-circuit. Short-circuit cutoff during impression of negative current in branch V.
T0216	-W short-circuit. Short-circuit cutoff during impression of negative current in branch W.
T0221	Earth fault Phase U. Earth fault cutoff during impression of positive current in branch U.
T0222	Earth fault Phase V. Earth fault cutoff during impression of positive current in branch V.
T0223	Earth fault Phase W. Earth fault cutoff during impression of pos. current in branch W.
T0224	-U earth fault. Earth fault cutoff during impression of negative current in branch U.
T0225	-V earth fault. Earth fault cutoff during impression of negative current in branch V.
T0226	-W earth fault. Earth fault cutoff during impression of negative current in branch W.
T0231	U Soft earth fault. The DC-link voltage has increased. Insulation problem in motor.
T0232	V Soft earth fault. The DC-link voltage has increased. Insulation problem in motor.
T0233	W Soft earth fault. The DC-link voltage has increased. Insulation problem in motor.
T0234	-U Soft earth fault Phase U. Insulation problem in motor.
T0235	-V Soft earth fault Phase V. Insulation problem in motor.
T0236	-W Soft earth fault Phase W. Insulation problem in motor.
T0260	Asymmetric phase voltages.
Err.S41	Internal error. Abort and restart the test.

If Test 2 signals an earth fault while Test 1 did not signal an earth fault, a current measurement will probably be defective.

If Test 2 signals a short-circuit, there is either a short-circuit in the load or a current measurement is defective.



7.2.3.3 Start device test via operator panel


The device test can be started via the operator panel.

- Switch on enable at inputs STOA and STOB.
- Select menu item "Test" in "Local" menu.
- Select Test 1 or Test 2. It is recommended that you start with Test 1.
- Press "ENT" button to start Test 1.

If Test 1 is finished and no error was detected, "t1 good" will be displayed.

- Confirm by pressing the "ENT" button. Menu item "Test 2" will be displayed.
- Press "ENT" button to start Test 2.

If Test 2 is finished and no error was detected, "t2 good" will be displayed.



Test 3: Refer to chapter 7.2.3.6 "Fan test".

If an error was detected and a message was displayed, the relevant error must be repaired following the instructions in chapters 7.2.3.1 "Earth fault and short circuit test (Test 1)" or 7.2.3.2 "Load test (Test 2)".

Parameter *Status device test* **1541** indicates the status of the device test and messages generated during the test.

After a message, the test can be continued by pressing "ENT".

Press "ESC" to stop the test. In this case, message "tESt" is displayed.



If "STO" is displayed if the device test is to be started, enable must be switched on at inputs STOA and STOB.

7.2.3.4 Start device test via control software or bus system

1540 Start device test manual

The device test can be started via the control software VPlus or a connected bus system

Start device test manual 1540	Function
0 - Clear status	Deletes the messages generated during the test. Factory setting.
1 - Continue	Continues the current test after a message.
2 - Cancel	Stops the current test.
11 - Start Test 1	Starts Test 1 (earth fault and short-circuit test).
12 - Start Test 2	Starts Test 2 (load test).
13 - Start Test 1 and Test 2	Starts Test 1 (earth fault and short-circuit test) and Test 2 (load test).



Enable at inputs STOA and STOB must be switched on in order to be able to carry out the test.

Parameter *Status device test* **1541** indicates the status of the device test and messages generated during the test.



7.2.3.5 Automatic device test after error switch-off

1542 Start device test automatic

The device test can be started automatically after each error switch-off of the frequency inverter. The device test will start once the frequency inverter is restarted after an error switch-off.

Start device test automatic 1542	Function
0 - Off	No automatic device test after error switch-off. Factory set-
0 011	ting.
	Test 1 (earth fault and short-circuit test) will start automati-
1 - Start Test 1	cally after an error switch-off of the frequency inverter fol-
	lowed by a start command.
2 Chart Toot 2	Test 2 (load test) will start automatically after an error switch-
2 - Start Test 2	off of the frequency inverter followed by a start command.
	Test 1 (earth fault and short-circuit test) and Test 2 (load
3 - Start Test 1 and Test 2	test) will start automatically after an error switch-off of the
	frequency inverter followed by a start command.

NOTE

The automatic device test may result in a delayed start of the motor after a start command.

Parameter *Status Device Test* **1541** indicates the status of the device test and messages generated during the test.

The device test will possibly start some time after the frequency inverter is switched on because the test must not be carried out with the motor magnetized.

7.2.3.6 Fan test


The function of the interior fan and heat sink fan is tested. Dependent on the type of the frequency inverter, fans are possibly not installed (refer to chapter 11.2 "Device data").

The device test can be started via the operator panel.

- Switch on enable at inputs STOA and STOB.
- Select menu item "Test" in "Local" menu.
- Select Test 3.
- Press "ENT" button to start Test 3.

The interior fan and heat sink fan must rotate.

Press "ESC" button to finish the test.





If "STO" is displayed if the fan test is to be started, enable must be switched on at inputs STOA and STOB.

Check for unusual operating noise and remove any soiling and dust if necessary.

If a fan does not rotate contact the service of BONFIGLIOLI.



7.3 Operational Behavior

The operational behavior of the frequency inverter can be adjusted to the application by setting the parameters appropriately. In particular the acceleration and deceleration behavior can be selected according to the selected *Configuration* **30**. Additionally, features such as Auto Start, and the synchronization and positioning functions facilitate the integration in the application.

7.3.1 Control

The frequency inverters are suitable for data communication and can be extended by communication modules. In this way, they can be integrated in an automation and control system. Parameterization and commissioning can be done via the operator panel or a communication interface.

Control can be done via contacts, keypad on the operator panel or communication interface.

412 Local/Remote

Parameter *Local/Remote* **412** defines the command sources for start, stop and direction of rotation are to be issued. The parameter enables choosing from control via contacts, operator panel or communication interface.

1	Local/Remote 412	Function
0 -	Control via Contacts	The commands start and stop as well as the definition of the direction of rotation (parameters <i>Start Clockwise</i> 68 , <i>Start Anticlockwise</i> 69) are issued via digital inputs. Run, Stop and Reset commands from the keypad keys are ignored.
1 -	Control via Statema- chine	The Start and Stop commands as well as the direction of rotation are controlled via the Remote Statemachine of the communication interface. The control is done via the Controlword, which can be monitored via 410 <i>Controlword</i> or which can be used to simulate it. With 411 <i>Statusword</i> the state of the drive can be monitored. The statusword is typically sent to the overlying control (PLC). Run, Stop and Reset commands from the keypad keys are ignored.
2 -	Control via Remote- Contacts	The Start and Stop commands as well as the direction of rotation are controlled via logic signals through the communication protocol. Run, Stop and Reset commands from the keypad keys are ignored.
3 -	Control via Keypad	The start and stop commands as well as the direction of rotation are entered via the operator panel.
4 -	Control via Keypad or Cont.	The start and stop commands as well as the direction of rotation are entered via the operator panel or via digital inputs. Factory setting .
5 -	Control 3-Wire	Control of direction of rotation (parameters <i>Start Clockwise</i> 68 , <i>Start Anticlockwise</i> 69) and signal <i>Start 3-wire control</i> 87 via digital inputs.

MARNING



If the operation mode is changed while the drive is running, the drive will not be stopped if no stop command is present in the new operation mode.

In order to be able to control the drive, the output stage must be enabled by digital inputs STOA and STOB.



Signals via physical contacts (IN1D...IN5D, MFI1, MFI2) are only evaluated if an operation mode with "Control via Contact" or "Control 3-Wire" (0, 4 or 5) is selected.

In all other operation modes (1, 2, 3) physical contacts are only evaluated, if the corresponding signals in the digital inputs with the suffix (Hardware) are selected. Please comply with chapter 7.6.6 "Digital inputs".

Signals not referring to a physical input are evaluated independent of the operation mode *Local/Remote* **412**.



Lock the Reference value facilities of the control panel

If the setting possibility of the reference frequency at the operator panel must be locked: For the following parameters the setting "5 - Keypad-Motorpot." must not be selected.

- Reference Frequency Source 1 475, Reference Frequency Source 2 492
- Reference Percentage Source 1 476, Reference Percentage Source 2 494

Set parameter *Set Password* **27** to prevent the resetting of parameters. Refer to chapter 7.1.3 "Set password".

NOTE

The setting of parameter *Set Password* **27** only does not lock the control facilities of the keypad. Start, Stop, Change direction of rotation, Poti F and Poti P are still available.

7.3.2 Starting behavior

The starting behavior of the machine can be configured. In Configuration 110 (V/f control of asynchronous motor) the starting behavior can be set via parameter *Operation mode* **620**.

In the field-orientated control method of configurations 410 (asynchronous motor) and 610 (synchronous motor), the starting behavior can be set via the limits *Maximum flux-formation time* **780** and *Current during flux-formation* **781**.

Parameter of starting behavior in the configurations

	U/f	DMR Asynchronous motor	DMR Synchronous motor
Configuration 30	110	410	610
620	X		
621	X		
622	X		
623	X	X	X
624	X	X	X
625	X	X	X
779		X	X
780	X	X	X
781	X	X	X

620 Operation mode (starting behavior)

The parameter *Operation mode* **620** for the starting behavior is available if *Configuration* **30** = "110 - IM: sensorless control" (V/f control of asynchronous motor) is selected. Depending on the operation mode selected, the motor is magnetized first or a starting current is impressed. The voltage drop across the stator resistance which reduces the torque in the lower frequency range can be compensated by the IxR compensation.

To ensure the correct function of the IxR compensation, the stator resistance is determined during the guided commissioning (Setup). The IxR compensation is only activated when the stator resistance was determined correctly.

Operation mode 620	Starting behavior
0 - Off	During startup, at an output frequency of 0 Hz, the voltage is set via parameter <i>Starting voltage</i> 600 . After this, the output voltage and the output frequency are changed according to the control method. The break-away torque and the current at the start are determined by the adjusted starting voltage. It may be necessary to optimize the starting behavior via the parameter <i>Starting voltage</i> 600 .



Operation mode 620	Starting behavior
1 - Magnetisation	In this operation mode, the <i>Current during flux-formation</i> 781 for magnetization is impressed into the motor after enable. The output frequency is kept at zero Hz not exceeding the <i>Maximum flux-formation time</i> 780 . After this time has expired (at the latest), the output frequency follows the adjusted V/f characteristic.
2 - Magnetisation + current impression	Operation mode 2 includes operation mode 1. After the <i>Maximum flux-formation time</i> 780 has elapsed (at the latest), the output frequency is increased according to the set acceleration and the starting current is impressed. If the output frequency reaches the value set with the parameter <i>Frequency limit</i> 624 , the <i>Starting current</i> 623 is withdrawn. There is a smooth transition to 1.4 times the frequency limit to the set V/f characteristic. As from this operating point, the output current depends on the load. Factory setting .
3 - Magnetisation + IxR-compensation	Operation mode 3 includes operation mode 1. When the output frequency reaches the value set with parameter <i>Frequency limit</i> 624 , the increase of the output voltage by the IxR compensation becomes effective. The V/f characteristic is displaced by the portion of voltage which depends on the stator resistance.
Magnetisation + 4 - current impression + IxR- compensation	In this operation mode, the current set with the parameter <i>Current during flux-formation</i> 781 is impressed into the motor for magnetization after enable. The output frequency is kept at zero Hz not exceeding the <i>Maximum flux-formation time</i> 780 . After the time has elapsed (at the latest), the output frequency is increased according to the set acceleration and the starting current is impressed. If the output frequency reaches the value set with the parameter <i>Frequency limit</i> 624 , the <i>Starting current</i> 623 is withdrawn. There is a smooth transition to the V/f characteristic, and a load-dependent output current is obtained. At the same time, the increase of the output voltage by the IxR compensation becomes effective as from this output frequency. The V/f characteristic is displaced by the portion of voltage which depends on the stator resistance.
Magnetisation + 12 - current impression with ramp stop	Operation mode 12 contains an additional function to guarantee a starting behavior under difficult conditions. The magnetization and starting current impression are done according to operation mode 2. The ramp stop takes the current consumption of the motor at the corresponding operating point into account and controls the frequency and voltage change by stopping the ramp. The <i>Controller status</i> 275 signals the intervention of the controller by displaying the message "RSTP".
Magnetisation + current impression with ramp stop + IxR-compensation	In this operation mode, the functions of operation mode 12 are extended by the compensation of the volt-age drop across the stator resistance. When the output frequency reaches the value set with parameter <i>Frequency limit</i> 624 , the increase of the output voltage by the IxR compensation becomes effective. The V/f characteristic is displaced by the portion of voltage which depends on the stator resistance.

621 Amplification 622 Integral time

In setting *Configuration* **30** = "110 - IM: sensorless control" (V/f control of asynchronous motor), a current controller is available for the starting behavior. The PI controller controls the current impression via parameter *Starting current* **623**. The proportional and integrating part of the current controller can be set via parameters *Amplification* **621** and *Integral time* **622**.

Parameters Setting			Setting	
No. Description		Min. Max. F		Fact. sett.
621	Amplification	0.01	10.00	2.00
622	Integral time	1 ms	30000 ms	50 ms



623 Starting current

The *Starting current* **623** ensures, particularly for high-torque start, a sufficient torque until the *Frequency limit* **624** is reached.

Applications in which high current is permanently needed at a low speed are to be realized using forced-ventilated motors to prevent thermal overload.

	Parameters	Setting		
No.	Description	Min.	Max.	Fact. sett.
623	Starting current	0.0 A	$o_c \cdot I_{FIN}$	I_{FIN}

 I_{FIN} : Nominal value of frequency inverter

In the following settings, the starting current impression is used for the starting behavior:

- Configuration 30 = "110 IM: sensor-less control" (V/f control of asynchronous motor),
 Operation mode 620 = 2, 4, 12 or 14
- Configuration 30= "410 IM: sensor-less field-orientated control (DMC)", asynchronous motor
- Configuration 30= "610 PMSM: sensor-less field-orientated control (DMC)", synchronous motor

624 Frequency limit

The *Starting current* **623** is impressed until the *Frequency limit* **624** is reached. Permanent operating points below the frequency limit are only permissible if forced-ventilated motors are used.

The transition to the control method of the selected *Configuration* **30** takes place above the frequency limit.

The *Frequency limit* **624** is set up automatically during the guided motor commissioning in field oriented control configurations 410 and 610. In V/f control configuration 110 the parameter *Frequency limit* **624** is not changed by the guided motor commissioning.

	Parameters	Setting		
No.	Description	Min.	Max.	Fact. sett.
624	Frequency Limit	0.00 Hz	100.00 Hz	2.60 Hz

In the following settings, the starting current impression is used for the starting behavior:

- Configuration 30 = "110 IM: sensor-less control" (V/f characteristic of asynchronous motor),
 Operation mode 620 = 2, 3, 4, 12 or 14
- Configuration 30= "410 IM: sensor-less field-orientated control (DMC)", asynchronous motor
- Configuration 30= "610 PMSM: sensor-less field-orientated control (DMC)", synchronous motor

625 Brake release time

In order to protect the motor holding brake against damage, the motor may only start after the brake has been released. Startup to reference speed is effected only after the *Brake release time* **625** has elapsed. The time should be set such that it is at least as long as the time required for releasing the holding brake. By using negative values for the parameter, release of the brake is delayed. This can be done in order to prevent loads from falling down, for example.

	Parameters	Setting		
No.	Description	Min.	Max.	Fact. sett.
625	Brake release time	-5000 ms	5000 ms	0 ms

o_c: Overload capacity of frequency inverter.



779 Minimum flux-formation time

The time required for flux-formation changes depending on the rotor time constant of the motor. By setting the parameters *Maximum flux-formation time* **780** and *Minimum flux-formation time* **779**, a constant flux-formation time can be reached. With the parameter *Minimum flux-formation time* **779**, the minimum time for current impression is set. In this way, the time between a start signal and the start of the drive can be defined. For an appropriate setting of the parameters, the rotor time constant, the required starting torque and the parameter *Current during flux-formation* **781** must be considered.

Parameters		Setting		
No.	Description	Min. Max. Fact. set		
770	Minimum flux-formation time 1 ms	10000 ms	10 ms ¹⁾	
//9		1 ms	10000 ms	50 ms ²⁾

¹⁾Configuration 30 = 410

²⁾Configuration 30 = 610

<i>Minimum flux-formation time</i> $779 = 0$	Flux-formation is stopped as soon
	 as the reference flux value or the
	 maximum flux-formation time were reached
<i>Minimum flux-formation time</i> 779 > 0	Current is impressed for flux-formation at least for this time even if the reference flux value was reached.
Minimum flux-formation time 779	Flux-formation is stopped after the set flux-formation time,
= Maximum flux-formation time 780	regardless of whether the reference flux value was
	reached or not.
Minimum flux-formation time 779	Flux-formation is stopped after the maximum flux-
< Maximum flux-formation time 780	formation time.

780 Maximum flux-formation time 781 Current during flux-formation

The field-orientated control is based on separate control of the flux-forming and the torque-forming current component. Upon startup, the machine is magnetized and a current is impressed first. With the parameter $Current\ during\ flux-formation\ 781$ the magnetization current I_{sd} is set, with the parameter $Maximum\ flux-formation\ time\ 780$ the maximum time for the current impression is set.

The current impression is done until the reference value of the rated magnetizing current is reached or the *Maximum flux-formation time* **780** is exceeded.

Parameters		Setting			
No.	Description	Min. Max. Fact. set			
	780 Maximum flux-formation time	1 ms		300 ms ¹⁾	
780			10000 ms	1000 ms ²⁾	
				50 ms ³⁾	
781	Current during flux-formation	$0.1 \cdot I_{\sf FIN}$	$o_{c} I_{FIN}$	${ m I}_{\sf FIN}$	

I_{FIN}: Nominal value of frequency inverter

o_c: Overload capacity of frequency inverter.

¹⁾Configuration 30 = 110

²⁾Configuration 30 = 410

 $^{^{3)}}$ Configuration **30** = 610



7.3.3 Stopping behavior

630 Operation mode (P68&P69=1 | P68&P69=0)

The stopping behavior can be defined via parameter *Operation mode* (P68&P69=1 / P68&P69=0) **630**. The signal states of the digital inputs or logic signals for parameters *Start clockwise* **68** and *Start anticlockwise* **69** activate the stopping procedure. Digital inputs or logic signals can be assigned to these parameters. In the factory settings, *Start clockwise* **68** is assigned "71 - IN1D" (terminal X11.4) and *Start anticlockwise* **69** is assigned "72 - IN2D" (terminal X11.5). By combination of the digital input states or logic signals, the stopping behaviors can be selected from the following table.

	Operation mode Stopping behavior						
		Start clockwise = 0 and Start anticlockwise = 0					
	Operation mode (P68&P69=1	Stoppir	Stopping behaviour (refer to table "Stopping behavior)				
P68&P69=0) 630		0	1	2	4	5	7
	Stopping behavior 0 (Coast to Stop)	0	1	2	4	5	7
and = 1	Stopping behavior 1 (Stop and switch off)	10	11	12	14	15	17
e = 1 wise	Stopping behavior 2 (Stop and hold)	20	21	22	24	25	27
clockwise = 1 anticlockwise	Stopping behavior 4 (Emergency stop and switch off)	40	41	42	44	45	47
cloc	Stopping behavior 5 (Emergency stop and hold)	50	51	52	54	55	57
Start Start	Stopping behavior 7 (DC brake)	70	71	72	74	75	77

Operation mode **630** of the stopping behavior is to be parameterized according to the matrix. The selection of the operation modes can vary according to the control method and the available control inputs.

Example:

The motor is to stop according to stopping behavior 1 if the digital logic signals $Start\ Clockwise\ \mathbf{68} = 1$ and $Start\ Anticlockwise\ \mathbf{69} = 1$.

Additionally, the motor is to stop according to stopping behavior 2 if the digital logic signals Start Clockwise **68** = 0 and Start Anticlockwise **69** = 0.

To achieve this, the value 12 (Stop, Off | Stop, Hold) must be set for parameter $Operation \ mode \ (P68\&P69=1 \mid P68\&P69=0)$ **630**.

By selecting the stopping behavior you also select the control of a mechanical brake if operation mode "41-Open brake" is used for one digital output for controlling the brake.

	Stopping behavior			
Stopping behavior 0	The inverter is disabled immediately. The drive deenergized immediately and			
Coast to Stop	coasts freely.			
Stopping behavior 1 Stop and Switch off	The drive is brought to a standstill at the set deceleration. As soon as the drive is at a standstill, the inverter is disabled after a after a holding time. The holding time can be set via the parameter <i>Holding time stop function</i> 638 . Depending on the setting of the parameter <i>Operation mode</i> 620 the <i>Starting current</i> 623 is impressed or the <i>Starting voltage</i> 600 is applied for the duration of the holding time.			



	Stopping behavior			
Stopping behavior 2	The drive is brought to a standstill at the set deceleration and remains permanently supplied with cur-rent. Depending on the setting of the parameter <i>Operation mode</i> 620 the <i>Starting</i>			
Stop and hold	current 623 is impressed or the <i>Starting voltage</i> 600 is applied as from standstill.			
	The drive is brought to a standstill at the emergency stop deceleration. As			
Stopping behavior 4	soon as the drive is at a standstill, the inverter is disabled after a after a holding time.			
Emergency stop and	The holding time can be set via the parameter <i>Holding time stop function</i>			
Switch off	638 . Depending on the setting of the parameter <i>Operation mode</i> 620 , the			
Switch on	Starting current 623 is impressed or the Starting voltage 600 is applied as from standstill.			
Stopping behavior 5	The drive is brought to a standstill at the emergency stop deceleration and remains permanently supplied with current.			
Emergency stop and hold	Depending on the setting of the parameter <i>Operation mode</i> 620 the <i>Starting current</i> 623 is impressed or the <i>Starting voltage</i> 600 is applied as from standstill.			
Stopping behavior 7	Direct current braking is activated immediately. In this process, the direct current set with parameter <i>Braking current</i> 631 is impressed for the <i>Braking</i>			
DC brake	time 632 . Comply with the notes in chapter 7.3.6 "Direct current brake". Only available in the configuration 110 (V/f control).			

Comply with chapter 7.6.5.5 "Release brake" on addressing mechanical brakes.

When a synchronous motor is connected, BONFIGLIOLI recommends setting $Operation \ mode \ 630 = 22$.

637 Switch-Off Threshold Stop Function

The *Switch-Off Threshold Stop Function* **637** defines the frequency as from which a stand-still of the drive is recognized. This percentage parameter value is relative to the set *Maximum frequency* **419**.

The switch-off threshold is to be adjusted according to the load behavior of the drive and the device output, as the drive must be controlled to a speed below the switch-off threshold.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
637	Switch-Off Threshold Stop Function	0.0%	100.0%	1.0%

⚠ WARNING



If the motor builds up a stopping torque, it may be possible that the switch-off threshold stop function is not reached due to the slip frequency and the standstill of the drive is not recognized. In this case, increase the value of the *Switch-off threshold stop function* **637**.

638 Holding time stop function

The *Holding time stop function* **638** is considered in stopping behaviors 1 and 4. Controlling to speed zero leads to a heating of the motor and should only be done for a short period in internally ventilated motors.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
638	Holding time stop function	0.0 s	200.0 s	1.0 s



7.3.4 Auto start

⚠ WARNING



Comply with VDE provision 0100 part 227 and pro-vision 0113, in particular Sections 5.4, protection against automatic after main line voltage failure and voltage recovery, and Section 5.5 "Undervoltage protection".

Appropriate measures must be taken to exclude any risk for staff, machines and production goods.

In addition to that, all specific regulations relevant to the application as well all national directives are to be complied with.

651 Operation mode (Auto start)

The auto start function is suitable for applications which permit a start at mains voltage by their function. By activation of the auto start function via parameter *Operation mode* **651**, the frequency inverter accelerates the drive after application of the mains voltage. Control signals STOA and STOB for enable and the start command are required as per the regulations. When the motor is switched on, it is accelerated according to the parameterization and the reference value signal.

Operation mode 651	Function
0 - Off	No auto start. The drive is accelerated, after application of the mains voltage, as soon as the enable and the start command are present (edge-triggered). Factory setting .
1 - Switched on	The drive is accelerated by the frequency inverter as soon as the mains voltage is applied (level-triggered).

7.3.5 Flying Start

645 Operation Mode Flying Start

The synchronization to a rotating drive is necessary in applications which drive the motor by their behavior or in which the drive is still rotating after an error switch-off. Via *Operation Mode Flying Start* **645**, the motor speed is synchronized to the current motor speed without an "Overcurrent" fault message. After this, the motor is accelerated to the reference speed at the set acceleration. This synchronization function determines the current rotary frequency of the drive via a search run.

The synchronization in operation modes 1 to 4 is accelerated by short test impulses. Rotary frequencies of up to 175 Hz are determined within 100 ms to 300 ms. For higher frequencies, a wrong frequency is determined and the synchronization fails. In operation modes 1 to 4, the Flying Start cannot determine whether a synchronization attempt has failed.

For operation of a synchronous motor, the flux direction can be determined in order to prevent alignment of the motor shaft (jerking) during start-up. Determining the flux direction takes approx. 20 ms. In this process, there are short torque pulses. This method is not suitable for very dynamic drives since the torque pulses result in a rotation of the drive and consequently in wrong measurements. Once the flux direction was determined, the flux is formed (Parameter *Minimum flux-formation time* **779**, *Maximum flux-formation time* **780**, *Current during flux-formation* **781**) in order to improve the starting behavior.



_	ration Mode Fly- ing Start 645	Function
0 -	Off	The synchronization to a rotating drive is de-activated. Factory setting.
1 -	On	An attempt is made to synchronize to the drive in positive direction (clockwise field of rotation) and in negative direction (anticlockwise field of rotation). During operation of a synchronous motor (<i>Configuration</i> 30 = 610), the flux direction is determined additionally when the drive is at a standstill.
2 -	On, according to reference	The search direction is defined by the sign of the reference value. If a positive reference value (clockwise field of rotation) is entered, the search is in a positive direction (clockwise field of rotation), with a negative reference value, the search is in a negative direction (anti-clockwise field of rotation). During operation of a synchronous motor ($Configuration 30 = 610$), the flux direction is determined additionally when the drive is at a standstill.
3 -	On, clockwise only	Synchronization to the drive is only done in positive direction (clockwise field of rotation). During operation of a synchronous motor (<i>Configuration</i> 30 = 610), the flux direction is determined additionally when the drive is at a standstill.
4 -	On, anticlockwise only	Synchronization to the drive is only done in negative direction (anticlockwise field of rotation). During operation of a synchronous motor (<i>Configuration</i> 30 = 610), the flux direction is determined additionally when the drive is at a standstill.
20 -	Determine flux direction only	For a synchronous motor ($Configuration$ 30 = 610), only the flux direction is determined. The drive must be at a standstill. Synchronization to a turning drive is not possible. This method is faster than operation modes 1 4.
30 -	Operation above frequency limit	For a synchronous motor ($Configuration$ 30 = 610), only the Flying Start is performed. The search is continued until a rotary frequency is detected which is greater than the $Frequency\ limit$ 624. If the stator frequency drops below the frequency limit, the search run is continued. This operation mode can be used for synchronous motors in torque-controlled drives. An example application is the operation in wind energy converters. For an asynchronous motor ($Configuration$ 30 = 410): Wait for speed. Applicable for torque-controlled drives which have to supply only reaction torque without active acceleration. If the drive is externally accelerated to the speed which is sufficient for sensor-less field-orientated control, switchover to torque control is carried out.

Operation modes 2, 3 and 4 define a direction of rotation for the Flying Start and avoid a deviating direction. The Flying Start can accelerate drives by checking the rotary frequency if the drives have a low moment of inertia and/or a small load moment.

In operation modes 1 to 4, it cannot be ruled out that a wrong direction of rotation is determined. For example, a frequency not equal to zero may be determined although the drive is at a standstill. If there is no overcurrent, the drive is accelerated accordingly. The direction of rotation is defined in operation modes 2, 3 and 4.

NOTE

The Flying Start function is designed for the operation of motors without brake. Brake motors may not be operated optimum in individual cases (depending of parameterization and brake control) with the Flying start function.



7.3.6 Direct current brake

631 Braking Current

632 Braking Time

Stopping behavior 7 (Parameter *Operation Mode* **630**) includes the direct current brake. Using the direct current brake a motor can be decelerated faster than without direct current brake. By impressing a direct current part into the motor the losses inside the motor are artificially increased. The impression of the *Braking Current* **631** results in the motor heating up and should only be done for a short period in the case of internally ventilated motors.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
631	Braking Current	0.00 A	$\sqrt{2} \cdot I_{FIN}$	$\sqrt{2} \cdot I_{FIN}$

I_{FIN}: Nominal value of frequency inverter

For the application of the Direct current brake the parameter *Configuration* **30** must be set to "110 - IM: sensor-less control" (control in accordance with V/f-characteristic).

The setting of the parameter *Braking Time* **632** defines the time-controlled stopping behavior. Contact-controlled operation of the direct current brake is activated by entering the value zero for the *Braking Time* **632**.

Time controlled:

The direct current is controlled by the status of the signals Start clockwise and Start anticlockwise. The current set by the parameter *Braking Current* **631** flows until the time set by the parameter *Braking Time* **632** has expired.

For the duration of the braking time, the combined control signals Start clockwise and Start anticlockwise must be logical 0 (Low) or 1 (High).

Contact-controlled:

If the parameter *Braking time* **632** is set to the value 0.0 s, the direct current brake is controlled by the Start clockwise and Start anticlockwise signals. The time monitoring and limitation by *Braking Time* **632** are deactivated. The braking current will be impressed until the controller enable control signal (STOA and STOB) becomes logical 0 (low).

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
632	Braking Time	0.0 s	200.0 s	10.0 s

633 Demagnetizing time

To avoid current surges, which can possibly lead to an error switch-off of the frequency inverter, a direct current may only be impressed into the motor after the motor has been demagnetized. As the demagnetization time depends on the motor used, it can be set with the parameter *Demagnetizing time* **633**.

The selected demagnetizing time should be approximately three times the *Act. Rotor Time Constant* **227**.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
633	Demagnetizing Time	0.1 s	30.0 s	5.0 s

634 Amplification 635 Integral Time

The selected stopping behavior is supplemented by a current controller to control the direct current brake. The PI controller controls the current impression of the parameterized *Braking Current* **631**. The proportional and integrating part of the current controller can be set via parameters *Amplification* **634** and *Integral Time* **635**. The control functions can be deactivated by setting the parameters to 0.



Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
634	Amplification	0.00	10.00	1.00
635	Integral Time	0 ms	1000 ms	50 ms

7.3.7 Positioning

458 Operation Mode (Positioning)

Positioning is effected in operation mode "Reference positioning" via specification of the position distance.

Reference positioning uses a digital reference signal on digital input IN1D (terminal X11.4) for positioning the drive independent of the speed.

The function "Reference positioning" is available in configurations 110, 410 and 610 and is activated by selecting operation mode 1 for parameter *Operation Mode* **458**.

Operation mode 458	Function
0 - Off	Positioning switched off.
1 - Reference positioning	Reference positioning via definition of the positioning distance (revolutions). The reference point is identified via digital input IN1D (terminal X11.4).

459 Signal source

Reference positioning is started with the status change of the reference signal at digital input IN1D (terminal X11.4). Logic evaluation can be selected via the parameter signal source.

Signal source 459	Function
1 - IN1D, falling edge	The positioning starts with the change of the logic signal from 1 (High) to 0 (Low) at the reference point.
11 - IN1D, rising edge	The positioning starts with the change of the logic signal from 1 (Low) to 0 (High) at the reference point.
21 - IN1D, rising/falling edge	Positioning is started with a signal change at the reference point.

If the digital input IN1D is used for the reference signal, it must be checked if this input is linked to another function. By default, digital input IN1D has the function "Start clockwise" (Parameter *Start clockwise* **68**).

Do not use digital input IN1D for positioning and a stopping behavior (parameter *Operation mode* **630**) at the same time.

460 Positioning distance

The feedback of the current position is referred to the revolutions of the motors relative to the time of the reference signal. The positioning accuracy depends on the current *Actual Frequency* **241**, the *Deceleration* (*clockwise*) **421**, the *No. of pole pairs* **373**, the selected *Positioning distance* **460** and the configured control behavior.

The distance between the reference point and the required position is to be defined in motor revolutions. The calculation of the distance covered is done with the selected *Positioning distance* **460** according to the application.

The setting 0.000 U for the *Positioning distance* **460** causes an immediate stop of the drive according to the selected stopping behavior for *Operation mode* **630**.

Parameters		Setting			
No.	Description	Min. Max. Fact. sett.			
460	Positioning distance	0.000 U	1000000.000 U	0.000 U	

U = Revolutions



The actual value parameter *Revolutions* **470** facilitates the setting and optimization of the function. The revolutions of the motor displayed should correspond to the *Positioning distance* **460** at the required position.

The minimum number of revolutions needed until the required position is reached depends on the *Actual frequency* **241** and *Deceleration (Clockwise)* **421** (or *Deceleration Anticlockwise* **423**) as well as the *No. of pole pairs* **373** of the motor.

$$U_{minimum} = \frac{f^2}{2 \cdot a \cdot p}$$
 $U_{min} = min. number of rotations$
 $f = Actual frequency 241$
 $a = Deceleration 421 (or 423)$
 $p = No. of pole pairs 373 of motor$

Example: f = 20 Hz, a = 5 Hz/s, $p = 2 \Rightarrow U_{min} = 20$

With an actual frequency of 20 Hz and a delay of 5 Hz/s, at least 20 rotations are needed until stand-still at the required position. This is the minimum value for the *Positioning distance* **460**, a shorter positioning distance is not possible. If the number of rotations until the required position is reached is to be lower, the frequency must be reduced, the deceleration increased, or the reference point must be shifted.

461 Signal correction

The registration of the reference position via a digital signal can be influenced by a variable dead time while the control command is read and processed. The signal running time is compensated by a positive figure for the *Signal correction* **461**. The setting of a negative signal correction decelerates the processing of the digital signal.

	Parameters		Setting		
No.	Description	Min. Max. Fact. sett.			
461	Signal correction	-327.68 ms	+327.67 ms	0.00 ms	

462 Load correction

The influences on the positioning which depend on the operating point can be cor-rected empirically via parameter *Load correction* **462**. If the required position is not reached, the deceleration duration is increased by a positive load correction value. The distance between the reference point and the required position is extended. Negative values accelerate the braking process and reduce the positioning distance. The limit of the negative signal correction results from the application and the *Positioning distance* **460**.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
462	Load correction	-32768	+32767	0



463 Activity after positioning

The behavior of the positioning after the required position of the drive is reached can be defined via parameter *Activity after positioning* **463**.

Activity after positioning 463	Function
0 - End positioning	The drive is stopped with the stop-ping behavior of <i>Operation mode</i> 630 . In this setting only the second digit of <i>Operation mode</i> 630 is evaluated. If the state "Hold" is selected, this state is considered, all other states will result in state "Switch Off".
1 - Waiting for positioning sig- nal	The drive is stopped until the next signal edge; with a new edge of the position signal, it is accelerated in the previous direction of rotation.
2 - Reversal by new edge	The drive is held until the next signal edge; with a new edge of the position signal, it is accelerated in the opposite direction of rotation.
3 - Positioning; off	The drive is stopped and the power output stage of the inverter is switched off.
4 - Start by time control	The drive is stopped for the <i>Waiting Time</i> 464 ; after the waiting time, it is accelerated in the previous direction of rotation.
5 - Reversal by time control	The drive is stopped for the <i>Waiting Time</i> 464 ; after the waiting time, it is accelerated in the opposite direction of rotation.

464 Waiting Time


The position reached can be maintained for the *Waiting Time* **464**, then the drive is accelerated according to operation mode 4 or 5.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
464	Waiting Time	0 ms	3600000 ms	0 ms

Positioning, $Operation \ Mode \ 458 = 1$

The diagram shows how the positioning to the set positioning distance is effected. The positioning distance remains constant at different frequency values. At the reference point, the position signal S_{Posi} is generated. Starting from frequency f_{max} , the positioning is effected at the set *Deceleration* (clockwise) **421**. At a lower frequency value f_1 , the frequency remains constant for some time before the drive is stopped at the set deceleration.

If, during acceleration or deceleration of the machine, positioning is started by the signal S_{Posi} , the frequency at the time of the positioning signal is maintained.



Examples of reference positioning as a function of the parameter settings selected:

- The reference point is identified by a signal at digital input IN1D (terminal X11.4).



- The Positioning distance 460 with parameter value 0.000U (default) defines a direct stop of the drive with the deceleration behavior selected in parameter Operation mode 630 and the selected Deceleration (clockwise) 421. If a Positioning distance 460 is set, the positioning is effected at the set deceleration.
- The Signal correction 461 of the signal run time from the measurement point to the frequency inverter is not used if it is set to 0 ms.
- The Load correction 462 can compensate a faulty positioning by the load behavior. By default, this function is deactivated, i.e. set to 0.
- The *Activity after positioning* **463** is defined by operation mode 0 "End positioning".
- The Waiting Time 464 is not considered because operation mode 0 is selected for the parameter Action after positioning 463.
- Parameter Revolutions 470 shows the actual positioning distance and enables direct comparison to the required Positioning distance 460. In the case of deviations, a Signal correction 461 or Load correction 462 can be performed.

7.4 Error and warning behavior

Operation of the frequency inverter with the connected load is monitored continuously. The monitoring functions can be parameterized with the corresponding limit values specifically for the relevant application. If the limits were set below the switch-off limit of the frequency inverter, an error switch-off can be prevented by suitable measures if a warning message is issued.

The warning message can be read via parameter *Warnings* **269** or output via one of the digital control outputs.

7.4.1 Overload Ixt

405 Warning limit short-term 1xt 406 Warning limit long-term 1xt

The permissible load behavior depends on the technical data of the frequency inverters and the ambient conditions.

The selected *Switching frequency* **400** defines the rated current and the available overload for one second or sixty seconds. The *Warning limit short-term Ixt* **405** and *Warning limit long-term Ixt* **406** are to be parameterized accordingly.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
405	Warning limit short-term Ixt	6%	100%	80%
406	Warning limit long-term Ixt	6%	100%	80%

Output signals

Reaching of warning limits is reported via digital signals.

165 - Warning Ixt	The Warning Limit Short-Term Ixt 405 or Warning Limit Long-Term Ixt
7 - Ixt warning	²⁾ 406 has been reached.

¹⁾ For linking to frequency inverter functions.

²⁾ For output via a digital output. Select the signal source for one of the parameters 531, 532, 533, 554. See chapter 7.6.5 "Digital outputs".



7.4.2 Temperature

407 Warning limit heat sink temp.

408 Warning limit inside temp.

The ambient conditions and the energy dissipation at the current operating point result in the frequency inverter heating up. In order to avoid an error switch-off of the frequency inverter, the *Warning limit heat sink temp*. **407** for the heat sink temperature limit and the *Warning limit inside temp*. **408** as an internal temperature limit are to be parameterized. The temperature value at which a warning message is output is calculated from the type-dependent temperature limit minus the adjusted warning limit.

The switch-off limit of the frequency inverter is dependent of the construction size.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
407	Warning limit heat sink temp.	-25 °C	0 °C	-5 °C
408	Warning limit inside temp.	-25 °C	0 °C	-5 °C

The exceeding of the maximum permissible internal temperature is signaled if the sensor for internal temperature or the sensor for the electrolytic capacitor temperature measures the type-specific limit value. For internal temperature and electrolytic capacitor temperature different limits are defined.

Output signals

Reaching of warning limits is reported via digital signals.

<u>166 -</u> 8 -	Heat sink tempera- ture warning	2)	The value "temperature limit minus <i>Warning limit heat sink temp</i> . 407 " was reached.
167 -	Inside temperature	1)	The value "temperature limit minus Warning limit inside temp. 408"
9 -	warning	2)	was reached.
170 -		1)	The value
	Warning over-		 "temperature limit minus Warning limit heat sink temp. 407" or
12 -	temperature	2)	"temperature limit minus Warning limit inside temp. 408"was reached.

¹⁾ For linking to frequency inverter functions.

7.4.3 Controller status

409 Controller-Status Message

Intervention by a controller can be displayed via the operator panel. The selected control methods and the matching monitoring functions prevent a switch-off of the frequency inverter. The intervention of the function changes the operating behavior of the application and can be displayed by the status messages with parameter *Controller status* **275**. The limit values and events which result in the intervention by the corresponding controller are described in the corresponding chapters. The behavior during the intervention of a controller is configured with the parameter *Controller-Status Message* **409**.

Controller-Status Message 409	Function
0 - No Message	The intervention of a controller is not reported. The controllers influencing the operating behavior are displayed in the <i>Controller status</i> 275 parameter.
1 – Warning Status	The limitation by a controller is displayed as a warning by the operator panel.

Chapter 7.6.5.8 "Warning mask" contains a list of controllers and describes further ways for evaluating the controller states.

²⁾ For output via a digital output. Select the signal source for one of the parameters 531, 532, 533, 554. See chapter 7.6.5 "Digital outputs".



7.4.4 Frequency switch-off limit

417 Frequency Switch-off Limit

The maximum permissible output frequency of the frequency inverter can be set to a low frequency value via parameter *Frequency Switch-off Limit* **417**. If this frequency limit is exceeded by the *Stator frequency* **210** or the *Actual frequency* **241**, the frequency inverter is switched off and error signal "F1100" is displayed.

	Parameters	Setting		
No.	Description	Min.	Max.	Fact. sett.
417	Frequency Switch-off Limit	0.00 Hz	999.99 Hz	999.99 Hz

Please comply with the descriptions of parameters *Minimum frequency* **418** and *Maximum frequency* **419** in chapter 7.5.1.1 "Limits".

7.4.5 External error

535 Operation mode ext. error

Parameterization of an external error enables switching off or shutting down several frequency inverters at a time if a fault occurs in the plant or the drive. If an error occurs in a frequency inverter, the error signal can be transmitted via a bus system and the required reaction can be triggered in another frequency inverter. Parameter *External error* **183** can be assigned the logic signal or digital input signal which is to trigger the external error.

Via parameter Operation mode ext. error 535, the response to an external error can be configured.

Operation mode 535	Function
0 - Disabled	No response to external errors.
1 - Error-Switch-Off	The drive is switched off and the error message "F1454 External Error" is output if the logic signal or digital input signal for parameter <i>External Error</i> 183 is present.
2 - Shutdown, Error	The drive is stopped at the current deceleration ramp and the error message "F1454 External Error" is output if the logic signal or digital input signal for parameter <i>External error</i> 183 is present.
3 - Emergency-Stop, Error	The drive is stopped at the set emergency stop ramp and the error message "F1454 External Error" is output if the logic signal or digital input signal for parameter <i>External error</i> 183 is present.

For setting up external warnings parameters *User Warning 1* **1363** and *User Warning 2* **1364** can be used. Check chapter 7.6.5.9 "Warning mask, application" for further details.

7.4.6 Motor temperature

570 Operation Mode Motor Temp.

Automatic shut-down of the frequency inverter or the output of a warning message offers protection against overheating of the motor. For monitoring the motor temperature, a temperature sensor must be connected to multifunction input 2. Parameter *Operation Mode Motor Temp.* **570** must be set according to the connected temperature sensor.

The motor temperature is evaluated via one of the following temperature sensors:

- Thermal contact (bimetal temperature sensor)
- PTC resistor (motor PTC)
- KTY measuring resistor
- Resistor PT1000

Motor temperature measurement enables:

- monitoring of temperature limits via a thermal contact or PTC resistor or
- temperature measurement, temperature monitoring and temperature display via a KTY measuring resistor or a resistor PT1000



	ration Mode Motor p. 570	Function
	Off	Motor temperature monitoring switched off.
1 -	ThermContact, P204: Warning only	Monitoring for temperature limit. A thermal overload is displayed via the operator panel and parameter <i>Warnings</i> 269 . For parameter <i>Thermal contact for P570</i> 204 , the digital input to which the thermal contact is connected must be selected. In the factory setup, multifunction input 2 can be used for connection of a thermal contact (<i>Thermal contact for P570</i> 204 is set to MFI2D). The input signal must be digital. The evaluation (NPN/PNP) of the input signal can be set via parameter <i>Operation mode MFI2</i> 562 .
2 -	ThermContact, P204: Error Switch-Off	Monitoring for temperature limit. The frequency inverter is switched off immediately if the motor is thermally overloaded. The error switch-off is displayed by message F0400. For parameter <i>Thermal contact for P570</i> 204 , the digital input to which the thermal contact is connected must be selected. In the factory setup, multifunction input 2 can be used for connection of a thermal contact (<i>Thermal contact for P570</i> 204 is set to MFI2D). The input signal must be digital. The evaluation (NPN/PNP) of the input signal can be set via parameter <i>Operation mode MFI2</i> 562 .
3 -	ThermContact, P204: Err.Switch-Off 1 min delayed	Monitoring for temperature limit. The frequency inverter is switched off if the motor is thermally overloaded. The error switch-off is displayed by message F0400. The error switch-off is delayed by one minute. For parameter <i>Thermal contact for P570</i> 204 , the digital input to which the thermal contact is connected must be selected. In the factory setup, multifunction input 2 can be used for connection of a thermal contact (<i>Thermal contact for P570</i> 204 is set to MFI2D). The input signal must be digital. The evaluation (NPN/PNP) of the input signal can be set via parameter <i>Operation mode MFI2</i> 562 .
11 -	MPTC, MFI2: Warning only	Monitoring for temperature limit. A thermal overload is displayed via the operator panel and parameter <i>Warnings</i> 269 . Multifunction input 2 can be used as input for monitoring of a temperature value with motor PTC (PTC as per DIN 44081). The input signal must be analog.
12 -	MPTC, MFI2: Error Switch-Off	Monitoring for temperature limit. The frequency inverter is switched off immediately if the motor is thermally overloaded. The error switch-off is displayed by message F0400. Multifunction input 2 can be used as input for monitoring of a temperature value with motor PTC (PTC as per DIN 44081). The input signal must be analog.
13 -	MPTC, MFI2: Err.Switch- Off 1 min delayed	Monitoring for temperature limit. The frequency inverter is switched off if the motor is thermally overloaded. The error switch-off is displayed by message F0400. The error switch-off is delayed by one minute. Multifunction input 2 can be used as input for monitoring of a temperature value with motor PTC (PTC as per DIN 44081). The input signal must be analog.
21 -	KTY, MFI2: Warning only	Temperature measurement. A thermal overload is displayed via the operator panel and parameter <i>Warnings</i> 269 . The warning is displayed as soon as the value of <i>Max. Temp. Motor Winding</i> 617 is reached. Multifunction input 2 can be reached as input for temperature measurement with a KTY measuring resistor (KTY84). The input signal must be analog. Parameter <i>Winding temperature</i> 226 shows the actual value.



Operation Mode Motor Temp. 570	Function
22 - KTY, MFI2: Error Switch- Off	Temperature measurement. The frequency inverter is switched off immediately as soon as the value of <i>Max. Temp. Motor Winding</i> 617 is reached. The error switch-off is displayed by message F0400. Multifunction input 2 can be reached as input for temperature measurement with a KTY measuring resistor (KTY84). The input signal must be analog. Parameter <i>Winding Temperature</i> 226 shows the actual value.
23 - KTY, MFI2: Err.Switch- Off 1 min delayed	Temperature measurement. The frequency inverter is switched off as soon as the value of <i>Max. Temp. Motor Winding</i> 617 is reached. The error switch-off is displayed by message F0400. The error switch-off is delayed by one minute. Multifunction input 2 can be reached as input for temperature measurement with a KTY measuring resistor (KTY84). The input signal must be analog. Parameter <i>Winding Temperature</i> 226 shows the actual value.
31 - PT1000, MFI2: Warning only	Temperature measurement. A thermal overload is displayed via the operator panel and parameter <i>Warnings</i> 269 . The warning is displayed as soon as the value of <i>Max. Temp. Motor Winding</i> 617 is reached. Multifunction input 2 can be reached as input for temperature measurement with a measuring resistor PT1000. The input signal must be analog. Parameter <i>Winding Temperature</i> 226 shows the actual value.
32 - PT1000, MFI2: Error Switch-Off	Temperature measurement. The frequency inverter is switched off immediately as soon as the value of <i>Max. Temp. Motor Winding</i> 617 is reached. The error switch-off is displayed by message F0400. Multifunction input 2 can be reached as input for temperature measurement with a measuring resistor PT1000. The input signal must be analog. Parameter <i>Winding Temperature</i> 226 shows the actual value.
PT1000, MFI2: 33 - Err.Switch-Off 1 min delayed	Temperature measurement. The frequency inverter is switched off as soon as the value of <i>Max. Temp. Motor Winding</i> 617 is reached. The error switch-off is displayed by message F0400. The error switch-off is delayed by one minute. Multifunction input 2 can be reached as input for temperature measurement with a measuring resistor PT1000. The input signal must be analog. Parameter <i>Winding Temperature</i> 226 shows the actual value.

Error Acknowledgment

- Thermal contact or MPTC: An error message can be acknowledged if the sensor does not signal overtemperature anymore.
- KTY or PT1000: An error message can be acknowledged if the motor temperature has dropped below the switch-off threshold by 5°C.

Possibilities of error acknowledgement:

- via operator panel or
- via parameter Error Acknowledgement 103 which is assigned a logic signal or a digital input
 Evaluation of the motor temperature is independent of the controller enable.



If motor temperature monitoring with MPTC, KTY or PT1000 is selected via parameter *Operation Mode Motor Temp.* **570**, multifunction input 2 cannot be used for other functions. In this case, parameters 560 ... 567 of multifunction input 2 don't have any function.





If motor temperature monitoring with thermal contact is selected via parameter *Operation Mode Motor Temp.* **570**, multifunction input 2 can only be set, via parameter *Operation mode MFI2* **562** to "3 - Digital NPN (active: 0 V)" or "4 - Digital PNP (active: 24 V)". In this case, multifunction input 2 cannot be used for controlling other functions.



If another digital input is used for connection of the thermal contact, this input must be selected for parameter *Thermal contact for P570* **204**.



Multifunction input 2 can be used for other functions if the factory setting is changed for parameter *Thermal contact for P570* **204** (i.e. if a digital input is selected, not multifunction input 2).

617 Max. Temp. Motor Winding

Via parameter *Max*. *Temp*. *Motor Winding* **617**, you can set the temperature value above which a warning message is output or an error switch-off of the frequency inverter is effected.

The value of *Max. Temp. Motor Winding* **617** is evaluated if the analog signal of a temperature sensor is connected to multifunction input 2 and one of the following settings is selected for parameter *Operation Mode Motor Temp.* **570**:

- 21 ... 23: KTY
- 31 ... 33: PT1000

	Parameters	Setting		
No.	Description	Min.	Max.	Fact. sett.
617	Max. Temp. Motor Winding	0 °C	200 °C	150 °C

Output signals

Warnings are displayed in parameter *Warnings* **269** and output via digital signals.

68 -			The monitoring function – selected via <i>Operation Mode Motor</i>
10 -	2)	Motortempera- ture warning	Temp. 570 – signals a thermal overload or reaching of the value
17 -		tare marring	Max. Temp. Motor Winding 617.

¹⁾ For linking to frequency inverter functions.

7.4.6.1 Technical demands on measuring resistors

PTC resistor

Multifunction input 2 (terminal X12.4) is designed for connection of a PTC resistor with the following specifications:

Rated response temperature: 90 °C to 160 °C in steps of 10 K

Temperature characteristic: according to DIN 44081

KTY84 measuring resistor

Multifunction input 2 (terminal X12.4) is designed for connection of a KTY84 measuring resistor with the following specifications:


Resistance: $1 \text{ k}\Omega$ at 100 °C ambient temperature

Measuring range: -40 ... 300 °C Temperature coefficient: 0.61%/K

of

²⁾ For output via a digital output. Select the signal source for one of the parameters 531, 532, 533, 554. See chapter 7.6.5 "Digital outputs".

³⁾ For monitoring via parameter *Create Warning Mask* **536**.



KTY resistance R depending on ambient temperature Tamb


Measuring resistor PT1000

Multifunction input 2 is designed for connection of a PT 1000 measuring resistor with the following specifications:

Resistance: 1 $k\Omega$ at 0 $^{\circ}$ C ambient temperature

Measuring range: -40 ... 550 °C

Connection



Operation mode motor temp. **570** =

7.4.7 Phase failure

576 Phase Supervision

If a failure of one of the three motor or mains phases is not noticed, the frequency inverter, the motor and the mechanical drive components may be damaged. In order to prevent these components from being damaged, the phases are monitored for failure. Via parameter *Phase Supervision* **576**, the behavior in case of a phase failure can be set.



Pha	se Supervision 576	Function
10 -	Mains: Error Switch-Off	In the case of a phase failure, the error switch-off takes place after 5 minutes, fault F0703 is displayed. During this time, the warning message A0100 is displayed.
11 -		The phase monitor switches the frequency inverter off:
	Mains & Motor: Error Switch-Off	 immediately with error message F0403 in the case of a motor phase failure
		 after 5 minutes with error message F0703 in the case of a mains phase failure
20 -	Mains: Shutdown	In the case of a mains phase failure, the drive is stopped after 5 minutes, fault F0703 is displayed.
21 -	Mains & Motor: Shutdown	 The drive is switched off: immediately, in the case of a motor phase failure
		 The drive is stopped: after 5 minutes in the case of a mains phase failure

7.4.8 Automatic Error Acknowledgment

578 Allowed No. of Auto-Acknowl. 579 Restart Delay

The automatic error acknowledgment enables acknowledgment of the faults Overcurrent F0507 and Overvoltage F0700 without intervention by an overriding control system or the user. If one of the aforementioned errors occurs, the frequency inverter switches the power semi-conductors off and waits for the time stated with the parameter *Restart Delay* **579**. If the error is acknowledged, the speed of the machine is determined with the quick Search Run function and synchronized to the ro-tating machine. The automatic error acknowledgment makes use of "Quick Synchronization" operation mode, regardless of the *Flying Start Operation Mode* **645**. The information given on this function in chapter 7.3.5 "Flying Start" must be observed.

With parameter *Allowed No. of Auto-Acknowl.* **578**, you can define the number of automatic error acknowledgements which are permitted within 10 minutes.

An acknowledgement repeated above the permissible number within 10 minutes will result in the frequency inverter being switched off.

The errors Overcurrent F0507 and Overvoltage F0700 have separate error acknowledgement counters.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
578	Allowed No. of Auto-Acknowl.	0	20	5
579	Restart Delay	0 ms	1000 ms	20 ms

7.5 Reference Values

7.5.1 Reference frequency channel

475 Reference Frequency Source 1 492 Reference Frequency Source 2

Via the reference frequency channel, you can define how the reference rotary frequency for the motor is to be specified. For each of parameters *Reference Frequency Source 1* **475** and *Reference Frequency Source 2* **492**, you can select a reference value specification option. The selected reference values are added and output as rotary frequency reference value for the motor.

The settings of frequency limits (Parameter *Minimum Frequency* **418** and *Maximum Frequency* **419**) and blocking frequencies (parameter 1st Blocking Frequency **447**, 2nd Blocking Frequency **448**) as well as *Frequency Hysteresis* **449** are considered.





If the same setting is selected for parameter *Reference Frequency Source 1* **475** and *Reference Frequency Source 2* **492**, the reference value is not doubled. In this case the reference value is the single value of the selected reference value source.

Selection of source for reference value:

Pataranae Fragueray Source I 475	Function
Reference Frequency Source 1 475 Reference Frequency Source 2 492	
0 - Zero	Reference value is zero.
1 - Analog Value MFI1A	Multifunction input 1 is the reference value source. Via parameter <i>Operation Mode MFI1</i> 452 , the input must be set up as an analog input (voltage or current). By setting the voltage or current value at multifunction input 1, you can set the output frequency. Factory setting for <i>Reference Frequency Source 1</i> 475 . See chapter 7.6.1 "Multifunction input MFI1".
2 - Analog Value MFI2A	Multifunction input 2 is the reference value source. Via parameter <i>Operation mode MFI2</i> 562 , the input must be set up as an analog input (voltage or current). By setting the voltage or current value at multifunction input 2, you can set the output frequency. See chapter 7.6.2 "Multifunction input MFI2".
3 - Fixed Frequency	The selected fixed frequency is the reference value source. The fixed frequency of the current data set is selected via <i>Fixed frequency changeover 1</i> 66 , <i>Fixed frequency changeover 3</i> 131 . The fixed frequency values can be set in parameters 480 488. See chapter 7.5.1.3 "Fixed frequencies".
4 - Motorpot. via Digital Inputs	Reference value source is the function <i>Frequency motor-poti up</i> 62 and <i>Frequency motorpoti down</i> 63 . The output frequency can be set by digital signals. See chapter 7.5.3 "Motor potentiometer".
5 - Keypad-Motorpot.	The operator panel is the reference value source, with keys ▲ for increasing the frequency and ▼ for reducing the frequency. Factory setting for <i>Reference frequency source 2</i> 492 . See chapter 7.5.3.4.1 "Control via reference frequency channel".
10 - Repetition Frequency	The frequency signal at digital input IN2D is the reference value source. For parameter <i>Operation mode IN2D</i> 496 of the repetition frequency input, "20 - repetition frequency single evaluation" or "21 - repetition frequency double evaluation" must be selected. See chapter 7.6.7.2 "Repetition frequency input".
20 - Fieldbus Reference Value	The reference value is transmitted via a bus system. Profibus : The value of PZD2 is used as reference value. CANopen : The value of object 0x6042 Target Velocity is used as reference value.
30 - Technology Controller	The output of the PID controller is the reference value source. If this source is selected for <i>Reference frequency source 1</i> 475 or <i>Reference frequency source 2</i> 492 , the technology controller is switched on. See chapter 7.9.3 "PID controller (technology controller)"
40 - electr. Gear	The output of the electronic gear is the reference value source. If this source is selected for <i>Reference frequency source 1</i> 475 or <i>Reference frequency source 2</i> 492 , the electronic gear is switched on. See chapter 7.5.4 "Electronic gear".
2501 - PLC Output Frequency 1	Frequency output 1 of a PLC function block is the reference value source. See application manual "PLC".




Reference Frequency Source 1 475 Reference Frequency Source 2 492	
2502 - PLC Output Frequency 2	Frequency output 2 of a PLC function block is the reference value source. See application manual "PLC".

The reference frequency channel can be used in all configurations (parameter *Configuration* **30**).

Block diagram

The block diagram shows the reference frequency specification options.



Lock the reference value facilities of the control panel

If the setting possibility of the reference frequency at the operator panel must be locked:

- For parameter *Reference Frequency Source 1* **475** the setting "5 Keypad-Motorpot." must not be selected and
- for parameter *Reference Frequency Source 2* **492** the setting "5 Keypad-Motorpot." must not be selected.
- Set parameter *Set Password* **27** to prevent the resetting of parameters. Refer to chapter 7.1.3 "Set password".



NOTE

The setting of Parameter *Set Password* **27** only does not lock the control facilities of the keypad. Start, Stop, Change direction of rotation, Poti F and Poti P are still available.

7.5.1.1 Limits

418 Minimum Frequency 419 Maximum Frequency

The area of the output frequency of the frequency inverter and thus the speed setting range are defined by the parameters *Minimum Frequency* **418** and *Maximum Frequency* **419**. The corresponding control methods use the two limit values for scaling and calculating the frequency.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
418	Minimum Frequency	0.00 Hz	999.99 Hz	3.50 Hz
419	Maximum Frequency	0.00 Hz	999.99 Hz	50.00 Hz

The parameters *Minimum Frequency* **418** and *Maximum Frequency* **419** can only be changed while the output stage is inhibited.

719 Slip Frequency

The torque-forming current component and thus the slip frequency of the 3-phase machine depend on the required torque in the case of the field-orientated control methods. The field-orientated control method also includes the parameter *Slip Frequency* **719** to limit the torque in the calculation of the machine model. The rated slip calculated from the rated motor parameters is limited in accordance with the *Slip Frequency* **719** which is parameterized as a percentage.

Parameters			Setting	
No.	Description	Min.	Max.	Fact. sett.
719	Slip Frequency	0%	10000%	330%

7.5.1.2 Positive and negative reference frequencies

493 Operation Mode (reference frequency source)

Via parameter *Operation Mode* **493**, you can define if the reference frequency value set via parameters *Reference Frequency Source 1* **475** and *Reference Frequency Source 2* **492** is to be either positive or negative only or if it can be both positive and negative. You can also output the reference frequency as an inverted value (compared to the selected reference value source).

Operation Mode 493	Function
0 - Off	The reference frequency channel is switched off. The reference
0 011	frequency is 0 Hz.
	The reference frequency can be both positive and negative. The
1 - +/- reference value	values of Reference frequency source 1 475 and Reference fre-
	quency source 2 492 are added up. Factory setting.
	The reference frequency can only be positive. The reference fre-
	quency is limited to the range from 0 Hz to the Maximum frequen-
2 - Positive only	cy 419 . The values of <i>Reference frequency source 1</i> 475 and <i>Ref</i> -
	erence frequency source 2 492 are added up, then the result is
	limited to positive values.
	The reference frequency is inverted (compared to the sign of the
2 Invested	selected reference value source). The values of Reference frequen-
3 - Inverted	cy source 1 475 and Reference frequency source 2 492 are added
	up, then the result is inverted.



7.5.1.3 Fixed frequencies

480 Fixed frequency 1

481 Fixed frequency 2

482 Fixed frequency 3

483 Fixed frequency 4

485 Fixed frequency 5

486 Fixed frequency 6

487 Fixed frequency 7 488 Fixed frequency 8

Via digital logic signals or digital inputs fixed preset reference values can be selected.

The fixed frequencies are reference values for the rotary frequency of the motor. Eight fixed frequencies can be set. The fixed frequencies can be selected via *Fixed Frequency Change-Over 1* **66**, *Fixed Frequency Change-Over 2* **67** and *Fixed Frequency Change-Over 3* **131**. Logic signals or digital inputs must be assigned to the parameters *Fixed Frequency Change-Over 1* **66**, *Fixed Frequency Change-Over 2* **67** and *Fixed Frequency Change-Over 3* **131**.

Via the reference frequency channel (see chapter 7.5.1 "Reference frequency channel"), the fixed frequencies can be selected and linked to other reference value sources. Linking is effected via parameters *Reference Frequency Source 1* **475** and *Reference Frequency Source 2* **492**.

	Parameters		Setting	
No.	Description	Min.	Max.	Fact. sett.
480	Fixed Frequency 1	-999.99 Hz	999.99 Hz	0.00 Hz
481	Fixed Frequency 2	-999.99 Hz	999.99 Hz	10.00 Hz
482	Fixed Frequency 3	-999.99 Hz	999.99 Hz	25.00 Hz
483	Fixed Frequency 4	-999.99 Hz	999.99 Hz	50.00 Hz
485	Fixed Frequency 5	-999.99 Hz	999.99 Hz	5.00 Hz
486	Fixed Frequency 6	-999.99 Hz	999.99 Hz	10.00 Hz
487	Fixed Frequency 7	-999.99 Hz	999.99 Hz	25.00 Hz
488	Fixed Frequency 8	-999.99 Hz	999.99 Hz	50.00 Hz

- Set the required number of fixed frequencies (parameters 480 ... 488).
- For fixed frequency changeover (parameters 66, 67, 131), select digital inputs.
- Select fixed frequencies with signals at digital inputs.



66 Fixed Frequency Change-Over 1 67 Fixed Frequency Change-Over 2 131 Fixed Frequency Change-Over 3

By combining the logic states of the fixed frequency change-over inputs 1, 2 and 3, fixed frequencies 1 through 8 (parameters 480 to 488) can be selected.

	Selection of fixed frequencies					
Fixed Frequency Change-Over 1	Fixed Frequency Change-Over 2	Fixed Frequency Change-Over 3	Active fixed value	Facto settin	,	
66	67	131	ricare fixed value		9	
0	0	0	Fixed frequency 1 480	0	Hz	
1	0	0	Fixed frequency 2 481	10	Hz	
1	1	0	Fixed frequency 3 482	25	Hz	
0	1	0	Fixed frequency 4 483	50	Hz	
0	1	1	Fixed frequency 5 485	5	Hz	
1	1	1	Fixed frequency 6 486	10	Hz	
1	0	1	Fixed frequency 7 487	25	Hz	
0	0	1	Fixed frequency 8 488	50	Hz	

0 = contact open 1 = contact closed

Number of digital inputs	Number of fixed frequencies per data set
1	2
2	4
3	8

Fixed frequency change-over factory settings:

No.	Parameters	Setting
66	Fixed frequency change-over 1	74 – IN4D
67	Fixed frequency change-over 2	7 - Off
131	Fixed frequency change-over 3	7 - Off

If the data set change-Over 1 70 and Data Set Change-Over 2 71, you can preset up to 32 fixed frequencies as reference values.

The fixed frequency changeover can also be controlled via digital signals (instead of digital inputs) by functions of the frequency inverter.

Via parameter *Operation Mode* **493**, you can change the direction of rotation of the motor. See chapter 7.5.1.2 "Positive and negative reference frequencies". The direction of rotation can also be preset with the digital signal sources assigned to the parameters *Start Clockwise* **68** and *Start Anticlockwise* **69**.

Via the reference frequency channel (see chapter 7.5.1 "Reference frequency channel"), the fixed reference values can be selected and linked to other reference value sources.

7.5.1.4 Ramps

420 Acceleration (Clockwise)

421 Deceleration (Clockwise)

422 Acceleration Anticlockwise

423 Deceleration Anticlockwise

The ramps determine how quickly the frequency value is changed if the reference value changes or after a start, stop or brake command. The maximum admissible ramp gradient can be selected according to the application and the current consumption of the motor.



For setting identical frequency ramps for both directions of rotation, the parameterization via the parameters *Acceleration (Clockwise)* **420** and *Deceleration (Clockwise)* **421** is sufficient. The values of the frequency ramps are taken over for *Acceleration Anticlockwise* **422** and *Deceleration Anticlockwise* **423** if these have been parameterized to the factory setting of -0.01 Hz/s.

The parameter value of 0.00 Hz/s for the acceleration blocks the corresponding direction of rotation. A set *Ramp Rise Time* **430** affects the ramps.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
420	Acceleration (Clockwise)	0.00 Hz/s	9999.99 Hz/s	5.00 Hz/s
421	Deceleration (Clockwise)	-0.01 Hz/s ¹⁾	9999.99 Hz/s	5.00 Hz/s
422	Acceleration Anticlockwise	-0.01 Hz/s ²⁾	9999.99 Hz/s	-0.01 Hz/s ²⁾
423	Deceleration Anticlockwise	-0.01 Hz/s ²⁾	9999.99 Hz/s	-0.01 Hz/s ²⁾

¹⁾ Value -0.01 Hz/s means: Acceleration (Clockwise) **420** is applied.

²⁾ Value -0.01 Hz/s means: The ramps of clockwise operation are applied.




The setting 0.00 Hz/s won't accelerate or decelerate the drive due to the limitation of the ramp.

424 Emergency Stop Clockwise 425 Emergency Stop Anticlockwise

The ramps for the *Emergency Stop Clockwise* **424** and *Emergency Stop Anticlockwise* **425** of the drive to be activated via *Operation Mode* **630** for the stopping behavior must be selected according to the application. The non-linear (S-shaped) curve of the ramps is not active in the case of an emergency stop of the drive.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
424	Emergency Stop Clockwise	0.01 Hz/s	9999.99 Hz/s	5.00 Hz/s
425	Emergency Stop Anticlockwise	0.01 Hz/s	9999.99 Hz/s	5.00 Hz/s





426 Maximum Leading

The parameter *Maximum Leading* **426** limits the difference between the output of the ramp and the current actual value of the drive. The set maximum deviation is a dead time for the control system which should be kept as low as possible.

In case the drive is loaded heavily and high acceleration and deceleration values are selected it is possible, that a set controller limit is reached while the drive is accelerated or decelerated. In this case, the drive cannot follow the defined acceleration or deceleration ramps. With *Maximum Leading* **426**, you can limit the maximum leading of the ramp.

Parameters			Setting	
No.	Description	Min.	Max.	Fact. sett.
426	Maximum Leading	0.01 Hz	999.99 Hz	5.00 Hz

Example: Frequency at ramp output = 20 Hz, current actual value of drive = 15 Hz, selected $Maximum\ Leading\ 426$ = 5 Hz

The frequency at the ramp output is increased to 20 Hz only, it is not increased further. The difference (leading) between the frequency value at the ramp output and the current actual frequency of the drive is limited to 5 Hz in this way.

430 Ramp Rise Time


The load occurring in a linear acceleration of the drive is reduced by the adjustable modification speed (S-curve). Via the S-curve, the drive can be accelerated and decelerated more uniformly and load peaks upon the start of the acceleration and deceleration can be avoided. The non-linear curve of the frequency indicates states the time range in which the frequency is to be guided to the set ramp. Setting the ramp rise time increases the acceleration and deceleration times.

The value set for the *Ramp Rise Time* **430** is effective for:

- acceleration and deceleration
- clockwise and anticlockwise operation

If the ramp time is set to 0 ms, the S curve is deactivated.

Parameters			Setting	
No.	Description	Min.	Max.	Fact. sett.
430	Ramp Rise Time	0 ms	10000 ms	0 ms



 $---: Ramp \ rise \ time \ 430 = 0 \ ms$





If the data set is changed during acceleration or deceleration, it is ensured that the S-curve of the previous data set is finished first. Unintentional jumps between different gradients of the S-curve are avoided.

7.5.1.5 Blocking frequencies

447 1st Blocking Frequency 448 2nd Blocking Frequency


449 Frequency Hysteresis

In certain applications, it is necessary to block out reference frequencies. In this way, resonance points of the system as stationary operating points are avoided. The parameters *1st Blocking Frequency* **447**, *2nd Blocking Frequency* **448** and *Frequency Hysteresis* **449** define two resonance points.

A blocking frequency is active if the parameter values of the blocking frequency and the frequency hysteresis are not equal to 0.00 Hz.

The area faded out as a stationary working point by the hysteresis is passed through as quickly as possible according to the ramp set. If the output frequency is limited as a result of the selected control parameter settings, e.g. if the current limit is reached, the hysteresis is passed through with a delay. The behavior of the reference value can be determined from its direction of movement according to the following diagram.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
447	1st Blocking Frequency	0.00 Hz	999.99 Hz	0.00 Hz
448	2nd Blocking Frequency	0.00 Hz	999.99 Hz	0.00 Hz
449	Frequency Hysteresis	0.00 Hz	100.00 Hz	0.00 Hz





7.5.1.6 JOG frequency

81 JOG Start 489 JOG Frequency

The drive rotates at a preset frequency when the JOG function is started. The rotary frequency can be set via the parameter *JOG Frequency* **489**.

The JOG function can be started:

- Via the button "RUN" on the operator panel. The "JOG" menu must be selected.
- Via parameter JOG Start 81. The parameter must be assigned a logic signal or a digital input.

Preconditions for start of JOG function:

- Enable via digital inputs STOA and STOB must be set.
- Signals for parameters Start Clockwise 68 and Start Anticlockwise 69 must not be set.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
489	JOG Frequency	-999.99 Hz	999.99 Hz	5.00 Hz

Positive values of *JOG Frequency* **489** effect clockwise rotation, negative values effect anticlockwise rotation.

JOG Start 81	Function	
Selection of signal source	The selected signal source starts the JOG function. The drive is accelerated to the value of <i>JOG Frequency</i> 489 .	

Acceleration and deceleration

If enable is set and the JOG function is started, the drive is accelerated at the set frequency ramps to the value of *JOG Frequency* **489**.

If the signal *JOG Start* **81** is reset (or the button "RUN" is released), the drive is decelerated at the set frequency ramps until it comes to a standstill.

Limit

The output frequency is limited to the value of *Maximum Frequency* **419**. There is no limitation to the value of *Minimum Frequency* **418**. Blocking frequencies (parameters 447 to 449) are not considered.



Controls via *JOG Start* **81** and button "RUN" in "JOG" menu may be used at the same time.

If a start command is issued during JOG operation (Parameter *Start Clockwise* **68** or *Start Anticlockwise* **69**), the frequency inverter returns to normal operation mode. If the start command is reset, the frequency inverter returns to JOG operation again.

7.5.2 Reference percentage channel

476 Reference Percentage Source 1

494 Reference Percentage Source 2

The reference percentage channel combines various signal sources for definition of the reference figures. The percentage scaling facilitates integration into the application and processing of process parameters. Reference percentages may be used, for example, for setting reference values for the PID controller (technology controller) of torques.

For each of parameters *Reference Percentage Source 1* **476** and *Reference Percentage Source 2* **494**, you can select a reference value source. The selected reference values are added.

Percentage value limit settings (Parameter *Minimum Reference Percentage* **518** and *Maximum Reference Percentage* **519**) are considered.





If the same setting is selected for parameter *Reference Percentage Source 1* **476** and *Reference Percentage Source 2* **494**, the reference value is not doubled. In this case the reference value is the single value of the selected reference value source.

Selection of source for reference value:


Reference Percentage Source 1 476 Reference Percentage Source 2 494	Function
0 - Zero	Reference value is zero.
1 - Analog Value MFI1A	Multifunction input 1 is the reference value source (terminal X12.3). Via <i>Operation mode MFII</i> 452 , the input must be set up as an analog input (voltage or current). Factory setting for <i>Reference percentage source 1</i> 476 . See chapter 7.6.1 "Multifunction input MFI1".
2 - Analog Value MFI2A	Multifunction input 2 is the reference value source (terminal X12.4). Via <i>Operation mode MFI2</i> 562 , the input must be set up as an analog input (voltage or current). See chapter 7.6.2 "Multifunction input MFI2".
3 - Fixed Percentage	The selected fixed percentage is the reference value source. The fixed percentage of the current data set is selected via <i>Fixed percentage value changeover 1</i> 75 and <i>Fixed percentage value changeover 2</i> 76 . See chapter 7.5.2 "Fixed percentages".
4 - Motorpot. via Digital Inputs	Reference value source is the function <i>Percentage motor-poti up</i> 72 and <i>Percentage motorpoti down</i> 73 . See chapter 7.5.3 "Motor potentiometer".
5 - Keypad-Motorpot.	The operator panel is the reference value source, with keys ▲ for increasing the percentage and ▼ for reducing the percentage. Factory setting for <i>Reference percentage source 2</i> 494 . See chapter 7.5.3.4.2 "Control via reference percentage channel".
10 - Repetition Percentage Value	Digital input IN2D (terminal X11.5) which is set as PWM input or the pulse train input are used as the reference value source. PWM input: For parameter <i>Operation mode IN2D</i> 496 , select setting "10 - PWM input 0% – 100%" or "11 - PWM input -100% – 100%". Pulse train input: For parameter <i>Operation mode IN2D</i> 496 , select setting "30 - pulse train". See chapter 7.6.7 "Input PWM/repetition frequency/pulse train".
20 - Fieldbus Percentage Value	The reference value is transmitted via a bus system. The field bus must write the value in format xxx.xx % into parameter 524 , from which the value is then used.
95 - Obj 0x6071 Target Torque	The torque reference value for torque control is transmitted via CANopen bus system. The signal source contains the value of CANopen object 0x6071. Refer to the communication manual CANopen.
2521 - PLC Output Percentage 1	Percentage output 1 of a PLC-function is the reference value source. See application manual "PLC".
2522 - PLC Output Percentage 2	Percentage output 2 of a PLC-function is the reference value source. See application manual "PLC".


The reference percentage channel can be used in all configurations (parameter *Configuration* **30**).



Block diagram

The block diagram shows the reference percentage setting options.





Lock the control possibilities of the control panel

If the setting possibility of the reference percentage at the operator panel must be locked:

- For parameter Reference Percentage Source 1 476 the setting "5 Keypad-Motorpot." must not be selected and
- for parameter *Reference Percentage Source 2* **494** the setting "5 Keypad-Motorpot." must not be selected.
- Set parameter *Set Password* **27** to prevent the resetting of parameters. Refer to chapter 7.1.3 "Set password".

NOTE

The setting of Parameter *Set Password* **27** only does not lock the control facilities of the keypad. Start, Stop, Change direction of rotation, Poti F and Poti P are still available.



7.5.2.1 Limits

518 Minimum Reference Percentage 519 Maximum Reference Percentage

The setting range of the percentages is defined by the parameters *Minimum Reference Percentage* **518** and *Maximum Reference Percentage* **519**. The relevant control methods use the two limit values for scaling and calculating the frequency.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
518	Minimum Reference Percentage	0.00%	300.00%	0.00%
519	Maximum Reference Percentage	0.00%	300.00%	100.00%

7.5.2.2 Positive and negative reference percentages

495 Operation Mode (reference percentage source)

Via parameter *Operation Mode* **495**, you can define if the reference value set via parameters *Reference Percentage Source 1* **476** and *Reference Percentage Source 2* **494** is to be either positive or negative only or if it can be both positive and negative. You can also output the reference percentage as an inverted value (compared to the selected reference value source).

Operation mode 495	Function
0 - Off	Reference percentage channel is switched off. Reference percentage is 0%.
1 - +/- reference value	The reference percentage can be both positive and negative. The values of <i>Reference Percentage Source 1</i> 476 and <i>Reference Percentage Source 2</i> 494 are added up. Factory setting .
2 - Positive only	The reference percentage can only be positive. The reference percentage is limited to the range from 0% to the <i>Maximum Reference Percentage</i> 519 . The values of <i>Reference Percentage Source 1</i> 476 and <i>Reference Percentage Source</i> 2 494 are added up, then the result is limited to positive values.
3 - Inverted	The reference percentage is inverted (compared to the sign of the selected reference value source). The values of <i>Reference Percentage Source 1</i> 476 and <i>Reference Percentage Source 2</i> 494 are added up, then the result is inverted.

The inversion of the reference percentage by means of signal start-anticlockwise or operator panel is only possible if the reference percentage is used as torque reference. Use parameter n-/T-Control Change-Over **164** for switching-on the torque control.

7.5.2.3 Fixed percentages

520 Fixed Percentage 1

521 Fixed Percentage 2

522 Fixed Percentage 3

523 Fixed Percentage 4

Via digital logic signals or digital inputs fixed preset reference values can be selected.

The fixed percentages define reference values. Four fixed percentages can be set. The fixed percentages can be selected via *Fixed Percent Change-Over 1* **75** and *Fixed Percent Change-Over 2* **76**. Logic signals or digital inputs must be assigned to the parameters *Fixed Percent Change-Over 1* **75** and *Fixed Percent Change-Over 2* **76**.

Via the reference percentage channel (see chapter 7.5.2 "Reference percentage channel"), the fixed percentages can be selected and linked to other reference value sources. Linking is effected via parameters *Reference Percentage Source 1* **476** and *Reference Percentage Source 2* **494**.



Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
520	Fixed Percentage 1	-300.00%	300.00%	0.00%
521	Fixed Percentage 2	-300.00%	300.00%	20.00%
522	Fixed Percentage 3	-300.00%	300.00%	50.00%
523	Fixed Percentage 4	-300.00%	300.00%	100.00%

- Set the required number of fixed percentages (parameters 520 ... 523).
- For fixed percentage changeover (parameters 75, 76, 131), select digital inputs.
- Select fixed percentages with signals at digital inputs.

75 Fixed Percent Change-Over 1 76 Fixed Percent Change-Over 2

By combining the logic states of the fixed percentage changeover modes 1 and 2, fixed percentages 1 through 4 can be selected:

Fixed percentage control					
Fixed Percent	Fixed Percent	Active fixed value			
Change-Over 1 75	Change-Over 2 76	Active fixed value			
0	0	Fixed Percentage 1 520			
1	0	Fixed Percentage 2 521			
1	1	Fixed Percentage 3 522			
0	1	Fixed Percentage 4 523			

0 = contact open 1 = contact closed

Number of digital inputs	Number of fixed percentage values per data set	
1	2	
2	4	

If the data set change-Over 1 70 and Data Set Change-Over 2 71, you can preset up to 16 fixed percentages as reference values.

The fixed percentage changeover can also be controlled via digital signals, instead of digital inputs, by functions of the frequency inverter.

Via parameter *Operation Mode* **495**, you can change the direction of rotation of the motor. See chapter 7.5.2.2 "Positive and negative reference percentages". The direction of rotation can also be preset with the digital signal sources assigned to the parameters *Start clockwise* **68** and *Start anti-clockwise* **69**.

Via the reference percentage channel (see chapter 7.5.2 "Reference percentage channel"), the fixed reference values can be selected and linked to other reference value sources.

7.5.2.4 Ramps

477 Gradient Percentage Ramp

The percentage value ramps scale the change of the reference value (in percent) for the corresponding input function. The acceleration and deceleration of the drive are parameterized via the frequency ramps.

The behavior *Gradient Percentage Ramp* **477** corresponds to a function which takes the time behavior of the drive system into account. If the parameter is set to 0 %/s, this function is deactivated and a direct reference value modification for the following function is obtained.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
477	Gradient Percentage Ramp	0 %/s	60000 %/s	10 %/s



7.5.3 Motor potentiometer

The reference speed (or the percentage reference value) of the drive can be set via digital control signals or with the operator panel:

- Digital control signals: Function "Motorpoti via digital inputs"
- Operator panel: Function "Keypad motorpoti"

The functions "Motorpoti via digital inputs" and "Keypad motorpoti" can be selected via the following parameters.

Via the reference frequency channel:

- Reference Frequency Source 1 475
- Reference Frequency Source 2 492

Via the reference percentage channel:

- Reference Percentage Source 1 476
- Reference Percentage Source 2 494



The functions "Motorpoti via digital inputs" and "Keypad motorpoti" (control via operator panel) can be selected at the same time. To that end, one of the functions must be selected for *Reference Frequency Source 1* **475** and the other function for *Reference Frequency Source 2* **492**. Then the reference value can be changed by both keypad and digital inputs.

7.5.3.1 Operation modes of motor potentiometer

474 Operation Mode (motorpoti)

Operation Mode **474** of the functions "Motorpoti via digital inputs" and "Keypad motorpoti" defines the behavior of the function at different operating points of the frequency inverter. When the drive starts, it can accelerate to the last reference value set. Upon dataset changeover, the set reference value can be taken over.

Operation Mode 474	Function
0 - Not Latching	The drive accelerates to the set minimum reference value upon each start. Factory setting .
1 - Latching	When started, the motor accelerates to the reference value selected before the switch-off. The reference value is also stored when the device is switched off.
2 - Taking Over	Use this operation mode for dataset changeover of the reference value channel. The current reference value is used when the motorpoti function is activated.
3 - Taking Over and Latching	This operation mode combines the operation modes 1 and 2.

7.5.3.2 Ramp of motor potentiometer

473 Ramp Frequency-Motorpoti

The speed of the modification of the reference value (ramp) can be set via parameter *Ramp Frequency-Motorpoti* **473**. The ramp is used in the following controls with the reference frequency channel:

- Motorpoti via digital inputs
- Keypad motorpoti (control via operator panel)

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
473	Ramp Frequency-Motorpoti	0.00 Hz/s	999.99 Hz/s	2.00 Hz/s



As a maximum, the acceleration and deceleration of the motorpoti function can only reach the values of the frequency ramps (Parameters 420 to 423), even if *Ramp Frequency-Motorpoti* **473** is set to a higher value.

509 Ramp Percentage-Motorpoti

The speed of the modification of the reference value (ramp) can be set via parameter *Ramp Percentage-Motorpoti* **509**. The ramp is used in the following controls with the reference percentage channel:

- Motorpoti via digital inputs
- Keypad motorpoti (control via operator panel)

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
509	Ramp Percentage-Motorpoti	0.00 %/s	600.00 %/s	10.00 %/s

As a maximum, the speed of the reference value change reaches the value of *Gradient Percentage Ramp* **477**, even if *Ramp Percentage-Motorpoti* **509** is set to a higher value.

7.5.3.3 Motor potentiometer via digital inputs

For the parameterization of the control of the motor potentiometer via digital inputs, it has to be checked if the motor potentiometer is used as frequency reference value or percentage reference value.

7.5.3.3.1 Control via reference frequency channel

62 Frequency Motorpoti Up

63 Frequency Motorpoti Down

The reference frequency of the drive can be set via digital control signals.

Via digital control inputs, the function "Motorpoti up" or "Motorpoti down" is triggered. Logic signals or digital inputs must be assigned to the parameters *Frequency Motorpoti Up* **62** or *Frequency Motorpoti Down* **63**.

- Command "Frequency motorpoti up": The reference frequency increases at the set value of Ramp Frequency-Motorpoti 473.
- Command "Frequency motorpoti down": The reference frequency decreases at the set value of *Ramp Frequency-Motorpoti* **473**.

Motor potentiomet	ter via digital inputs	Function
Frequency Motorpoti	Frequency Motorpoti	
<i>Up</i> 62	<i>Down</i> 63	
0	0	The reference frequency does not change.
1	0	The reference frequency increases at the set ramp.
0	1	The reference frequency decreases at the set ramp.
1	1	The reference frequency is reset to the value of <i>Minimum Frequency</i> 418 . If another reference frequency source is selected via parameter <i>Reference Frequency Source 1</i> 475 or <i>Reference Frequency Source 2</i> 492 , the reference frequency is reset to the value of this source.

0 = contact open 1 = contact closed



A WARNING



If a negative reference value is set, the drive is decelerated with command "Frequency motorpoti up". The reference value is changed in positive direction.

Limit

The reference values are limited via the parameters *Minimum Frequency* **418** and *Maximum Frequency* **419**.

Direction of rotation reversal

If parameter *Minimum Frequency* **418** is set to zero, the direction of rotation of the drive can be reversed via the motorpoti function.

"Motorpotentiometer via digital inputs" as reference value

The function "Motorpotentiometer via digital inputs" can be selected via the following parameters:

- Reference Frequency Source 1 475
- Reference Frequency Source 2 **492**

See chapter 7.5.1 "Reference frequency channel".

Frequency setting using the motorpoti function can be used for adjustable varying speed or for speed control. In the case of a torque control (Parameter n-/T-Control Change-Over **164**), this function is switched off and a percentage setting option via the motorpoti function is available.

Chapter 7.6.6.1 "List of control signals" contains a table summarizing the available signal sources for parameters *Frequency Motorpoti Up* **62** and *Frequency Motorpoti Down* **63**.

Addition of reference values

If the reference value of the motorpoti function is added to another reference value, (via *Reference Frequency Source 2* **475** plus *Reference Frequency Source 2* **492**):

- If the value of Maximum Frequency 419 is reached and the other reference value is increased, the
 output value of the motorpoti function is reduced. It is reduced, so that the sum of both reference
 values is equal to the maximum frequency.
- If the value of *Minimum Frequency* 418 is reached and the other reference value is reduced, the
 output value of the motorpoti function is increased. It is increased, so that the sum of both reference values is equal to the minimum frequency.
- In the settings for Operation Mode 493 = "1 (+/-reference value)" or "3 inverted", the point of reversal of direction of rotation can be shifted by the output value of the motorpoti function. The drive changes its direction of rotation if the total of the two reference values changes the sign.

7.5.3.3.2 Control via reference percentage channel

72 Percent Motorpoti Up

73 Percent Motorpoti Down

The reference percentage can be set via digital control signals.

Via digital control inputs, the function "Motorpoti up" or "Motorpoti down" is triggered. Parameters *Percent Motorpoti Up* **72** or *Percent Motorpoti Down* **73** must be assigned logic signals or digital inputs.

- Command "Up": The reference percentage increases at the set value of Ramp Percentage-Motorpoti 509.
- Command "Down": The reference percentage decreases at the set value of *Ramp Percentage-Motorpoti* **509**.



Motor potentiomet	ter via digital inputs	Function
Percent Motorpoti	Percent Motorpoti	
<i>Up</i> 72	<i>Down</i> 73	
0	0	The reference percentage does not change.
1	0	The reference percentage increases at the set ramp.
0	1	The reference percentage decreases at the set ramp.
1	1	The reference percentage is reset to the value of <i>Minimum Reference Percentage</i> 518 . If another reference percentage source is selected via parameter <i>Reference Percentage Source 1</i> 476 or <i>Reference Percentage Source 2</i> 494 , the reference frequency is reset to the value of this source.

0 = contact open

1 = contact closed



⚠ WARNING

If a negative reference value is set, the drive is decelerated with command "Percentage motorpoti up". The reference value is changed in positive direction.

I imit

The reference values are limited via parameters *Minimum Reference Percentage* **518** and *Maximum Reference Percentage* **519**.

Direction of rotation reversal

If parameter *Minimum Reference Percentage* **518** is set to zero, the direction of rotation of the drive can be reversed via the motorpoti function.

"Motorpotentiometer via digital inputs" as reference value

The function "Motorpotentiometer via digital inputs" can be selected via the following parameters:

- Reference Percentage Source 1 476
- Reference Percentage Source 2 494

See chapter 7.5.2 "Reference percentage channel".

Chapter 7.6.6.1 "List of control signals" contains a table summarizing the available signal sources for parameters *Percent Motorpoti Up* **72** and *Percent Motorpoti Down* **73**.

Addition of reference values

If the reference value of the motorpoti function is added to another reference value, (via *Reference Percentage Source 1* **476** plus *Reference Percentage Source 2* **494**):

- If the value of Maximum Reference Percentage 519 is reached and the other reference value is
 increased, the output value of the motorpoti function is reduced. It is reduced, so that the sum of
 both reference values is equal to the maximum reference percentage value.
- If the value of *Minimum Reference Percentage* 518 is reached and the other reference value is reduced, the output value of the motorpoti function is increased. It is increased, so that the sum of both reference values is equal to the minimum reference percentage value.
- In the settings for Operation Mode 495 = "1 (+/-reference value)" or "3 inverted", the point of reversal of direction of rotation can be shifted by the output value of the motorpoti function. The drive changes its direction of rotation if the total of the two reference values changes the sign.



7.5.3.4 Keypad motorpoti: Control via operator panel

For the parameterization of the control of the motor potentiometer via operator panel, it has to be checked if the motor potentiometer is used as frequency reference value or percentage reference value.



Depending on the parameter settings and how the function is used, it can happen that the first actuation of the key doesn't cause a visible reaction. In this case the first actuation activates the function.

7.5.3.4.1 Control via reference frequency channel

The reference frequency of the drive can be set via the operator panel in menu "Local"/"Poti F".

The reference frequency is increased or decreased via the arrow buttons.

- Button ▲: The reference frequency increases at the set value of Ramp Frequency-Motorpoti 473.
- Button ▼: The reference frequency decreases at the set value of *Ramp Frequency-Motorpoti* **473**.
- Button ▲ pressed briefly: The reference frequency is increased by 0.1 Hz each time the button is pressed.
- Button ▼ pressed briefly: The reference frequency is reduced by 0.1 Hz each time the button is pressed.

Press the buttons briefly to fine-tune the reference frequency.

Addressing			
	l motor ometer	Function	
_	ı	The reference frequency does not change.	
•	ı	The reference frequency increases at the set ramp. Pressed briefly: Reference frequency increases by 0.1 Hz.	
-	•	The reference frequency decreases at the set ramp. Pressed briefly: Reference frequency decreases by 0.1 Hz.	
▲ + ▼ The reference frequency is reset to its initial value.		The reference frequency is reset to its initial value.	

⚠ WARNING

If a negative reference value is set, the drive is accelerated by pressing the button ∇ . The reference value is increased in negative direction.

Limit

The reference values are limited via parameters *Minimum Frequency* **418** and *Maximum Frequency* **419**.

Direction of rotation reversal

If parameter *Minimum Frequency* **418** is set to zero, the direction of rotation of the drive can be reversed via the motorpoti function.

NOTE

In order to be able to select menu "Poti F" on the operator panel, *Reference Frequency Source 1* **475** or *Reference Frequency Source 2* **492** must be set to "5 - Keypad-Motorpot.". By default, *Reference Frequency Source 2* **492** is set to "5 - Keypad-Motorpot.".



Keypad motorpoti as reference value

The function "Keypad motorpoti" can be selected via the following parameters:

- Reference Frequency Source 1 475
- Reference Frequency Source 2 492

See chapter 7.5.1 "Reference frequency channel".

If you leave menu "Poti F", the drive cannot be controlled via the operator panel and remains in the previous status.

For starting, stopping and reversing the direction of rotation of the drive via the operator panel, parameter *Local/Remote* **412** must be set appropriately (Selection "3 - Control via Keypad" or "4 - Control via Keypad+Cont."). The factory settings enable control via the operator panel and via digital inputs. See chapter 7.3.1 "Control".

Frequency setting using the motorpoti function can be used in speed actuated or speed controlled control methods. In the case of a torque control, this function is switched off and a percentage setting option via the motorpoti function is available.

Addition of reference values

If the reference value of the motorpoti function is added to another reference value, (via *Reference Frequency Source 2* **475** plus *Reference Frequency Source 2* **492**):

- If the value of Maximum Frequency 419 is reached and the other reference value is increased, the
 output value of the motorpoti function is reduced. It is reduced, so that the sum of both reference
 values is equal to the maximum frequency.
- If the value of *Minimum Frequency* 418 is reached and the other reference value is reduced, the output value of the motorpoti function is increased. It is increased, so that the sum of both reference values is equal to the minimum frequency.
- In the settings for Operation Mode 493 = "1 (+/-reference)" or "3 inverted", the point of reversal of direction of rotation can be shifted by the output value of the motorpoti function. The drive changes its direction of rotation if the total of the two reference values changes the sign.

Lock the control possibilities of the control panel

If drive start and stop and the change of direction of rotation at the operator panel must be locked:

- For parameter *Local/Remote* **412** select a value that is different from 3 or 4.
- Set parameter *Set Password* **27** to prevent the resetting of the parameter. Refer to chapter 7.1.3 "Set password".

7.5.3.4.2 Control via reference percentage channel

The reference percentage of the drive can be set via the operator panel in menu "Local"/"Poti P".

The reference percentage is increased or decreased via the arrow buttons.

- Button ▲: The reference percentage increases at the set value of Ramp Percentage-Motorpoti 509.
- Button ▼: The reference percentage decreases at the set value of Ramp Percentage-Motorpoti 509.
- Button ▲ pressed briefly: The reference percentage is increased by 0.1% each time the button is pressed.
- Button ▼ pressed briefly: The reference percentage is reduced by 0.1% each time the button is pressed.

Press the buttons briefly to fine-tune the reference percentage.



Addressing		
Keypad motor potentiometer Function		Function
_	ı	The reference percentage does not change.
A	ı	The reference percentage increases at the set ramp. Pressed briefly: Reference percentage increases by 0.1%.
_	▼	The reference percentage decreases at the set ramp. Pressed briefly: Reference percentage decreases by 0.1%.
A -	▲ + ▼ The reference percentage is reset to its initial value.	

⚠ WARNING

If a negative reference value is set, the drive is accelerated by pressing the button ▼.

Limit

The reference values are limited via parameters *Minimum Reference Percentage* **518** and *Maximum Reference Percentage* **519**.

Direction of rotation reversal

If parameter *Minimum Reference Percentage* **518** is set to zero, the direction of rotation of the drive can be reversed via the motorpoti function.

Note

In order to be able to select menu "Poti P" on the operator panel, *Reference Percentage Source 1* **476** or *Reference Percentage Source 2* **494** must be set to "5 - Keypad-Motorpot.". By default, *Reference Percentage Source 2* **494** is set to "5 - Keypad-Motorpot".

Keypad motorpoti as reference value

The function "Keypad motorpoti" can be selected via the following parameters:

- Reference Percentage Source 1 476
- Reference Percentage Source 2 494

See chapter 7.5.2 "Reference percentage channel".

If you leave menu "Poti P", the drive cannot be controlled via the operator panel and remains in the previous status.

For starting, stopping and reversing the direction of rotation of the drive via the operator panel, parameter *Local/Remote* **412** must be set appropriately (Selection "3 - Control via Keypad" or "4 - Control via Keypad+Cont."). The factory settings enable control via the operator panel and via digital inputs. See chapter 7.3.1 "Control".

Addition of reference values

If the reference value of the motorpoti function is added to another reference value, (via *Reference Percentage Source 1* **476** plus *Reference Percentage Source 2* **494**):

- If the value of Maximum Reference Percentage 519 is reached and the other reference value is increased, the output value of the motorpoti function is reduced. It is reduced, so that the sum of both reference values is equal to the maximum reference percentage value.
- If the value of Minimum Reference Percentage 518 is reached and the other reference value is reduced, the output value of the motorpoti function is increased. It is increased, so that the sum of both reference values is equal to the minimum reference percentage value.
- In the settings for Operation Mode 495 = "1 (+/-reference)" or "3 inverted", the point of reversal of direction of rotation can be shifted by the output value of the motorpoti function. The drive changes its direction of rotation if the total of the two reference values changes the sign.



Lock the control possibilities of the control panel

If drive start and stop and the change of direction of rotation at the operator panel must be locked:

- For parameter Local/Remote 412 select a value that is different from 3 or 4.
- Set parameter *Set Password* **27** to prevent the resetting of the parameter. Refer to chapter 7.1.3 "Set password".

7.5.4 Electronic gear

Starting the electronic gear: Set one of the following parameters.

Parameters Reference Frequency Source 1 475	Factory setting 1 - Analog Value MFI1A	Set 40 - el. Gear
or		
Reference Frequency Source 2 492	5 - Keypad-Motorpot.	40 - el. Gear

The electronic gear enables the synchronization of drives without mechanical transmission elements such as shafts or clutches. The reference value for the slave drive is the repetition frequency determined by the master drive. This value can be multiplied by a gear factor. The transmission from the master drive to the slave drive is done via a repetition frequency signal or via system bus.

The gear factor can be set permanently or varied during operation via freely configurable digital and analog signal sources through the percentage reference channel.

125 Source Master Reference

On the slave drive, the reference value for the electronic gear must be selected via parameter *Source Master Reference* **125**. For example, "288 - Repetition Frequency Input" must be selected as the reference value source if the reference value is defined as a repetition frequency via digital input IN2D. In this case, *Operation Mode IN2D* **496** must be set to "20 - RF Single Evaluation" or "21 - RF Double Evaluation" (RF: Repetition Frequency).

If a system bus interface is used, the reference value can be defined via the system bus. Set parameter *Source Master Reference* **125** according to system bus PDO which receives the reference value.

7.5.4.1 Scope of function

- Electronic gear
- Reference value defined via repetition frequency input or system bus
- Gear factor, numerator and denominator can be set separately
- Gear factor can be scaled during the operation
- Offset frequencies can be added depending on digital signals



The system bus transmission of the repetition frequency value from the master drive to the slave drive is effected via the system bus interface at terminals X12.5 and X12.6 or via an optional communication module CM-CAN.

7.5.4.2 Operation modes of electronic gear

689 Operation Mode (electronic gear)


Via parameter *Operation Mode* **689** for the electronic gear, you can determine if the gear factor is to be set permanently or to be scaled via a signal source, e.g. an analog input signal at the slave drive. The repetition frequency of the master drive is multiplied by the gear factor.

Via parameter *Reference Frequency Source 1* **475** or *Reference Frequency Source 2* **492**, the output value of the electronic gear must be selected as the source in the reference frequency channel.



Operation Mode 689	Function
0 - Off	The electronic gear is deactivated. Factory setting .
P. 685 Numera- 1 - tor/P. 686 Denom- inator	The repetition frequency value specified via the repetition frequency input is multiplied by the gear factor. This is the reference frequency for the slave drive. The gear factor is calculated from the values of parameters <i>Gear Factor Numerator</i> 685 and <i>Gear Factor Denominator</i> 686 .
Analog Numera- 2 - tor/P. 686 Denom- inator	The repetition frequency value specified via the repetition frequency input is multiplied by the gear factor. This is the reference frequency for the slave drive. The numerator of the gear factor is scaled using the <i>Reference Percentage Source 1</i> 476 . The denominator of the gear factor is the value set in parameter <i>Gear Factor Denominator</i> 686 .
P. 685 Numera- 3 - tor/Analog De- nominator	The repetition frequency value specified via the repetition frequency input is multiplied by the gear factor. This is the reference frequency for the slave drive. The numerator of the gear factor is the value set in parameter <i>Gear Factor Numerator</i> 685 . The denominator of the gear factor is scaled using the <i>Reference Percentage Source</i> 1 476 .

Block diagram of electronic gear:





Setting of the reference percentage via parameters *Reference Percentage Source 1* **476** and *Reference Percentage Source 2* **494** is described in chapter 7.5.2 "Reference percentage channel".

7.5.4.3 Gear factor

The gear factor can be set permanently or scaled via the *Reference Percentage Source* **476** during operation. Scaling during operation can be effected via an analog voltage signal at a multifunction input. The multifunction input must be set up as an analog input (multifunction input at terminal X12.3: parameter *Operation Mode MFII* **452**, multifunction input at terminal X12.4: parameter *Operation Mode MFI2* **562**).

Setting of the gear factor enables the realization of applications which require an adjustment of the transmission ratio during operations, e.g. winding machines.

7.5.4.3.1 Setting a fixed gear factor

685 Gear Factor Numerator 686 Gear Factor Denominator

Via parameters *Gear Factor Numerator* **685** and *Gear Factor Denominator* **686**, the gear factor is set permanently at the frequency inverter of the slave drive.

Gear factor =
$$\frac{Gear\ Factor\ Numerator\ \mathbf{685}}{Gear\ Factor\ Denominator\ \mathbf{686}}$$

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
685	Gear Factor Numerator	-300.00	300.00	1.00
686	Gear Factor Denominator	0.01	300.00	1.00

7.5.4.3.2 Setting a variable gear factor

687 Analog factor at 100% 688 Analog factor at 0%

With parameters *Analog factor at 100%* **687** and *Analog factor at 0%* **688**, the range of the gear factor is scaled. For parameter *Operation Mode* **689**, setting "2 - (Analog Numerator/P. 686 Denominator)" or "3 - (P. 685 Numerator/Analog Denominator)" must be selected. The scaling is done via the *Reference Percentage Source 1* **476** and *Reference Percentage Source 2* **494** via which the signal sources for determining the reference value are selected. With the signal source selected, e.g. an analog signal at a multifunction input, the gear factor can be changed during operation.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
687	Analog factor at 100%	0.00	100.00	1.20
688	Analog factor at 0%	0.00	100.00	0.80

For a block diagram of the electronic gear, refer to chapter 7.5.4.2 "Operation modes of electronic gear".

Example:


In an application, a slave drive is to follow a master drive, with the speed of the slave having to be increased continuously without changing the speed specified by the master. The gear factor control is to be done using an analog voltage signal (0...10 V).



Configuration example:

- Via parameter *Operation Mode* **689**, set operation mode "2 (Analog Numerator/P. 686 Denominator)" for the electronic gear for a change of the gear factor by the numerator.
- Set the minimum and maximum limit for the numerator value via parameters *Analog factor at 100%* **687** and *Analog factor at 0%* **688**.
- Set the *Gear Factor Denominator* **686** to the required value.
- Set multifunction input MFI1 as an analog voltage input by adjusting *Operation Mode MFI1* **452** to "1 Voltage 0...10 V".
- For the Reference Percentage Source 1 476, select operation mode "1 Analog Value MFI1A".

In this example, the default settings for $Analog\ factor\ at\ 100\%\ 687$ and $Analog\ factor\ at\ 0\%\ 688$, an adjusted gear factor denominator of 2 and a reference percentage of 75% will result in a gear factor numerator of 1.1 and a reference frequency for the Slave of 10 Hz * 1,1 / 2 = 5.5 Hz.



7.5.4.4 Offset

Via the parameters *Reference Frequency Source 2* **492**, you can select frequencies as an offset which are added to the reference frequency.

Adding a fixed frequency to the reference frequency:

- Set parameter Reference Frequency Source 2 **492** to "3 Fixed Frequency".
- In one of parameters 480 ... 488 (fixed frequencies) set a frequency value.
- Select the fixed frequency of the set parameter via parameters 66, 67 and 131 (fixed frequency changeover).

See chapter 7.5.1.3 "Fixed frequencies".

The frequency for the offset can be set via the operator panel if *Reference Frequency Source 2* **492** is set to "5 - Keypad-Motorpot.".

Parameter *Reference Frequency Source 2* **492** offers further options to define the frequency for the offset. See chapter 7.5.1 "Reference frequency channel".

7.5.4.5 Actual values

Via parameter *Repetition Frequency Input* **252**, the reference frequency can be displayed at the repetition frequency input.

Via parameter *Reference Ramp Frequency* **283**, the actual value of the frequency after multiplication by the gear factor and addition of the optionally selectable repetition frequencies can be displayed.

7.5.4.6 Adjustment Options

The following instructions describe options for setting the electronic gear. The settings must be adjusted to the application.





⚠ WARNING

The control functions listed in the following table may affect the synchronous operation of the drives. It should be checked if these additional control functions are switched on and if they are required.

	Parameters	Function
573	Operation mode	Intelligent current limits
610	Operation mode	Current limit value controller
660	Operation mode	Slip compensation
670	Operation mode	Voltage controller
164	n/T Control change over	Switch over Torque control
475	Reference Frequency Source 1	Added reference frequency value
492	Reference Frequency Source 2	Added reference frequency value

Via parameter *Controller Status* **275**, you can display if a controller is active.

The function of the electronic gear is realized by configuring digital inputs of the slave frequency inverter as a reference frequency input. If the master drive is a frequency inverter, the repetition frequency output of the master frequency inverter is used.

7.5.4.6.1 Frequency inverter as master drive

If the master drive of the electronic gear is a frequency inverter, the following parameters (for example) can be set for the transmission of the repetition frequency.

- Select operation mode "20 Repetition Frequency MFO1F" for parameter *Operation Mode MFO1* (X13.6) **550.** As a result, the multifunction output is used as a repetition frequency output.
- Via parameter *RF/PT: Output Value MFO1F* **555**, select an operation mode for multifunction output 1.
- Set the value entered for parameter *RF*: *Division Marks* **556** according to the frequency required at the repetition frequency output. This is the number of pulses per motor revolution for the repetition frequency. The pulse duration depends on the motor speed. By default, this parameter is set to 1024. When making the settings, take the frequency limit of the frequency output of 150 kHz into account. The maximum value S_{max} which can be set for parameter *RF*: *Division Marks* **556** is:

$$\mathsf{S}_{\mathsf{max}} = \frac{\mathsf{150\,000\,Hz}}{\mathsf{Frequency\,value}}$$

7.5.4.6.2 Frequency inverter as slave drive

For the function of the electronic gear via the repetition frequency, the following parameters (for example) can be set at the frequency inverter of the Slave drive.

- For parameter *Operation Mode IN2D* **496** select: "20 RF Single Evaluation" or "21 RF Double Evaluation" (RF: Repetition Frequency). Digital input IN2D is the repetition frequency input. See chapter 7.6.7.2 "Repetition frequency input".
- Since the rated speed decreases when the number of pole pairs is higher (n~1/p), different speeds may result if the master drive and slave drive have the same reference frequencies. Adjust the values for parameters *Divider* **497** of the repetition frequency input of the slave drive and *RF*: *Division marks* **556** of the repetition frequency output of the master according to the number of pole pairs of the motors in order to obtain the same speeds for the master drive and the slave drive. Different speeds can be realized by setting the gear factor.

Different values for parameters *Rep. Freq: Divider* **497** of the repetition frequency input of the slave drive and *RF: Division Marks* **556** of the repetition frequency output of the master result in different speeds of the master drive and the slave drive if the number of pole pairs of the motors is the same.



- Set parameters *Acceleration (Clockwise)* **420** and *Deceleration (Clockwise)* **421** or *Acceleration Anticlockwise* **422** and *Deceleration Anticlockwise* **423** to the required values. For synchronous acceleration and deceleration of the drives, set the values of the slave drive slightly higher (in example 10 %) than the values of the master drive. These increased values are to ensure that the slave drive can follow the master drive in dynamic operation cases.
- For a synchronous start of the master drive and the slave drive, set the *Minimum Frequency* **418** of the slave drive to 0 in order to prevent an early start of the slave drive if the controller enable signal is present.
- Select an *Operation Mode* **689**. Via parameters *Gear Factor Numerator* **685** and *Gear Factor Denominator* **686**, set the required transmission ratio.

.

⚠ WARNING

In order to avoid time delays during the processing of the repetition frequency, the slave frequency inverter should be enabled before the master frequency inverter.




⚠ WARNING

The reference frequency is transmitted, but not the direction of rotation. In this case, the direction of rotation must be defined via the digital inputs IN1D and IN2D at the slave drive.

7.6 Control inputs and outputs

The control inputs and outputs can be parameterized freely. All hardware inputs and outputs are preset to frequently used functions by default for simple commissioning.

7.6.1 Multifunction input MFI1



452 Operation Mode MFI1 (Multifunction input 1)

Multifunction input MFI1 can be configured as a voltage, current or a digital input. In the configuration as a digital input, the evaluation can be selected as PNP (high-switching) or NPN (low-switching).

Depending on the selected *Operation Mode MFI1* **452**, various functions of the frequency inverter can be controlled.



Operation Mode MF11 452	Function
1 - Voltage 010V	Voltage signal (MFI1A), 0 V 10 V. Fixed characteristic. Factory setting .
2 - Current 020 mA	Current signal (MFI1A), 0 mA20 mA. Fixed characteristic.
3 - Digital NPN (active: 0 V)	Digital signal (MFI1D) 0 V 24 V. Low-switching (with negative signal).
4 - Digital PNP (active: 24 V)	Digital signal (MFI1D) 0 V 24 V. High-switching (with positive signal).
5 - Current 420 mA	Current signal (MFI1A), 4 mA20 mA. Fixed characteristic.
6 - Voltage, characteristic	Voltage signal (MFI1A), 0 V 10 V. The output signal is influenced by the set characteristic. The characteristic can be set via parameters 454 457.
7 - Current, characteristic	Current signal (MFI1A) 0 mA 20 mA. The output signal is influenced by the set characteristic. The characteristic can be set via parameters 454 457.

Multifunction input MFI1 is configured by default for an analog reference value source with a voltage signal of 0 V to 10 V.

Alternatively, you can select the operation mode for an analog current signal of 0 \dots 20 mA or 4 \dots 20 mA. The current signal is continuously monitored and the fault message "F1407" displayed if the maximum figure is exceeded.

7.6.1.1 Multifunction input set as analog input MFI1A

The Multifunction input can be evaluated either as analogue or digital signal. In the following the evaluation for analogue signals is described.

7.6.1.1.1 Voltage input and current input

For parameter *Operation Mode MFI1* **452**, "1 - Voltage 0...10V", "2 - Current 0...20 mA" or "5 - Current 4...20 mA" must be selected.

Operation Mode MFI1 452	Function
1 - Voltage 010 V	Voltage signal (MFI1A), 0 V 10 V. Fixed characteristic.
	Factory setting.
2 - Current 020 mA	Current signal (MFI1A), 0 mA20 mA. Fixed characteristic.
4 - Current 420 mA	Current signal (MFI1A), 4 mA20 mA. Fixed characteristic.

The analog input signal is mapped to a reference frequency or percentage.

Voltage 0...10 V

Parameter *Operation Mode MFI1* **452** is set to "1 - Voltage 0...10 V". The coordinates of the points relate, as a percentage, to the analog signal with 9.8 V and parameter *Maximum Frequency* **419** or parameter *Maximum Reference Percentage* **519**. The zero-crossing of the frequency or the percentage value lies at 0.2 V. The deviations from 10 V and 0 V allow the operation even with voltage supplies that have small deviations from the nominal values.

Incliniation:

$$\frac{9.8 \, V - 0.2 \, V}{\textit{Maximum reference value}} \, \widehat{=} \, \frac{9.6 \, V}{\textit{Maximum Frequency } 419} \, \widehat{=} \, \frac{9.6 \, V}{\textit{Maximum Perc. } 519}$$

Current 0...20 mA Current 0...20 mA

Parameter *Operation Mode MFI1* **452** must be set to "2 - Current 0...20 mA". The coordinates of the points relate, as a percentage, to the analog signal with 19.6 mA and parameter *Maximum Frequency* **419** or parameter *Maximum Reference Percentage* **519**. The zero-crossing of the frequency or the percentage value lies at 0.4 mA. The deviations from 20 mA and 0 mA allow the operation even with voltage supplies that have small deviations from the nominal values.




Incliniation:

$$\frac{19.6 \ mA - 0.4 \ mA}{Maximum \ reference \ value} \stackrel{\frown}{=} \frac{19.2 \ mA}{Maximum \ Frequency \ 419} \stackrel{\frown}{=} \frac{19.2 \ mA}{Maximum \ Perc. \ 519}$$

Current 4...20 mA

Parameter *Operation Mode MFI1* **452** must be set to "5 - Current 4...20 mA". The coordinates of the points relate, as a percentage, to the analog signal with 19.6 mA and parameter *Maximum Frequency* **419** or parameter *Maximum Reference Percentage* **519**. The zero-crossing of the frequency or the percentage value lies at 4.4 mA. The deviations from 20 mA and 4 mA allow the operation even with voltage supplies that have small deviations from the nominal values. Incliniation:

$$\frac{19.6\ mA - 4.4\ mA}{Maximum\ reference\ value} \stackrel{\frown}{=} \frac{15.2\ mA}{Maximum\ Frequency\ 419} \stackrel{\frown}{=} \frac{15.2\ mA}{Maximum\ Perc.\ 519}$$



7.6.1.1.2 Voltage input characteristic and current input characteristic

For parameter *Operation Mode MFI1* **452**, "6 - Voltage, characteristic" or "7 - Current, characteristic" must be selected.

Operation Mode MFI1 452	Function
6 - Voltage, characteristic	Voltage signal (MFI1A), 0 V 10 V. The output signal is influenced by the set characteristic. The characteristic can be set via parameters 454 457.
7 - Current, characteristic	Current signal (MFI1A) 0 mA 20 mA. The output signal is influenced by the set characteristic. The characteristic can be set via parameters 454 457.

454 Characteristic Curve Point X1

455 Characteristic Curve Point Y1

456 Characteristic Curve Point X2

457 Characteristic Curve Point Y2

The analog input signal is mapped to a reference frequency or percentage. Parameterization can be done via two points of the linear characteristic of the reference value channel.

Point 1 with coordinates X1 and Y1 and point 2 with coordinates X2 and Y2 can be set in four data sets.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
454	Characteristic Curve Point X1	0.00%	100.00%	2.00%
455	Characteristic Curve Point Y1	-100.00%	100.00%	0.00%
456	Characteristic Curve Point X2	0.00%	100.00%	98.00%
457	Characteristic Curve Point Y2	-100.00%	100.00%	100.00%



The coordinates of the points relate, as a percentage, to the analog signal with 10 V or 20 mA and parameter *Maximum Frequency* **419** or parameter *Maximum Reference Percentage* **519**. The direction of rotation can be changed via the digital inputs and/or by selection of the points.

⚠ WARNING

<u>^</u>


Attention!

The monitoring of the analog input signal via the parameter *Error/Warning Behaviour* **453** demands the check of parameter *Characteristic Curve Point X1* **454**.

In the settings

- "6 Voltage, characteristic" or
- "7 Current, characteristic"


of parameter *Operation Mode MFI1* **452**, the following characteristic is effective:



The characteristic can be adjusted via parameters 454 ... 457 of the application.

The freely configurable characteristic enables setting a tolerance at the ends as well as a reversal of the direction of rotation.

The following example shows the inverse reference value specification with additional reversal of the direction of rotation. This is often used in pressure control systems.



Point 1:

$$X1 = 2.00\% \cdot 10 \text{ V} = 0.20 \text{ V}$$

 $Y1 = 100.00\% \cdot 50.00 \text{ Hz} = 50.00 \text{ Hz}$

Point 2:
$$X2 = 98.00\% \cdot 10 \text{ V} = 9.80 \text{ V}$$

$$Y2 = -80.00\% \cdot 50.00 \text{ Hz} = -40.00 \text{ Hz}$$

The change of direction of rotation is done in this example at an analog input signal of 5.5 V. pos./neg. maximum figure.

The definition of the analog input characteristic can be calculated via the two-point form of the line equation. The speed Y of the drive is controlled according to the analog control signal X.

$$Y = \frac{Y2 - Y1}{X2 - X1} \cdot (X - X1) + Y1$$



Scaling

The analog input signal is mapped to the freely configurable characteristic. The maximum admissible setting range of the drive can be set via the frequency limits or percentage limits. In the case of the parameterization of a bipolar characteristic, the set minimum and maximum limits for both directions of rotation are effective. The percentage values of the characteristic points are relative to the limits selected.

Parameters		Setting		
No. Description Mi		Min.	Max.	Fact. sett.
418	Minimum Frequency	0.00 Hz	999.99 Hz	3.50 Hz
419	Maximum Frequency	0.00 Hz	999.99 Hz	50.00 Hz


The control system uses the maximum value of the output frequency, which is calculated from the *Maximum Frequency* **419** and the compensated slip of the drive mechanism. The frequency limits define the speed range of the drive, and the percentage values supplement the scaling of the analog input characteristic in accordance with the functions configured.

Parameters		Setting		
No. Description Min.		Min.	Max.	Fact. sett.
518	Minimum Reference Percentage	0.00%	300.00%	0.00%
519	Maximum Reference Percentage	0.00%	300.00%	100.00%

450 Tolerance Band


The analog input characteristic with change of sign of the reference value can be adapted by the parameter *Tolerance Band* **450** of the application. The adjustable tolerance band extends the zero passage of the speed relative to the analog control signal. The parameter value (percent) is relative to the maximum current or voltage signal.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
450	Tolerance Band	0.00%	25.00%	2.00%



Hysteresis

The default *Minimum Frequency* **418** or *Minimum Reference Percentage* **518** extends the parameterized tolerance band to the hysteresis.



Tolerance band with set maximum frequency

For example, the output variable coming from positive input signals is kept on the positive minimum value until the input signal becomes lower than the value for the tolerance band in the negative direction. Then, the output variable follows the set characteristic.

7.6.1.1.3 Monitoring of analog input signal

451 Filter time constant

The time constant of the filter for the analog reference value can be set via the parameter *Filter time constant* **451**. The time constant indicates the time during which the input signal is averaged by means of a low pass filter, in example in order to eliminate fault effects.

The setting range is between 0 ms and 5000 ms in 15 steps.

Filter time constant 451	Function
0 - Time constant 0 ms	Filter deactivated – The analog reference value is forwarded unfiltered.
2 - Time constant 2 ms	Filter activated – averaging of the input signal via the set value
4 - Time constant 4 ms	of the filter time constants.
8 - Time constant 8 ms	
16 - Time constant 16 ms	
32 - Time constant 32 ms	
64 - Time constant 64 ms	
128 - Time constant 128 ms	
256 - Time constant 256 ms	
512 - Time constant 512 ms	
1000 - Time constant 1000 ms	
2000 - Time constant 2000 ms	
3000 - Time constant 3000 ms	
4000 - Time constant 4000 ms	
5000 - Time constant 5000 ms	



453 Error/Warning Behaviour

For monitoring the analog input signal, an operation mode can be selected via parameter Er- $ror/Warning\ Behaviour\ 453$.

Error/Warning Behaviour 453	Function
0 - Off	The input signal is not monitored. Factory setting.
1 - Warning < 1V/2 mA	If the input signal is lower than 1 V or 2 mA, a warning message is issued.
2 - Shutdown < 1V/2 mA	If the input signal is lower than 1 V or 2 mA, a warning and fault message is issued. The drive is decelerated according to stopping behavior 2.
3 - Error-Switch-Off < 1V/2 mA	If the input signal is lower than 1 V or 2 mA, a warning and fault message is issued and the drive coasts to a standstill (stopping behavior 0).

Monitoring of the analog input signal is active regardless of the enable of the frequency inverter.

Operation mode 2 defines the shut-down and stopping of the drive, regardless of the setting of parameter *Operation Mode* **630** for the stopping behavior. The drive is stopped according to stopping behavior 2. If the set holding time has expired, an error message is issued. The drive can be started again by switching the start signal on and off.

Operation mode 3 defines the free coasting of the drive (as described in stopping behavior 0), regardless of the setting of parameter *Operation Mode* **630** for the stopping behavior.




⚠ WARNING

Attention!

The monitoring of the analog input signal via the parameter *Error/Warning Behaviour* **453** demands the check of parameter *Characteristic Curve Point X1* **454**.

Example: $Error/Warning\ Behaviour\ 453$ = "2 - Shutdown < 1V/2mA" or "3 - Error Switch-Off < 1V/2mA". In the factory settings of the parameter $Characteristic\ Curve\ Point\ X1\ 454$ shutting down or error switch-off are affected at an output frequency \neq 0 Hz. If shutting down or error switch-off are to be effected at an output frequency of 0 Hz, the Point X1 must be adjusted (e.g. X1=10% /1 V).



7.6.1.2 Multifunction input set as digital input MFI1D


Multifunction input MFI1 (terminal X12.3) can be configured as a digital input. Via parameter *Operation Mode MFI1* **452**, the evaluation can be selected as PNP (high-switching) or NPN (low-switching). The multifunction input set as digital input can be linked to the functions of the frequency inverter. Signal "76 - MFI1D" must be assigned a function.

Operation Mode MFI1 452	Function
3 - Digital NPN (active: 0 V)	Digital signal (MFI1D) 0 V 24 V. Low-switching (with negative signal).
4 - Digital PNP (active: 24 V)	Digital signal (MFI1D) 0 V 24 V. High-switching (with positive signal).



Signal source	Function
76 - MFI1D	Assign to a function, e.g. select signal source for parameter.

7.6.2 Multifunction input MFI2



562 Operation Mode MFI2 (Multifunction input 2)

Multifunction input MFI2 can be configured as a voltage, current or a digital input. In the configuration as a digital input, the evaluation can be selected as PNP (high-switching) or NPN (low-switching).

Depending on the selected *Operation Mode MFI2* **562**, various functions of the frequency inverter can be controlled.

Operation Mode MFI2 562	Function
1 - Voltage 010 V	Voltage signal (MFI2A), 0 V 10 V. Fixed characteristic.
2 - Current 020 mA	Current signal (MFI2A), 0 mA 20 mA. Fixed characteristic.
3 - Digital NPN (active: 0 V)	Digital signal (MFI2D) 0 V 24 V. Low-switching (with negative signal). Factory setting.
4 - Digital PNP (active: 24 V)	Digital signal (MFI2D) 0 V 24 V. High-switching (with positive signal).
5 - Current 420 mA	Current signal (MFI2A), 4 mA 20 mA. Fixed characteristic
6 - Voltage, characteristic	Voltage signal (MFI2A), 0 V 10 V. The output signal is influenced by the set characteristic. The characteristic can be set via parameters 564 567.
7 - Current, characteristic	Current signal (MFI2A) 0 mA 20 mA. The output signal is influenced by the set characteristic. The characteristic can be set via parameters 564 567.

By default, multifunction input MFI2 is set as a digital input for connection of a motor thermal contact. Alternatively, you can select the operation mode for an analog voltage or current signal. The current signal is continuously monitored and the fault message "F1407" displayed if the maximum figure is exceeded.

7.6.2.1 Multifunction input set as analog input MFI2A

The Multifunction input can be evaluated either as analogue or digital signal. In the following the evaluation for analogue signals is described.

7.6.2.1.1 Voltage input and current input

For parameter *Operation Mode MFI2* **562**, "1 - Voltage 0...10 V", "2 - Current 0...20 mA" or "5 - Current 4...20 mA" must be selected.

Operation Mode MFI2 562	Function
1 - Voltage 010 V	Voltage signal (MFI2A), 0 V 10 V. Fixed characteristic.
2 - Current 020 mA	Current signal (MFI2A), 0 mA 20 mA. Fixed characteristic.
5 - Current 420 mA	Current signal (MFI2A), 4 mA 20 mA. Fixed characteristic



The analog input signal is mapped to a reference frequency or percentage.

The analog input signal is mapped to a reference frequency or percentage.

Voltage 0...10 V

Parameter *Operation Mode MFII* **452** is set to "1 - Voltage 0...10 V". The coordinates of the points relate, as a percentage, to the analog signal with 9.8 V and parameter *Maximum Frequency* **419** or parameter *Maximum Reference Percentage* **519**. The zero-crossing of the frequency or the percentage value lies at 0.2 V. The deviations from 10 V and 0 V allow the operation even with voltage supplies that have small deviations from the nominal values.

Incliniation:

$$\frac{9.8 V - 0.2 V}{\textit{Maximum reference value}} \stackrel{\frown}{=} \frac{9.6 V}{\textit{Maximum Frequency } 419} \stackrel{\frown}{=} \frac{9.6 V}{\textit{Maximum Perc. } 519}$$

Current 0...20 mA Current 0...20 mA

Parameter *Operation Mode MFI1* **452** must be set to "2 - Current 0...20 mA". The coordinates of the points relate, as a percentage, to the analog signal with 19.6 mA and parameter *Maximum Frequency* **419** or parameter *Maximum Reference Percentage* **519**. The zero-crossing of the frequency or the percentage value lies at 0.4 mA. The deviations from 20 mA and 0 mA allow the operation even with voltage supplies that have small deviations from the nominal values.


Incliniation:

$$\frac{19.6 \ mA - 0.4 \ mA}{Maximum \ reference \ value} \stackrel{\frown}{=} \frac{19.2 \ mA}{Maximum \ Frequency \ 419} \stackrel{\frown}{=} \frac{19.2 \ mA}{Maximum \ Perc. \ 519}$$

Current 4...20 mA

Parameter *Operation Mode MFI1* **452** must be set to "5 - Current 4...20 mA". The coordinates of the points relate, as a percentage, to the analog signal with 19.6 mA and parameter *Maximum Frequency* **419** or parameter *Maximum Reference Percentage* **519**. The zero-crossing of the frequency or the percentage value lies at 4.4 mA. The deviations from 20 mA and 4 mA allow the operation even with voltage supplies that have small deviations from the nominal values. Incliniation:

$$\frac{19.6 \ mA - 4.4 \ mA}{Maximum \ reference \ value} \stackrel{\frown}{=} \frac{15.2 \ mA}{Maximum \ Frequency \ 419} \stackrel{\frown}{=} \frac{15.2 \ mA}{Maximum \ Perc. \ 519}$$





7.6.2.1.2 Voltage input characteristic and current input characteristic

For parameter *Operation Mode MFI2* **562**, "6 - Voltage, characteristic" or "7 - Current, characteristic" must be selected.

Operation Mode MFI2 562	Function
6 - Voltage, characteristic	Voltage signal (MFI2A), 0 V 10 V. The output signal is influenced by the set characteristic. The characteristic can be set via
	parameters 564 567.
7 - Current, characteristic	Current signal (MFI2A) 0 mA 20 mA. The output signal is influenced by the set characteristic. The characteristic can be set via parameters 564 567.

564 Characteristic Curve Point X1

565 Characteristic Curve Point Y1

566 Characteristic Curve Point X2

567 Characteristic Curve Point Y2

The analog input signal is mapped to a reference frequency or percentage. Parameterization can be done via two points of the linear characteristic of the reference value channel.

Point 1 with coordinates X1 and Y1 and point 2 with coordinates X2 and Y2 can be set in four data sets

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
564	Characteristic Curve Point X1	0.00%	100.00%	2.00%
565	Characteristic Curve Point Y1	-100.00%	100.00%	0.00%
566	Characteristic Curve Point X2	0.00%	100.00%	98.00%
567	Characteristic Curve Point Y2	-100.00%	100.00%	100.00%

The coordinates of the points relate, as a percentage, to the analog signal with 10 V or 20 mA and parameter *Maximum Frequency* **419** or parameter *Maximum Reference Percentage* **519**. The direction of rotation can be changed via the digital inputs and/or by selection of the points.




⚠ WARNING

The monitoring of the analog input signal via the parameter *Error/Warning Behaviour* **563** demands the check of parameter *Characteristic Curve Point X1* **564**.

In the settings

- "6 Voltage, characteristic" or
- "7 Current, characteristic"

of parameter *Operation Mode MFI1* **452**, the following characteristic is effective:



Point 1:

 $X1 = 2.00\% \cdot 10 \ V = 0.20 \ V$

 $Y1 = 0.00\% \cdot 50.00 \ Hz = 0.00 \ Hz$

Point 2:

 $X2 = 98.00\% \cdot 10 \ V = 9.80 \ V$


 $Y2 = 100.00\% \cdot 50.00 \ Hz = 50.00 \ Hz$



The characteristic can be adjusted via parameters 564 ... 567 of the application.

The freely configurable characteristic enables setting a tolerance at the ends as well as a reversal of the direction of rotation.

The following example shows the inverse reference value specification with additional reversal of the direction of rotation. This is often used in pressure control systems.



Point 1: $X1 = 2.00\% \cdot 10 \text{ V} = 0.20 \text{ V}$

 $Y1 = 100.00\% \cdot 50.00 \ Hz = 50.00 \ Hz$

Point 2:

 $X2 = 98.00\% \cdot 10 \; V = 9.80 \; V$

 $Y2 = -80.00\% \cdot 50.00 \ Hz = -40.00 \ Hz$

The change of direction of rotation is done in this example at an analog input signal of 5.5 V. pos./neg. maximum figure

The definition of the analog input characteristic can be calculated via the two-point form of the line equation. The speed Y of the drive is controlled ac-cording to the analog control signal X.

$$Y = \frac{Y2 - Y1}{X2 - X1} \cdot \left(X - X1\right) + Y1$$

Scaling

The analog input signal is mapped to the freely configurable characteristic. The maximum admissible setting range of the drive can be set via the frequency limits or percentage limits. In the case of the parameterization of a bipolar characteristic, the set minimum and maximum limits for both directions of rotation are effective. The percentage values of the characteristic points are relative to the limits selected.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
418	Minimum Frequency	0.00 Hz	999.99 Hz	3.50 Hz
419	Maximum Frequency	0.00 Hz	999.99 Hz	50.00 Hz

The control system uses the maximum value of the output frequency, which is calculated from the *Maximum Frequency* **419** and the compensated slip of the drive mechanism. The frequency limits define the speed range of the drive. The percentage limits complement the scaling of the analog input characteristic according to the configured functions.


Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
518	Minimum Reference Percentage	0.00%	300.00%	0.00%
519	Maximum Reference Percentage	0.00%	300.00%	100.00%




560 Tolerance Band

The analog input characteristic with change of sign of the reference value can be adapted by the parameter *Tolerance Band* **560** of the application. The adjustable tolerance band extends the zero passage of the speed relative to the analog control signal. The parameter value (percent) is relative to the maximum current or voltage signal.

	Parameters		Setting	
No.	Description	Min.	Max.	Fact. sett.
560	Tolerance Band	0.00%	25.00%	2.00%



The default *Minimum Frequency* **418** or *Minimum Reference Percentage* **518** extends the parameterized tolerance band to the hysteresis.



Tolerance band with set maximum frequency

For example, the output variable coming from positive input signals is kept on the positive minimum value until the input signal becomes lower than the value for the tolerance band in the negative direction. Then, the output variable follows the set characteristic.



7.6.2.1.3 Monitoring of analog input signal

561 Filter time constant

The time constant of the filter for the analog reference value can be set via the parameter *Filter time constant* **561**. The time constant indicates the time during which the input signal is averaged by means of a low pass filter, e.g. in order to eliminate fault effects.

The setting range is between 0 ms and 5000 ms in 15 steps.

Filter time constant 561	Function
0 - Time constant 0 ms	Filter deactivated – The analog reference value is forwarded unfiltered.
2 - Time constant 2 ms	Filter activated – averaging of the input signal via the set value
4 - Time constant 4 ms	of the filter time constants.
8 - Time constant 8 ms	
16 - Time constant 16 ms	
32 - Time constant 32 ms	
64 - Time constant 64 ms	
128 - Time constant 128 ms	
256 - Time constant 256 ms	
512 - Time constant 512 ms	
1000 - Time constant 1000 ms	
2000 - Time constant 2000 ms	
3000 - Time constant 3000 ms	
4000 - Time constant 4000 ms	
5000 - Time constant 5000 ms	

563 Error/Warning Behaviour

For monitoring the analog input signal, an operation mode can be selected via parameter *Error/Warning Behaviour* **563**.

Error/Warning Behaviuor 563	Function
0 - Off	The input signal is not monitored. Factory setting.
1 - Warning < 1V/2 mA	If the input signal is lower than 1 V or 2 mA, a warning message is issued.
2 - Shutdown < 1V/2 mA	If the input signal is lower than 1 V or 2 mA, a warning and fault message is issued. The drive is decelerated according to stopping behavior 2.
3 - Error-Switch-Off < 1V/2 mA	If the input signal is lower than 1 V or 2 mA, a warning and fault message is issued and the drive coasts to a standstill (stopping behavior 0).

Monitoring of the analog input signal is active regardless of the enable of the frequency inverter.

Operation mode 2 defines the shut-down and stopping of the drive, regardless of the setting of parameter *Operation Mode* **630** for the stopping behavior. The drive is stopped according to stopping behavior 2. If the set holding time has expired, an error message is issued. The drive can be started again by switching the start signal on and off.

Operation mode 3 defines the free coasting of the drive (as described in stopping behavior 0), regardless of the setting of parameter *Operation Mode* **630** for the stopping behavior.






⚠ WARNING

The monitoring of the analog input signal via the parameter *Error/Warning Behaviour* **563** demands the check of parameter *Characteristic Curve Point X1* **564**.

Example: $Error/warning\ behavior\ 563$ = "2 - Shutdown < 1V/2mA" or "3 - Error-Switch-Off < 1V/2mA". In the factory settings of the parameter $Characteristic\ Curve\ Point\ X1\ 564$ shutting down or error switch-off are to be effected at an output frequency $\neq 0$ Hz. If shutting down or error switch-off are to be effected at an output frequency of 0 Hz, the Point X1 must be adjusted (e.g. X1=10% /1 V).



7.6.2.2 Multifunction input set as digital input MFI2D

Multifunction input MFI2 (terminal X12.4) can be configured as a digital input. Via parameter *Operation Mode MFI2* **562**, the evaluation can be selected as PNP (high-switching) or NPN (low-switching). The multifunction input set as digital input can be linked to the functions of the frequency inverter. Signal "77 - MFI2D" must be assigned a function.


In the factory settings, signal "532 - MFI2D (Hardware)" is assigned to parameter *Thermal contact for P570* **204**.

Operation Mode MFI2 562	Function	
3 - Digital NPN (active: 0 V)	Digital signal (MFI2D) 0 V 24 V. Low-switching (with negative signal). Factory setting.	
4 - Digital PNP (active: 24 V)	Digital signal (MFI2D) 0 V 24 V. High-switching (with positive signal).	

Signal source	Function
532 - MFI2D	Assign to a function, e.g. select signal source for parameter. Factory setting:
Hardware)	Thermal contact for P570 204 = "532 - MFI2D (Hardware)".
77 - MFI2D	Assign to a function, e.g. select signal source for parameter.



7.6.3 Multifunction output MFO1



550 Operation Mode MFO1 (X13.6) (multifunction output)

Multifunction output MFO1 (terminal X13.6) can either be configured as a digital, analog, repetition frequency or pulse train output. Depending on the selected $Operation\ Mode\ MFO1\ (X13.6)\ 550$, a connection with various functions of the software is possible. The operation modes not used are deactivated internally.

Ope	ration mode MF01 (X13.6) 550	Function
0 -	Off	Multifunction output has logic signal LOW.
1 -	Digital MFO1D	Multifunction output is configured as digital output (0 \dots 24 V^{1}).
10 -	Analog (PWM) MFO1A	Multifunction output is configured as analog output (0 24 V). Factory setting. PWM frequency = 126 Hz.
11 -	Analog (PWM) MFO1A	Multifunction output is configured as analog output (0 24 V). Factory setting. PWM frequency = 32 kHz. Function available in devices marked integrated Functional Safety.
20 -	Repetition frequen- cy (RF) MFO1F	Multifunction output is configured as repetition frequency output (0 24 V, $f_{max} = 150$ kHz).
30 -	Pulse train (PT) MFO1F	Multifunction output is configured as pulse train output.

¹⁾ Dependent on the voltage supply of the control unit. The maximum guaranteed values is 15 V.

Output characteristic (analog mode)

If the multifunction output is set as an analog output, an output characteristic can be set. Parameter $Operation\ Mode\ MFO1\ (X13.6)\$ 550 must be set to "10 - Analog (PWM) MFO1A" (factory setting).


551 Analog: Voltage 100% 552 Analog: Voltage 0%


The voltage range of the output signal at the multifunction output can be adjusted. The value range of the actual value selected via parameter $Analog: Source\ MFO1A\ 553$ is assigned to the value range of the output signal which is adjusted via the parameters $Analog:\ Voltage\ 100\%\ 551$ and $Analog:\ Voltage\ 0\%\ 552$.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
551	Analog: Voltage 100%	0.0 V	22.0 V	10.0 V
552	Analog: Voltage 0%	0.0 V	22.0 V	0.0 V

Analog: Source MFO1A **553** with actual absolute value:

Analog: Source MFO1A **553** with sign:







With the parameters *Analog: Voltage 100%* **551** and *Analog: Voltage 0%***552**, the voltage range at 100% and 0% of the output parameter is set. If the output value exceeds the reference value, the output voltage also exceeds the value of the parameter *Analog: Voltage 100%***551** up to the maximum value of 22 V (or the maximum value of an external voltage supply).

NOTE

If $Operation\ Mode\ MFO1\ (X13.6)\ 550 = Analog\ (PWM)\ MFO1A\ and\ parameter\ s\ Analog:\ Voltage\ 100\%\ 551 < Analog:\ Voltage\ 0\%\ 552$, then the smaller voltage value of $Analog:\ Voltage\ 100\%\ 551$ is put out.

553 Analog: Source MFO1A

If the multifunction output is to be used as analog output, parameter $Operation\ Mode\ MFO1\ (X13.6)$ **550** must be set to "10 - Analog (PWM) MFO1A".

For parameter *Analog: Source MFO1A* **553**, the analog actual value to be output at the multifunction output can be selected.

Parameters Operation mode MFO1 (X13.6) 550	Factory setting 10 - Analog (PWM) MFO1A	Set 10 - Analog (PWM) MFO1A
Analog: Source MFO1A 553	7 - Abs. Actual Frequency	Select an analog signal source.

Analog: Source MF01A 553	Function
0 - Off	Analog mode at the multifunction output is switched off.
1 - Abs. Fs	Abs. value of the stator frequency. 0.00 Hz <i>Maximum Frequency</i> 419 .
2 - Abs. Fs betw. fmin/fmax	Abs. value of the stator frequency. <i>Minimum Frequency</i> 418 <i>Maximum Frequency</i> 419 .
7 - Abs. Actual Frequency	Abs. value of act. frequency. 0.00 Hz <i>Maximum Frequency</i> 419 . Factory setting .
10 - Abs. Reference Percentage	Absolute value of reference value from reference percentage channel. Total of <i>Reference Percentage Source 1</i> 476 and <i>Reference Percentage Source 2</i> 494 .
11 - Abs. Ref. Percentage betw. %min/%max	Absolute value of reference value from reference percentage channel. <i>Minimum Reference Percentage</i> 518 <i>Maximum Reference Percentage</i> 519 . Total of <i>Reference Percentage Source 1</i> 476 and <i>Reference Percentage Source</i> 2 494 .
20 - Abs. Iactive	Abs. value of current effective current I_{Active} . 0.0 A Nominal frequency inverter current.
21 - Abs. Isd	Abs. value of flux-forming current component. 0.0 A Nominal frequency inverter current.
22 - Abs. Isq	Abs. value of torque-forming current component. 0.0 A Nominal frequency inverter current.
30 - Abs. Pactive	Abs. value of current effective power P _{Active} . 0.0 kW <i>Rated Mech. Power</i> 376 .
31 - Abs. T	Abs. value of calculated torque M, 0.0 Nm rated torque.
32 - Abs. Inside Temperature	Abs. value of measured inside temperature20 °C 100 °C.
33 - Abs. Heat Sink Tempera- ture	Abs. value of measured heat sink temperature20 °C 100 °C.
34 - Abs. Capacitor temperature	Abs. value of measured capacitor temperature20 °C 100 °C.
40 - Abs. Analog Input MFI1A	Abs. signal value at analog input MFI1A. DC 0.0 V 10.0 V.
41 - Abs. Analog Input MFI2A	Abs. signal value at analog input MFI2A. DC 0.0 V 10.0 V.
50 - Abs. I	Abs. current value of measured output currents. 0.0 A Nominal frequency inverter current.
51 - DC-Link Voltage	DC-link voltage U _d . DC 0.0 V 1000.0 V.
52 - V	Output voltage. 3xAC 0.0 V 1000.0 V.



Analog: Source MFO1A 553	Function
61 - Abs. Val. PLC-Output Percentage 1	Output value "2521 – PLC Output Percentage 1" of a PLC-function is output via the multifunction output. Refer to application manual "PLC".
62 - Abs. Val. PLC-Output Percentage 2	Output value "2522 – PLC Output Percentage 2" of a PLC-function is output via the multifunction output. Refer to application manual "PLC".
101 to 162	Operation modes in analog operation with signs.

By default, the multifunction output is configured for the output of a pulse width modulated output signal with a reference voltage value of DC $10\ V$.

554 Digital: Source MFO1D

If the multifunction output is to be used as a digital output, parameter $Operation\ Mode\ MFO1\ (X13.6)$ **550** must be set to "1 - Digital MFO1D".

For parameter *Digital: Source MFO1D* **554**, the signal to be output at the multifunction output can be selected.

Parameters Operation mode MFO1 (X13.6) 550	Factory setting 10 - Analog (PWM) MFO1A	Set 1 - Digital MFO1D
Digital: Source MFO1D 554	4 - Setting frequency (Refer to 7.6.5.2 "Setting frequency".)	Select a digital signal source. (Refer to 7.6.5 "Digital outputs", table "Operation modes for digital outputs".)

555 RF/PT: Output Value MFO1F(repetition frequency/pulse train)

Multifunction output MFO1 can be used as a frequency output. Parameter $Operation\ Mode\ MFO1\ (X13.6)\ 550$ must be set to "20 - Repetition Frequency (RF) MFO1F". The output signal can be selected via parameter RF/PT: $Output\ Value\ MFO1F\ 555$.

Parameters	Factory setting	Set
Operation mode	10 - Analog (PWM) MFO1A	20 - Repetition Frequency (RF) MFO1F
MFO1 (X13.6) 550		

RF/PT: Output Value MFO1F 555	Function
0 - Off	Repetition frequency mode switched off.
1 - Actual Frequency	Abs. value of the <i>Actual frequency</i> 241 . Factory setting .
2 - Stator Frequency	Abs. value of the <i>Stator frequency</i> 210 .
5 - Repetition Frequency Input	Abs. value of the <i>Repetition frequency input</i> 252 .

The maximum frequency value output is:

 $f_{outp, max} = 2 \times (Maximum \ Frequency \ 419) \times (RF : Division \ marks \ 556)$

Scaling

If the multifunction output is set as a frequency output, the output frequency can be scaled. Parameter *Operation Mode MFO1 (X13.6)* **550** must be set to "20 - Repetition frequency (RF) MFO1F".

556 RF: Division marks (repetition frequency mode)

The repetition frequency mode for the multifunction output corresponds to the emulation of an incremental sensor. The parameter RF: $Division\ marks\ 556$ must be parameterized according to the frequency to be output.



	Parameters Setting			
No.	Description	Min.	Max.	Fact. sett.
556	RF: Division marks	30	8192	1024

The frequency limit of $f_{max} = 150$ kHz may not be exceeded in the calculation of the parameter *RF*: *Division marks* **556**.

$$S_{max} = \frac{150000 \text{ Hz}}{\text{Reference frequency value}}$$

Pulse train output

A pulse train signal (pulse sequence) can be output as a master frequency.

If the multifunction output is to be used as a pulse train output, parameter $Operation\ Mode\ MFO1\ (X13.6)$ **550** must be set to "30 - Pulse Train (PT) MFO1F".

Parameters	Factory setting	Set
Operation mode MFO1	10 - Analog (PWM) MFO1A	30 - Pulse Train (PT) MFO1F
(X13.6) 550		

557 PT: Scaling Frequency (pulse train)

Parameter *PT: Scaling Frequency* **557** indicates which frequency the multifunction output outputs at 100% maximum frequency. Thus, the scaling also depends on the setting of parameter *Maximum frequency* **419**.

Parameters			Setting	
No.	Description	Min.	Max.	Fact. sett.
557	PT: Scaling Frequency	0	32000	25000

If parameter *PT: Scaling Frequency* **557** is set to zero, the frequency value at the multifunction output will not be scaled.

The output value is limited to the value 2 x *Maximum Frequency* **419**.

Example: Reference value 50 Hz, Maximum Frequency 419 = 100 Hz


PT: Scaling Frequency 557	Output frequency [Hz]
0	50
1	0.5
10	5
100	50
1000	500

Example: Reference value 25 Hz, Maximum Frequency 419 = 50 Hz

PT: Scaling Frequency 557	Output frequency [Hz]
0	25
1000	500



7.6.4 Digital input/output IN3D/OUT3D



558 Operation mode terminal X11.6 (digital input/output)

Terminal X11.6 can be set as a digital input or digital output. In the factory setting, terminal X11.6 can be used as input for dataset changeover.

Operation mode terminal X11.6 558	Function
0 - Input IN3D	The digital input/output is set as digital input. Factory setting.
1 - Output OUT3D	The digital input/output is set as digital output.

559 Digital inputs PNP/NPN

If the digital input output (terminal X11.6) is set as digital input, the evaluation can be selected as PNP (high-switching) or NPN (low-switching) via parameter *Digital inputs PNP/NPN* **559**. Parameter *Operation Mode Terminal X11.6* **558** must be set to "0 - Input IN3D".

Digital inputs PNP/NPN 559	Function
0 - NPN (active: 0 V)	Digital input NPN. Low-switching (with negative signal).
1 - PNP (active: 24 V)	Digital input PNP. High-switching (with positive signal). Factory setting.



The parameter also effect the NPN/PNP evaluation change-over of IN1D, IN2D, IN4D and IN5D.

The digital input IN3D can control functions of the frequency inverter via signal "73 - IN3D". In the factory setting, digital input IN3D has the function "Dataset changeover 1" if *Operation Mode Terminal X11.6* **558** is set to "0 - input IN3D".

Parameters	Factory setting
Data Set Change-Over 1 70	73 - IN3D (input signal at digital input IN3D)

The signal selected via parameter *Operation Mode OUT3D* (X11.6) **533**, is output at the digital input/output (terminal X11.6). Parameter *Operation Mode Terminal X11.6* **558** must be set to "1 - Output OUT3D".

Parameter	Factory setting
Operation Mode OUT3D (X11.6) 533	103 - Inv. Error Signal



7.6.5 Digital outputs

531 Operation Mode OUT1D (X13.5) (Digital output)

532 Operation Mode OUT2D (X10/relay)

533 Operation Mode OUT3D (X11.6) (Digital input/output)

554 Digital: Source MFO1D (Multifunction output)

The digital signals listed in table "Operation modes for digital outputs" can be output via:

- Digital output
- Multifunction output (set as digital output)
- Digital input/output (set as digital output)
- Relay output

If the multifunction output or digital input/output is to output a digital value, the relevant output must be set up as a digital output:

Output	Terminal	Parameters	Factory setting	Set
Multifunction output	X13.6	<i>Operation Mode MFO1</i> (X13.6) 550	Analog 10 - (PWM) MFO1A	1 - Digital MFO1D
Digital in- put/output	X11.6	Operation Mode Terminal X11.6 558	0 - Input IN3D	1 - Output OUT3D

Factory settings of digital outputs

Output	Terminal	Parameters	Fa	ctory setting
Digital out- put	X13.5	Operation Mode OUT1D (X13.5) 531	2 -	Run signal
Multifunc- tion output	X13.6	Digital: Source MFO1D 554	4 -	Setting frequency
Digital in- put/output	X11.6	Operation Mode OUT3D (X11.6) 533	103 -	Inv. error signal
Relay out- put	X10	Operation Mode OUT2D (X10/relay) 532	103 -	Inv. error signal

NOTE

The relay output at terminal X10 is switched off if the communication between control and power circuitry of the frequency inverter is faulty. This avoids dangerous conditions for example in the brake control of hoist applications.

Operation modes for digital outputs

Operation mode 531, 532, 533, 554	Function
0 - Off	Digital output is switched off
1 - Ready or Standby Signal	Frequency inverter is initialized and on stand-by or in operation
2 - Run Signal	Enable signals STOA and STOB and a start command are present, output frequency available.
3 - Error Signal	The message is displayed via parameter <i>Actual error</i> 259 .
4 - Setting Frequency	The <i>Stator frequency</i> 210 is higher than the parameterized <i>Setting frequency</i> 510 . See chapter 7.6.5.2 "Setting frequency".
5 - Reference Frequency reached	The <i>Actual frequency</i> 241 of the drive has reached the <i>Internal reference frequency</i> 228 . See chapter 7.6.5.3 "Reference value reached".
6 - Reference Percentage reached	The <i>Actual percentage</i> 230 has reached the <i>Reference percentage</i> 229 . See chapter 7.6.5.3 "Reference value reached".



Operation mode 531, 532, 533, 55	4 Function
7 - Ixt warning	The Warning limit short-term Ixt 405 or Warning Limit
, see training	Long-Term Ixt 406 is reached.
8 - Warning Heat Sink Temperature	Max. heat sink temperature T_K minus the Warning limit heat sink temp. 407 reached.
9 - Warning Inside Temperature	Maximum inside temperature T_K minus the <i>Warning limit inside temp.</i> 408 reached.
10 - Warning Motor Temperature	Warning according to configured <i>Operation mode motor temp.</i> 570 and <i>Max. motor winding temp.</i> 617 .
11 - Warning, General	The message is displayed via parameter <i>Warnings</i> 269 .
12 - Warning Overtemperature	The selected limit values <i>Warning limit heat sink temp</i> . 407 , <i>Warning limit inside temp</i> . 408 or the maximum motor temperature have been exceeded.
13 - Mains Failure	Failure of the mains voltage and power regulation active according to <i>Operation Mode</i> 670 for the voltage controller.
14 - Warning Motor Protect. Switch	Parameterized <i>Operation Mode</i> 571 for the motor circuit breaker triggered.
15 - Warning Current Limitation	A controller or the <i>Operation Mode</i> 573 of the intelligent current limits limit the output current. See chapter 7.6.5.6 "Current limitation".
16 - Conroller Current Limit. Long Term Ixt	The overload reserve for 60 s has been used up and the output current is being limited. See chapter 7.6.5.6 "Current limitation".
17 - Conroller Current Limit. Short Term Ixt	The overload reserve for 1 s has been used up and the output current is being limited. See chapter 7.6.5.6 "Current limitation".
18 - Controller Current Limit. Tc	Max. heat sink temperature T_K reached, intelligent current limits of <i>Operation Mode</i> 573 active. See chapter 7.6.5.6 "Current limitation".
19 - Controller Current Limit. Motor Tem	Maximum motor temperature reached, intelligent current limits of <i>Operation Mode</i> 573 active. See chapter 7.6.5.6 "Current limitation".
22 - Warning V-Belt	Warning of <i>Operation mode</i> 581 of V-belt monitoring
25 - Warning Mask	Message of the configurable parameter <i>Create warning mask</i> 536 . See chapter 7.6.5.8 "Warning mask".
26 - Warning, Application	A warning application is signaled. Display of the actual value is effected via parameter <i>Application Warnings</i> 273. See chapter 7.6.5.9 "Warning mask, application".
27 - Warning Mask, Application	Message of the configurable parameter <i>Create warning mask application</i> 626 .
28 - Warning, gen + Warning, Applicatio	A warning or warning application is signaled.
29 - Warn. Mask, gen + Warn. Mask, Appl.	Message of configurable parameters <i>Create warning mask</i> 536 and <i>Create Warning Mask Application</i> 626 .
30 - Flux-Forming finished	Magnetic field has been impressed. See chapter 7.6.5.4 "Flux forming finished".
31 - Handshake Traverse Function	Signal of the traverse function. See chapter 7.10.8 "Traverse function"
41 - Brake release	Activation of a brake unit depending on the <i>Operation Mode</i> 620 for the starting behavior, <i>Operation Mode</i> 630 for the stopping behavior or the configured brake control system. See chapter 7.6.5.5 "Release brake".
43 - External fan	The <i>Switch-on temperature</i> 39 has been reached. An external fan can be switched on by the signal. See chapter 7.6.5.7 "External fan".
50 - Warning service fan	The time remaining until service has expired. See chapter 10.3.2 "Fan".



Operation mode 531, 532, 53	33, 554	Function
51 - Warning service DC-link		The time remaining until service has expired. See chapter 10.3.1 "DC-link".
80 - PLC-Output Buffer 1		Output signal of a PLC function. Signal source "2401 - PLC output buffer 1" is the output signal. The assignment is performed via parameter <i>PLC-target output 1</i> 1350 or <i>PLC-target output 2</i> 1351 .
81 - PLC-Output Buffer 2	1	Output signal of a PLC function. Signal source "2402 - PLC output buffer 2" is the output signal. In a table function the assignment is performed via parameter <i>PLC-target output 1</i> 1350 or <i>PLC-target output 2</i> 1351 .
82 - PLC-Output Buffer 3		Output signal of a PLC function. Signal source "2403 - PLC output buffer 3" is the output signal. In a table function the assignment is performed via parameter <i>PLC-target output 1</i> 1350 or <i>PLC-target output 2</i> 1351 .
83 - PLC-Output Buffer 4		Output signal of a PLC function. Signal source "2404 - PLC output buffer 4" is the output signal. In a table function the assignment is performed via parameter <i>PLC-target output 1</i> 1350 or <i>PLC-target output 2</i> 1351 .
90 to Obj 0x3003 DigOut 1 to 94 Obj 0x3003 DigOut 5	2	Sources of CAN objects.
100 to 194		Operation modes inverted (LOW active).

7.6.5.1 Digital message

Signals output via a digital output can be linked to a function of the frequency inverter. The signals selected for the following parameters can be linked to functions:

- *Operation mode OUT1D (X13.5)* **531(**digital output)
- Operation mode OUT2D (X10/relay) **532**
- *Operation mode OUT3D (X11.6)***533 (digital input/output)**
- Digital: Source MFO1D 554 (multifunction output)

Signal	at di	aital	output	Oι	JT1D

175 -	Digital message OUT1D	Signal selected via Operation Mode OUT1D (X13.5) 531.		
Signal	at digital output Ol	JT2D (relay output)		
176 -	176 - Digital message OUT2D relay Signal selected via Operation Mode OUT2D (X10/relay) 532 .			
Signal at digital input/output (terminal X11.6)				
177 -	Digital message OUT3D	Signal selected via <i>Operation Mode OUT3D (X11.6)</i> 533 . Set: <i>Operation Mode Terminal X11.6</i> 558 = "1 - Output OUT3D".		
Signal at multifunction output				
181 -	Digital message MFO1D	Signal selected via $Digital$: $Source\ MFO1D\ 554$. Set: $Operation\ Mode\ MFO1\ (X13.6)\ 550 = "1 - Digital\ MFO1D".$		

² Comply with instructions on CANopen.

1

¹ Refer to application manual "PLC".



7.6.5.2 Setting frequency

510 Setting Frequency


517 Setting Frequency Switch Off Delta

If operation mode 4 - "Setting frequency" is selected for a digital output, the corresponding output will be active if the actual value *Stator frequency* **210** is greater than the value of *Setting Frequency* **510**.

The relevant output is switched over again once the *Stator frequency* **210** drops below the value "*Setting frequency* **510** minus *Setting Frequency Switch Off Delta* **517**".

Signal source 164 - "Setting frequency" can be linked to the functions of the frequency inverter.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
510	Setting Frequency	0.00 Hz	999.99 Hz	3.00 Hz
517	Setting Frequency Switch Off Delta	0.00 Hz	999.99 Hz	2.00 Hz





If Setting Frequency Switch Off Delta **517** > Setting Frequency **510** the output is never reset after the first switching on. Set up fitting values during commissioning.

Operation mode OUT1D (X13.5) 531(digital output)	or		
Operation mode OUT2D (X10/relay) 532	or	4 6 11: 6	
Operation mode OUT3D (X11.6) 533 (digital input/output)	or	4 - Setting frequency	
Digital: Source MFO1D 554 (multifunction output)			
Setting frequency 510		Set the value [Hz].	
For linking to functions		164 - Setting frequency	

7.6.5.3 Reference value reached

549 Reference Value Reached: Tolerance Band

In operation mode 5 - "Reference frequency reached" for a digital output, a message is generated via the corresponding output when the actual frequency has reached the reference value.

In operation mode 6 - "Reference percentage reached" for a digital output, a message is generated via the corresponding output when the actual percentage has reached the reference value.


Signal source 163 - "Reference frequency reached" or 178 - "Reference percentage reached" can be linked to the functions of the frequency inverter.

The hysteresis can be defined as a percentage of the adjustable range (Max - Min) via parameter *Reference Value Reached: Tolerance Band* **549**.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
549	Reference Value Reached: Tolerance Band	0.01%	20.00%	5.00%




Operation mode OUT1D (X13.5) 531 (digital output)	or	5 - Reference frequency reached
Operation mode OUT2D (X10/relay) 532	or	or 6 - Reference percentage
Operation mode OUT3D (X11.6) 533 (digital input/output) Digital: Source MFO1D 554 (multifunction output)	or	reached
Reference Value Reached: Tolerance Band 549		Set the value [%].
For linking to functions		163 - Reference frequency reached
		or
		178 - Reference percentage reached



Example:

Maximum control deviation [Hz] = $\Delta f \times Reference Value Reached : Hysteresis 549$ [%] = $(Maximum Frequency 419 - Minimum Frequency 418) \times Reference Value Reached : Hysteresis 549$ [%] = $(50 \text{ Hz} - 3.5 \text{ Hz}) \times 5\% = 2.325 \text{ Hz}$



7.6.5.4 Flux forming finished

If operation mode "30 - flux forming finished" is selected for a digital output, the corresponding output becomes active when the flux-formation is finished. The time for the flux-formation results from the operating state of the machine and the set parameters for magnetizing the machine. The magnetizing can be defined via the starting behavior and is influenced by the amount of the set starting current. See chapter 7.3.2 "Starting behavior".



7.6.5.5 Release brake

The Open brake function in operation mode 41 enables the activation of a corre-sponding unit via the digital control output. The function uses both the control commands via the contact inputs and the set starting and stopping behavior for controlling the digital output.

According to the configured starting behavior, the output is switched on when the magnetizing of the motor is finished. When the *Brake release time* **625** has elapsed, the drive is accelerated. See chapter 7.3.2 "Starting behavior".

The stopping behavior of the drive depends on the configuration of the parameters *Operation mode* **630**. See chapter 7.3.3 "Stopping behavior".

If stopping behavior 2 or 5 with stop function is selected, the drive is controlled to zero speed and the digital output is not switched off. In the other operation modes of the stop behavior, the control of the brake is possible. At the start of a free coasting of the drive, the digital output is switched off.

This is similar to the behavior in the case of stopping behavior with shutdown. The drive is de-celerated and supplied with current for the set holding time. Within the set holding time, the control output is switched off and thus the brake activated.

	Control of Brake		
Stopping behavior 0	Operation mode "41 - Open brake" switches off the digital output assigned to the function immediately. The mechanical brake is activated.		
Stopping behavior 1, 4	Operation mode "41 - Open brake" switches off the digital output assigned to the function when the <i>Switch-off threshold stop function</i> 637 is reached. The mechanical brake is activated.		
Stopping behavior 2, 5	Operation mode "41 - Open brake" leaves the digital output assigned to the function switched on. The mechanical brake remains open.		
Stopping behavior 7	Operation mode "41 - Open brake" switches off the digital output assigned to the function when the <i>Braking time</i> 632 has elapsed. The mechanical brake is activated.		

7.6.5.6 Current limitation

Operation modes 15 to 19 link the digital outputs and the relay output to the functions of the intelligent current limits. The reduction of power by the set figure in percent of the rated current depends on the selected operation mode. Accord-ingly, the event for intervention of the current limitation can be output via the op-eration modes of the digital outputs. If the function of the intelligent current limits is deactivated within the sensorless control, operation modes 16 to 19 are switched off in the same way.

7.6.5.7 External fan

Operation mode "43 - external fan" enables the control of an external fan. Via the digital output, the fan is switched on as soon as the *Switch-on temperature* **39** for the internal fans was reached. See chapter 7.10.2 "Fan".

7.6.5.8 Warning mask

536 Create warning mask

The Warning mask signals via a digital signal if an afore configured warning applies. The configuration of the Warning mask is carried out via *Create warning mask* **536**. Warnings and controller status messages can be combined. This enables internal or external control using a common output signal. The display of *Warning* **269** and *Controller Status* **275** is not affected by the Warning mask.

Select a setting 1 ... 43 for message activation.

Select a setting 101 ... 143 for deactivation of a message.



Cı	reate warning mask 536	Function
0 -	No change	Configured warning mask is not modified.
1 -	Activate everything	The warnings and controller status messages stated are linked in the warning mask.
2 -	Activate all Warnings	The warnings reports stated are linked in the warning mask.
3 -	Activate all controller states	The controller status reports stated are linked in the warning mask.
10 -	Activate Warning Ixt	The frequency inverter is overloaded
11 -	Activate Warning short-term Ixt	Overload reserve for 1 s minus the <i>Warning limit short-term Ixt</i> 405 has been reached.
12 -	Activate Warning long-term Ixt	Overload reserve for 60 s minus the <i>Warning limit long-term Ixt</i> 406 has been reached.
13 -	Activate Warning heat sink temperature	Max. heat sink temperature T_K minus the Warning limit heat sink temp. 407 reached.
14 -	Activate Warning inside temperature	Max. inside temperature T_K minus the Warning limit inside temp. 408 reached.
15 -	Activate Warning limit	The controller stated in <i>Controller Status</i> 275 limits the reference value.
16 -	Activate Warning Init	Frequency inverter is being initialized
17 -	Activate Warning Motor Temperature	Warning behavior according to parameterized <i>Operation Mode Motor Temp.</i> 570 at maximum motor temperature T _{PTC.}
18 -	Activate Warning Mains Failure	Phase Supervision 576 reports a phase failure.
19 -	Activate Warning Motor Protective Switch	Operation Mode 571 for motor circuit breaker triggered.
20 -	Activate Warning Fmax	The <i>Maximum Frequency</i> 419 was exceeded. The frequency limitation is active
21 -	Activate Warning analog input MFI1A	The input signal at analog input MFI1A is less than 1 V/2 mA in accordance with operation mode Error/Warning Behaviour 453 .
22 -	Activate Warning analog input MFI2A	The input signal at analog input MFI2A is less than 1 V/2 mA in accordance with operation mode Error/Warning Behaviour 563.
23 -	Activate Warnings system bus	A slave on the system bus signals an error.
24 -	Activate Warning Udc	The DC link voltage has reached the type-dependent minimum value.
25 -	Activate Application Warning	A warning application is signaled.
30 -	Activate Warning Controller Udc Dynamic Operation	Controller is active according to <i>Operation Mode</i> 670 .
31 -	Activate Warning Controller Shutdown	The output frequency in the case of a power failure is below the <i>Shutdown Threshold</i> 675 .
32 -	Activate Warning Controller Mains Failure	Failure of the mains voltage and power regulation active according to <i>Operation Mode</i> 670 for the voltage controller.
33 -	Activate Warning Controller Udc Limitation	The DC link voltage has exceeded the <i>Reference DC-Link Limitation</i> 680 .
34 -	Activate Warning Controller Voltage Pre-Control	The <i>Dyn. Voltage Pre-Control</i> 605 accelerates the control characteristics.
35 -	Activate Warning Controller I abs.	The output current is limited.
36 -	Activate Warning Controller Torque Limitation	The output power or the torque is limited by the speed controller.
37 -	Activate Warning Controller Torque Control	Switch-over of field-orientated control between speed and torque-controlled control method.
38 -	Activate Warning Ramp Stop	The <i>Operation Mode</i> 620 selected in starting be-havior limits the output current.



Create warning mask 536	Function
39 - Activate Warning Contr. Intel. Curr. Lim. LT-Ixt	Overload limit of the long-term Ixt (60 s) reached, intelligent current limits active.
40 - Activate Warning Contr. Intel. Curr. Lim. ST-Ixt	Overload limit of the short-term Ixt (1 s) reached, intelligent current limits active.
41 - Activate Warning Contr. In- tel. Curr. Lim. Tc	Max. heat sink temperature T_K reached, <i>Operation Mode</i> 573 for intelligent current limits active.
42 - Activate Warning Contr. Intel. Curr. Lim. Motor Temp.	Max. motor temperature T _{PTC} reached, <i>Operation Mode</i> 573 for intelligent current limits active.
43 - Activate Warning Controller Freq. Limitation	Reference frequency reached the <i>Maximum Frequency</i> 419 . The frequency limitation is active.
101 to 143	Deactivation of the operation mode within the warning mask.

The selected warning mask can be read out via parameter *Actual Warning Mask* **537**. The above operation modes of parameter *Create Warning Mask* **536** are encoded in the *Actual Warning Mask* **537**. The code is calculated by hexadecimal addition of the individual operation modes and the corresponding abbreviation.

	Wa	arning	code	Create Warning Mask 536
Α	FFFF	FFFF	-	1 - Activate everything
Α	0000	FFFF	-	2 - Activate all warnings
Α	FFFF	0000	-	3 - Activate all controller states
Α	0000	0001	Ixt	10 - Warning Ixt
Α	0000	0002	IxtSt	11 - Warning short-term Ixt
Α	0000	0004	IxtLt	12 - Warning long-term Ixt
Α	0000	8000	Tc	13 - Warning heat sink temperature
Α	0000	0010	Ti	14 - Warning inside temperature
Α	0000	0020	Lim	15 - Warning limit
Α	0000	0040	INIT	16 - Warning Init
Α	0000	0800	MTemp	17 - Motor temperature warning
Α	0000	0100	Mains	18 - Warning mains failure
Α	0000	0200	PMS	19 - Warning motor circuit breaker
Α	0000	0400	Flim	20 - Warning Fmax
Α	0000	0800	A1	21 - Warning analog input MFI1A
Α	0000	1000	A2	22 - Warning analog input MFI2A
Α	0000	2000	Sysbus	23 - Warning system bus
Α	0000	4000	UDC	24 - Warning Udc
Α	0000	8000	WARN2	25 - Warning, application
Α	0001	0000	UDdyn	30 - Controller Udc dynamic operation
Α	0002	0000	UDstop	31 - Controller shutdown
Α	0004	0000	UDctr	32 - Controller mains failure
Α	8000	0000	UDlim	33 - Controller Udc limitation
Α	0010	0000	Boost	34 - Controller voltage pre-control
Α	0020	0000	Ilim	35 - Controller I abs
Α	0040	0000	Tlim	36 - Controller torque limitation
Α	0800	0000	Tctr	37 - Controller torque control
Α	0100	0000	Rstp	38 - Ramp stop
Α	0200	0000	IxtLtlim	39 - Contr. intel. curr. lim. LT-Ixt
Α	0400	0000	IxtStlim	40 - Contr. intel. curr. lim. ST-Ixt
Α	0800	0000	Tclim	41 - Contr. intel. curr. lim. Tc
Α	1000	0000	MtempLim	42 - Contr. intel. curr. lim. motor temp.
Α	2000	0000	Flim	43 - Controller Freq. Limitation



Output signals

The output of a warning is signaled.

157 - Warning	1) Output of warning activated in C (W : M / F2)
25 - mask	Output of warning activated in <i>Create Warning Mask</i> 536 .

¹⁾ For linking to frequency inverter functions.

²⁾ For output via a digital output. Select the signal source for one of the parameters 531, 532, 533, 554. See chapter 7.6.5 "Digital outputs".



Parameter *Warning* **269** and *Warning* **356** (error environment) show the warnings independent from the created Warning mask.

Parameter *Controller Status* **275** and *Controller Status* **355** (error environment) show the Controller Status independent from the created Warning mask.

7.6.5.9 Warning mask, application

626 Create Warning Mask Application

The Warning mask Application signals via a digital signal if an afore configured warning applies. The configuration of the Warning mask Application is carried out via *Create Appl. Warning Mask* **626**. Depending on the application, any number of warnings can be configured. This enables internal and/or external control using a common output signal. The display of *Warning Application* **273** is not affected by the Warning mask.

Create Appl. Warning Mask 626	Function
0 - No change	The configured warning mask is not changed.
2 - Activate all warnings	The warnings reports stated are linked in the warning mask.
10 - Warning V-belt	Operation Mode 581 for V-belt monitoring signals noload operation of the application.
16 - Warning Service	The time remaining until service of DC-link or fan has expired.
17 - Warning User 1	The signal set on digital input <i>User Warning 1</i> 1363 is active.
18 - Warning User 2	The signal set on digital input <i>User Warning 2</i> 1364 is active.
102 - Deactivate all warnings	All warnings are deactivated.
110 - Deactivate warning V-belt	Warning 10 is deactivated.
116 - Deactivate warning service	Warning 16 is deactivated.
117 - Deactivate warning User 1	Warning 17 is deactivated.
118 - Deactivate warning User 2	Warning 18 is deactivated.

The selected warning mask application can be read out via parameter *Actual Appl. Warning Mask* **627**. The above operation modes of parameter *Create Appl. Warning Mask* **626** are encoded in the *Actual Appl. Warning Mask* **627**. The code is calculated by hexadecimal addition of the individual operation modes and the corresponding abbreviation.

	Warn	ing code	Create Appl. Warning Mask 626
Α	01C1	-	2 - Activate all warnings
Α	0001	BELT	10 - Warning V-belt
Α	0040	SERVICE	16 - Warning Service
Α	0800	User 1	17 - Warning User 1
Α	0100	User 2	18 - Warning User 2



Output signals

The output of a warning is signaled.

215 -	Warning	1)	
27 -	mask, appli- cation	2)	Output of warning activated in <i>Create Appl. Warning Mask</i> 626 .

¹⁾ For linking to frequency inverter functions.

²⁾ For output via a digital output. Select the signal source for one of the parameters 531, 532, 533, 554. See chapter 7.6.5 "Digital outputs".



Parameter *Warning Application* **273** shows the Application Warnings independent from the created Warning mask.

7.6.6 Digital inputs

The assignment of the control signals to the available software functions can be adapted to the application in question. In addition to the available digital control inputs, further internal logic signals are available as sources.

Each of the individual software functions is assigned to the various signal sources via parameterizable inputs. This enables a flexible use of the digital control signals.

559 Digital inputs PNP/NPN

Via parameter *Digital inputs PNP/NPN* **559**, the evaluation at the digital inputs can be selected as PNP (high-switching) or NPN (low-switching).

Terminal	Digital inputs PNP/NPN 559	Function
X11.4 X11.5 X11.6	0 - NPN (active: 0 V)	Digital input NPN. Low-switching (with negative signal).
X12.1 X12.2	1 - PIND (ACTIVA: 74 V)	Digital input PNP. High-switching (with positive signal). Factory setting.

In order to use multifunction input MFI1 as a digital input, setting 3 or 4 must be selected for parameter *Operation Mode MFI1* **452**.

Terminal	Operation Mode MFI1 452	Function
V12.2	3 - Digital NPN (active: 0 V)	Low-switching (with negative signal).
X12.3	4 - Digital PNP (active: 24 V)	High-switching (with positive signal).

In order to use multifunction input MFI2 as a digital input, setting 3 or 4 must be selected for parameter *Operation Mode MFI2* **562**.

Terminal	Operation Mode MFI2 562	Function
X12.4	3 - Digital NPN (active: 0 V)	Low-switching (with negative signal). Factory setting.
	4 - Digital PNP (active: 24 V)	High-switching (with positive signal).

In order to use the digital input/output (terminal X11.6) as a digital input, setting "0 - Input IN3D" must be selected for parameter *Operation Mode Terminal X11.6* **558**.

Terminal	Operation Mode Terminal X11.6 558	Function
X11.6	11 - 10000 10051)	The digital input/output is set as digital input. Factory setting .

For setting of X11.6 as digital output, refer to chapter 7.6.4 "Digital input/output IN3D/OUT3D".



7.6.6.1 List of control signals

- Select the function that is to be controlled. For example Start drive in anticlockwise operation.
- Select the control signal for the parameter of the function. For example select "74 IN4D" for parameter *Start Anticlockwise* **69**. In this case the drive starts anticlockwise operation if a signal applies on digital input IN4D (enable signal must also be set).

Control signals	Function
Selection for parameter 6 - On	Signal input is switched on
7 - Off	Signal input is switched on.
7 - 011	Signal input is switched off.
70 - Inverter Release	Enable signal of the frequency inverter via digital inputs STOA (X11.3) and STOB (X13.3). Or enable signal in remote mode via communication interface.
71 - IN1D	Signal at digital input IN1D (X11.4). Or signal in remote mode via communication interface.
72 - IN2D	Signal at digital input IN2D (X11.5). Or signal in remote mode via communication interface.
73 - IN3D	Signal at digital input IN3D (digital input/output, X11.6) in Op - $eration\ Mode\ Terminal\ X11.6\ {\bf 558} = "0 - input\ IN3D".$ Or signal in remote mode via communication interface.
74 - IN4D	Signal at digital input IN4D (X12.1). Or signal in remote mode via communication interface.
75 - IN5D	Signal at digital input IN5D (X12.2). Or signal in remote mode via communication interface.
76 - MFI1D	Signal at multifunction input MFI1 (X12.3) in <i>Operation mode MFI1</i> 452 "3 - digital NPN (active: 0 V)" or "4 - digital PNP (active: 24 V)". Or signal in remote mode via communication interface.
77 - MFI2D	Signal at multifunction input MFI2 (X12.) in <i>Operation Mode MFI2</i> 562 "3 - Digital NPN (active: 0 V)" or "4 - Digital PNP (active: 24 V)". Or signal in remote mode via communication interface.
157 - Warning Mask	The defined warning mask of parameter <i>Create Warning Mask</i> 536 signals a critical operating point.
160 - Ready Signal	Frequency inverter is initialized and ready for operation.
161 - Run Signal	Enable signals (STOA and STOB) and a start command (<i>Start Clockwise</i> 68 or <i>Start Anticlockwise</i> 69) are applied, output frequency present.
162 - Error Signal	Monitoring function signals an operational fault.
163 - Reference Frequency reached	Signal when the <i>Actual Frequency</i> 241 has reached the reference frequency
164 - Setting Frequency	The actual <i>Stator Frequency</i> 210 is higher than the value of <i>Setting Frequency</i> 510 .
165 - Warning Ixt	The monitoring functions report an overload of the frequency inverter
166 - Warning Heat Sink Temperature	Maximum heat sink temperature T_K minus the $\textit{Warning Limit Heat Sink Temp.}$ 407 reached.
167 - Warning Inside Tempera- ture	Maximum inside temperature T_i minus the Warning Limit Inside Temp. 408 reached.
168 - Warning Motor Tempera- ture	Warning behavior according to parameterized <i>Operation Mode Motor Temp.</i> 570 at maximum motor temperature T _{PTC} .
169 - General Warning	Signal when <i>Warnings</i> 269 are displayed with a critical operating point



Control signals Selection for parameter	Function
170 - Warning Overtemperature	 The value (Maximum heat sink temperature T_K) minus (Warning Limit Heat Sink Temp. 407) or (Maximum inside temperature T_i) minus (Warning Limit Inside Temp. 408)
175 0: 1 10: 10:1710	was reached.
175 - Digital Signal OUT1D	Signal selected via <i>Op. Mode OUT1D (X13.5)</i> 531 .
176 - Digital Signal OUT2D Relay	Signal selected via <i>Op. Mode OUT2D (X10/Relay)</i> 532 .
177 - Digital Signal OUT3D	Signal selected via Op. Mode OUT3D (X11.6) 533.
178 - Reference Percentage reached	Signal when the <i>Actual Percentage Value</i> 230 has reached the <i>Reference Percentage Value</i> 229 .
179 - Mains Failure	Failure of the mains voltage and power regulation active according to <i>Operation Mode</i> 670 for the voltage controller.
180 - Warning Motor Protection Switch	Parameterized <i>Operation Mode</i> 571 of the motor circuit breaker triggered.
181 - Digital Signal MFO1D	Signal selected via Digital: Source MFO1D 554.
215 - Warning Mask, Application	The defined warning mask of parameter <i>Create Appl. Warning Mask</i> 626 signals a critical operating point.
216 - Application Warning	All Application Warnings are deactivated. Display is effected via parameter <i>Application Warnings</i> 273 .
219 - Technology Controller within Backlash	The control deviation lies within the range defined by <i>Back-lash</i> 618 .
264 - Warning service DC-link	Signal if the time remaining until service has expired. Parameter <i>Operation Mode Service Interval DC-link</i> 1534 must be set to "2 - Alarm Message". Parameter <i>Maintenance Note</i> 1533 displays a message.
265 - Warning service fan	Signal if the time remaining until service has expired. Parameter <i>Operation Mode Service Interval Fan</i> 1535 must be set to "2 - Alarm Message". Parameter <i>Maintenance Note</i> 1533 displays a message.
270 to 277	Operation modes 70 to 77 of the digital inputs inverted (LOW active).
284 - STOA inverted	Inverted signal status on digital input STOA for enable.
285 - STOB inverted	Inverted signal status on digital input STOB for enable.
292 - STOA	Signal status on digital input STOA for enable.
293 - STOB	Signal status on digital input STOB for enable.
323 - Power is on	Signal if mains voltage is switched on and pre-charging is finished.
471 - Energy saving function is active	Parameter <i>Operation mode energy saving function</i> 1550 is set to "1 - manual" or "2 - automatic". The digital input or logic signal selected for parameter <i>Energy saving function on</i> 1552 has switched on the energy saving function.



Sel	Control signals ection for parameter		Function
525 -	Inverter Re- lease(Hardware)		Enable signal of the frequency inverter via digital inputs STOA (X11.3) and STOB (X13.3).
526 -	IN1D (Hardware)		Signal at digital input IN1D (X11.4).
527 -	IN2D (Hardware)		Signal at digital input IN2D (X11.5).
528 -	IN3D (Hardware)		Signal at digital input IN3D (digital input/output, X11.6) in Op - $eration\ Mode\ Terminal\ X11.6\ {\bf 558} = "0 - Input\ IN3D".$
529 -	IN4D (Hardware)		Signal at digital input IN4D (X12.1).
530 -	IN5D (Hardware)	1	Signal at digital input IN5D (X12.2).
531 -	MFI1D (Hardware)		Signal at multifunction input MFI1 (X12.3) in <i>Operation Mode MFI1</i> 452 "3 - Digital NPN (active: 0 V)" or "4 - Digital PNP (active: 24 V)".
532 -	MFI2D (Hardware)		Signal at multifunction input MFI2 (X12.) in <i>Operation Mode MFI2</i> 562 "3 - Digital NPN (active: 0 V)" or "4 - Digital PNP (active: 24 V)".
537 to	544		Operation modes 525 to 532 of the digital inputs inverted (LOW active).
640 to 655	Out-PZD3 Boolean to Out-PZD18 Boolean	2	Process data for Profibus communication. Optional communication module CM-PDP-V1 with Profibus interface is required.
700 -	RxPDO1 Boolean1		Process data object for system bus communication.
701 -	RxPDO1 Boolean2		Process data object for system bus communication.
702 -	RxPDO1 Boolean3		Process data object for system bus communication.
703 -	RxPDO1 Boolean4	3	Process data object for system bus communication.
710 to	713		Operation modes 700 to 703 for RxPDO2.
720 to	723		Operation modes 700 to 703 for RxPDO3.
730 -	Sysbus emergency		Signal of system bus communication.
810 to 814	Obj 0x3003 DigOut 1 to Obj 0x3003 DigOut 5	4	Sources of CAN objects for CANopen® communication.
832 to 847	Obj 0x3005 Demux Out 1 to Obj 0x3005 Demux Out 16		Sources at output of demultiplexer for CANopen® communication.
910 to 925	Output DeMux bit 0 to Output DeMux bit 15	5	Bit 0 to Bit 15 on output of de-multiplexer; de-multiplexed process data signal via system bus or Profibus on input of multiplexers (parameter <i>DeMux Input</i> 1253).
2401 to 2416	PLC-Output Buffer 1 to PLC-Output buffer 16	6	Output signals of PLC-functions.

 ¹ The digital signal is independent from the configuration of the parameter *Local/Remote* 412.
 ² Refer to instructions on Profibus.
 ³ Refer to instructions on system bus.
 ⁴ Refer to instructions on CANopen.
 ⁵ Refer to instructions on system bus or Profibus.
 ⁶ Refer to application manual PLC.





Signals via physical contacts (IN1D...IN5D, MFI1, MFI2) are only evaluated if an operation mode *Local/Remote* **412** with "Control via Contact" or "Control 3-Wire" (0, 4 or 5) is selected.

In all other operation modes *Local/Remote* **412** (1, 2, 3) physical contacts are only evaluated, if the corresponding signals in the digital inputs with the suffix (Hardware) are selected.

Signals not referring to a physical input are evaluated independent of the operation mode *Local/Remote* **412**.

7.6.6.2 Start command

68 Start Clockwise 69 Start Anticlockwise

The parameters *Start Clockwise* **68** and *Start Anticlockwise* **69** can be linked to the available digital control inputs or the internal logic signals. The drive is only accelerated according to the control method after a start command.

The logic functions are used for the specification of the direction of rotation, but also for using the parameterized *Operation Mode* **620** for the starting behavior and *Operation Mode* **630** for the stopping behavior.


Parameter	Factory setting
Start Clockwise 68	71 – IN1D
Start Anticlockwise 69	72 – IN2D

7.6.6.3 3-Wire Control

87 Start 3-Wire Ctrl

In the case of 3-wire control, the drive is controlled using digital pulses. The drive is prepared for starting via the logic state of the signal *Start 3-Wire Ctrl* **87** and started by a Start clockwise pulse (Parameter *Start Clockwise* **68**) or a start anticlockwise pulse (parameter *Start Anticlockwise* **69**). By switching off the signal *Start 3-Wire Ctrl* **87**, the drive is stopped.

The control signals for Start clockwise and Start anticlockwise are pulses. The functions Start clockwise and Start anticlockwise for the drive are latching-type functions when signal *Start 3-Wire Ctrl* **87** is switched on. Latching is cancelled when the latching signal is switched off.



- (C) Clockwise
- (A) Anticlockwise

- (1) Signals are ignored
- (2) Time t < 32 ms

The drive is started according to the configured starting behavior if the signal *Start 3-Wire Ctrl* **87** is switched on and a positive signal edge for Start clockwise or Start anticlockwise is detected.

Once the drive has started, new edges (1) on the start signals will be ignored.

If the start signal is shorter than 32 ms (2) or if both start signals were switched on within 32 ms (2), the drive will be switched off according to the configured stopping behavior.



3-wire control is activated with parameter *Local/Remote* **412**:

Local/Remote 412	Function
5 - Control 3-wire	Control of direction of rotation (parameter <i>Start Clockwise</i> 68 , <i>Start Anticlockwise</i> 69) and signal <i>Start 3-Wire Ctrl</i> 87 via digital inputs.

See chapter 7.3.1 "Control" for further operation modes of parameter *Local/Remote* **412**.

Parameter	Factory setting
Start 3-Wire Ctrl 87	7 - Off

7.6.6.4 Motor potentiometer

62 Frequency Motorpoti Up

63 Frequency Motorpoti Down

The reference frequency of the drive can be set via digital control signals. See chapter 7.5.3.3.1 "Control via reference frequency channel".

Parameter	Factory setting
Frequency Motorpoti Up 62	7 - Off
Frequency Motorpoti Down 63	7 - Off

72 Percent Motorpoti Up

73 Percent Motorpoti Down

The reference percentage can be set via digital control signals. See chapter 7.5.3.3.2 "Control via reference percentage channel".

Paramete	Factory setting
Percent Motorpoti Up 62	7 - Off
Percent Motorpoti Down 63	7 - Off

7.6.6.5 Fixed frequency changeover

66 Fixed Frequency Change-Over 1

67 Fixed Frequency Change-Over 2

131 Fixed Frequency Change-Over 3

By combining the logic states of the fixed frequency changeover modes 1, 2 and 3, the fixed frequencies 1 to 8 (parameters 480 to 488) can be selected. See chapter 7.5.1.3 "Fixed frequencies".

Parameter	Factory setting
Fixed Frequency Change-Over 1 66	74 - IN4D
Fixed Frequency Change-Over 2 67	7 - Off
Fixed Frequency Change-Over 3 131	7 - Off

7.6.6.6 Fixed percentage changeover

75 Fixed Percent Change-Over 1

76 Fixed Percent Change-Over 2

By combining the logic states of *Fixed Percent Change-Over 1* **75**and *Fixed Percent Change-Over 2* **76**, the fixed percentages 1 to 4 (Parameters 520 to 523) can be selected. See chapter 7.5.2.3 "Fixed percentages".

Parameter	Factory setting
Fixed Percent Change-Over 1 75	7 - Off
Fixed Percent Change-Over 2 76	7 - Off



7.6.6.7 Jog Start

81 JOG Start

The selected signal source starts the JOG-function. The drive accelerates to the rotary frequency set via parameter *JOG Frequency* **489**.

Parameter	Factory setting
JOG Start 81	7 - Off

7.6.6.8 Error Acknowledgment

103 Error Acknowledgement

The frequency inverters feature various monitoring functions which can be adapted via the error and warning behavior. Switching the frequency inverter off at the various operating points should be avoided by an application-related parameterization. If there is a fault switch-off, this report can be given via the parameter Program(ming) 34 or the logic signal can be acknowledged with parameter $Error\ Acknowledgment$ 103.

Parameter	Factory setting
Error Acknowledgment 103	75 - IN5D

Possibilities of error acknowledgement:

- Via the Stop key of the operator panel
 A reset via the STOP key can only be executed, if Parameter Local/Remote 412 allows the control via keypad
- via parameter Program(ming) 34
- via parameter Error Acknowledgement 103 which is assigned a logic signal or a digital input
 A reset via a digital input can only be executed, if Parameter Local/Remote 412 allows that control or if a physical input with the suffix (Hardware) is selected.
- When using a Fieldbus and control via Statemachine: Setting the reset bit in the Controlword. Refer to the Communication manuals for details.

7.6.6.9 Thermal contact

204 Thermal contact for P570

The monitoring of the motor temperature is a part of the error and warning behavior which can be configured as required. Parameter *Thermal contact for P570* **204** links the digital input signal to the *Operation Mode Motor Temp.* **570**. See chapter 7.4.6 "Motor temperature". By default, multifunction input 2 is used for connection of a thermal contact.

Parameter	Factory setting
Thermal contact for P570 204	532 - MFI2D (Hardware), multifunction input 2 (terminal
,	X12.4)
Operation Mode Motor Temp. 570	0 - Off

- For parameter *Thermal contact for P570* **204**, the digital input to which the thermal contact is connected must be selected.
- For parameter *Operation Mode Motor Temp.* **570**, select an evaluation (warning or error switch-off).

If a multifunction input is selected for parameter *Thermal contact for P570* **204**, the multifunction input must be configured as a digital input:

Multifunction input 1	Operation Mode MFI1 452	3 -	Digital NPN (active: 0 V)
		4 -	Digital PNP (active: 24 V)
Multifunction input 2	Operation Mode MFI2 562		Digital NPN (active: 0 V)
Haldiranedon inpac 2			Factory setting
		4 -	Digital PNP (active: 24 V)



Select NPN or PNP according to the required evaluation of the thermal contact.

If a thermal contact is connected to multifunction input 2, no change of *Thermal contact for P570* **204** and *Operation Mode MFI2* **562** is required in the factory setting. You only have to set up the required evaluation via parameter *Operation Mode Motor Temp.* **570**.

7.6.6.10 n-/T-control changeover

164 n-/T-Control Change-Over

The field-orientated control procedures in configurations 410 and 610 contain the functions for speed or torque-de-pendent control of the drive. The changeover can be done in ongoing operation, as an additional functionality monitors the transition between the two con-trol systems. The speed controller or the torque controller is active, depending on the *n-/T-Control Change-Over* **164**.

For information on how to set up the speed controller, refer to chapter 7.9.5.3 "Speed controller".

For information on how to set up the torque controller, refer to chapter 7.9.5.2 "Torque controller".

Parameter	Factory setting
n-/T-Control Change-Over 164	7 - Off

7.6.6.11 Dataset changeover

70 Data Set Change-Over 1 71 Data Set Change-Over 2

Parameter values can be stored in four different data sets. This enables the use of various parameter values depending on the current operation point of the frequency inverter. The changeover between the four data sets is done via the logic signals assigned to the parameters *Data Set Change-Over 1* **70** and *Data Set Change-Over 2* **71**.

Addressing			
Data Set Change- Over 1 70	Data Set Change- Over 2 71	Active data set	
0	0	Data set 1 (DS1)	
1	0	Data set 2 (DS2)	
1	1	Data set 3 (DS3)	
0	1	Data set 4 (DS4)	

0 = contact open 1 = contact closed

Parameter	Factory setting	Terminal
Data Set Change-Over 1 70	73 - IN3D	X11.6
Data Set Change-Over 2 71	7 - Off	-

The actual value parameter Active Data Set 249 shows the selected data set.


Save in a data set: parameter values that are measured during Setup

Select "Setup" manually in menu of operator panel.

The data set selection is displayed.

- Select data set 0 if all data sets are to contain the same parameter values.
- Select one of the data sets 1 ... 4 for commissioning of several motors or for different operating points.

Example: For auto set-up (auto-tuning) and motor data, select data set 1.






If "Setup" is performed, the entered and measured motor data is saved in the selected data set.

Set a parameter value in a data set

Example: Set nominal motor voltage P370 in data set 2.



When the frequency inverter is switched on for the first time, the data set selection is not displayed. In this case, all entered and measured motor data will be saved in all four data sets.

7.6.6.12 Handshake Traverse

49 Handshake Traverse Function

Via parameter *Handshake Traverse Function* **49**, the signal source is selected for specification of the direction of rotation of the slave drive of the traverse function. The traverse function is switched on via parameter *Operation Mode* **435**. See chapter 7.10.8 "Traverse function".

Parameter	Factory setting
Handshake Traverse Function 49	7 - Off

7.6.6.13 Brake chopper release

95 Brake Chopper Release

Via the signal assigned to parameter *Brake Chopper Release* **95**, the brake chopper can be released or disabled. In the factory settings, the brake chopper is released if the frequency inverter release is switched on.

Parameter	Factory setting	Terminals
Brake Chopper Release 95	70 - Inverter Release	X11.3 and X13.3

Example:

Brake Chopper Release **95** = "6- On": The brake chopper is released.

Brake Chopper Release **95** = "7- Off": The brake chopper is disabled.

For information on how to set up the brake chopper, refer to chapter 7.10.4 "Brake chopper and brake resist".

NOTE

A connected brake resistor is only used if the brake chopper release is present. At brake operations or other generator states an overvoltage switch off can happen if the electrical energy is not dissipated.

7.6.6.14 User warning

1363 User Warning 1

1364 User Warning 2

Parameterization of an user warning enables triggering a warning in the device via a digital signal if a critical state in the plant occurs. The warning is displayed in *Warnings Application* **273** and can be transmitted to a higher-level control like a PLC. Please check parameter *Create warning mask application* **626** and chapter 7.6.5.9 "Warning mask, application" for further explanations.



7.6.6.15 External error

183 External Error

Parameterization of an external error enables switching off or shutting down several frequency inverters at a time if a fault occurs in the plant or the drive. If an error occurs in a frequency inverter, the error signal can be transmitted via a bus system and the required reaction can be triggered in another frequency inverter. The logic signal or digital input signal which is to trigger the external error can be assigned to parameter *External Error* **183**.

Via parameter *Op. Mode ext. Error* **535**, the response to an external error can be configured. See chapter 7.4.5 "External error".

Ope	ration Mode 535	Function
0 -	Disabled	No response to external errors. Factory setting.
1 - Error-Switch-Off output if the logic signal or digital input signal for parameter		The drive is switched off and the error message "F1454 External Error" is output if the logic signal or digital input signal for parameter <i>External Error</i> 183 is present.
2 - 3	Shutdown, Error	The drive is stopped at the current deceleration ramp and the error message "F1454 External Error" is output if the logic signal or digital input signal for parameter <i>External Error</i> 183 is present.
3 -	Emergency-Stop, Error	The drive is stopped at the set emergency stop ramp and the error message "F1454 External Error" is output if the logic signal or digital input signal for parameter <i>External Error</i> 183 is present.

Parameter	Factory setting
External Error 183	7 - Off

For setting up external warnings parameters *User Warning 1* **1363** and *User Warning 2* **1364** can be used. Check chapter 7.6.5.9 "Warning mask, application" for further details.

7.6.6.16 PLC

Logic functions and analog functions with functional block programming

With the PLC-functions (table of functions and graphic functional block programming), external analog or digital signals and internal logic signals of the frequency inverter can be linked to one another. Apart from standard AND, OR and XOR combinations, various complex logic functions and analog functions are available. The corresponding output value can be used for other logic instructions and digital outputs. Logic instructions can be combined to one another so that complex links can be realized. Analog values can be processed and output via analog outputs.

The instructions enable flexible adjustment for linking different input signals.

Analog functions include, for example, comparisons of analog input values, mathematical functions, PID control functions, filters, limitations, switches and counters.

Example:

A drive is to start if

- enable is given AND IN4D is set OR
- enable is given AND IN5D and MFI1D are set.

Refer to application manual "PLC".

7.6.6.17 Multiplexer/demultiplexer

The multiplexer/demultiplexer enables the transfer of various digital signals between an overriding controller and frequency inverters via field bus or between frequency inverters via the system bus.

Multiplexer:

1252 Mux Inputs

The multiplexer features 16 inputs for logic signals or digital input signals.



On the output, the logic signal 927 - "Output MUX" for the inputs of the TxPDO process data of the system bus or for PZDx-IN process data of the Profibus can be used.

Parameter		Factory setting		
1252	Mux Inputs	7 -	Off	

1250 Mux Input Index (write) 1251 Mux Input index (read)

The parameters *Mux Input Index (write)* **1250** and *Mux Input Index (read)* **1251** for the input signals of the multiplexer enable parameterization via the operator panel or the application VTable in VPlus.

Parameters		Setting		
No. Description		Min.	Max.	Fact. sett.
1250	Mux Input Index (write) 1)	0	33	1
1251	Mux Input Index (read)	0	33	1

1)	non-volatile (fixed parameterization):		Volatile:	
	0: All indices in EEPROM		17:	All indices in RAM
	116:	One index in EEPROM	1833:	One index 116 in RAM

NOTE

Setting "0" for Mux Input Index (write) 1250 changes all data in EEPROM and RAM.

In the case of non-volatile storage (0...16), the changed values are still available when power supply is switched on again.

In the case of volatile storage (17...33), the data is only stored in RAM. If the unit is switched off, this data is lost and the data required are loaded from EEPROM.

Demultiplexer:

1253 DeMux Input

The demultiplexer features an input $DeMux\ Input\ 1253$ whose signal can be for the process data RxPDO of the system bus or OUT-PZDx of Profibus.


On the output of the demultiplexer, the logic signals "910 - Output DeMux Bit 0" to "925 - Output DeMux Bit15" are available, e.g. for control of PLC-functions.

Operation modes for DeMux input 1253		
9 -	Zero	
704 727 -	RxPDO Word	
740, 741 -	Remote control word , remote state word	
754 757 -	OUT-PZD word	
900 -	Controller status	
927 -	Output MUX	

	Demultiplexer outputs
910 925 -	Output DeMux Bit 0 output DeMux Bit 15



Example: Transfer of a user-defined status word from a slave to a master via system bus or Profibus, parameterization of multiplexer and demultiplexer using PC application VTable in VPlus



Settings on transmitter:

- In VPlus, start application VTable via the button bar.
- In VTable assign the required signal sources for sending to parameter *Mux. Inputs* **1252** index 1 to index 16. A setting for index 0 results in this setting being taken over for all other indices.
- Assign signal source "927 Output MUX" to a TxPDO process data parameter of the system bus or a PZDx-IN process data parameter of Profibus.

Settings on receiver:

• Assign the corresponding RxPDO signal sources of the system bus or OUT-PZD signal sources of Profibus to parameter *DeMux Input* **1253**.

The transmitted signals are available at the receiver as signal sources 910 to 925.

7.6.7 Input PWM/repetition frequency/pulse train

496 Operation Mode IN2D (PWM/repetition frequency/pulse train)

A PWM signal (pulse-width modulated signal), frequency signal or a pulse train (pulse sequence) signal can be used for definition of a reference value. The signal at digital input IN2D (at terminal X11.5) is evaluated according to the selected *Operation Mode IN2D* **496**.

Operation Mode IN2D 496	Function
0 - Off	The PWM signal or repetition frequency is zero.
0 - OII	Factory setting.
	PWM signal detection at digital input IN2D (at terminal X11.5).
10 - PWM, 0% - 100%	0 100% of Maximum Reference Percentage 519 or 0 100%
	of Maximum Frequency 419. See 7.6.7.1 "PWM input".
	PWM signal detection at digital input IN2D (at terminal X11.5).
11 - PWM, -100% – 100%	-100 100% of Maximum Reference Percentage 519 or
11 - PWM, -100% - 100%	-100 100% of <i>Maximum Frequency</i> 419 . See 7.6.7.1 "PWM
	input".
	Repetition frequency input at digital input IN2D (at terminal
20 DE Cingle Evaluation	X11.5). One edge of the frequency signal is evaluated. The signal
20 - RF Single Evaluation	can also be evaluated as a percentage. See 7.6.7.2 "Repetition
	frequency input".



Operation Mode IN2D 496	Function
21 - RF Double Evaluation	Repetition frequency input at digital input IN2D (at terminal X11.5). Both edges of the frequency signal are evaluated. The signal can also be evaluated as a percentage. See 7.6.7.2 "Repetition frequency input".
30 - Pulse Train	Pulse train (pulse sequence) signal at digital input IN2D (at terminal X11.5) as reference frequency. Via parameter <i>Pulse Train Scaling Frequency</i> 654 , you can set which input frequency corresponds to the value of <i>Maximum Frequency</i> 419 . See 7.6.7.3 "Pulse train". Percentage: Via parameter <i>Pulse Train Scaling Frequency</i> 654 , you can set which percentage corresponds to the value of <i>Maximum Reference Percentage</i> 519 . The signal can also be evaluated as a percentage.



Digital input IN2D is intended for use as PWM input, repetition frequency input or pulse train input. Digital input IN2D cannot be used for other functions if the function PWM input, repetition frequency or pulse train is selected for *Operation Mode IN2D* **496**.

In the factory settings, IN2D is linked to parameter *Start Anticlockwise* **69**. If the PWM, repetition frequency or pulse train input and the function "Start anticlockwise" are to be used parameter *Start Anticlockwise* **69** must be assigned another digital input.

7.6.7.1 **PWM input**

Digital input IN2D (terminal X11.5) can be used as PWM input. For parameter $Operation\ Mode\ IN2D\ 496$, select setting "10 - PWM, 0% -100%" or "11 - PWM, -100% - 100%".

For definition of reference values, the following settings can be selected:


- Reference Percentage Source 1 476 = "10 Repetition Percentage Value".
- Reference Percentage Source 2 494 = "10 Repetition Percentage Value".

The percentage is referred to *Maximum Reference Percentage* **519**.

652 PWM-Offset 653 PWM-Amplification

Via parameters *PWM-Offset* **652** and *PWM-Amplification* **653**, the PWM input signal can be adjusted for the application.

Parameters		Setting		
No. Description		Min.	Max.	Fact. sett.
652	PWM-Offset	-100.00%	100.00%	0.00%
653	PWM-Amplification	5.0%	1000.0%	100.0%



PWM value =
$$PWM - Offset$$
 652 + $\left(\frac{Ton}{T} [\%] \times PWM - Amplification 653\right)$

PWM-Input 258 shows the actual value of the PWM input.

PWM frequencies in the range between 50 Hz and 15 kHz can be evaluated.



Output as frequency value

The input percentage value can be selected as frequency value for the reference frequency channel. Parameter *Reference Frequency Source 1* **475** or *Reference Frequency Source 2* **492** enables the selection:

The range 0% ... 100% or -100% ... 100% on the PWM-input corresponds to the frequency range 0... *Maximum Frequency* **419**.

$$f = \frac{Input \ value}{100\%} * Maximum \ Frequency$$
 419

7.6.7.2 Repetition frequency input

Digital input IN2D (terminal X11.5) can be used as repetition frequency input. For parameter *Operation Mode IN2D* **496**, "20 - RF Single Evaluation" or "21 - RF Double Evaluation" must be selected. For definition of reference values, the following settings can be selected:

- Reference frequency source 1 475 = "10 Repetition Frequency".
- Reference frequency source 2 492 = "10 Repetition Frequency".

The percentage is referred to *Maximum Frequency* **419**.

497 Rep.Freq: Divider

The signal frequency at the selected repetition frequency input can be scaled via parameter *Rep.Freq: Divider* **497**. The parameter value is comparable to the number of division marks of an encoder per revolution of the drive. The frequency limit of digital input IN2D is to be taken into account for the frequency of the input signal.

Parameters		Setting		
No.	Description	Min. Max. Fact. sett.		
497	Rep.Freq: Divider	1	8192	1024

An inverted evaluation can be set via the reference frequency channel in parameter *Operation Mode* **493**. See chapter 7.5.1.2 "Positive and negative reference frequencies".

Parameter *Repetition Frequency/Pulse Train* **252** shows the actual value of the repetition frequency input.

Output as percentage

In the case of a parameterization as repetition frequency, the read frequency value is also available as a percentage for the reference percentage channel. 0 ... 100% correspond to the signal frequency range 0 ... *Maximum Frequency* **419** at the repetition frequency input. The conversion is done using the following formula:

Percentage value =
$$\frac{\text{Frequency value}}{\text{Maximum Frequency 419}} \times 100\%$$

7.6.7.3 Pulse train

At digital input IN2D (terminal X11.5), a pulse train (pulse sequence) signal can be defined as reference value. Parameter *Operation Mode IN2D* **496** must be set to "30 - Pulse Train".

For setting of the reference values, the following settings can be selected:

- Reference Frequency Source 1 475 = "10 Repetition Frequency".
- Reference Frequency Source 2 492 = "10 Repetition Frequency".



654 Pulse Train Scaling Frequency

The pulse train (pulse sequence) signal at digital input IN2D (terminal X11.5) is scaled. Via parameter *Pulse Train Scaling Frequency* **654**, you can set which input frequency corresponds to the value of *Maximum Frequency* **419**. A read frequency of *Maximum Frequency* **419** means that at the pulse train input, a frequency with the value of the scaling factor is applied.

	Parameters		Setting	
No.	Description	Min. Max. Fact. set		
654	Pulse Train Scaling Frequency	0	32000	25000

If parameter *Pulse Train Scaling Frequency* **654** is set to zero, the frequency value at the digital input will not be scaled.

Parameter Repetition Frequency/Pulse Train 252 shows the actual value of pulse train input.


Pulse train signal on IN2D as reference value:

Reference Frequency Source 1 475 or Reference Frequency Source 2 492	10 - Repetition Frequency
Operation mode IN2D 496	30 - Pulse Train
Pulse Train Scaling Frequency 654	The scaled pulse train signal is the reference frequency
	value.

IN2D • X11.5 P496 30-Pulse Train
$$\rightarrow$$
 $f_{reference}$ P654 \square Hz

Reference frequency value:

$$\label{eq:freference} \textit{freference} = \textit{fin2d} \times \frac{\textit{Maximum Frequency 419}}{\textit{Pulse Train Scaling Frequency 654 [Hz]}}$$



Example:

Input frequency at IN2D: $f_{IN2D} = 5000 \text{ Hz}$

Reference frequency value:

Reference frequency values				
Pulse Train	= 0	$f_{reference} = f_{IN2D}$ (5000 Hz), limited to 50 Hz (<i>Maximum Frequency</i> 419)		
Scaling Fre-	= 25000	$f_{reference} = 10 \text{ Hz}$		
<i>quency</i> 654				

Output as percentage

In the case of a parameterization as a pulse train, the read frequency value is also available as a percentage for the reference percentage channel. 0 ... 100% correspond to the signal frequency range 0 ... *Maximum Frequency* **419** at the pulse train input. The conversion is done using the following formula:

Percentage value =
$$\frac{\text{Frequency value}}{\text{Maximum Frequency 419}} \times 100\%$$



7.6.7.4 Further setting options

An offset can be set via the reference frequency channel or via the function of the electronic gear. For example, you can set in the reference frequency channel: *Reference Frequency Source 1* **475** = "10 - Repetition Frequency" and *Reference Frequency Source 2* **492** = "3 - Fixed Frequency". Via the fixed frequencies (parameters 480 ... 488), you can set the required offset. A filter can be set via PLC-function (see application manual "PLC").

7.7 V/f characteristic

606 Type V/f characteristic

Via parameter Type V/f Characteristic 606, you can set the characteristic to linear or quadratic.

Туре	Function
1 - Linear	Linear V/f characteristic: U ~ f. Factory setting.
2 - Quadratic	Quadratic V/f characteristic: $ U \sim f^2$. For applications where the torque increases quadratically to the speed. Suitable for energy saving. See chapter 8.2 "Quadratic V/f characteristic". Too small set values of the V/f characteristic affect the dynamic behavior of the drive.

7.8 Linear V/f characteristic


600 Starting Voltage 601 Voltage Rise 602 Rise Frequency 603 Cut-Off Voltage 604 Cut-Off Frequency

The sensorless control in configuration 110 (parameter *Configuration* **30**) is based on the proportional change of output voltage compared to the output frequency according to the configured characteristic.

By setting the V/f-characteristic, the voltage of the connected 3-phase motor is controlled according to the frequency. The torque to be applied by the motor at the corresponding operating point demands the control of the output voltage proportional to the frequency. At a constant output voltage/output frequency ratio of the frequency inverter, the magnetization is constant in the nominal operating range of the 3-phase motor. The rating point of the motor or end point of the V/f-characteristic is set via the guided commissioning with the parameter *Cut-Off Voltage* **603** and the parameter *Cut-Off Frequency* **604**.

The lower frequency range, where an increased voltage is necessary for the start of the drive, is critical. The voltage at an output frequency of zero is set with parameter *Starting Voltage* **600**. A voltage increase deviating from the linear course of the V/f-characteristic can be defined by parameters *Voltage Rise* **601** and *Rise Frequency* **602**. The parameter value percentage is calculated from the linear V/f-characteristic. Via the parameters *Minimum Frequency* **418** and *Maximum Frequency* **419**, the working range of the motor or the V/f-characteristic is defined.

Linear characteristic in setting "1 - Linear" for Type V/f Characteristic 606.



(FMIN): Minimum Frequency 418, (FMAX): Maximum Frequency 419,

(US): Starting Voltage 600,

(UK): Voltage Rise 601, (FK): Rise Frequency 602

(UC): Cut-Off Voltage 603, (FC): Cut-Off Frequency 604

	Parameters	Setting			
No.	. Description		Min.	Max.	Fact. sett.
600	Starting Voltage		0.0 V	100.0 V	5.0 V
601	. Voltage Rise		-100%	200%	10%
602	Rise frequency		0%	100%	20%
602	Cut-Off Voltage	AGL202	30.0 V	280.0 V	230.0 V
603	Cut-On voitage	AGL402	60.0 V	560.0 V	400.0 V
604	04 Cut-Off Frequency		0.00 Hz	999.99 Hz	50.00 Hz



The guided commissioning takes the parameterized rated motor values and reference data of the frequency inverter into account when it comes to pre-set-ting the V/f-characteristic. In the case of asynchronous machines, the speed can be increased at a constant torque if the motor winding can be switched over from star to delta connection. If the data for delta connection indicated on the rating plate of the asynchronous motor were entered, the cut-off frequency is increased automatically by the square root of three.

The *Cut-Off Voltage* **603** (UC) and *Cut-Off Frequency* **604** (FC) set in the factory are derived from the motor data *Rated Voltage* **370** and *Rated Frequency* **375**. With the parameterized *Starting Voltage* **600** (US), the linear equation of the V/f-characteristic results.

$$U = \left(\frac{UC - US}{FC - 0}\right) \cdot f + US = \left(\frac{400.0 \text{ V} - 5.0 \text{ V}}{50.00 \text{ Hz} - 0.00 \text{ Hz}}\right) \cdot f + 5.0 \text{ V}$$

The Rise Frequency 602 (FK) is entered as a percentage of the Cut-Off Frequency 604 (FC), the default value is f = 10 Hz. The output voltage for the default Voltage Rise 601 is calculated as U = 92.4 V.

$$U = \left[\left(\frac{UC - US}{FC - 0} \right) \cdot \left(FK \cdot FC \right) + US \right] \cdot \left(1 + UK \right) = \left[\left(\frac{400 \ V - 5 \ V}{50 \ Hz - 0 \ Hz} \right) \cdot \left(0.2 \cdot 50 \ Hz \right) + 5 \ V \right] \cdot 1.1 = \underline{92.4 \ V}$$



7.8.1 Dynamic voltage pre-control

605 Dyn. Voltage Pre-Control

The *Dyn. Voltage Pre-Control* **605** accelerates the control behavior of the current limit controller (parameter *Operation Mode* **610**) and of the voltage controller (parameter *Operation Mode* **670**). The output voltage value resulting from the V/F characteristic is changed by addition of the calculated voltage pre-control.

Parameters		Setting		
No.	Description	Min. Max. Fact. se		
605	Dyn. Voltage Pre-Control	0%	200%	100%

7.9 Control functions

With the control function the control reactions can be set up fitting to the application.

7.9.1 Intelligent current limits

573 Operation Mode (intelligent current limits)

The current limits to be set according to the application avoid inadmissible loading of the connected load and prevent a fault switch-off of the frequency inverter. The function extends the current controller available in the control system. The overload reserve of the frequency inverter can be used optimally by means of the intelligent current limits, in particular in applications with dynamic load al-ternations. Parameter *Operation Mode* **573** defines the threshold to the activation of the intelligent current limit. The parameterized rated motor current or the reference current of the frequency inverter is synchronized as the limit value of the intelligent current limits.

In the control method according to V/f-characteristic (setting 110 of *Configuration* **30**) the intelligent current limits take effect to the current limit controller. The intelligent current limits are active only in the case of an active current limit controller.

In the field-orientated control (setting 410 or 610 of *Configuration* **30**) the maximum torque-forming current is limited by the intelligent current limits.

Operation Mode 573	Function
0 - Off	The function is switched off.
1 - Ixt	Limitation to the overload of the frequency inverter (Ixt).
10 - Tc	Limitation to the maximum heat sink temperature (T _C).
11 - Ixt + Tc	Operation mode 1 and 10 (Ixt + T_C).
20 - Motor Temp.	Limitation to the motor temperature (T_{Motor}) .
21 - Motor Temp.+ Ixt	Operation mode 20 and 1 (T _{Motor} + Ixt).
30 - Tc + Motor Temp.	Operation mode 10 and 20 $(T_C + T_{Motor})$.
31 - Tc + Motor Temp. + Ixt	Operation mode 10 and 20 ($T_C + T_{Motor} + Ixt$). Factory setting.

In the operation modes with overload reserve (Ixt) there is a reduction of the output current when the threshold value is exceeded, with a distinction being made between long and short-term overload reserve. After the short-term overload (1 s) has been used up, the output current is reduced to the long-term overload current matching the present switching frequency. After the long-term overload current has been used up (60 s), the output current is reduced to the rated current which also depends on the switching frequency.

If the output current has already been reduced due to the fact that the long-term overload has used up, the short-term overload is no longer available even if it has not been used up beforehand. The defined overload reserve (Ixt) of the frequency inverter is available again after a power reduction lasting 10 minutes.



574 Power Limit 575 Limitation Time

The threshold selected via parameter *Operation Mode* **573** is monitored. If parameter *Operation Mode* **573** is selected to motor or heat sink temperature monitoring, the power is reduced to the value of *Power Limit* **574** once the limit value is reached. The power is reduced until the temperature has dropped sufficiently. You can set an additional time *Limitation Time* **575** for which the limitation after falling below the limit value should be maintained. In motor operation, the output current and the speed will be reduced. The load behavior of the motor must depend on the speed.

The power limit should be selected as small as possible in order to give the drive sufficient time to cool down. The reference value is the rated output of the frequency inverter or the set rated power of the motor.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
574	Power Limit	40.00%	95.00%	80.00%
575	Limitation Time	5 min	300 min	15 min

Output signals

Reaching of a limit – selected in *Operation Mode* **573** – can be signaled via digital outputs.

15 -	Warning Current Limitation	The intelligent current limits limit the output current.
16 -	Controller Current Limit. Long Term Ixt	The overload reserve for 60 s has been used up and the out-
10 -	Long Term Ixt	put current is being limited.
17	Controller Current Limit. Short Term Ixt	The overload reserve for 1 s has been used up and the output
1/-	Short Term Ixt	current is being limited.
10	Controller Current Limit. Tc	Max. heat sink temperature T _K reached. The intelligent current
16 -	Controller Current Limit. 10	limits are active.
10	Controller Current Limit.	Max. motor temperature reached. The intelligent current limits
19 -	Motor Temp.	are active.



7.9.2 Voltage controller

670 Operation Mode (voltage controller)

The voltage controller contains the functions necessary for monitoring the DC link voltage.

- The DC link voltage which rises in generator operation (in example during the braking process) of the motor is controlled to the set limit value by the voltage controller.
- The power failure regulation uses the rotation energy of the drive to bridge short-term power failures.

The voltage controller is set with parameter *Operation Mode* **670**.

Operation mode 670	Function
0 - Off	The function is switched off. Brake and Motor chopper are active and switch with the parameterized thresholds of P506 and P507.
1 - Udc-Limitation active	DC link limitation active. Overvoltage controller switched on, the Brake and Motor chopper are active and switch with the parameterized thresholds of P506 and P507. Factory setting .
2 - Mains Support active	Power failure regulation switched on. Brake and Motor chopper are active and switch with the parameterized thresholds of P506 and P507. Suitable for quick shutdown.
3 - Udc-Limit. & Mains Supp. active	Overvoltage controller and power failure regulation switched on, with motor chopper.
12 - Mains Support active, Chopper not active	Power failure regulation switched on. During the Mains Support, motor and brake chopper are deactivated. In all other cases motor and brake chopper are active and switch with the parameterized thresholds of P506 and P507.
Udc-Limit. & Mains 13 - Supp. active, Chopper not active	Overvoltage controller and power failure regulation switched on. During the Mains Support, motor and brake chopper are deactivated. In all other cases motor and brake chopper are active and switch with the parameterized thresholds of P506 and P507.

The function motor chopper is available only in the field-orientated control methods in configuration 410 (parameter *Configuration* **30**).

When an operation mode with motor chopper is selected, set the $Trigger\ Threshold\ 507 < (Reference\ DC-Link\ Limitation\ 680\ -\ 10\ V)$. See chapter 7.10.5 "Motor chopper".



For synchronous motors (Configuration **30** = 610), the motor chopper function is deactivated to prevent damages to the motor. The other functions of the voltage controller are not affected by this.


For asynchronous motors in V/f control (Configuration 30 = 110), the motor chopper function is not operative. The other functions of the voltage controller are not affected by this.



The brake chopper is active dependent of the setting of *Reference DC-Link Limitation* **680.** See chapter 7.10.4 "Brake chopper and brake resistor" for parameterizing the switching threshold.



Operation mode overvoltage control, Voltage controller: Parameter *Operation Mode* 670 = 1



680 Reference DC-Link Limitation 681 Max. Frequency Rise


The overvoltage controller prevents a switch-off of the frequency inverter in generator operation. The reduction of the drive speed by a ramp gradient selected via parameter *Deceleration Clockwise* **421**, or *Deceleration Anticlockwise* **423** can lead to an overvoltage in the DC link. If the voltage exceeds the figure set by the parameter *Reference DC-Link Limitation* **680**, the deceleration is reduced in such a way that the DC link voltage is regulated to the set value. If the DC link voltage cannot be regulated to the set reference value by the reduction of the deceleration, the deceleration is stopped and the output frequency raised. The output frequency is calculated by addition of the parameter value *Max. Frequency Rise* **681** to the frequency at the operating point of the controller intervention.

Parameters			Setting		
No. Description		Min.	Max.	Fact. sett.	
680	Deference DC Link Limitation	AGL202	225.0 V	387.5 V	380.0 V
	Reference DC-Link Limitation AGL402		325.0 V	775.0 V	760.0 V
681	681 Max. Frequency Rise		0.00 Hz	999.99 Hz	10.00 Hz

For a reliable operation of the overvoltage controller, Bonfiglioli Vectron recommends to set the motor-chopper $Trigger\ Threshold\ 507\ <\ (Reference\ DC-Link\ Limitation\ 680\ -\ 10\ V).$ See chapter 7.10.5 "Motor chopper".



Operation mode power failure regulation. Voltage controller: Parameter Operation mode 670 = 2 without Mains resumption



671 Mains Failure Threshold 672 Reference Mains Support Value

With the power failure regulation, short-term power failures can be bridged. Mains failure is detected when the DC link voltage has dropped below the set value of parameter *Mains Failure Threshold* **671**. If a mains failure is detected, the controller tries to regulate the DC link voltage to the value set with parameter *Reference Mains Support Value* **672**. To that end, the output frequency is continuously reduced and the motor with its rotating masses is switched over to generator operation. Using field oriented Control (FOC, SERVO) the reduction of the output frequency is done according to the configuration with a maximum of the current set by the parameter *Gen. Ref. Current Limit* **683**.



Gen. Ref. Current Limit **683** is active in configurations 410 and 610 (FOC and SERVO).

The threshold values of the voltage controller are calculated starting with the current DC link voltage with the parameters *Mains Failure Threshold* **671** and *Reference Mains Support Value* **672**.

If the mains voltage is restored before a switch-off is effected by the mains undervoltage detection system, the drive is accelerated to its reference frequency at the set acceleration or according to the parameter *Acceleration on Mains Resumption* **674**. If the value of parameter *Acceleration on Mains Resumption* **674** is set to the default value of 0.00 Hz/s, the drive is accelerated at the values set for the ramp parameters *Acceleration (Clockwise)* **420** or *Acceleration Anticlockwise* **422**.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
671	Mains Failure Threshold	-200.0 V	-50.0 V	-100.0 V
672	Reference mains support value	-200.0 V	-10.0 V	-40.0 V





The frequency inverter reacts to the signals at the control inputs both when the power failure regulation is switched on and in normal operation. A control via externally supplied control signals is only possible in the case of a no-break supply. As an alternative, supply of the control signals through the frequency inverter is to be used.


Output signals


Mains failure and mains support are signaled via digital signals.

179 - Mains failure	Failure of mains voltage and mains support – selected via Operation Mode
13 - Mains failure	²⁾ 670 of the voltage controller.

¹⁾ For linking to frequency inverter functions.

²⁾ For output via a digital output. Select the signal source for one of the parameters 531, 532, 533, 554. See chapter 7.6.5 "Digital outputs".





675 Shutdown Threshold 676 Reference Shutdown Value

The DC link voltage which is available in the case of a power failure is supplied by the motor. The output frequency is continuously reduced and the motor with its rotating masses is switched over to generator operation. The reduction of the output frequency is done with a maximum of the current set by the parameter *Gen. Ref. Current Limit* **683** or the ramp *Mains Support Deceleration* **673**. *Mains Support Deceleration* **673** is only active if the Actual frequency is smaller than *Shutdown Threshold* **675**.

The time required until the motor has come to a standstill results from the regenerative energy of the system which results in an increase in the DC link voltage. The DC link voltage set with the parameter *Reference Shutdown Value* **676** is used by the voltage controller as a control figure and kept constant. The voltage rise enables optimization of the braking behavior and the time until the drive has come to a standstill. The behavior of the controller can be compared to stopping behavior 2 (Shutdown and Stop), as the voltage controller brings the drive to a standstill at the maximum deceleration ramp and supplies it with the remaining DC link voltage.

If the DC-link voltage is restored before the shutdown of the drive, but after falling below *Shutdown Threshold* **675**, the drive is still decelerated to standstill.



If the mains voltage is restored after the shutdown of the drive but before the undervoltage switch-off has been reached, the frequency inverter signals a fault. The operator panel displays the fault message "F0702".

If the mains failure without shutdown ($Shutdown\ Threshold\ 675 = 0\ Hz$) takes so long that the frequency has been reduced to 0 Hz, the drive is accelerated to the reference frequency when the mains supply is restored.

If the mains failure with or without shutdown takes so long that the frequency inverter shuts off completely, the frequency inverter will be in the "Standby" state when the mains supply is restored. If the inverter is enabled again, the drive will start. If the drive is to start automatically after restoration of the mains supply if the inverter is enabled permanently, *Operation Mode* **651** of auto start must be switched on.

	Parameters		Setting		
No.	Description		Min.	Max.	Fact. sett.
675	Shutdown Threshold		0.00 Hz	999.99 Hz	0.00 Hz
676 Reference Shutdown Value	AGL202	225.0 V	375.5 V	365.0 V	
	AGL402		425.0 V	775.0 V	730.0 V



Reference Shutdown Value **676** becomes effective below the frequency value *Shutdown Threshold* **675**.

673 Mains Support Deceleration 674 Acceleration on Mains Resumption 683 Gen. Ref. Current Limit

The voltage controller uses the limit values of the DC link voltage. If the default value is changed, the *Acceleration on Mains Resumption* **674** replaces the set ramp parameter values *Acceleration (Clockwise)* **420** or *Acceleration Anticlockwise* **422**. The voltage control in a mains failure changes from the frequency limit *Shutdown Threshold* **675** from *Reference Mains Support Value* **672** to the *Reference Shutdown Value* **676**. The value of *Gen. Ref. Current Limit* **683** or the ramp *Mains Support Deceleration* **673** defines the maximum deceleration of the drive required in order to reach the voltage value *Reference Shutdown Value* **676**. *Mains Support Deceleration* **673** is only active if the Actual frequency is smaller than *Shutdown Threshold* **675**.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
683	Gen. Ref. Current Limit	0.0 A	$o_c \cdot I_{FIN}$	${ m I}_{\sf FIN}$
673	Mains Support Deceleration	0.01 Hz/s	9999.99 Hz/s	50.00 Hz/s
674	Acceleration on Mains Resumption	0.00 Hz/s	9999.99 Hz/s	0.00 Hz/s

I_{FIN}: Nominal value of frequency inverter o_c: Overload capacity of frequency inverter



Mains Support Deceleration **673** is active in configuration 110 (V/f). *Gen. Ref. Current Limit* **683** is active in configurations 410 and 610 (FOC and SERVO).



677 Amplification 678 Integral Time

The proportional and integrating part of the voltage controller can be set via parameters *Amplification* **677** and *Integral Time* **678**. The control functions are deactivated by setting the parameters to 0. The controllers are P and I controllers in the corresponding settings.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
677	Amplification	0.00	30.00	1 ¹⁾ 2 ²⁾
678	Integral Time	0 ms	10000 ms	8 ms ¹⁾ 23 ms ²⁾

The factory settings depend on the selected configuration and control procedure.

7.9.3 PID controller (technology controller)

The PID controller can be used for process control. The connection of PID desired set value and PID real value of the application with the functions of the frequency inverter enables process control without further components. In this way, applications such as pressure, volume flow or speed control can be implemented easily.

Starting the PID controller: Set one of the following parameters.

Parameters	Factory setting	Set
Reference Frequency Source 1 475	1 - Analog Value MFI1A	30 - Technology Controller
or		
Reference Frequency Source 2 492	5 - Keypad-Motorpot.	30 - Technology Controller

Desired set value for PID controller: Set one of the following parameters.

Parameters	Factory setting	Set
Reference Percentage Source 1 476	1 - Analog Value MFI1A ¹	Select analog input or percent-
or		age. For example "2 - Analog
Reference Percentage Source 2 494	5 - Keypad-Motorpot.	Value MFI2A ² or "3 - Fixed Percentage".

For example: analog desired set value at MFI2A.

(Reference Percentage Source 1 **476** or Reference Percentage Source 2 **494** = "2 - Analog Value MFI2A")

Set terminal X12.4 as analog input.

input MFI2".

¹⁾Configuration 30 = 110

 $^{^{2)}}$ Configuration **30** = 410, 610

¹ MFI1A: Multifunction input at terminal X12.3.

² MFI2A: Multifunction input at terminal X12.4.



For example: The desired set value is a fixed percentage.

Reference Percentage Source 1 **476** or Reference Percentage Source 2 **494** ="3 - Fixed Percentage") Set and select fixed percentage.

Parameters	Factory setting	Set
Parameters 520, 521, 522, 523 (fixed percentages)	0%, 20%, 50%, 100%	Enter a value. See chapter 7.5.2.3 "Fixed percent-
Fixed Percent Change-Over 1 75 and Fixed Percent Change-Over 2 76	7 - Off	ages". Select digital inputs or logic signals. See chapter 7.6.6.6 "Fixed percentage changeover".

Real value for PID controller

Parameters	Factory setting	Set
Actual Percentage Source 478		Select input where PID real val-
		ue is applied.

For example: analog PID real value at MFI1A. Set terminal X12.3 as analog input.

Parameters	Factory setting	Set
Operation Mode MFI1 452		Voltage input or current input. See chapter 7.6.1 "Multifunction input MFI1".

For the adjustment to the application, setting the minimum and maximum frequency may be required:

Parameters	Factory setting
Minimum Frequency 418	3.50 Hz
Maximum Frequency 419	50.00 Hz

The values of the set ramps (parameters 420 to 426 and 430) are considered if the PID controller is used.

The technology controller can be started via the signals of parameters *Start Clockwise* **68** or *Start Anticlockwise* **69**.

The control deviation (difference between reference percentage and actual percentage is signaled to the PID controller. The PID controller adjusts the output frequency of the frequency inverter such that the control deviation is minimized.

P controller: The output of the P controller is the product of the control deviation and the amplification and follows the control deviation linearly and without delay. A control deviation will be maintained.

I controller: The output of the I controller is the integral of the control deviation. The task of the I controller is to eliminate the control deviation. The integral time defines how fast the control deviation is compensated. If the I controller is set too dynamically (fast compensation of deviations), the system may become unstable and vibrate. If the I controller is set too passively (slow compensation of deviations), the stationary error is not compensated sufficiently. For this reason, the integral portion must be adjusted plant-specifically.


D controller: The D controller assesses the change of the control deviation and calculates it change rate. This value is multiplied by the derivative time. The D controller responds to announced changes and causes a fast control behavior. The D controller can stabilize the control circuit and reduce vibration. On the other hand, errors (e.g. interference voltages) are amplified.

In order to use the output value of the PID controller as the reference frequency, setting "30 - Technology Controller" must be selected for *Reference Frequency Source 1* **475** or *Reference Frequency Source 2* **492**. If the technology controller is selected as the reference frequency source, the settings of the PID controller are activated.



The behavior of the PID controller is set with:

- Proportional part Amplification 444
- Integral part Integral Time 445
- Differential part Derivative Time 446



Reference percentage channel is shown (simplified). See chapter 7.5.2 "Reference percentage channel".

Application examples

Application	Function
Pressure control	The pressure in a process is kept at a constant level by means of a pres-
Fressure control	sure sensor.
Flow rate control	The flow rate in a process is kept at a constant level by means of a flow
Flow rate control	sensor.
Tananauati wa aantwal	The temperature is kept at a constant level by controlling a fan by means
Temperature control	of a thermostat.

Via dataset changeover via control contacts, the PID controller can be adjusted to different operating points.

476,494 Reference percentage source, PID desired set value input

The desired set value source of the control can be selected via parameter *Reference Percentage Source 1* **476** or *Reference Percentage Source 2* **494**. The values of both parameters are added. See chapter 7.5.2 "Reference percentage channel".




478 Actual Percentage Source, PID real value input

The analog input or the repetition frequency input to which the PID real value is applied can be selected via parameter *Actual Percentage Source* **478**. The actual value can also be transmitted via a bus system.

Actual Percentage Source 478	Function
1 - Analog Input MFI1A	Analog signal at multifunction input 1 (terminal X12.3). Factory setting. Via parameter <i>Operation mode MFII</i> 452 , the input must be set up as an analog input (voltage or current). See chapter 7.6.1 "Multifunction input MFI1".
2 - Analog Input MFI2A	Analog signal at multifunction input 2 (terminal X12.4). Via parameter <i>Operation mode MFI2</i> 562 , the input must be set up as an analog input (voltage or current). See chapter 7.6.2 "Multifunction input MFI2".
32 - Rep. Percentage Input	Percentage signal at digital input IN2D. Evaluation can be selected via parameter <i>Operation mode IN2D</i> 496 . See chapter 7.6.7.2 "Repetition frequency input".
40 - Actual Percentage RAM	Value of parameter <i>Actual Percentage RAM</i> 529 . <i>Actual Percentage RAM</i> 529 can be set via Fieldbus, but is not visible in VPlus or the keypad.
704 - RxPDO1 Word 1	Process data from system bus. Refer to system bus instructions.
705 - RxPDO1 Word 2	Process data from system bus. Refer to system bus instructions.
2521 - PLC-Output Percentage 1	Output value of a PLC-function. Percentage output 1 of the table function is the PID real value source. See application manual "PLC".
2522 - PLC-Output Percentage 2	Output value of a PLC-function. Percentage output 2 of the table function is the PID real value source. See application manual "PLC".



Inputs for reference percentage source



440 Operation Mode Actual Value Failure

Via parameter *Operation Mode Actual Value Failure* **440**, you can set how the frequency inverter will respond to a missing PID real value (<0.5%). In this way, the drive can be prevented from starting if a PID real value is missing. The function enables, for example, monitoring of a sensor cable for broken wires. The function should be switched on in order to avoid critical operating behavior, e.g. acceleration to maximum frequency if the actual value signal fails.

	5
Operation mode 440	Function
0 - Off	No response if PID real value is missing. Missing PID real values (<0.5%) will be evaluated as PID real values.
1 - Active, Fixed Frequency 1	If the PID real value is missing, the output frequency is guided to the value of <i>Fixed Frequency 1</i> 480 . Factory setting .
10 - Active, Stop + Error	If the PID real value is missing, the drive will be shut down and error F1409 "actual value is missing" will be signaled.
20 - Active, Error	If the PID real value is missing, error F1409 " actual value is missing" will be signaled.



480 Fixed Frequency 1 (in case of missing PID real value)

If the PID real value is missing (<0.5%), the output frequency is guided to the value of *Fixed Frequency 1* **480**. The minimum value monitoring prevents an acceleration of the drive if the PID real value is missing. If the PID real value is available again, the controller continues operation automatically.

	Parameters Setting			
No.	Description	Min.	Max.	Fact. sett.
480	Fixed Frequency 1	-999.99 Hz	999.99 Hz	0.00 Hz

The *Fixed Frequency 1* **480** must be in the range between *Minimum Frequency* **418** and *Maximum Frequency* **419**. If the *Fixed Frequency 1* **480** is set to a value smaller than the *Minimum Frequency* **418**, the output frequency is guided to *Minimum Frequency* **418**. The frequency will not drop below *Minimum Frequency* **418**.

444 Amplification (P)

Parameter *Amplification* **444** defines the amplification factor by which the control deviation is multiplied. The control deviation can be reduced by large amplification values, but very high values may cause the control circuit to become unstable (vibrations). If the value is set too low, large control deviations are possible.

	Parameters		Setting	
No.	Description	Min.	Max.	Fact. sett.
444	Amplification	-15.00	+15.00	1.00

The sign of the amplification defines the control direction, i.e. if the PID real value increases and the sign of the amplification is positive, the output frequency is reduces (e.g. pressure control). With a rising PID real value and negative sign of the amplification, the output frequency is increased (e.g. in temperature control systems, refrigerating machines, condensers).

445 Integral Time (I)

Parameter *Integral Time* **445** defines the time constant for calculation of the integral of the PID input signal. The I controller totals the control deviation over time and divides the result by the value of *Integral Time* **445**. If the *Integral Time* **445** is set to small values, the control deviation is compensated quickly. Very low values for the *Integral Time* **445** may cause the control circuit to become unstable (vibrations).

Parameters Setting				
No.	Description	Min.	Max.	Fact. sett.
445	Integral Time	0 ms	32767 ms	200 ms

If parameter *Integral Time* **445** is set to zero, the I controller is deactivated.

The amplification (P) is included in the calculation of the integral time (I), see figure PID controller.

BONFIGLIOLI recommends setting the *Integral Time* **445** to a value greater than the sampling time, which is 2 ms in the case of the *Agile* device.

441 Max. I-Component

Parameter *Max. I-Component* **441** defines the maximum output signal of the I-controller. In applications with quickly changing load torques, vibrations of the control circuit are possible. In order to avoid vibration, parameter *Max. I-Component* **441** can limit the output signal of the I-controller.

Parameters Setting				
No.	Description	Min.	Max.	Fact. sett.
441	Max. I-Component	0.00 Hz	999.99 Hz	50.00 Hz



446 Derivative time (D)

If the control behavior of the PI controller (or P controller) is too slow, a faster control can be achieved by activating and adjusting the differential part (*Derivative time* **446**). However, if the differential part is activated, the control circuit has a higher tendency toward vibration. For this reason, the differential part should be activated and changed carefully.

By default, the differential part is set to $Derivative \ time \ 446 = 0 \ ms$, i.e. it is deactivated. High values for $Derivative \ time \ 446$ cause fast control, but amplify interferences.

The amplification (P) is included in the calculation of the derivative time (D), see figure PID controller.

Parameters Setting				
No.	Description	Min.	Max.	Fact. sett.
446	Derivative time	0 ms	1000 ms	0 ms

442 Maximum Frequency 443 Minimum Frequency

Parameters *Maximum Frequency* **442** and *Minimum Frequency* **443** define the working range of the controller. In this way, you can also define if the PID controller is to operate the drive in one direction only or if both directions of rotations are to be possible.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
442	Maximum Frequency	0 Hz	999.99 Hz	50.00 Hz
443	Minimum Frequency	-999.99 Hz	0 Hz	-50.00 Hz



If the PID controller is to operate the drive in both directions, (*Minimum Frequency* **443**< 0 Hz), Parameter *Minimum Frequency* **418** should be set to 0 Hz.



If *Maximum Frequency* **442** and *Minimum Frequency* **443** are set asymmetric (in example *Maximum Frequency* **442** = 30.00 Hz and *Minimum Frequency* **443** = -20.00 Hz with positive *Amplification* **444**), setting the Start-Right-Control will result in using *Maximum Frequency* **442** for Clockwise rotation (positive control deviation) and *Minimum Frequency* **443** for Anticlockwise rotation (negative control deviation).

Setting the Start-Left-Control will result in using *Minimum Frequency* **443** for Clockwise rotation (positive control deviation) and *Maximum Frequency* **442** for Anticlockwise rotation (negative control deviation).

618 Backlash

With parameter *Backlash* **618**, you can set a range in which a control deviation is not processed. In this way, frequent post-controlling and jerking of the drive can be avoided.

Requirement: *Stator Frequency* **210** < *Switch-Off Threshold Stop Function* **637**.

	Parameters Setting			
No.	Description	Min.	Max.	Fact. sett.
618	Backlash	0%	30.00%	0%

616 Backlash Motor Power off

In different applications it could be requested to switch off the power stage with a small control deviation and low output frequency. With parameter *Backlash Motor Power off* **616** this behavior can be set up.



Backlash	Function
Motor Power off 440	
0 - Off	The switch off of the power stage is not influenced.
0 - Οπ	Factory setting.
	If the control deviation < Backlash 618 and at the same time the
1 - Active, Fixed Frequency 1	Actual Frequency < Switch-Off Threshold Stop Function 637 the
	power stage is switched off.



The Switch off behavior, which is set up by the Stopping behavior (*Operation mode* **630**) is not changed by *Backlash Motor Power off* **616**. While this function is switched on, the power stage is additionally switched off if the control deviation < *Backlash* **618** and Actual Frequency < *Switch-Off Threshold Stop Function* **637**. The motor is switched on again as soon as the control deviation is larger again than the set up threshold of *Backlash* **618**.

7.9.4 Functions of sensorless control

The configurations of the sensorless control contain the following additional functions, which supplement the behavior according to the parameterized V/f characteristic (Configuration 30 = 110).

7.9.4.1 Slip compensation

660 Operation Mode (slip compensation)

The load-dependent difference between the reference speed and the actual speed of the 3-phase motor is referred to as the slip. This dependency can be compensated by the current meas-urement in the output phases of the frequency inverter.

The activation of *Operation Mode* **660** for the slip compensation enables as speed control without feedback. The stator frequency and speed are corrected depending on the load.

Operation Mode 660	Function
0 - Off	The slip compensation is deactivated. Factory setting.
1 - On	The load-dependent slip speed is compensated

The slip compensation is activated during the guided commissioning. The *Stator Resistance* **377** is required to ensure a correct function and is measured during the guided commissioning.

If no guided commissioning is executed, the slip compensation can be activated manually. In these cases, enter the value for the *Stator Resistance* **377** manually according to the motor data sheet.

For parameter *Configuration* **30**, setting "110 - IM: sensorless control" (V/f characteristic) must be selected.

661 Amplification 662 Max. Slip Ramp 663 Frequency Lower Limit

The control behavior of the slip compensation can only be optimized via the parameters in the case of specific applications. The parameter *Amplification* **661** determines the correction of the speed and the effect of the slip compensation proportionally to the change of load. Parameter *Max. Slip Ramp* **662** defines the maximum frequency change per second in order to avoid an overload in the case of a load change.

The parameter *Frequency Lower Limit* **663** determines the frequency as from which the slip compensation becomes active.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
661	Amplification	0%	300.0%	100.0%
662	Max. Slip Ramp	0.01 Hz/s	650.00 Hz/s	5.00 Hz/s
663	Frequency Lower Limit	0.01 Hz	999.99 Hz	0.01 Hz



7.9.4.2 Current limit value controller

610 Operation Mode (current limit value controller)

Via a load-dependent speed control, the current limit value controller ensures that the drive system is not overloaded. This is extended by the intelligent current limits described in the previous chapter. The current limit value controller reduces the load on the drive, e.g. during acceleration, by stopping the acceleration ramp. The switch-off of the frequency inverter which happens when the acceleration ramps have been set at an excessive gradient is thus prevented.

The current limit value controller is switched on and off via parameter *Operation Mode* **610**.

Operation Mode 610	Function
0 - Off	The current limit value controller functions and the intelligent current limits have been deactivated. Factory setting.
1 - On	The current limit value controller is active.

611 Amplification

612 Integral Time

The control behavior of the current limit controller can be set via the proportional part, parameter *Amplification* **611** and the integrating part, parameter *Integral Time* **612**. If, in exceptional cases, optimization of the controller parameters is required, proceed with the following steps:

- Change parameter Current Limit 613 with a big step, analyze the changes in the Scope.
- For a more dynamic behavior increase *Amplification* **611** and/or decrease *Integral Time* **612**.
- For a less dynamic behavior decrease *Amplification* **611** and/or increase *Integral Time* **612**.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
611	Amplification	0.01	30.00	1.00
612	Integral Time	1 ms	10000 ms	24 ms



The dynamism of the current limit value controller and the voltage controller is influenced by the setting of the parameter *Dyn. Voltage Pre-Control* **605**.

613 Current Limit

614 Frequency Limit

Behavior in motor operation:

If the current set via parameter *Current Limit* **613** is exceeded, the activated current limit value controller will reduce the output frequency until the current limit is no longer exceeded. The output frequency is reduced as a maximum to the frequency set by the parameter *Frequency Limit* **614**. If the current value drops below the *Current Limit* **613**, the output frequency is raised back to the reference value.

Behavior in generator operation:

If the current set via parameter *Current Limit* **613** is exceeded, the activated current limit value controller will increase the output frequency until the current limit is no longer exceeded. The output frequency is increased, as a maximum, to the set *Maximum Frequency* **419**. If the current is below the *Current Limit* **613**, the output frequency is reduced to the required reference value again.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
613	Current Limit	0.0 A	$o_c \cdot I_{FIN}$	$o_{\text{c}}{\cdot}I_{\text{FIN}}$
614	Frequency Limit	0.00 Hz	999.99 Hz	0.00 Hz

I_{FIN}: Nominal value of frequency inverter o_c: Overload capacity of frequency inverter



7.9.5 Functions of field-orientated control

The field-orientated control systems are based on a cascade control and the calculation of a complex machine model. In the course of the guided commissioning, a map of the connected machine is produced by the parameter identification and transferred to various parameters. Some of these parameters are visible and can be optimized for various operating points.

7.9.5.1 Current controller

700 Amplification 701 Integral Time

The current controller with the parameters *Amplification* **700** and *Integral Time* **701** is applicable for field-orientated control (setting 410 or 610 of parameter *Configuration* **30**).

In the control according to V/f-characteristic (setting 110 of parameter *Configuration* **30**) the current controller is only applicable for the function Flying Start (parameter *Operation Mode Flying Start* **645**).

The inner control loop of the field-orientated control comprises two current controllers. The field-orientated control thus impresses the motor current into the machine via two components to be controlled.

This is done by:

- controlling the flux-forming current value I_{sd}
- controlling the torque-forming current value I_{sq}

By separate regulation of these two parameters, a decoupling of the system equivalent to an externally excited direct current machine is achieved.

The set-up of the two current controllers is identical and enables joint setting of am-plification as well as the integral time for both controllers. For this, the parameters *Amplification* **700** and Parameter *Integral Time* **701** are available. The proportional and integration and component of the current controllers can be switched off by setting the parameters to zero.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
700	Amplification	0.00	8.00	0.13
701	Integral Time	0.00 ms	10.00 ms	10.00 ms

The guided commissioning has selected the parameters of the current controller in such a way that they can be used without having to be changed in most applications.

If, in exceptional cases, an optimization of the behavior of the current controllers is to be done, the reference value jump during the flux-formation phase can be used for this. The reference value of the flux-forming current components leaps to the figure *Current during Flux-Formation* **781** with suitable parameterization and then changes controlled to the magnetizing current after the expiry of the *Max. Flux-Formation Time* **780**. The operating point necessary for the adjustment demands the setting of parameter *Minimum Frequency* **418**, as the drive is accelerated after magnetizing. The measurement of the jump reply, which is defined by the ratio of the currents mentioned, should be done in the motor supply line by means of a measuring current transformer of a sufficient bandwidth.



The internally calculated actual value for the flux-forming current component cannot be output via the analog output for this measurement as the time resolution of the measurement is not sufficient.

To set the parameters of the PI controller, the *Amplification* **700** is increased first until the actual value overshoots distinctly during the control process. Now, the amplification is reduced to about fifty percent again and then the *Integral Time* **701** is synchronized until actual value overshoots slightly during the control process.



The settings of the current controllers should not be too dynamic in order to ensure a sufficient reserve range. The control tends to increased oscillations if the reverse range is reduced.

The dimensioning of the current controller parameters by calculation of the time constant is to be done for a switching frequency of 2 kHz. For other switching frequencies, the values are adapted internally so that the setting can remain un-changed for all switching frequencies. The dynamic properties of the current controller improve if the switching and scanning frequency increases.

The fixed time interval for the modulation results in the following scanning frequencies of the current controller via parameter *Switching Frequency* **400**.

Setting					
Switching frequency Scanning frequency					
2 kHz	2 kHz				
4 kHz	4 kHz				
8 kHz	8 kHz				
16 kHz	8 kHz				

746 Cross-Coupling Factor

For an asynchronous motor (Configuration~30 = 410) and synchronous motor (Configuration~30 = 610), the coupling between the flux-forming current Isd and the torque-forming current Isq can be undone largely by the activated cross-coupling compensation. In this way, it is possible to impress the torque-forming current in the machine more quickly and the speed control circuit has a lower tendency toward vibration.

The cross-coupling exists between the flux-forming current Isd and the torque-forming current Isq and is caused by the voltage drop at the stator inductivity and the stator leakage inductivity. For this reason, the cross-coupling increases with the stator frequency. The cross-coupling becomes particularly apparent in the case of high stator frequencies at relatively small switching frequencies (e.g. 300 Hz stator frequency at 4 kHz switching frequency), as with small switching frequencies, the current controller slows down.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
746	Cross Coupling Easter	0.000/	200.000/	100.00%1)
/46	Cross-Coupling Factor	0.00%	300.00%	75.00% ²⁾

¹⁾Configuration 30 = 410

Cross-coupling compensation can be optimized as follows:

- First, set the speed controller. To that end, define reference speed jumps at small rotary frequencies. See chapter 7.9.5.3 "Speed controller".
- Set a speed of approx. $\frac{2}{3}$ of the rated speed.
- Define reference speed jumps again. During the accelerations, currents Isq of approx. 50% of the rated current should occur.
- Starting from 0%, increase the value of *Cross-Coupling Factor* **746** in steps of 25%, for example.
- The influence by Isq on Isd during the reference speed jumps should decrease with increasing values of *Cross-Coupling Factor* **746**. For checking, signal sources Isd and Isq can be oscilographed using the scope function of the PC user software. A minimum influence should be reached at 100%.
- Set the Cross-Coupling Factor **746** to a value slightly below the determined optimum value.

Very high values for *Cross-Coupling Factor* **746** (e.g. 125%) may result in an overcurrent circuit break.

²⁾Configuration 30 = 610



7.9.5.2 Torque controller

The sensorless field oriented control for ASM (configuration 410) and the sensorless field oriented control for PSM (configuration 610) can be used for sensorless torque control alternative to the speed control. The torque control is usable above the $Frequency\ Limit\ 624$. Below the $Frequency\ Limit\ 624$ the current impression is active with the current reference frequency as reference value. In this case the torque is not controlled, but results depending on the load and the $Starting\ current\ 623$. To achieve a starting in torque control, the reference frequency should be set higher than $Frequency\ Limit\ 624$. This is guaranteed in example by setting $Minimum\ frequency\ 418 > Frequency\ Limit\ 624$.

f < Frequency Limit **624**: Current impression $f \ge Frequency Limit$ **624**: Direct Torque Control

The *Frequency Limit* **624** is set automatically during the motor setup.

The energy saving function shouldn't be used when using the Torque controller, since it influences the control dynamics significantly.

An overview of important parameters for using the Torque Controller is compiled in chapter 6.7.8 "Torque control".

7.9.5.2.1 Torque reference

The reference torque can be specified as follows:

- Set parameter *n-/T-Control Change-Over* **164** to "6 On" or link it to a digital signal and switch this on.
- Via parameter Reference Percentage Source 1 476 or Reference Percentage Source 2 494, select a source for the reference torque.

For example:

- The reference torque can be set via the arrow keys of the operator panel if the following setting is selected: Reference Percentage Source 2 494 = "5 keypad motorpoti (factory setting)".
- The reference torque can be set via multifunction input 1 (MFI1A) if the following setting is selected: *Reference Percentage Source 1* **476** = "1 analog value MFI1A (factory setting)".
- 100 % Torque refer to the calculated Torque from Rated Mech. Power 376 (Motor power) and Rated Speed 372 (Motor nominal speed).

Parameter *Torque* **224** shows the actual torque.

Select an applicable operation mode for parameter *Operation Mode Flying Start* **645**. Refer to chapter 7.3.5 "Flying Start".

7.9.5.2.2 Upper limit and lower limit of the frequency in Torque Control

767 Frequency Upper Limit 768 Frequency Lower Limit

In many cases limitation of the speed is required in the operating points with reduced or without load torque, because the speed regulates itself to the torque reference and the load behavior. To avoid an unintentional speed (mostly too high speeds, in some cases also too small speeds and avoidance of current impression), the frequency is limited by *Frequency Upper Limit* **767** and *Frequency Lower Limit* **768** by the speed controller.

As from the limit value the drive is controlled to maximum speed (*Frequency Upper Limit* **767** and *Frequency Lower Limit* **768**), which corresponds to the behavior of the speed controller. Additionally, the controller limits the speed to *Maximum Frequency* **419**. This limitation is set by the speed controller – changes in the speed controller affect the speed behavior in the limit area of the 3 mentioned parameters.

In the current impression, the speed is limited additional to $Minimum\ Frequency\ 418$ – in Direct Torque Control this limit is not active.



Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
767	Frequency Upper Limit	-999.99 Hz	999.99 Hz	999.99 Hz
768	Frequency Lower Limit	-999.99 Hz	999.99 Hz	-999.99 Hz

Note: Positive values limit the speed in clockwise direction; negative values limit the speed in anticlockwise direction. In example, if both values are positive (> 0 Hz), anticlockwise movement is inhibited.

⚠ WARNING



If the torque control is activated while the actual frequency lies outside the defined range of *Frequency Upper Limit* **767** and *Frequency Lower Limit* **768** (in example when switching on a stopped machine or when the Flying start synchronizes), the allowed frequency is driven to without ramps. The torque is only limited by the limitations of the speed controller (current and torque). Therefore an unexpected dynamic behavior can occur.

7.9.5.2.3 Limit Value Sources

769 Frequency upper limit source 770 Frequency lower limit source

The frequency can be limited by setting fixed values or linking an analog input. The assignment is done for the torque controller via *Frequency Upper Limit source* **769** and *Frequency Upper Limit source* **770**. The frequency limits of the analog value relate to 0 Hz and *Maximum Frequency* **419**. Setting a torque limit is done for *Minimum Reference Percentage* **518** and *Maximum Reference Percentage* **519**.

Oper	ration mode 769, 770	Function
1 -	Analog input MFI1A	The source is the multifunctional input 1 in analog operation mode (parameter <i>Operation Mode MFII</i> 452). The scaling refers to $100 \% = Maximum\ frequency\ $ 419 for the upper limit and $0 \% = 0$ Hz for the lower limit.
2 -	Analog input MFI2A	The source is the multifunctional input 2 in analog operation mode (parameter <i>Operation Mode MFI2</i> 562). The scaling refers to $100 \% = Maximum\ frequency$ 419 for the upper limit and $0 \% = 0$ Hz for the lower limit.
10 -	Fixed limit	The selected parameter values are taken into account to limit the speed controller. Factory setting .
708 -	RxPDO1 Long1	Process data of system bus. Refer to instructions on system bus. The value is processed as frequency.
709 -	RxPDO1 Long2	Process data of system bus. Refer to instructions on system bus. The value is processed as frequency.
2501 -	PLC Output Frequency 1	Output value of a PLC function. Refer to application manual PLC.
2502 -	PLC Output Frequency 2	Output value of a PLC function. Refer to application manual PLC.
10001	12502	Inverted values of signal sources 1 to 2502.

7.9.5.2.4 Switching over between speed control and torque control

Via the signal assigned to parameter n-/T-Control Change-Over **164**, you can switch between speed control and torque control. See chapter 7.6.6.10 "n-/T-control changeover".




7.9.5.3 Speed controller

720 Operation mode (speed controller)

The control of the torque-forming current components is done in the outer control loop by the speed controller. Via parameter *Operation Mode* **720**, you can select the operation mode for the speed controller. The operation mode defines the use of the parameterizable limits. These are referred to the direction of rotation and the direction of the torque and depend on the selected configuration.

Operation Mode 720	Function
0 - Speed controller off	The controller is deactivated or the torque-forming component is
	zero.
1 - Limits for motor/generator op.	The limitation of the speed controller assigns the upper limit to the motor operation of the drive. Independent of the direction of rotation, the same limit is used. The same applies in the case of regenerative operation with the lower limit. Factory setting.
2 - Limits pos./neg. torque	The assignment of the limit is done by the sign of the value to be limited. Independent of the motor or generator operating points of the drive, the positive limitation is done by the upper limit. The lower limit is regarded as a negative limitation.



721 Amplification 1 (|f| < P738)

722 Integral Time 1 (|f| < P738)

723 Amplification 2 (|f| >P738)

724 Integral Time 2 (|f| >P738)

738 Speed Control Switch-Over Limit

748 Backlash Damping

The properties of the speed controller can be adapted for adjustment and optimization of the controller

The amplification and integral time of the speed controller can be set via parameters $Amplification\ 1$ (|f|<P738) **721** and $Integral\ Time\ 1$ (|f|<P738) **722**. For the second speed range, parameters $Amplification\ 2$ (|f|>P738) **723**, $Integral\ Time\ 2$ (|f|>P738) **724** can be set. The distinction between the speed ranges is done by the value set with parameter $Speed\ Control\ Switch-Over\ Limit\ T38$. Parameters $Amplification\ 1$ (|f|<P738) **721** and $Integral\ Time\ 1$ (|f|<P738) **722** are considered with the default parameter $Speed\ Control\ Switch-Over\ Limit\ T38$ is set to a value greater than 0.00 Hz, parameters $Amplification\ 1$ (|f|<P738) **721**, $Integral\ Time\ 1$ (|f|<P738) **722** will be active below this limit, and parameters $Amplification\ 2$ (|f|>P738) **723**, $Integral\ Time\ 2$ (|f|>P738) **724** will be active above this limit.

The parameterized amplification at the current operating point can additionally be assessed via the parameter *Backlash Damping* **748** depending on the control deviation. In particular the small signal behavior in applications with a gearbox can be improved by a value higher than zero percent.



Parameters				
No.	Description	Min.	Max.	Fact. sett.
721	Amplification 1 (f <p738)< td=""><td>0.00</td><td>200.00</td><td></td></p738)<>	0.00	200.00	
722	Integral Time 1(f <p738)< td=""><td>0 ms</td><td>60000 ms</td><td>_ 1)</td></p738)<>	0 ms	60000 ms	_ 1)
723	Amplification 2 (f >P738)	0.00	200.00	- /
724	Integral Time 2 (f >P738)	0 ms	60000 ms	
738	Speed Control Switch-Over Limit	0.00 Hz	999.99 Hz	55.00 Hz
748	Backlash Damping	0%	300%	100%

The optimization of the speed controller can be done with the help of a reference value leap. The amount of the leap is defined by the set ramp or limitation. The optimization of the PI controller should be done at the maximum admissible reference figure change rate. First, the amplification is increased until the actual value overshoots distinctly during the control process. This is indicated by a strong os-cillation of the speed and by the running noises. In the next step, reduce the amplification slightly (1/2 ...3/4 etc.). Then reduce the integral time (larger I component) until the actual value overshoots only slightly in the control process.

If necessary, check the speed control settings in the case of dynamic operations (acceleration, deceleration). The frequency at which the switch-over of the controller parameters is effected can be set via parameter *Speed Control Switch-Over Limit* **738**.

7.9.5.3.1 Limitation of speed controller

The output signal of the speed controller is the torque-forming current component Isq. The output and the I portion of the speed controller can be limited via parameters *Current Limit* **728**, *Current Limit Generator Op.* **729**, *Torque Limit* **730**, *Torque Limit Generator Operation* **731** or *Power Limit* **739**, *Power Limit Generator Operation* **740**. The limits of the proportional portion are set via parameters *P-Comp. Torque Upper Limit* **732** and *P-Comp. Torque Lower Limit* **733**.

728 Current Limit 729 Current Limit Generator Op.

The output value of the speed controller is limited by an upper and a lower current limit. From the set values for *Current limit* **728** and *Current limit generator operation* **729**, the limits are calculated, considering the set magnetizing current. The parameter values are entered in Amperes. The current limits of the controller can be linked to the fixed limits and analog input parameters. The assignment is done via the parameters *Isq Limit Source Motor Operation* **734** and *Isq Limit Source Generator Op.* **735**.

Parameters		Setting		
No. Description		Min.	Max.	Fact. sett.
728	Current Limit	0.0 A	$o_c \cdot I_{FIN}$	$o_{c} \cdot I_{FIN}$
729	Current Limit Generator Op.	-0.01 A ¹⁾	$o_{c}{\cdot}I_{FIN}$	-0.01 A

I_{FIN}: Nominal value of frequency inverter

o_c: Overload capacity of frequency inverter

¹⁾ If the minimum value is set, the value of *Current Limit* **728** is used.

234

¹ The default settings for amplification and integral time refer to the recommended machine data. This enables a first function test in a large number of applications. Switch-over between settings 1 and 2 for the current frequency range is done by the software ac-cording to the selected limit value.




730 Torque Limit

731 Torque Limit Generator Operation

The output value of the speed controller is limited by an upper and a lower torque limit, parameter *Torque Limit* **730** and parameter *Torque Limit Generator Operation* **731**. The limit values are input as a percentage of the rated motor torque. The assignment of fixed values or analog limit values is done via the parameters *Torque Limit Source Motor Op.* **736** and *Torque Limit Source Gen. Op.* **737**.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
730	Torque Limit	0.00%	650.00%	650.00%
731	Torque Limit Generator Operation	0.00%	650.00%	650.00%



732 P-Comp. Torque Upper Limit 733 P-Comp. Torque Lower Limit

The output value of the P component of the torque controller is limited by parameter *P-Comp. Torque Upper Limit* **732** and *P-Comp. Torque Lower Limit* **733**. The limit values are input as torque limits as a percentage of the rated motor torque.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
732	P-Comp. Torque Upper Limit	0.00%	650.00%	650.00%
733	P-Comp. Torque Lower Limit	0.00%	650.00%	650.00%

739 Power Limit

740 Power Limit Generator Operation

The power output by the motor is proportional to the product of speed and torque. This output power can be limited at the speed controller output with *Power Limit* **739** and *Power Limit Generator Operation* **740**. The power limits are entered in kW.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
739	Power Limit	0.00 kW	2· o _c ·P _{FIN}	$2 \cdot o_c \cdot P_{FIN}$
740	Power Limit Generator Operation	0.00 kW	2· o _c ·P _{FIN}	$2 \cdot o_c \cdot P_{FIN}$

 P_{FIN} = Nominal Frequency inverter power

o_c: Overload capacity of frequency inverter



7.9.5.3.2 Limit value sources

734 Isq Limit Source Motor Operation

735 Isq Limit Source Generator Op.

736 Torque Limit Source Motor Op.

737 Torque Limit Source Gen. Op.

As an alternative to limiting the output values by a fixed value, linking to an analog input value is also possible. The analog value is limited via parameters *Minimum Reference Percentage* **518**, *Maximum Reference Percentage* **519**, but does not consider the *Gradient Percentage Ramp* **477** of the reference percentage value channel.

The assignment is done with the help of the parameters *Isq Limit Source Motor Operation* **734** and *Isq Limit Source Generator Op.* **735** for the torque-forming current component Isq.

The sources for the torque limits can be selected via the parameters *Torque Limit Source Motor Op.* **736** and *Torque Limit Source Gen. Op.* **737**.

	peration mode 4, 735, 736, 737	Function
	Analog Input MFI1A	Multifunction input 1 is the source. Via parameter <i>Operation Mode MFII</i> 452 , multifunction input 1 must be set up as a voltage or current input.
102 -	Analog Input MFI2A	Multifunction input 2 is the source. Via parameter <i>Operation Mode MFI2</i> 562 , multifunction input 2 must be set up as a voltage or current input.
105 -	Repetition Percentage Input	The percentage signal at the repetition frequency input (IN2D, terminal X11.5). <i>Operation Mode IN2D</i> 496 must be set to 20 or 21. See chapter 7.6.7 "Input PWM/repetition frequency/pulse train".
110 -	Fixed Limit	The selected parameter figures for limiting the speed controller are taken into account. Factory setting .
714 -	RxPDO2 Word 1	Process data of the system bus. Refer to instructions on system bus.
715 -	RxPDO2 Word 2	Process data of the system bus. Refer to instructions on system bus.
2521 -	PLC Output Percentage 1	Output value of a PLC-function. Refer to application manual "PLC".
2522 -	PLC Output Percentage 2	Output value of a PLC-function. Refer to application manual "PLC".



The limit values and assignment to different limit value sources are data set related in the configurations. The use of the data record changeover demands an examination of the parameters in question.

7.9.5.3.3 Switching over between speed control and torque control

Via the signal assigned to parameter n-/T-Control Change-Over **164**, you can switch between speed control and torque control. See chapter 7.6.6.10 "n-/T-control changeover".

7.9.5.4 Acceleration pre-control

725 Operation Mode

The acceleration pre-control controlled parallel to the speed controller reduces the reaction time of the drive system to a change of reference values.

The acceleration pre-control is active in the speed-controlled configurations and can be activated via parameter *Operation Mode* **725**.

Operation Mode 725	Function
0 - Off	The control system is not influenced. Factory setting.
1 - Switched on	The acceleration pre-control is active according to the limit values.



726 Minimum Acceleration 727 Mech. Time Constant

The minimum acceleration time defines the modification speed of the reference speed value as from which a torque necessary for acceleration of the drive is pre-controlled. The acceleration of the mass is a function of the *Mech. Time Constant* **727** of the system. The value calculated from the increase of the reference value and the multiplication factor of the torque required is added to the output signal of the speed controller.

	Parameters	Setting		
No.	Description	Min.	Max.	Fact. sett.
726	Minimum Acceleration	0.1 Hz/s	6500.0 Hz/s	1.0 Hz/s
727	Mech. Time Constant	1 ms	60000 ms	10 ms

For optimal setting, the acceleration pre-control is switched on and the mechanical time constant is set to the minimum value. The output value of the speed controller is compared to the minimum acceleration time during the acceleration processes. The frequency ramp is to be set to the highest value occurring in operation at which the output figure of the speed controller is not yet limited. Set the value of *Minimum Acceleration* **726** to half the set acceleration ramp. In this way, it is ensured that the acceleration pre-control becomes active.

During several acceleration attempts, increase the Mech. $Time\ Constant\ 727$ until the output value (signal source 37 – acceleration pre-control output) during the acceleration roughly corresponds to the torque-forming current I_{sq} (signal source 141). In the case of drives with a high friction or other high resistance torque, deduct the corresponding portion from the torque-forming current I_{sq} before. This setting should also minimize overshooting of the speed controller. Alternatively, you can calculate the mechanical time constant at a known mass moment of inertia. The mechanical time constant is the time the drive needs during acceleration from standstill with rated torque applied until the $Rated\ Speed\ 372$ is reached.

7.9.5.5 Field controller

717 Flux Reference Value 741 Amplification 742 Integral time

The flux-forming current component is controlled by the field controller. The guided commissioning optimizes the parameters of the field con-troller by measuring the time constant and magnetizing curve of the connected asynchronous motor. The parameters of the field controller are selected such that they can be used without changes in most applications. The proportional and the integrating part of the field controller are to be set via parameters *Amplification* **741** und *Integral Time* **742**.

Parameters			Setting	
No.	Description	Min.	Max.	Fact. sett.
717	Flux Reference Value	0.01%	300.00%	100.00%
741	Amplification	0.0	100.0	5.0
742	Integral Time	0.0 ms	1000.0 ms	100.0 ms

Please note, that changes within the Field controller parameters should only be done in the basic speed area.

When an optimization of the Field controller is necessary, set the $Integral\ Time\ 742 = Act.\ Rotor\ Time\ Constant\ 227\ /\ 2$, meaning to the half of the rotor time constant. In most application cases, this change is sufficient.

When further optimizations are necessary, follow the step described in the following procedure.

- Set the output frequency in a way (i.e. via the frequency reference value), that the actual value *Modulation* **223** = 80...90 % *Reference Modulation* **750**.
- Now change the Flux Reference Value **717** from 100 % to 90 %. Oscillograph the actuating variable I_{sd} . The course of the signal of the flux-forming current I_{sd} should reach the stationary value after overshooting without oscillation.



- Change the parameters *Amplification* **741** and *Integral Time* **742** according to the application requirements.
- Change the *Flux Reference Value* **717** back to 100 % und repeat the flux reference step while you can analyze the changes with the oscillograph. Repeat these steps if necessary.

If a quick transition into field weakening is necessary for the application, the integral time should be reduced. Increase the *Amplification* **741** in order to achieve a good dynamism of the controller.

An increased overshoot is necessary for a good control behavior in controlling of a load with low-pass behavior, e.g. an asynchronous motor.

7.9.5.5.1 Limitation of field controller

743 Ref. Isd Upper Limit 744 Ref. Isd Lower Limit

The output signal of the field controller, the integrating and proportional components are limited via parameters *Ref. Isd Upper Limit* **743** and *Ref. Isd Lower Limit* **744**. The guided commissioning (set-up) in *Configuration* **30** = 410 set parameter *Ref. Isd Upper Limit* **743** according to parameter *Rated Current* **371**.

In setting *Configuration* **30** = "610 -PMSM: sensor-less field-orientated control (DMC)" (synchronous motor), parameters *Ref. Isd Upper Limit* **743** and *Ref Isd Lower Limit* **744** are set to 10% of the value of *Rated Current* **371** during guided commissioning (setup).

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
743	Ref. Isd Upper Limit	0.0	$o_{c} \cdot I_{FIN}$	${ m I}_{\sf FIN}$
744	Ref. Isd Lower Limit	- I _{FIN}	I_{FIN}	0.0

 $I_{\mbox{\scriptsize FIN}}\!\!:$ Nominal value of frequency inverter

o_c: Overload capacity of frequency inverter.

The limits of the field controller define not only the maximum current occurring, but also the dynamic properties of the controller. The upper and lower limits restrict the modification speed of the motor flux and the torque resulting from it. In particular the speed area above the nominal frequency should be observed for the modification of the flux-forming component. The upper limit is to be estimated from the product of the set magnetizing current and the correction factor *Flux Reference Value* **717**, although the limit must not exceed the overload current of the drive.

7.9.5.6 Modulation controller

750 Reference Modulation

752 Integral Time

753 Operation Mode (modulation controller)

The modulation controller, which is designed as an I regulator, automatically adapts the output value of the frequency inverter to the machine behavior in the basic speed area and in the field weakening area. If the modulation exceeds the figure set with parameter *Reference Modulation* **750**, the field-forming current component and thus the flux in the machine are reduced.

In order to make the best possible use of the voltage available, the figure selected via parameter *Operation Mode* **753** is put into proportion to the DC link voltage. That means that with a high mains voltage there is also a high output voltage available, the drive only reaches the field weakening area later and produces a higher torque.

Operation Mode 753	Function
0 - Usq control	The modulation is calculated from the ratio of torque-forming voltage component U _{sq} to the DC link voltage.
1 - U abs. value control	The modulation is calculated from the abs. voltage value / DC link voltage ratio. Factory setting.

The integrating part of the modulation controller is to be set via parameter *Integral Time* **752**.



Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
750	Reference Modulator	3.00%	105.00%	102.00%
752	Integral Time	0.0 ms	1000.0 ms	10.0 ms

The percentage setting of the $Reference\ Modulation\ 750$ is basically a function of the leakage inductivity of the machine. The default value was selected such that in most cases the remaining deviation of 5% is sufficient as a reserve range for the current controller. For the optimization of the controller parameters, the drive is accelerated with a flat ramp into the area of field weakening, so that the modulation controller intervenes. The limit is set via parameter $Reference\ Modulation\ 750$. Then, the control loop can be excited with a jump function by modifying the reference modulation (changeover between 95% and 50%). By means of an oscillographed measurement of the flux-forming current component on the analog output of the frequency inverter, the controlling process of the modulation controller can be assessed. The course of the signal of the flux-forming current I_{sd} should reach the stationary value after overshooting without oscillation. An oscillating of the course of the current can be damped by increasing the integral time.

7.9.5.6.1 Limitation of modulation controller

755 Reference Imr Lower Limit 756 Control Deviation Limitation

The output signal of the modulation controller is the internal reference flux. The controller output and the integrating part are limited via the parameter *Reference Imr Lower Limit* **755** or the product of *Rated Magnetising Current* **716** and *Flux Reference Value* **717**. The magnetizing current parameter forming the upper limit is to be set to the rated value of the machine. For the lower limit, select a value which also builds up an adequate flux in the machine in the field weakening area. The limitation of the control deviation at the output of the modulation controller prevents a possible oscillation of the control loop in the case of load surges. The parameter *Control Deviation Limitation* **756** is stated as an absolute value and acts both as a positive and a negative limit.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
755	Reference Imr Lower Limit	$0.01 \cdot I_{FIN}$	$o_c \cdot I_{FIN}$	$0.01 \cdot I_{FIN}$
756	Control Deviation Limitation	0.00%	100.00%	10.00%

I_{FIN}: Nominal value of frequency inverter o_c: Overload capacity of frequency inverter.

7.9.6 Real-time tuning (optimizing motor parameters in operation)

1520 Operation mode real-time tuning

Motor parameters measured during commissioning (setup) at standstill will change during operation, e.g. as a result of changing motor winding temperatures. Real-time tuning compensates these changes. While the drive is running, the controller settings are adjusted continuously to changing motor properties and the control behavior is optimized. Real-time tuning can be used in V/f characteristic control (Configuration 30 = 110) and the field-orientated control methods (Configuration 30 = 410 or 610).

Parameter *Operation mode real-time tuning* **1520** enables the following settings:

- Activation of real-time tuning.
- Optimized control parameters are to be saved after shut-down of the frequency inverter.
- Optimized controller parameters are to be applied in a new data set after a data set changeover.



Operation mode real-time tuning 1520	Function
0 - Off	Real-time tuning is switched off. The controller settings and motor parameters are not changed during operation. Factory setting.
1 - On	Real-time tuning is switched on. After shut-down or restart of the frequency inverter or after a data set changeover, the changed controller parameters are deleted again and replaced by the static values. The static values contain the motor data measured during commissioning (setup).
3 - Latching	Real-time tuning is switched on. Optimized control parameters are saved after shut-down of the frequency inverter (non-volatile). Each data set is saved separately. In this way, real-time tuning may also be used for operating cases with motor changeover.
5 - Taking Over	Real-time tuning is switched on. Optimized control parameters are not saved after shut-down or restart of the frequency inverter. Optimized controller settings are applied in a new data set after a data set changeover.
7 - Latching and Taking Over	Combination of "Latching" and "Taking Over". Real-time tuning is switched on. Optimized control parameters are saved after shutdown or restart of the frequency inverter (non-volatile). Optimized controller settings are applied in a new data set after a data set changeover.

7.10 Special functions

The configurable functions of the corresponding control methods enable another field of application of the frequency inverters. The integration in the application is made easier by special functions.

7.10.1 Pulse width modulation

400 Switching Frequency

The motor noises can be reduced by changing over the parameter *Switching Frequency* **400**. A reduction of the switching frequency should be up to a maximum ration of 1:10 to the frequency of the output signal for a sine-shaped output signal. The maximum possible switching frequency depends on the drive output and the ambient conditions. For the required technical data refer to the corresponding table and the device type diagrams.

Parameters Configuration 30			Setting			
No.	Description	Selection	Min.	Max.	Fact. sett.	
400	Switching Frequency	110	2 kHz	16 144-	2 kHz	
		410, 610	4 kHz	16 kHz	4 kHz	

The factory setting of parameter *Switching Frequency* **400** depends on the setting of parameter *Configuration* **30**.

401 Min. Switching Frequency

The heat losses increase proportionally to the load point of the frequency inverter and the switching frequency. The automatic reduction adjusts the switching frequency to the current operating state of the frequency inverter in order to provide the output performance required for the drive task at the greatest possible dynamics and a low noise level.

The switching frequency is adapted between the limits which can be set with the parameters *Switching Frequency* **400** and *Min. Switching Frequency* **401**. If the *Min. Switching Frequency* **401** is larger than or equal to the *Switching Frequency* **400**, the automatic reduction is deactivated.

	Parameters	Setting			
No.	Description	Min.	Max.	Fact. sett.	
401	Min. Switching Frequency	2 kHz	16 kHz	2 kHz	



580 Reduction Limit Ti/Tc

The change of the switching frequency depends on the heat sink temperature switch-off limit and the output current. The temperature limit to be exceeded so that the switching frequency is reduced can be set via parameter $Reduction\ Limit\ Ti/Tc\ 580$. If the heat sink temperature falls below the threshold set via parameter $Reduction\ Limit\ Ti/Tc\ 580$ by 5 °C, the switching frequency is increased again step by step.

	Parameters	Setting			
No.	Description	Min.	Max.	Fact. sett.	
580	Reduction Limit Ti/Tc	-25 °C	0 ℃	-4 °C	



The limit for the switching frequency reduction is influenced by the intelligent current limits depending on the selected *Operation Mode* **573** and the output current. If they have been switched off or provide the full overload current, the switching frequency is reduced when the output current exceeds the limit of 87.5% of the long-term overload current (60 s). The switching frequency is increased if the output current drops below the reference current of the next highest switching frequency.

7.10.2 Fan

39 Switch-On Temperature

The fans run in two power stages.

The fans ar switched on with the following conditions:

- If the inside, capacitor or heat sink temperature exceeds the value of *Switch-On Temperature* **39**, the inside fan and the heat sink fan will be switched on and run at half power.
 - A possible external fan is also switched on via the parameterized digital output.
- Independent of the setting of *Switch-On Temperature* **39** the fans start at half power when internal fixed temperature thresholds (internal temperature, Capacitor temperature) haven been reached.
- If the measured temperatures increase also at half power of the fans, the fans will be switched to full power when a critical temperature threshold is reached.



To protect the device a device fault is triggered when reaching an internal switching off temperature threshold.

The fans will be switched off again as soon as the heat sink temperature has dropped below the $Switch-On\ Temperature\ 39$ by 5 °C and the internal temperatures dropped 5°C below their first switch-on thresholds.

	Parameters	Setting			
No.	Description	Min.	Max.	Fact. sett.	
39	Switch-On Temperature	0 °C	60 °C	30 °C	

Further fan control setting options

Operation mode "43 - external fan" for digital outputs additionally enables the control of an external fan. Via the digital output, the external fan is switched on as soon as the *Switch-On Temperature* **39** for the internal fans was reached. See chapter 7.6.5 "Digital outputs".

Via parameter *Standby Mode* **1511**, you can set that the internal fans are switched off if enable is switched off. See chapter 8.3 "Standby mode".

7.10.3 Standby mode and energy saving function

Refer to chapter 8 "Energy saving".



7.10.4 Brake chopper and brake resistor

506 Trigger Threshold

The frequency inverters feature a brake chopper transistor. The external brake resistor is connected to terminals Rb1 and Rb2. The parameter *Trigger Threshold* **506** defines the switch-on threshold of the brake chopper. The generator output of the drive, which leads to the increase in the DC link voltage, is converted to heat by the external brake resistor above the limit set via parameter *Trigger Threshold* **506**.

	Parameters			Settin	g
No.	Description		Min.	Max.	Fact. sett.
FOC	Trigger Threshold	AGL202	225.0 V	1000.0 V	390.0 V
506	Trigger Threshold	AGL402	325.0 V	1000.0 V	780.0 V

Set parameter *Trigger Threshold* **506** such that it is between the maximum DC link voltage which the mains can generate and the maximum admissible DC link voltage of the frequency inverter.


$$U_{Mains} \cdot 1.1 \cdot \sqrt{2} < Ud_{BC} < Ud_{max}$$

If the parameter *Trigger Threshold* **506** is set larger than the maximum admissible DC link voltage, the brake chopper cannot become active; the brake chopper is switched off.

If the parameter *Trigger Threshold* **506** is set to a value below the DC link voltage generated by the mains, error message F0705 (chapter 13.1.1 "Error messages") is displayed if the start command is issued to the frequency inverter.

If the DC link voltage exceeds the maximum value of DC 800 V, error message F0700 (see chapter 13.1.1 "Error messages") will be signaled.

The sampling time of the function is $62.5 \,\mu s$. The brake chopper remains on for at least $62.5 \,\mu s$ after the set trigger threshold was exceeded even if the value drops below the trigger threshold within this period again.



Release or disable brake chopper

Via the signal assigned to parameter *Brake Chopper Release* **95**, the brake chopper can be released or disabled. See chapter 7.6.6.13 "Brake chopper release".



Please note that by default the Motor chopper *Trigger Threshold* **507** and the *Trigger Threshold* **506** are set up with different values. Check, that the two thresholds are set up fittingly for your application.

Please check chapter 7.10.5 "Motor chopper".



7.10.4.1 Dimensioning of brake resistor



♠ WARNUNG



Connect a brake resistor following the instructions and safety information provided in chapter 5.6.5 "Brake resistor".

The following values must be known for dimensioning:

- Peak braking power P_{b Peak} in W
- Resistance R_b in Ω
- Relative operation time OT in %
- Calculation of peak braking power Pb Peak

$$P_{b \, Peak} = \frac{J \cdot \left(n_1^2 - n_2^2\right)}{182 \cdot t_b} \quad \begin{array}{ll} P_{b \, Peak} & = & Peak \, braking \, power \, in \, W \\ J & = & Moment \, of \, inertia \, of \, drive \, system \, in \, kgm^2 \\ n_1 & = & Speed \, of \, drive \, system \, before \, the \, braking \, operation \, in \, min^{-1} \\ n_2 & = & Speed \, of \, drive \, system \, after \, the \, braking \, operation \, in \, min^{-1} \\ \end{array}$$

= Braking time in s

Calculation of resistance R_b

$$R_b = \frac{{U_d}_{BC}^2}{P_b} \hspace{1cm} \begin{array}{ll} R_b & = \mbox{ Resistance in } \Omega \\ U_{dBC} & = \mbox{ Switch-on threshold in V} \\ P_b \mbox{ Peak} & = \mbox{ Peak braking power in W} \end{array}$$

The switch-on threshold $U_{d\ BC}$ is the DC link voltage at which the brake resistor is switched on. The switch-on threshold can be set via parameter $Trigger\ Threshold\ 506$.



⚠ CAUTION

The resistance of the brake resistor must not be less than the minimum value $R_{b\,min}$ - 10%. The values for $R_{b\,min}$ are listed in chapter 11 "Technical data".

If the calculated resistance R_b of the brake resistor is between two standard series values, the lower resistance must be selected.

• Calculation of relative operation time OT

$$\text{OT} = \frac{t_b}{t_c} \qquad \qquad \text{OT} \qquad = \text{ Relative operation time (percentage duty cycle)} \\ t_b \qquad = \text{ Braking time (duty cycle)} \\ t_c \qquad = \text{ Cycle time}$$



Example:

$$t_b = 48 \text{ s, } t_c = 120 \text{ s}$$

$$OT = \frac{t_b}{t_c} = 0.4 = 40\%$$

In the case of infrequent short braking operations, typical values of the relative operation time OT are at 10%, for long braking operations (\geq 120 s) typical values are at 100%. In the case of frequent deceleration and acceleration operations, it is recommended that the relative operating time OT be calculated according to the above formula.

The calculated values for $P_{b\ Peal}$, R_{b} and OT can be used by the resistor manufacturers for determining the resistor-specific permanent power.



7.10.5 Motor chopper

507 Trigger Threshold

The field-orientated control systems for asynchronous motors (configuration 410 FOC) contain the function for adapted implementation of the generator energy into heat in the connected three-phase machine. This enables the realization of dynamic speed changes at minimum system costs. The torque and speed behavior of the drive system is not influenced by the parameterized braking behavior. The parameter *Trigger Threshold* **507** of the DC link voltage defines the switch-on threshold of the motor chopper function.

	Parameters			Setti	ng
No.	Descriptio	Min.	Max.	Fact. sett.	
F07	Triager Threshold	AGL202	225.0 V	1000.0 V	400.0 V
507	Trigger Threshold	AGL402	325.0 V	1000.0 V	800.0 V

Set parameter *Trigger Threshold* **507** such that it is between the maximum DC link voltage which the mains can generate and the maximum admissible DC link voltage of the frequency inverter.

$$U_{Mains} \cdot 1.1 \cdot \sqrt{2} < U_{dMC} < Ud_{max}$$

If the parameter *Trigger Threshold* **507** is set larger than the maximum admissible DC link voltage, the motor chopper cannot become active, the motor chopper is switched off.

If the set *Trigger Threshold* **507** is smaller than the maximum DC link voltage the mains can generate, error message F0706 (chapter 13.1.1 "Error messages") is displayed when the frequency inverter is switched on.



The motor chopper function only works if activated via voltage Controller *Operation Mode* **670**. See chapter 7.9.2 "Voltage controller".



For synchronous motors (Configuration~30=610), the motor chopper function is deactivated to prevent damages to the motor. The other functions of the voltage controller are not affected by this.



Please note that by default the Motor chopper *Trigger Threshold* **507** and the *Trigger Threshold* **506** are set up with different values. Check, that the two thresholds are set up fittingly for your application.

Please check chapter 7.10.4 "Brake chopper and brake resist".



7.10.6 Motor Protection

The protection of the motor against impermissible temperature rise requires monitoring mechanisms for recognizing a thermal overload to prevent a possible damage to the motor. The thermal state of a motor can be evaluated by different ways.

- 1.) Direct monitoring by temperature sensors inside the motor winding (Please check chapter 7.4.6 "Motor temperature")
 - PTC
 - KTY
 - PT100
 - Thermal contact
- 2.) Indirect monitoring of the motor temperature
 - Monitoring of the motor current based on the K characteristic of an integrated motor circuit breaker
 - Emulation of the motor heating by using a temperature-relevant mathematical model I²t


The choice of thermal control is mainly determined by type and operating conditions of the motor. For safe motor protection it is generally sufficient using one of the available possibilities. A combination of the two groups and their simultaneous operation is possible.

7.10.6.1 Motor protection by Motor Circuit Breaker

571 Operation Mode (motor circuit breaker)

Motor circuit breakers are used for protecting a motor and its supply cable against over-heating by overload. Depending on the overload level, they disconnect the motor from power supply immediately in the case of a short-circuit or they disconnect the motor if an overload has occurred for some time.

Conventional motor circuit breakers are commercially available for various applications with different trigger characteristics (L, G/U, R and K), as shown in the diagram below. As frequency inverters in most cases are used for supplying motors which are classified as operating equipment with very high starting currents, only the K-characteristic was realized in this function.





Unlike the operation of a conventional motor circuit breaker which disconnects the equipment to be protected immediately if the trigger threshold is reached, this function provides the possibility of issuing a warning instead of disconnecting the equipment immediately.

The rated current of the motor circuit breaker refers to the rated motor current stated via parameter *Rated Current* **371** of the corresponding data set. The rated values of the frequency inverter are to be considered accordingly when it comes to dimen-sioning the application.

The function of the motor circuit breaker can be linked to different data sets. In this way, it is possible to operate different motors via one frequency inverter. Thus, each motor can be equipped with its own motor circuit breaker.

In case a motor is operated via the frequency inverter for which some setting values, e.g. minimum and maximum frequency, are changed via the data set switch-over, only one motor circuit breaker may be installed. This functionality can be set for single or multi-motor operation via parameter *Operation Mode* **571**.

Ор	eration Mode 571	Function
	Off	The function is deactivated. Factory setting.
1 -	K-Char.,Mul.Motor Op.,Err.Sw.Off	In each of the four data sets, the rated values are monitored. Overloading the drive is prevented by the fault switch-off "F0401".
2 -	K- Char.,Sing.Motor,Err. SwOff	The rated values in the first data set are used independently of the active data set. Overloading the drive is prevented by the fault switch-off "F0401".
11 -	K-Char.,Multi-Motor Op.,Warning	In each of the four data sets, the rated values are monitored. Overloading the drive mechanism is signaled by a warning message "A0200".
22 -	K-Char.,Single- Motor,Warning	The rated values in the first data set are used independently of the active data set. Overloading the drive mechanism is signaled by a warning message "A0200".
42 -	I ² t, Single-Motor, Error Switch Off	Please check chapter 7.10.6.2 "Motor Protection by I2t- monitoring"
51 -	I ² t, Multi-Motor Op- eration, Warning	Please check chapter Motor Protection by I^2 t- monitoring7.10.6.2 "Motor Protection by I2t- monitoring"
53 -	I ² t, Single-Motor, Warning	Please check chapter 7.10.6.2 "Motor Protection by I2t- monitoring"
61 -	I ² t, Multi-Motor Op- eration, Warning and Error Switch Off	Please check chapter 7.10.6.2 "Motor Protection by I2t- monitoring"
62 -	I ² t, Single-Motor, Warning and Error Switch Off	Please check chapter 7.10.6.2 "Motor Protection by I ² t- monitoring"
101-	K-Char.,Multi-Motor Op.,Warning, stored	In each of the four data sets, the rated values are monitored. Overloading the drive is prevented by the fault switch-off "F0401". The internal state of the Motor circuit breaker is stored reset stable. These settings are to be used for short-time mains shut downs.
102-	Char.,Sing.Motor,Err. SwOff, stored	The rated values in the first data set are used independently of the active data set. Overloading the drive is prevented by the fault switch-off "F0401". The internal state of the Motor circuit breaker is stored reset stable. These settings are to be used for short-time mains shut downs.
111-	K-Char.,Multi-Motor Op.,Warning, stored	In each of the four data sets, the rated values are monitored. Overloading the drive mechanism is signaled by a warning message "A0200". The internal state of the Motor circuit breaker is stored reset stable. These settings are to be used for short-time mains shut downs.
122 -	K-Char.,Single- Motor,Warning, stored	The rated values in the first data set are used independently of the active data set. Overloading the drive mechanism is signaled by a warning message "A0200". The internal state of the Motor circuit breaker is stored reset stable. These settings are to be used for short-time mains shut downs

K-Char: K-characteristic of the motor circuit breaker



Multiple motor operation

Parameter *Operation Mode* **571** = 1 or 11, (101 or 111).

In multiple motor operation, it is assumed that each data set is assigned to a corresponding motor. For this, one motor and one motor circuit breaker are assigned to each data set. In this operation mode, the rated values of the active data set are monitored. The current output current of the frequency inverter is only taken into account in the motor circuit breaker activated by the data set. In the motor circuit breakers of the other data sets, zero current is expected, with the result that the thermal decay functions are taken into account. In combination with the data set changeover, the function of the motor circuit breakers is similar to that of motors connected alternately to the mains with their own circuit breakers.

Single motor operation

Parameter $Operation \ Mode \ 571 = 2 \text{ or } 22, (102 \text{ or } 122).$

The internal state of the motor circuit breaker is stored reset stable. These settings are to be used for short-time time mains shut downs. This way the motor protection is considered correctly also in applications where a short mains power off or a shutdown orccurs.

Reset stable

Parameter *Operation Mode* **571** = **101**, **102**, **111** or **122**.

The internal state of the motor protection switch is latched reset stable. These be used when regularly short mains interruptions occur. This way the motor protection correctly for short mains failures or short shut downs of the application.



In settings 101, 102, 111 and 112 of *Operation Mode* 571 the same values should be set in all data sets.

572 Frequency Limit

The motor protection, especially of self-ventilated motors is improved by an adjustable frequency limit. Percentage reference is the rated frequency.

	Parameters	Setting			
No.	Description	Min. Max. Fact. se			
572	Frequency Limit	0%	300%	0%	

In calculation the tripping time the measured output current in operating points below the frequency limit is evaluated by a factor between 1 and 2. The determination of this factor is a function of the stator frequency. The increased thermal load of self-ventilated motors in the lower speed range is therefore considered.

The table shows in extracts factors for motor rated frequency 50Hz.

	← Frequency limit 572 ← →									
	3	800%	200%	150%	100%	80%	60%	40%	20%	10%
0	2	200%	200%	200%	200%	200%	200%	200%	200%	200%
5	1	.88%	182%	177%	168%	162%	153%	139%	114%	100%
10	1	.77%	168%	160%	147%	139%	129%	114%	100%	100%
20	1	.60%	147%	137%	122%	114%	106%	100%	100%	100%
30	1	.47%	132%	122%	109%	103%	100%	100%	100%	100%
50	1	.29%	114%	106%	100%	100%	100%	100%	100%	100%
100	1	.06%	100%	100%	100%	100%	100%	100%	100%	100%
150	1	.00%	100%	100%	100%	100%	100%	100%	100%	100%



7.10.6.2 Motor Protection by I²t- monitoring


571 Operation Mode (I²t- monitoring)

To protect the motor against overload the I^2 t monitoring provides a further possibility for the user. This kind of motor protection is mainly used in servo technology.

When using servo motors the I^2t - monitoring is a proven alternative to motor protection switch. By integrating temperature-dependent parameters, measurable or known, the heating of a mathematical model is simulated. The kind of the I^2t monitoring mode can be selected by *Operation Mode* **571**. This parameter is switchable via data set.

The I^2t monitoring works by function $(I_{act}/I_n)^2$ as shown in the figure.

The monitored value is evaluated via a PT1 element with the thermal time constant of the stator. If the output of PT1 element is bigger than 120%, then an error message is generated and the drive switches off. The threshold of 120% prevents, that an overshoot leads to an immediate shutdown. In the application should be avoided exceeding 100% capacity of the stator winding permanently.



The output of the first PT1 element is linked to the input of the second PT1 element which includes the thermal motor time constant. This output may be permanently 100%.

This corresponds to the complete thermal capacity of the motor. If 102% is reached, the drive switches off with an error message. Both outputs are connected to the adjustable alarm limit.

Operation Mode 571	Function
42 – I ² t, Single-Motor, Error Switch Off	The I ² t capacity of the motor is monitored with rated values from the active dataset.
	If the fixed threshold values exceed $100\%_{motor}$ ($120\%_{stator}$), the drive switches off with fault "F0401" in the active dataset.
51 – I ² t, Multi-Motor Operation, Warning	The I²t capacity of the motors regarding their related ratings is monitored in each of the four data sets. If the <i>Warning Limit Motor I²t</i> 615 is reached, the warning message "A0200" is signaled from the active data set.
52 – I ² t, Single-Motor, Warning	The I ² t capacity of the motor is monitored with rated values from the active dataset.
	If the Warning Limit Motor I^2t 615 is reached, the warning message "A0200" is signaled from the active data set.



Operation Mode 571	Function
61 – I ² t, Multi-Motor Operation, Warning and Error Switch Off	The I^2t capacity of the motors regarding their related ratings is monitored in each of the four data sets. If the <i>Warning Limit Motor I</i> ² t 615 is reached, the warning message "A0200" is signaled from the active data set. If the fixed threshold values exceed $100\%_{motor}$ ($120\%_{stator}$), the drive switches off with fault "F0401" in the active dataset. Both incidences are triggered from the active dataset.
62 – I ² t, Single-Motor, Warning and Error Switch Off	The I ² t capacity of the motor is monitored with rated values from the active dataset.
	If the <i>Warning Limit Motor I</i> ² t 615 is reached, the warning message "A0200" is signaled from the active data set. If the fixed threshold values exceed $100\%_{motor}$ ($120\%_{stator}$), the drive switches off with fault "F0401" in the active dataset. Both incidences are triggered from the active dataset.

608 Thermal time constant motor 609 Thermal time constant rotor 615 Warning limit motor I²t

The thermal time constant of the motor is in the range from few minutes to a couple of hours.

This motor-specific parameter is set via *Thermal time constant motor* **608**.

Substantially smaller is the thermal stator time constant. To protect the stator winding additional monitoring is required which is determined by *Thermal time constant stator* **609**.

These values can be taken from the corresponding motor data sheets.

When estimated time constants are used because the required data are not available then an optimal thermal motor protection cannot be guaranteed.

A warning limit allows the user to prevent an imminent I^2t -fault trip through appropriate measures. Warning limit motor I^2t **615** is used to set the warning signal between 6% and 100% of thermal capacity.

	Parameters		Setting			
No.	Description	Control level	Min	Max	Fact. setting	
608	Thermal time constant Motor	1 in AGL 3 in ACU	1 min	240 min	30 min	
609	Thermal time constant Stator	1 in AGL 3 in ACU	1 s	600 s	15 s	
615	Warning Limit Motor I ² t	1 in AGL 3 in ACU	6%	100%	80%	

Output signals

Digital signals signal that of the function " motor protection " has been triggered.

180 -	Warning motor	1)	Triggering of the function " motor protection " according to <i>Operation</i>
14 -	protection	2)	Mode 571 is signaled.

¹⁾ For linking to frequency inverter functions

²⁾ For output via a digital output. Select the signal source for one of the parameters 531, 532, 533, 554. See chapter 7.6.5 "Digital outputs".



7.10.7 V-belt monitoring

581 Operation Mode (V-belt monitoring)

582 Trigger Limit lactive

583 Delay Time

Continuous monitoring of the load behavior and thus of the connection between the 3-phase machine and the load is the task of the V-belt monitoring system. Parameter *Operation Mode* **581** defines the functional behavior if the *Active Current* **214** or the torque-forming current component *Isq* **216** (field -orientated control method) drops below the set *Trigger Limit Iactive* **582** for a time longer than the set *Delay Time* **583**.

Operation Mode 581	Function
0 - Off	The function is deactivated. Factory setting.
1 - Warning	If the active current drops below the threshold value, the warning "A8000" is displayed.
2 - Error	The unloaded drive is switched off and fault message "F0402" is displayed

The error and warning messages can be output via the digital outputs (Signal 22 - "Warning V-Belt") and transmitted to an overriding controller, for example. The *Trigger Limit Iactive* **582** is to be parameterized as a percentage of the *Rated Current* **371** for the application and the possible operating points.

	Parameters	Setting		
No.	Description	Min.	Max.	Fact. sett.
582	Trigger Limit Iactive	0.1%	100.0%	10.0%
583	Delay Time	0.1 s	600.0 s	10.0 s

7.10.8 Traverse function

With the traverse function, a triangle-shaped frequency signal with the start-up and shut-down times to be set is superimposed on the output frequency. The resulting chronological order of the reference frequency of master drive and slave drive are shown in the following diagrams. The function can be used, for example, for drives which wind up thread on coils in textile machines. To avoid winding errors at the turning point of the thread guide, a proportional step is performed which causes a quick speed change.

435 Operation Mode (Traverse function)

Via parameter *Operation Mode* **435**, the drive is configured as a master drive or slave drive.

Operation mode 435	Function
0 - Off	The traverse function is deactivated. Factory setting.
1 - Master drive	Operation as master drive.
2 - Slave drive	Operation as slave drive.



436 Ramp-up Time


437 Ramp-down Time

438 TraverseAmplitude


439 Proportional Step

In the case of the master drive, the superimposed traverse frequency is linearly opposite to the limit *Traverse Amplitude* **438** and then reverses its direction. When the direction is reversed, a proportional step is effected. Via a handshake signal, the master drive informs the slave drive that the traverse output has changed its direction. The traverse function of the slave drive has the same gradient as the traverse function of the master drive, but an opposite sign. When the slave drive reaches the limit *Traverse Amplitude* **438** before switch-over of the handshake signal, the frequency is maintained until switch-over is effected. If the handshake signal is received before the frequency limit is reached, the direction is reversed immediately.

The Percentage values of *Traverse Amplitude* **438** and *Proportional Step* **439** refer to the current frequency value set up by *Reference Frequency* **48**.



Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
436	Ramp-up Time	0.01 s	320.00 s	5 s
437	Ramp-down Time	0.01 s	320.00 s	5 s
438	Traverse Amplitude	0.01%	50.00%	10%
439	Proportional Step	0.00%	50.00%	0.01%



Signal "14 - Traverse Function Output" is added to the reference frequency value. During traverse operation, the configured traverse parameter values cannot be changed. The source of the handshake signal is selected via *Handshake Traverse Function* **49**.



48 Reference Frequency

For traverse mode, the reference value source is selected via parameter *Reference Frequency* **48**.

Traverse mode becomes active when *Operation Mode* **435** is switched on. In traverse mode, the values for *Ramp-up Time* **436** and *Ramp-down Time* **437** are active.

Referenc	e Frequency 48
0 - Ramp output (factory setting)	93 - Slip compensation
1 5 - Fixed frequencies 1 4	109 - Udc-controller
9 - Zero	115 118 - Fixed frequencies 5 8
10 - Stator frequency	154 - Reference ramp value
12 - Tech. controller freq. output	155 - Actual speed
14 - Traverse function output	230 - Internal reference frequency
16 - I-limit output	288 - Repetition frequency input
21 - Rotor frequency	688 - Electronic gear output
50 - Reference analog value MFI1A	708 738 - RxPDO Long (system bus)
51 - Reference analog value MFI2A	774, 775 - Out-F PDPconv-long (Profibus)
56 - PWM Input	2501 2504 - PLC-output frequency 1 4
62 - Reference frequency channel	

Attention:

♠ WARNING




The frequency range for traverse mode is added additional to the frequency reference. Therefore the added frequency can result in values smaller than *Minimum Frequency* **418** or bigger than *Maximum Frequency* **419**.

To prevent too high frequencies, the summed frequency is limited:

Maximum Frequency 419	Limitation of the summed Frequency
Maximum Frequency 419 <= 100 Hz	Maximum Frequency 419 +20 Hz
Maximum Frequency 419 >= 100 Hz	Maximum Frequency 419 x 1.2

Traverse function with Setting *Reference Frequency* **48** 0 – Ramp output:





7.10.9 System data

For monitoring the application, process parameters are calculated from electrical control parameters.

389 Factor Actual System Value 1543 Base Parameter Actual System Value

Actual values (e.g. actual frequency, torque) can be scaled. The drive can be monitored via the actual value *Actual System Value* **242**.

The actual value to be monitored and scaled must be selected. For parameter *Base Parameter Actual System Value* **1543**, the number of the actual value parameter must be set. The value of the actual value parameter is multiplied by the *Factor Actual System Value* **389** and can be read out via parameter *Actual System Value* **242**.

Actual System Value 242 = (actual value from parameter 1543) x Factor Actual System Value 389

Parameters			Setting	
No.	Description	Min.	Max.	Fact. sett.
389	Factor Actual System Value	-100.000	100.000	1.000

Parameters		Setting			
No.	Description		Min.	Max.	Fact. sett.
1543	Base Parameter Actual System Value	Parameter number of actual value	0	1600	241 (Actual frequency)

Factory setting:

Actual System Value $242 = (Actual Frequency 241) \times 1.000$

- Set an actual value (parameter number) in parameter *Base Parameter Actual System Value* **1543**.
- Set a factor in parameter *Factor Actual System Value* **389**.

Parameter Actual System Value 242 shows the scaled actual value.

7.10.10 Service interval monitoring

Refer to chapter 10.3 "Monitoring of service interval".

7.10.11 Copy parameters

Parameter values can be saved on a memory card via operator panel or via PC control software VPlus.

Note:

Field bus communication is not possible or faulty during data storage or data reading by means of the memory card.

Note:

To use the copy function, use the memory card ("Resource pack") offered by Bonfiglioli Vectron.


Bonfiglioli Vectron doesn't take any responsibility for the malfunctioning of the memory cards of other manufacturers.



7.10.11.1 Copying using the operator panel

Storage on a memory card


Parameter values of a frequency inverter can be saved on standard digital memory cards (Bonfiglioli Vectron "Resource Pack") and uploaded on another frequency inverter.



SAVE Save parameter values in a file on the memory card.

- On the operator panel in menu "Copy", select item "Save".
- Confirm by pressing "ENT". The number of the next available file is displayed.
- Confirm by pressing "ENT". The parameter values are copied to the file on the memory card.

A progress indicator indicates the parameter numbers the values of which are currently copied to the memory card.





Please note, that always the highest existent number on the memory card is used to determine the next free data file number.


New Data file number = Highest existent Data file number + 1

If a file with number 9999 already exists, the data set to be stored cannot be stored correctly. Always take care, that at least number 9999 is available before Saving.

LOAD Uploading parameter values from memory card to a frequency inverter.

- On the operator panel in menu "Copy", select item "Load".
- Confirm by pressing "ENT". Using the arrow buttons, select the file you want to upload to the frequency inverter.
- Confirm by pressing "ENT". The parameter values of the selected file are uploaded to the frequency inverter.

A progress indicator indicates the parameter numbers the values of which are currently uploaded to the frequency inverter.





Messages

[noFile] No file with parameter values on memory card.

Parameter values were saved on memory card.

Parameter values were uploaded to frequency inverter.

Insufficient memory. The parameter values were not copied to the memory card completely.

Err002 No more file numbers available.

Error while writing on the memory card.

Error while reading from the memory card.

[Err005] Data content invalid.

Fault when loading from memory card, memory card has contact problems. Contact mounting of card.

Error while writing parameters of LOAD functions. Non-permissible parameter value.

Error while writing parameters of LOAD functions. Non-permissible parameter set.

Error while writing parameters of LOAD functions. Non-permissible write access.

Error while writing parameters of LOAD functions. Write error EEPROM.

Error while writing parameters of LOAD functions. Checksum error EEPROM.

Error while writing parameters of LOAD functions. Value is only allowed to be written at inhibited state.

Error while writing parameters of LOAD functions. Error parameter type.

Error while writing parameters of LOAD functions. Unknown parameter. The mentioned parameter is not contained inside the target device.

If an error occurs in the LOAD function while the parameters are written, the error number and the parameter number will be displayed alternately.

- Press button "ENT" to continue the function.
- Press button "ESC" to cancel the function.



Please check the compatibility of different firmware versions when copying parameter sets between different devices. When copying from a device with a newer firmware version into devices with older firmware versions in individual cases the warning message "Err 111" may appear.

The market software of the Agile device series is downward compatible. Data from devices with older firmware versions can be transferred to devices with newer firmware.




Parameters are always saved in control level 3 "Professional" on the memory card. This is independent of the currently selected control level.



7.10.11.2 Copying using the PC control software

Parameter values can be saved on standard digital memory cards (Bonfiglioli Vectron "Resource Pack") using the PC control software VPlus and uploaded on a frequency inverter.



Activate in the Saving mask for the usage on a MMC card always the function "Save to Multimedia Card". To save a file for a MMC card only file names in the range from 0001 to 9999 are allowed to be used. The file names must be entered in the format "four-digit" + file extension for the usage on a MMC card.



Please note, that when storing via VPlus always the parameters of the selected control level are stored. Bonfiglioli Vectron recommends to read out the frequency inverter in control level 3 in VPlus before storing the file.

7.10.12 Converter Profibus from/to Internal Notation

1370 In-F-PDP-word 1 1371 In-F-PDP-word 2 1372 In-F-intern-long 1 1373 In-F-intern-long 2 1374 In-F-Convert Reference

The Converter Profibus/Internal notation can convert a 16 bit Word into an internal 32 Bit frequency value and vice versa. This is useful in example, when several devices are linked together via Systembus and for commercial reasons only one device is equipped with a Profibus Option. Through the routing of the Profibus Word via the Systembus ("Tunneling") the necessary bandwidth can be reduced and the parameterization of the "Gateway" (Systembus Master with Profibus Slave communication) be simplified. The converter is used in this case in a device without Profibus module to convert the Profibus Notation into an internal reference value.

A similar procedure can be used to convert in example the Actual Frequency into a value according to Profibus notation.

The converter can also be used for other purposes, in example when using the internal PLC programming.

In-F-PDP-word 1 **1370** and *In-F-PDP-word 2* **1371** convert the Profibus Notation into the internal Frequency. 0x4000 in Profibus-Notation (=100 %) refers to *In-F-Convert Reference* **1374** in Hz.

In-F-intern- $long\ 1$ **1372** and In-F-intern- $long\ 2$ **1373** convert an internal frequency value into Profibus Notation. 0x4000 in Profibus-Notation (=100 %) refers to In-F- $Convert\ Reference\$ **1374** in Hz.

The Profibus Notation is limited to values from -200 % (0x8000) to +200 % (0x7FFF).

 0x4000 = 100% = $In\text{-}F\text{-}Convert\ Reference}$ 1374

 0x7FFF = 200% = $2x\ In\text{-}F\text{-}Convert\ Reference}$ 1374

 0x8000 = -200% = $-2x\ In\text{-}F\text{-}Convert\ Reference}$ 1374

 0xC000 = -100% = $-In\text{-}F\text{-}Convert\ Reference}$ 1374

The values converted this way can be used as internal source.

774 – Out-F-PDP-Conv1-long1 as output of In-F-PDP-word 1 **1370** (Profibus-Not. \rightarrow Frequency)

775 – Out-F-PDP-Conv1-long2 as output of In-F-PDP-word 2 **1371** (Profibus-Not. \rightarrow Frequency)

776 – Out-F-PDP-Conv1-word1 as output of In-F-PDP-long 1 1372 (Frequency \rightarrow Profibus-Not.)

777 – Out-F-PDP-Conv2-word2 as output of In-F-PDP-long 2 **1373** (Frequency \rightarrow Profibus-Not.)



8 Energy saving

Energy can be saved in a drive by reducing the losses in the electric motor or by reducing the energy consumption of the frequency inverter. In addition, the generator energy generated during braking operation can be used instead of converting it to heat.

Energy saving options

The frequency inverter offers the following energy saving options:

- Standby mode of frequency inverter
- Standby mode of operator panel
- Energy saving function: The operating point of the motor is optimized so that the power consumption is kept to a minimum.
- Quadratic V/f characteristic in the case of control of an asynchronous motor
- DC-link connection
- Energy-optimized braking
- PID controller (technology controller): When the reference value is reached, the motor is switched off.
- External DC 24 V power supply. Power supply can be switched off while the system is not in operation.
- Temperature-controlled fans
- Automatic switching frequency changeover
- In the frequency inverter, special energy saving circuitry is integrated

8.1 Energy saving function

The operating point of the motor is optimized so that the power consumption is kept to a minimum and energy saving is maximized. The energy saving function can be switched on if one of the following control methods for parameter *Configuration* **30** is selected:

- "110 IM sensor-less control" (V/f characteristic)
- "410 IM: sensor-less field-orientated control (DMC)"

Via the following parameters, the energy saving function can be set up:

- Operation Mode Energy Saving Function 1550
- Flux Reduction 1551
- Energy Saving Function On 1552

The energy saving function is suitable for:

- partial load operation of a drive
- drives without high or frequent load variations

The energy saving function is not suitable for operation of a synchronous motor. The energy saving parameters cannot be set if "610 - PMSM: sensor-less field-orientated control (DMC)" is selected for parameter *Configuration* **30**.

110 - IM sensor-less control (V/f characteristic)

In the case of the sensor-less control of an asynchronous motor according to the V/f characteristic, the optimum operating point of the motor is adjusted in order to keep power consumption to a minimum.

410 - IM: sensor-less field-orientated control (DMC)

In the case of the field-orientated control of an asynchronous motor, the optimum operating point of the motor is adjusted in order to keep power consumption to a minimum.



1550 Operation Mode Energy Saving Function

Parameter *Operation Mode Energy Saving Function* **1550** defines if the power consumption (magnetic flux) is reduced by an adjustable value or by an automatically determined value. Evaluation must be switched on via parameter *Energy Saving Function On* **1552**.

Operation Mode Energy	Function
Saving Function 1550	
0 - Off	Energy saving function is switched off. Factory setting.
	Energy saving function can be switched on via a digital input or a logic signal.
1 - manual	The digital input or the logic signal can be selected for parameter <i>Energy</i>
1 - Illallual	Saving Function On 1552.
	Energy is saved by reducing the flux. The value of the flux reduction can
	be set via parameter Flux Reduction 1551.
	Energy saving function can be switched on via a digital input or a logic signal.
2 sutomatic	The digital input or the logic signal can be selected for parameter <i>Energy</i>
2 - automatic	Saving Function On 1552.
	Energy is saved by reducing the flux. The value of the flux reduction is determined automatically.

1551 Flux reduction (energy saving function)

In order to save energy, the magnetic flux is reduced by the value of *Flux Reduction* **1551**. One of the following control methods must be selected:

- Configuration 30 = "110 IM sensor-less control" (V/f characteristic)
- Configuration 30= "410 IM: sensor-less field-orientated control (DMC)"

For parameter *Operation Mode Energy Saving Function* **1550**, "1 - manual" must be selected.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
1551	Flux Reduction	0%	100%	0%

High values impair the dynamic behaviour of the drive.



1552 Energy Saving Function On

The signal at a digital input or a logic signal switches on the energy saving function. The digital input or the logic signal must be selected for parameter *Energy Saving Function On* **1552**.

For parameter *Operation Mode Energy Saving Function* **1550**, "1 - manual" or "2 - automatic" must be selected.

Energy Saving Function On 1552	Function
7 - Off	No signal for switch-on of the energy saving function. Factory setting.
71 - IN1D	The signal at digital input IN1D (terminal X11.4) switches on the energy saving function.
72 - IN2D	The signal at digital input IN2D (terminal X11.5) switches on the energy saving function.
73 - IN3D	The signal at digital input IN3D (terminal X11.6) switches on the energy saving function. For <i>Operation Mode Terminal X11.6</i> 558 "0 - Input IN3D must be selected.
74 - IN4D	The signal at digital input IN4D (terminal X12.1) switches on the energy saving function.
75 - IN5D	The signal at digital input IN5D (terminal X12.2) switches on the energy saving function.
76 - MFI1D	The signal at multifunction input 1 (terminal X12.3) switches on the energy saving function. For <i>Operation Mode MFI1</i> 452 "3 - Digital NPN (active: 0 V)" or "4 - Digital PNP (active: 24 V)" must be selected.
77 - MFI2D	The signal at multifunction input 1 (terminal X12.3) switches on the energy saving function. For <i>Operation Mode MFII</i> 562 "3 - Digital NPN (active: 0 V)" or "4 - Digital PNP (active: 24 V)" must be selected.
<u>:</u>	
163 - Reference Frequency reached	The energy saving function is switched on if the frequency is reached.
164 - Setting Frequen- cy	The energy saving function is switched on if the value of <i>Setting Frequency</i> 510 is reached.

8.2 Quadratic V/f characteristic

For applications where the torque increases quadratically to the speed, e.g. control of a fan, the power consumption can be reduced and energy can be saved. In the low speed range where the full torque is not required, energy is saved.

Setting the quadratic V/f characteristic is possible if the following control method is selected for parameter *Configuration* **30**:


606 Type V/f characteristic

Via parameter *Type V/f characteristic* **606**, you can switch the characteristic from linear to quadratic.

Type V/f characteristic 606		Function
	1 - Linear	Linear V/f characteristic: U ~ f. Factory setting. See chapter 7.7 "V/f characteristic".
	2 - Quadratic	Quadratic V/f characteristic: U ~ f ² .

[&]quot;110 - IM sensor-less control" (V/f characteristic)

The quadratic characteristic follows the function: $|U| \sim f^2$.



After switching over to the quadratic characteristic, the characteristic is defined by the following parameters:

- Starting Voltage **600**
- Voltage Rise 601
- Rise Frequency 602
- Cut-Off Voltage **603**
- Cut-Off Frequency 604

The parameters must be adjusted to the application. Additionally, check the settings for *Starting Current* **623** and *Frequency Limit* **624**.

The parameters are described in chapters 7.7 "V/f characteristic" and 7.3.2 "Starting behavior".

The working range is between *Minimum Frequency* **418** and *Maximum Frequency* **419**.

8.3 Standby mode

Standby reduces the power consumption of the frequency inverter. The consumption is reduced and energy is saved.

1510 Time until Keypad Standby

The display of the operator panel is switched off if no button is pressed within the time set in parameter *Time until Keypad Standby* **1510**. Standby mode of the operator panel is indicated by a spot lighting up on the operator panel.

Standby mode is cancelled automatically is a warning or an error is signaled.

Standby mode of the operator panel is switched off if *Time until Keypad Standby* **1510** is set to zero. In this case, the display is switched on permanently.

Parameters		Setting		
No.	Description	Min.	Max.	Fact. sett.
1510	Time until Keypad Standby	0 Min	60 Min	0 Min



If the display of the operator panel is to be switched off as soon as enable of the frequency inverter is switched off – and not after a certain time –parameter Standby Mode **1511** can be set.

1511 Standby Mode (frequency inverter)

The frequency inverter reduces power consumption if

- the standby mode of the frequency inverter is switched on via parameter *Standby Mode* **1511**,
 and
- enable of the frequency inverter via digital inputs STOA and STOB is switched off



Attention!



⚠ WARNING

Do not select the operation modes 11, 21 or 22, if the DC-link connection ("+" and "-" at terminal X11) of the frequency inverter is connected to other devices.



⚠ WARNING

The operation modes to switch off the I/O's (settings 12, 21 or 23) have the following effects:

- The digital inputs are no longer evaluated, the last known values remain internally (i.e. *Digital inputs* **250**).
- The digital outputs are set to zero-potential, internally the values are set to zero (i.e. *Digital outputs* **254**).
- The output X13.4 DC 10Vout is switched to zero-potential.
- The analogue inputs are further evaluated, (i.e. *Analog Input* **251**).
- The analogue outputs are set to zero-potential, internally the values are set to zero (i.e. *Analog Output* **257**).



⚠ WARNING



For the the digital inputs (settings 12, 21 or 23) of the energy saving function "Pull-up" (PNP-Logic) or "Pull-down" (NPN-Logic) resistances are switched on to minimize the internal losses. When the energy saving function is activated, the digital inputs carry up to DC 24 V (PNP-logic) or DC 0 V (NPN-logic).

Bonfiglioli Vectron recommends not to use the settings 12, 21 and 23 for the engery saving function, if:

- The digital input signals are used for Agile devices and third party products at the same time.
- The digital input signals on the wire are connected with Pull-down (PNP-logic) or Pull-up (PNP-logic) resistances to Ground or DC 24 V (in example due to interference resistance).

Standby Mode 1511	Function
0 - Off	The Standby mode of the frequency inverter is switched off. Factory setting.
	The Standby mode is switched on. The following functions are switched off if enable is switched off:
1 - Step1 (=Keypad+fan)	 the display of the operator panel¹
	 the internal fans²
	Standby mode is switched on. The following functions are switched off if enable is switched off:
11 - Step1+Power unit	 the display of the operator panel
·	 the internal fans
	– the power unit

_

¹ This setting is independent of the setting of parameter *Time until Keypad Standby* **1510**.

² The internal fans will continue to run for a sufficiently long time and will be switched off then.



Standby Mode 1511	Function
Standby Mode 1311	Standby mode is switched on. The following functions are switched off if enable is switched off:
	 the display of the operator panel
12 - Step1+I/O	- the internal fans
	 the digital and analog inputs and outputs¹
	 the voltage output DC 10 V at terminal X13.4
	Standby mode is switched on. The following functions are switched off if enable is switched off:
13 - Step1+Communication ²	 the display of the operator panel
·	 the internal fans
	 an optional communication module
	Standby mode is switched on. The following functions are switched off if enable is switched off:
	 the display of the operator panel
21 - Step1+Power Unit+I/O	 the internal fans
,	 the power unit
	 the digital and analog inputs and outputs
	 the voltage output DC 10 V at terminal X13.4
	Standby mode is switched on. The following functions are switched off if enable is switched off:
Step1+ Power Unit +	 the display of the operator panel
22 - Step11 Tower offic 1	 the internal fans
	 the power unit
	 an optional communication module
	Standby mode is switched on. The following functions are switched off if enable is switched off:
	 the display of the operator panel
23 - Step1+I/O + Communica-	 the internal fans
tion	 the digital and analog inputs and outputs
	 the voltage output DC 10 V at terminal X13.4
	 an optional communication module
	Standby mode is switched on. The following functions are switched off if enable is switched off:
	 the display of the operator panel
24 5.11	 the internal fans
31 - Full	 the digital and analog inputs and outputs
	 the voltage output DC 10 V at terminal X13.4
	 an optional communication module
	 the power unit

 $^{^{1}}$ The enable inputs STOA an STOB remain functional. 2 The operation modes for communication module switch-off can be selected only if a communication module is installed.





If a fault is triggered, a deactivated keypad and a deactivated CM-Module (if existent) are switched on again.

Deactivated digital inputs are not switched on again. When the digital signals are in Standby, one of the following procedures can reset a fault:

- Reset the fault via Keypad with the STOP key
- Reset the fault via PLC (via Field bus communication)
- Set STOA and STOB to switch the device again operational and reset the fault in sequence via digital input set up in *Error acknowledgement* **103**.

8.4 Further energy saving options

DC-link connection

By DC-link connection of several frequency inverters, energy can be saved, as the energy recovered when one motor is decelerated can be used for accelerating the other drive. In this case, the acceleration energy does not have to be taken from mains supply.

If the deceleration energy from a motor is not used for accelerating the other motor it will be used for covering the consumption of the coupled frequency inverters.

Energy-optimized braking

The voltage controller can be set up such that the kinetic energy recovered during deceleration operations is not converted to heat in a brake resistor. The brake ramp will be adjusted automatically such that the DC-link voltage does not exceed a certain value. The motor is decelerated in an energy-saving way. The consumption of the frequency inverter is covered by the deceleration energy of the drive, so that no energy is taken from mains supply.

The voltage controller is described in chapter 7.9.2 "Voltage controller".

PID controller (technology controller): saving energy when the reference value is reached The PID controller (technology controller) can switch off the motor when the reference value (PID desired set value) is reached. Saving energy is possible particularly in the case of asynchronous motors, as these motors consume the magnetizing current even when they are at a standstill. The function can be used for filling level controls, for example. The function can be set up via parameter *Backlash* 618.

See chapter 7.9.3 "PID controller (technology controller)".

External DC 24 V power supply

Via an external 24V power supply, the control component of the frequency inverter can be powered independent of mains supply. The frequency inverter can be disconnected from mains supply via contactor, for example. Even with mains supply switched off, parameterization is still possible, the function of inputs and outputs and the communication are maintained.

The power consumption of the inverter during extended interruptions of operation can almost be reduced to zero.

See chapter 5.7.6 "External DC 24 V power supply".

Temperature-controlled fans

The fans are controlled in two stages. This is done for the inside fan and the heat sink fan together. If the inside, capacitor or heat sink temperature set via *Switch-On Temperature* **39** is exceeded, the heat sink fan and the inside fan are switched on at half power. The fans will be switched off again as soon as the temperatures have dropped below the *Switch-On Temperature* **39** by 5 °C again.

If the internally defined maximum inside, DC-link capacitor or heat sink temperature thresholds are reached (5 °C below maximum temperature), the fans are switched to full power. If the temperature drops to 5 °C below the switch-on threshold again, the fans return to the half-power stage.

See chapter 7.10.2 "Fan".

The control of the fans can additionally be set via parameter *Standby Mode* **1511**.

See chapter 8.3 "Standby mode".



Automatic switching frequency changeover

The power losses of semiconductor components depend on the switching frequency and the level of the switched current. In the case of a high current load, e.g. during acceleration of high loads, the switching frequency of the pulse width modulation may be reduced temporarily in order to reduce the losses of the frequency inverter. If the current drops again after the acceleration phase, a higher switching frequency will be set automatically.

See chapter 7.10.1 "Pulse width modulation".

Circuitry measures integrated in Agile

The following energy saving measures were integrated in the frequency inverter and do not require any setup.

- The integrated power supply units supplying the internal assembles are optimized to ensure minimum power losses.
- Low-loss current measurement: The own consumption of the measuring system is optimized to ensure minimum power losses.
- Supply of optional communication modules: If no communication module is connected, energy supply to the module slot is switched off.



9 Actual values

The various control functions and methods include electrical control variables and various calculated actual values of the machine or system. The different actual values can be read out for operational and error diagnosis via a communication interface or in the "Actual" menu of the operator panel.

9.1 Actual values of frequency inverter

	Actual values of frequency inverter			
No.	Description	Function		
222	DC-link voltage	Direct voltage in DC-link.		
223	Modulation	Output voltage of the frequency inverter relative to the mains voltage ($100\% = U_{FIN}$).		
228	Internal Reference Frequency	Total of <i>Reference frequency source 1</i> 475 and <i>Reference frequency source 2</i> 492 .		
229	Reference percentage	Total of <i>Reference percentage source 1</i> 476 and <i>Reference percentage source 2</i> 494 as reference value of the reference percentage channel.		
230	Actual percentage value	Actual value signal at the <i>Actual percentage source</i> 478 .		
243	Digital Inputs (Hardware)	 Status of digital inputs in decimally encoded form: of enable signal (STOA AND STOB) of the six digital inputs of multifunction input 1 in setting <i>Operation mode MFI1</i> 452 "3 - digital NPN (active: 0 V)" or "4 - digital PNP (active: 24 V)". of multifunction input 2 in setting <i>Operation mode MFI2</i> 562 "3 - digital NPN (active: 0 V)" or "4 - digital PNP (active: 24 V)". of digital input/output in setting <i>Operation mode terminal</i> X11.6 558 = "0 - input IN3D". Represents the status of the physical inputs (also refer to actual value <i>Digital inputs</i> 250). 		
244	Working hours counter	Operating hours in which the output stage of the inverter is active.		
245	Operation hours counter	Operating hours of the frequency inverter in which supply voltage is available.		
246	Capacitor temperature	Measured capacitor temperature. Warning or shutdown if temperature is too high.		
249	Active data set	According to <i>Data set change-Over 1</i> 70 and <i>Data set change-Over 2</i> 71 of the data set currently used.		
250	Digital inputs	 Status of digital inputs in decimally encoded form: of enable signal (STOA AND STOB) of the six digital inputs of multifunction input 1 in setting <i>Operation mode MFI1</i> 452 "3 - digital NPN (active: 0 V)" or "4 - digital PNP (active: 24 V)". of multifunction input 2 in setting <i>Operation mode MFI2</i> 562 "3 - digital NPN (active: 0 V)" or "4 - digital PNP (active: 24 V)". of digital input/output (terminal X11.6) in setting <i>Operation mode terminal X11.6</i> 558 = "0 - input IN3D". 		
251	Analog input MFI1A	Input signal at multifunction input 1. Via parameter <i>Operation mode MFI1</i> 452 , multifunction input 1 must be set up as a voltage or current input.		



	Actua	I values of frequency inverter
No.	Description	Function
252	Repetition frequency input	Signal on repetition frequency input according to <i>Operation mode IN2D</i> 496 .
253	Analog input MFI2A	Input signal at multifunction input 2. Via parameter <i>Operation mode MFI2</i> 562 , multifunction input 2 must be set up as a voltage or current input.
254	Digital outputs	Status of digital outputs in decimally encoded form: of digital output OUT1D of multifunction output in setting <i>Operation mode MFO1</i> (X13.6) 550 = "1 - Digital MFO1D" of digital input/output in setting <i>Operation modeterminal</i> X11.6 558 = "1 - output OUT3D". of relay output
255	Heat sink temperature	Measured heat sink temperature. Warning or shutdown if temperature is too high.
256	Inside temperature	Measured inside temperature. Warning or shutdown if temperature is too high.
257	Analog output MFO1A	Output signal at multifunction output 1 in setting <i>Operation</i> mode MFO1 (X13.6) 550 = "10 - Analog (PWM) MFO1A"
258	PWM input	Pulse-width modulated signal at PWM input according to <i>Operation mode IN2D</i> 496 .
259	Actual Error	Error message with error code and abbreviation. See chapter 13.1.1 "Error messages".
269	Warnings	Warning message with warning code and abbreviation. Please note: <i>Warnings</i> 269 is not affected by <i>Create warning mask</i> 536 .
273	Application Warnings	Warning message application with warning code and abbreviation. Please note: <i>Warnings Application</i> 273 is not affected by <i>Create warning mask</i> 626 .
275	Controller Status	The reference value signal is limited by the controller coded in the controller status.
277	STO Status	Signal status of digital inputs A (STOA) and B (STOB) for enable.
278	Frequency MFO1F	Output signal at multifunction output in setting <i>Operation mode</i> $MFO1~(X13.6)~{\bf 550} =$ "20 - repetition frequency (FF) MFO1F" or "30 - Pulse Train (PT) MFO1F".
282	Reference bus frequency	Reference value from serial interface.
283	Reference ramp frequency	Reference value from reference frequency channel.
470	Revolutions	Actual value of position distance of positioning operation.
1530	Service Interval DC-link	The time remaining until next service in percent of maintenance interval. If a value of 0% is displayed, service is required. It must also be checked if a component must be replaced. Refer to chapter 10.3.1 "DC-link".
1531	Service Interval Fan	The time remaining until next service in percent of maintenance interval. If a value of 0% is displayed, service is required. It must also be checked if a component must be replaced. Refer to chapter 10.3.2 "Fan".
1533	Maintenance Note	Service status. Refer to chapter 10.3 "Monitoring of service interval".
1541	Status device test	Service of device test. Refer to chapter 7.2.3 "Device test".



The actual values can be read out and monitored in the "Actual" menu of the operator panel.



9.1.1 STO Status

Parameter *STO Status* **277** can be used for extended diagnosis of the two digital inputs STOA and STOB for enable. The statuses of the inputs are shown in bit-encoded form.

Bit	Value	Meaning
0	1	STOA input missing.
1	2	STOB input missing.
2	4	Switch off STOA input.
3	8	Switch off STOB input.
4	16	Timeout STOA.
5	32	Timeout STOB.
6	64	Diagnosis error.
7	128	Frequency inverter error (fault).

The signal states at digital inputs STOA and STOB can be linked to functions of the frequency inverter.

70 -	Inverter Release	Enable signal of the frequency inverter via digital inputs STOA (X11.3) and STOB (X13.3). The signal is not available if parameter <i>Local/Remote</i> 412 is set to "2 - Control via Remote-Contacts".
270 -	Inverter Release inverted	Operation mode 70 inverted (LOW active).
525 -	Inverter Re- lease(Hardware)	Enable signal of the frequency inverter via digital inputs STOA (X11.3) and STOB (X13.3).
537 -	Inverter Re- lease(Hardware) inverted	Operation mode 525 inverted (LOW active).

9.2 Actual values of machine

The frequency inverter controls the behavior of the machine in the various operating points. Control parameters and actual values of the machine can be displayed.

	Actual values of machine			
No.	Description	Function		
210	Stator Frequency	The output voltage (motor voltage) of the fre-quency inverter.		
211	rms Current	Calculated effective output current (motor current) of the frequency inverter.		
212	Output Voltage	Calculated effective value of linked output voltage (motor voltage) of frequency inverter.		
213	Active Power	Active power calculated from the voltage, the current and the control variables.		
214	Active Current	Active current calculated from the rated motor parameters, the control variables and the current.		
215	Isd	Current component of the field-orientated control forming the magnetic flux.		
216	Isq	Torque-forming current component of field-orientated control.		
221	Slip Frequency	Difference from the synchronous frequency calculated from the rated motor parameters, the control variables and the current.		
224	Torque	Torque at the current output frequency calculated from the voltage, the current and the con-trol variables.		
225	Rotor Flux	Current magnetic flux relative to the rated motor parameters.		
226	Winding Temperature	Measured motor temperature value. Parameter <i>Operation mode motor temp</i> . 570 must be set up for temperature evaluation.		
227	Act. Rotor Time Constant	Calculated value of rotor time constant.		
235	Flux-Forming Voltage	Voltage component of the field-orientated control forming the magnetic flux.		



	Actual values of machine		
No.	Description	Function	
236	Torque-Forming Voltage	Voltage component of the field-orientated control forming the torque.	
238	Absolute Flux Value	Magnetic flux calculated according to the rated values and the operating point of the motor.	
239	Reactive Current	Reactive current calculated from the rated motor parameters, the control variables and the current.	
240	Actual Speed	Measured or calculated speed of drive.	
241	Actual Frequency	Measured or calculated frequency of drive.	



The actual values can be read out and monitored in the "Actual" menu of the operator panel.

9.3 Actual values of the system

The calculation of the actual figures of the system is based on the parameterized system data. Specific to the application, the parameters are calculated from the fac-tors, electrical variables and the controls. The correct display of the actual figures is a function of the parameterized data of the system.

9.3.1 Actual system value

The drive can be monitored via the actual value *Actual system value* **242**. See chapter 7.10.9 "System data".

Actual system value				
No.	Description	Function		
242	Actual System Value	Calculated actual value of drive.		

9.4 Actual value memory

The assessment of the operating behavior and the service of the frequency inverter in the application are facilitated by storing various actual values. The actual value memory guarantees monitoring of the individual variables for a definable period. The parameters of the actual value memory can be read out via a communication interface and displayed via the operator panel. In addition, the operator panel enables monitoring of the peak and mean values in the "Actual" menu branch.

	Actual value memory		
No.	Description	Function	
231	Peak Value Long Term Ixt	Utilization of the device-dependent overload of 60 seconds.	
232	Peak Value Short Term Ixt	Utilization of the device-dependent overload of 1 second.	
287	Peak Value Vdc	The maximum DC link voltage measured.	
288	Average Value Vdc	The mean DC link voltage calculated in the period of observation.	
289	Peak Value Heat Sink Temp.	The highest measured heat sink temperature of the frequency inverter.	
290	Average Value Heat Sink Temp.	The mean heat sink temperature calculated in the period of observation.	
291	Peak Value Inside Temperature	The maximum measured inside temperature in the frequency inverter.	
292	Average Value Inside Temperature	The mean inside temperature calculated in the pe-riod of observation.	
293	Peak Value Iabs.	The highest abs. current calculated from the measured motor phases.	
294	Average Value Iabs	The mean abs. current calculated in the period of observation.	



	Actual value memory		
No.	Description	Function	
295	Peak Value Active Power pos.	Calculated maximum active power in motor operation.	
296	Peak Value Active Power neg.	Calculated maximum active power in generator operation.	
297	Average Value Active Power	The mean active power calculated in the period of observation.	
298	Peak Value Capacitor Temp.	Maximum measured capacitor temperature.	
299	Average Value Capacitor Temp.	The mean capacitor temperature calculated in the period of observation.	
301	Energy, positive	The calculated energy to the motor in motor operation.	
302	Energy, negative	The calculated energy from the motor in generator operation.	



The actual values can be read out and monitored in the "Actual" menu of the operator panel.

237 Reset Memory

Parameter *Reset Memory* **237** in menu "Para" of the operator panel enables resetting of the mean and peak values. The mean value and the peak value are reset to zero.

	Reset Memory 237	Function
	No Reset	Values of actual value memory remain unchanged.
10 -	Peak value long-term Ixt	Reset Peak Value Long Term Ixt 231.
12 -	Peak value short-term Ixt	Reset Peak Value Short Term Ixt 232.
20 -	Peak value Vdc	Reset Peak Value Vdc 287.
21 -	Average Value Vdc	Reset Average Value Vdc 288.
30 -	Peak value Tc	Reset Peak Value Heat Sink Temp. 289.
31 -	Average Value Tc	Reset Average Value Heat Sink Temp. 290.
32 -	Peak value Ti	Reset Peak Value Inside Temperature 291.
33 -	Average Value Ti	Reset Average Value Inside Temperature 292.
34 -	Peak Value Capacitor Temp.	Reset Peak Value Capacitor Temp. 298.
35 -	Average Value Capacitor Temp.	Reset Average Value Capacitor Temp. 299.
40 -	Peak value Iabs.	Reset Peak Value Iabs 293.
41 -	Average value Iabs	Reset Average Value Iabs. 294.
50 -	Peak value Pactive pos.	Reset Peak Value Active Power pos. 295.
52 -	Peak value Pactive neg.	Reset Peak Value Active Power neg. 296.
53 -	Average value Pactive	Reset Average Value Active Power 297.
54 -	Energy, positive	Reset Energy, positive 301 .
56 -	Energy, negative	Reset Energy, negative 302 .
100 -	All peak values	Reset all saved peak values.
101 -	All average values	Reset all saved average values.
102 -	All values	Reset whole actual value memory.



9.5 Actual values of the CAN system bus

Actual values of the system bus			
No.	Description	Function	
978	Node-State	System bus state indication. Refer to system bus instructions.	
979	CAN-State	System bus state indication. Refer to system bus instructions.	

9.6 Actual values CANopen

Actual values CANopen		
No.	Description	Function
1290	Node-State	Status indication of CANopen® communication. Refer to CANopen® instructions.
1291	CAN-State	Status indication of CANopen® communication. Refer to CANopen® instructions.

9.7 Actual values Modbus and VABus

Actual values of frequency inverter			
No.	Description	Function	
11	VABus SST Error Register	Modbus or VABus error register. Refer to VABus instructions.	
282	Reference Bus Frequency	Reference value from serial interface.	
411	Status Word	Modbus or VABus error status word. Refer to Modbus or VABus instructions.	

9.8 Actual values Ethernet

Actual values of frequency inverter			
No.	Description	Function	
1431	Module Info	MAC ID: physical biunique Network address	



10 Service

This chapter contains information for maintaining the device.

10.1 Safety

⚠ WARNING

Any service work must be carried out by qualified staff.

Unauthorized opening and improper interventions can lead to personal injury or material damage. Repairs on the frequency inverters may only be carried out by the manufacturer or persons authorized by the manufacturer.

During any service work, comply with the documentation.

Disconnect the frequency inverter from mains voltage and protect it against being energized unintentionally.

Verify that the frequency inverter is discharged.

When the frequency inverter is disconnected from power supply, the mains, DC-link voltage and motor terminals may still be live for some time. Wait for some minutes until the DC link capacitors have discharged before starting to work at the unit.



Do not touch the terminals because the capacitors may still be charged.

If voltage supply is switched on, no covers of the frequency inverter may be removed.

After service, all covers must be installed and the terminals must be checked.

The frequency inverter complies with protection class IP20 only if the covers are mounted properly.

Avoid soiling during service work.

After service, make sure that no foreign particles (e.g. chips, dust, wires, screws, tools) are inside the frequency inverter.

Do not touch electronic components or contacts. The frequency inverter is equipped with components which are sensitive to electrostatic energy and can be damaged if handled improperly.

Only use original spare parts.

10.2 Regular service work

Cleaning instructions

- Use dry, oil-free air to remove dust.
- Use appropriate air pressure for cleaning.
- Do not use solvents for cleaning circuit boards.
- Use antistatic materials for cleaning in order to avoid electrostatic charging.



BONFIGLIOLI recommends regular maintenance of the frequency inverter. Service periods depend on the field of application and the ambient conditions.

Test/inspection object	Test/inspection and measure
Case and heat sink	Remove any soiling and dust.Check screws for tight fit, tighten if necessary.
	 Check component for damage and replace, if necessary.
Fan	Remove any soiling and dust.Check for unusual operating noise.
Door filter in electrical cabinet	Clean or replace.
Environment	Check if ambient conditions meet specifications. See chapter 11.2 "Device data". "The specification of the sp
Cooling	 Check if frequency inverter or motor emits excessive heat or if components change their color. In this cases: Check for overload.
	Check heat sink and motor for soiling.Check ambient temperature.
Electrical cables	 Check cable connections for safe connection. Check cables for damage, color changes and heat impact.
	Check cable insulation and shields for wear and tear.Replace damaged cables.
Brake resistor	Check for color changes and heat impact. Check connection.

Test run after service

Check the frequency inverter in a test run (if possible).

Test/inspection	Measure
Error list and error environment	Display error via operator panel or PC software VPlus. Eliminate cause of error and acknowledge error. See chapter 13.1 "Error list".
Power supply	Measure mains voltage. Note rated values on the rating plate of the frequency inverter. Measure voltage of external DC 24 V supply (if installed). Specification: See chapter 5.7.6 "External DC 24 V power supply".
Output current	Measure output current. Check the drive system and the load behavior if the output current is greater than the nominal value of the frequency in- verter over extended periods.
Vibration or unusual noise of motor	Check the coupled load. Fix loose components.



10.3 Monitoring of service interval

During operation of electric drives, mechanical and electrical components are exposed to wear and tear

The service interval remaining until the next service (percentage of maintenance interval) of the following components can be monitored:

- DC-link of frequency inverter
- Fan of frequency inverter

1533 Maintenance Note

When the service interval until service has expired (value 0%), the frequency inverter can indicate

- via parameter Maintenance Note 1533 that maintenance is required or
- output a warning message

The behavior can be set up.

The service interval remaining until service can be displayed via parameters. Service is required as soon as the remaining service interval until maintenance has expired (value 0%). It must also be checked if the component must be replaced.

10.3.1 DC-link

Signalling when service is required

The DC-link of the frequency inverter is equipped with electrolyte capacitors. The service interval for electrolyte capacitors is mainly defined by the temperature. In high temperatures the electrolytic liquid will evaporate, which reduces the capacitance of the capacitor. The temperature inside the electrolyte capacitor depends on two factors: the ambient temperature and the internal heating caused by current ripple. The temperature of the electrolyte capacitors is measured by a sensor, so that high ambient temperatures are taken into account for service interval calculation.

1534 Operation Mode Service Interval DC-link

Via parameter *Operation Mode Service Interval DC-link* **1534**, you can set how the warning is to occur when the remaining service interval until service has expired. The information can be indicated in a parameter or a service message can be output.

Operation Mode Service Interval DC-link 1534	Function					
0 - No Action	The service interval remaining until service is monitored. The remaining service interval (in percent) can be indicated via parameter <i>Service Interval DC-link</i> 1530 . No service info or message is output.					
1 - Service Parameter Message	The service interval remaining until service is monitored. The remaining service interval (in percent) can be indicated via parameter <i>Service Interval DC-link</i> 1530 . As soon as the remaining time until service has expired, parameter <i>Maintenance Note</i> 1533 will show the message "M0001 Service DC-Link". Factory setting.					
	The service interval remaining until service is monitored. The remaining service interval (in percent) can be indicated via parameter <i>Service Interval DC-link</i> 1530 . As soon as the time remaining until service has expired:					
2 - Alarm Message	 Parameter Maintenance Note 1533 will show the message "M0001 Service DC-Link". 					
	 A warning message will be output and a warning signal will be set. The warning will also be displayed on the operator panel. 					

Parameter *Maintenance Note* **1533** displays message "M0000" if the remaining service interval until service of the DC-link has not elapsed and no service is required.



Warning signal

Expiry of the time remaining until service is signaled.

264 -		For linking to frequency inverter functions.
	Warning service	For output via a digital output. Select the signal source for one of the
50 -	DC-link	parameters 531, 532, 533, or 554.
		See chapter 7.6.5 "Digital outputs".

Operation Mode Service Interval DC-link 1534 must be set to "2 - Warning".

Time remaining until next service

1530 Service Interval DC-link

Parameter *Service Interval DC-link* **1530** indicates the service interval remaining until next service in percent. If a value of 0% is displayed, service is recommended. It should also be checked if the component must be replaced.



High ambient temperature and frequency inverter is not in operation:

Even with the frequency inverter switched off, the electrolyte capacitors may age due to high ambient temperatures. The times at which the frequency inverter is switched off are not considered in the calculation of the time remaining until next service. As a result, the indicated service interval until next service may be too long.

The remaining service interval until service is an estimated value.

The remaining service interval until service (parameter *Service Interval DC-link* **1530**) can be set to 100% if setting "1 - DC-link" is selected for parameter *Reset Service Intervals* **1539**.

10.3.2 Fan

Signalling when service is required

The service interval remaining until service of the fan largely depends on the wear and tear of the bearing components. For this reason, the service interval remaining until service depends on the speed and operating time of the fan. The service interval remaining until service is calculated from these two values.

1535 Operation Mode Service Interval Fan

Via parameter *Operation Mode Service Interval Fan* **1535**, you can set how the warning is to occur when the remaining service interval until service has expired. The information can be indicated in a parameter or a service message can be output.



Operation Mode Service In- terval Fan 1535	Function
0 - No Action	The service interval remaining until service is monitored. The remaining service interval until service can be indicated via parameter <i>Service Interval Fan</i> 1531 . No service info or message is output.
1 - Service Parameter Message	The service interval remaining until service is monitored. The remaining service interval until service can be indicated via parameter <i>Service Interval Fan</i> 1531 . As soon as the remaining time until service has expired, parameter <i>Maintenance Note</i> 1533 will show the message "M0002 Service fan". Factory setting.
	The service interval remaining until service is monitored. The remaining service interval until service can be indicated via parameter <i>Service Interval Fan</i> 1531 . As soon as the time remaining until service has expired:
2 - Alarm Message	 Parameter Maintenance Note 1533 will show the message "M0002 Service fan".
	 A warning message will be output and a warning signal will be set. The warning will also be displayed on the operator panel.

Parameter *Maintenance Note* **1533** displays message "M0000" if the remaining time until service of the fan has not elapsed and no service is required.

Warning signal

Expiry of the time remaining until service is signaled.

265 -		For linking to frequency inverter functions.
	Warning service	For output via a digital output. Select the signal source for one of the
51 -	fan	parameters 531, 532, 533, or 554.
		See chapter 7.6.5 "Digital outputs".

Operation mode service interval fan 1534 must be set to "2 - Warning".

Service interval remaining until next service

1531 Service Interval Fan

Parameter *Service Interval Fan* **1531** indicates the service interval remaining until next service in percent of maintenance interval. If a value of 0% is displayed, service is required. It should also be checked if the component must be replaced.



The service interval remaining until service is an estimated value. The service interval actually remaining until next service also depends on the ambient conditions, for example. As a result, the indicated service interval until next service may be too high. Service the fan regularly. See chapter 10.2 "Regular service work".

The service interval remaining until service (parameter *Service Interval Fan* **1531**) can be set to 100% if setting "2 - fan" is selected for parameter *Reset Service Intervals* **1539**.



10.3.3 Reset service interval

1539 Reset Service Intervals

The remaining service interval until service (in percent) can be reset to the initial value via parameter *Reset Service Intervals* **1539**.

Reset Service Intervals 1539	Function
0 - No Action	No service interval remaining until service is reset.
1 - Reset Service Interval DC-Link	The service interval remaining until service of the DC-link is reset. Parameter <i>Service Interval DC-link</i> 1530 indicates 100% again.
2 - Reset Service Interval Fan	The service interval remaining until service of the fan is reset. Parameter <i>Service Interval Fan</i> 1531 indicates 100% again.



11 Technical data

This chapter contains the technical data of the Agile series.

General technical data 11.1

CE conformity The frequency inverters Agile meet the requirements of the low voltage directive

2006/95/EEC and EN 61800-5-1.

For compliance with standard 2004/108/EC, comply with installation instructions **EMC** directive

in this document.

Interference im-

munity

The frequency inverters *Agile* meet the requirements of EN 61800-3 for use in

industrial environments.

UL Approval Devices that are marked with the UL proof label fulfill the requirements according

to UL508c.

Ambient tempera-

Operation: 0...55 °C; as from 40 °C power reduction should be considered. ture

Environmental class Operation: 3K3 (EN60721-3-3),

maximum relative humidity 85%, no water condensation.

Degree of protec-

IP20 if covers and connection terminals are used properly.

tion

Altitude of installa- Up to 1000 m at rated specifications. Up to 3000 m at reduced power.

Storage according to EN 50178. Storage

BONFIGLIOLI recommends that the unit be connected to mains voltage for 60

minutes after one year, at the latest.

Overload capacity

 (o_c)

tion

Continuous operation 100% I_N

Up to 150% I_N for 60 s Up to 200% I_N for 1 s

Overload capacity can be used every 10 minutes.

Functions

- Control methods adjusted to motors and application (configuration)
- Adjustable speed/torque control
- Various protection functions for motor and frequency inverter
- Positioning relative to a reference point
- Flying Start function
- S-ramps for jerk limitation during acceleration and deceleration
- PID controller (technology controller)
- Parameterizable Master-Slave operation via system bus
- Error memory
- Simplified and extended control via PC (commissioning, parameterization, data set backup, diagnosis with Scope)
- Energy saving function
- Automatic service messages
- Self-learning controllers
- Communication: System bus, CANopen®, Modbus and VABus. Profibus with optional communication module.

Parameterization

- Freely programmable digital inputs and outputs
- PLC functions, can be realized via table functions or a graphical PC user interface
- Four separate data sets incl. motor parameter
- Pre-defined motor data BONFIGLIOLI motors



11.2 Device data

This chapter contains the Technical data of the different sizes of the Agile series.

General are valid for AGL202 and AGL402 devices are the following characteristics:

Output motor side							
Output voltage	J	V	Maximum value of input voltage, three-phase				
Protection	-	-	Short circuit proof and earth fault proof				
Rotary field frequency	f	Hz	0 1000, depending on switching frequency				
Integrated brake chopper	-	-	yes				
Input mains side							
Mains configuration	ı	-	TT, TN, IT				
Mains voltage range	U	٧	AGL202: 230 (-20 %) 240 (+10 %) AGL402: 380 (-15%) 480 (+10%)				
Mains frequency	f	Hz	45 69				
Overvoltage category	-	-	EN 50178 III, EN 61800-5-1 III				
Ambient conditions							
Cooling agent temperature (air)	т	0.0	0 40 (EN 60721-3-3),				
Cooling agent temperature (air)	T _n	°C	40 55 with power reduction (derating)				
Storage temperature	T_L	°C	-25 55				
Transport temperature	T_T	°C	-25 70				
Relative air humidity	-	%	Operation: maximum 85 non-condensing				
Relative all Hullilalty			Storage: 5 95				



AGL202 devices in the sizes 1 to 3 can be operated either with single phase or three phase connection. In single pase operation a lower power compared to three phase operation is available. The type codes correlate to the three phase power.



AGL202 (3~:0.18 to 0.55 kW, 1~:0.09 to 0.25 kW, 230 V) 11.2.1

Type	Туре										
						23	0 V				
Agile 202			-()1	_	02	-(03	-()5	
Size							1				
Output motor side											
Selected Mains supply			1ph	3ph	1ph	3ph	1ph	3ph	1ph	3ph	
Recommended	Р	kW	0.09	0.18	0.12	0.25	0.18	0.37	0.25	0.55	
motor shaft power	Р	KVV	0.09	0.10	0.12	0.25	0.10	0.57	0.25	0.55	
Output current	I	Α	0.8	1.3	1.0	1.5	1.3	2.0	1.5	3.0	
Long-term	I	Α	1.2	2	1.5	2.25	1.95	3.0	2.25	4.5	
overload current (60 s)	1	Α	1.2		1.5	2.23	1.93	3.0	2.23	т.Э	
Short-time	I	Α	1.6	2.6	2.0	3	2.6	4.0	3.0	6.0	
overload current (1 s)			1.0	2.0	2.0			7.0	5.0	0.0	
Switching frequency	f	kHz				2, 4,	8, 16				
Output, brake resistor		ı							,		
Minimum brake resistor	R	Ω	100	100	100	100	100	100	100	100	
Recommended brake resistor	R	Ω	300	220	250	200	220	140	200	100	
(385 V)			300	220	230	200		1.0	200	100	
Input mains side	T	T								1	
Rated current	I	Α	1.7	1.2	1.9	1.4	2.5	2.0	3.0	2.5	
Maximum mains current 1)	I	Α	2.5	2.2	2.9	2.5	3.6	3.3	4.2	4.0	
Fuses	I	Α	6	6	6	6	6	6	6	6	
Fuses UL type	I	Α			Buss	smann F	WP-10/	\14Fa			
Mechanics		ı									
Dimensions ²⁾	HxWxD						50 x 170)			
Weight (approx.)	m	kg					.1				
Degree of protection	-	-				IP20 (E					
				and mo	tor	0.2 4		le with :	sleeve)		
Terminals	Α	mm ²	termina			0.2 6	(rigid)				
	'`		1 CI IIIII I	als rela	y out-	0.1 1	.5				
			put:								
Installation	-	-					tical				
Interior fan	-	-	no								
Heat sink fan	-	-	no								
Ambient conditions											
Power dissipation (2 kHz	Р	W	12	12	19	19	29	29	42	42	
switching frequency)	<u> </u>			-							

According to DIN EN 61800-5-1.
 Dimensions of the basic device. Comply with the notes of the assembly variants in chapter 4.2 "Installation" for the standard assembly and chapter 12.9 "Assembly variants".



11.2.2 AGL202 (3~:0.75 to 2.2 kW, 1~:0.37 to 1.1 kW, 230 V)

Type	Гуре									
				230 V						
Agile 202			-()7	-	09	-	11	-:	13
Size				1						
Output motor side	•									
Selected Mains supply			1ph	3ph	1ph	3ph	1ph	3ph	1ph	3ph
Recommended	Р	kW	0.37	0.75	0.55	1.1	0.75	1.5	1.1	2.2
motor shaft power	Р	KVV	0.57	0.75	0.55	1.1	0.75	1.5	1.1	2.2
Output current	I	Α	2.0	3.5	3.0	5.0	3.5	6.0	5.0	9.0
Long-term	I	Α	3.0	5.25	4.5	7.5	5.25	9.0	7.5	13.5
overload current (60 s)	1	Α	3.0	3.23	٦.٥	7.5	3.23	9.0	7.5	13.3
Short-time	I	Α	4.0	7.0	6.0	10	7.0	12.0	10.0	18.0
overload current (1 s)			7.0	7.0	0.0			12.0	10.0	10.0
Switching frequency	f	kHz				2, 4,	8, 16			
Output, brake resistor		ı								
Minimum brake resistor	R	Ω	100	100	100	100	37	37	37	37
Recommended brake resistor	R	Ω	100	100	100	100	92	63	70	41
(385 V)		35	100	100	100	100	J2	05	/0	11
Input mains side		T								
Rated current	I	Α	4.2	3.4	5.3	4.9	7.6	6.5	11.2	9.5
Maximum mains current 1)	I	Α	5.5	5.1	6.9	6.7	11.4	10.8	15.5	14.5
Fuses	I	Α	6	6	6	6	10	10	16	16
Fuses UL type	I	Α			Buss	smann F	WP-10/	\14Fa		
Mechanics		ı								
Dimensions ²⁾	HxWxD						50 x 170)		
Weight (approx.)	m	kg					.1			
Degree of protection	-	-				IP20 (E				
				and mo	tor	0.2 4		le with s	sleeve)	
Terminals	Α	mm ²	termina			0.2 6	(rigid)			
Terrinals			1 CITIIII	als rela	y out-	0.1 1	.5			
			put:							
Installation	-	-					tical			
Interior fan	-	-	no							
Heat sink fan		-	yes							
Ambient conditions		ı								
Power dissipation (2 kHz	Р	w	53	53	70	70	89	89	122	122
switching frequency)					, 0	, ,				

¹⁾ According to DIN EN 61800-5-1.

²⁾ Dimensions of the basic device. Comply with the notes of the assembly variants in chapter 4.2 "Installation" for the standard assembly and chapter 12.9 "Assembly variants".



11.2.3 AGL202 (3~:3.0 to 4.0 kW, 1~:1.5 to 2.2 kW, 230 V)

Туре										
			230 V							
Agile 202			-:	15		-:	18			
Size				2						
Output motor side										
Selected Mains supply			1ph	(1)	3ph	1ph	3ph			
Recommended	Р	kW	1.5		3.0	2.2	4.0			
motor shaft power	Г	KVV				2.2	4.0			
Output current	I	Α	6.0	1	2.0	9.0	15.0			
Long-term	I	Α	9.0	1	8.0	13.5	22.5			
overload current (60 s)	1	^	J.0		0.0	15.5	22.5			
Short-time	I	Α	12.0	2	4.0	18.0	30.0			
overload current (1 s)			12.0				30.0			
Switching frequency	f	kHz			2, 4,	8, 16				
Output, brake resistor		T				Т				
Minimum brake resistor	R	Ω	18.5	1	8.5	18.5	18.5			
Recommended brake resistor	R	Ω	72		37	41	27			
(385 V)	- ' '		,,,			11				
Input mains side	1	ı				ı				
Rated current	I	Α	14.2		2.5	19.5	17.0			
Maximum mains current 1)	I	Α	20.6		8.5	28.0	25.5			
Fuses	I	Α	16		16	25	25			
Fuses UL type	I	Α		Buss	smann F	WP-20A14Fa				
Mechanics		T								
Dimensions ²⁾	HxWxD					30 x 196				
Weight (approx.)	m	kg				.5				
Degree of protection	-	-				N60529)				
			Mains and mo	tor		(flexible with	sleeve)			
Terminals	Α	mm ²	terminals:		0.2 6	. 6 (rigid)				
	'`		Terriniais reia	y out-	0.1 1).1 1.5				
			put:							
Installation	-	-				tical				
Interior fan	-	-	yes							
Heat sink fan	-	-	yes							
Ambient conditions						I				
Power dissipation (2 kHz	Р	W	133	1	L33	167	167			
switching frequency)		••	155 155 107 1							

According to DIN EN 61800-5-1.
 Dimensions of the basic device. Comply with the notes of the assembly variants in chapter 4.2 "Installation" for the standard assembly and chapter 12.9 "Assembly variants".



AGL202 (3~:5.5 to 7.5 kW, 1~:3.0 kW, 230 V) 11.2.4

Тур									
			230 V						
Agile 202			-19 -21						
Size				3					
Output motor side									
Selected Mains supply		1ph	3	3ph	1ph	3ph			
Recommended motor shaft power	Р	kW	3.0	Ţ	5.5	3.0	7.5		
Output current	I	Α	12.0	2	1.0	12.0	26.0		
Long-term overload current (60 s)	I	A	18.0		1.5	18.0	39.0		
Short-time overload current (1 s)	I	Α	24.0	4	2.0	24.0	44.0		
Switching frequency	f	kHz			2, 4,	8, 16			
Output, brake resistor									
Minimum brake resistor	R	Ω	18.5	1	8.5	18.5	18.5		
Recommended brake resistor (385 V)	R	Ω	32 1		19	32	18.5		
Input mains side									
Rated current	I	Α	26.7		2.5	26.7	30.0		
Maximum mains current 1)	I	Α	40.0		3.0	40.0	41.5		
Fuses	I	Α	35		35	35	35		
Fuses UL type	I	Α		Buss	smann F	WP-30A14Fa			
Mechanics									
Dimensions ²⁾	HxWxD	mm				25 x 205			
Weight (approx.)	m	kg				3			
Degree of protection	-	-				N60529)			
Terminals	A	mm ²	Mains and mo terminals:		0.2 6	f (flexible with s (rigid)	sleeve)		
Terrinidis			Terminals relay output: 0.1 1.5						
Installation	-	-			ver	tical			
Interior fan	-	-			У	es			
Heat sink fan	-	-			У	es			
Ambient conditions									
Power dissipation (2 kHz switching frequency)	Р	W	235	2	235	235	321		

According to DIN EN 61800-5-1.
 Dimensions of the basic device. Comply with the notes of the assembly variants in chapter 4.2 "Installation" for the standard assembly and chapter 12.9 "Assembly variants".



AGL402 (0.25 to 2.2 kW) 11.2.5

Type									
			400 V, 3-phase						
Agile 402			-02	-03	-05	-07	-09	-11	-13
Size						1			
Output motor side									
Recommended motor shaft power	Р	kW	0.25	0.37	0.55	0.75	1.1	1.5	2.2
Output current	I	Α	0.8	1.2	1.5	2.1	3.0	4.0	5.5
Long-term overload current (60 s)	I	Α	1.2	1.8	2.25	3.15	4.5	6.0	8.2
Short-time overload current (1 s)	I	Α	1.6	2.4	3.0	4.2	6.0	8.0	11.0
Switching frequency	f	kHz			2	, 4, 8, 1	16		
Output, brake resistor									
Minimum brake resistor	R	Ω	300	300	300	300	300	220	220
Recommended brake resistor	R	Ω	2432	1594	930	634	462	300	220
(770 V)	IX	75	2732	1337	930	054	702	300	220
Input mains side									
Rated current	I	Α	0.8	1.2	1.8	2.4	2.8	3.3	5.8
Maximum mains current 1)	I	Α	1.1	1.5	2.0	2.7	3.9	5.2	7.3
Fuses	I	Α	6	6	6	6	6	6	10
Fuses UL type	I	Α	Bussmann FWP-10A14Fa						
Mechanics									
Dimensions ²⁾ HxWxD m					200	x 60 x	170		
Weight (approx.)	m	kg				1.1			
Degree of protection	-	-			IP20	(EN60			
			Mains a	and mot	or ter-		. 4 (flexible with sleeve)		
Terminals	Α	mm ²					6 (rigid)		
Terrinidis			n 1 1 5						
7			put:						
Installation	-	-	vertical						
Interior fan	-	-	no						
Heat sink fan				no Yes					
Ambient conditions									
Power dissipation (2 kHz switch-	Р	W	19	29	42	53	70	89	122
ing frequency)									

According to DIN EN 61800-5-1.
 Dimensions of the basic device. Comply with the notes of the assembly variants in chapter 4.2 "Installation" for the standard assembly and chapter 12.9 "Assembly variants".



11.2.6 AGL402 (3.0 to 11.0 kW)

Туре									
						400 V	, 3-phase		
Agile 402			-15	-18	-19	-19	-21	-22	-23
Size				2				3	
Output motor side									
Recommended motor shaft power	Р	kW	3,0	4,0	5,5	5,5	7,5	9,2	11,0
Output current	I	Α	7,5	9,5	12,0	13,0	17,0	20,0	23,0
Long-term overload current (60 s)	I	Α	11,2	14,2	18,0	19,5	25,5	30,0	34,5
Short-time overload current (1 s)	I	Α	15,0	19,0	24,0	26,0	34,0	40,0	43,0
Switching frequency	f	kHz				2, 4	, 8, 16		
Output, brake resistor									
Minimum brake resistor	R	Ω	106	106	106	48	48	48	48
Recommended brake resistor	R	Ω	148	106	106	80	58	48	48
(770 V)	K	22	140	100	100	60	36	40	40
Input mains side									
Rated current	I	Α	6,8		13,8	14,2	15,8	20,0	26,0
Maximum mains current 1)	I	Α	9,8	12,8	17,2	17,2	23,0	28,1	33,6
Fuses	I	Α	10	10	16	16	25	25	35
Fuses UL type	I	I A Bussmann FWP-20A14Fa		Bussmann FWP-30A14Fa					
Mechanics									
Dimensions ²⁾	HxWxD	mm	200	x 80 x	< 196		200 x 1	25 x 205	
Weight (approx.)	m	kg		1,5				3	
Degree of protection	ı	ı				IP20 (EN60529)		
			Mains	and	motor	ter- 0	.2 4 (fle	exible wit	n sleeve)
Terminals	Α	mm ²	minals: 0.2 6 (rigid)						
Terrinas	^	''''	Terminals relay output: 0.1 1.5						
Installation	-	-	<u> </u>						
Interior fan	-	-							
Heat sink fan	-	-	- yes						
Ambient conditions									
Power dissipation (2 kHz switching frequency)	Р	W	133	167	230	235	321	393	470

¹⁾ According to DIN EN 61800-5-1.

²⁾ Dimensions of the basic device. Comply with the notes of the assembly variants in chapter 4.2 "Installation" for the standard assembly and chapter 12.9 "Assembly variants".



11.2.7 Increase of switching frequency

Increasing the switching frequency is permissible if the output current is reduced. Comply with the applicable standards and regulations for this operating point. The specified output currents are the maximum values for continuous operation.

230 V devices:

	Output current										
Fre	quency inv	erter/	S	witching 1phase C	frequency Operation	/ .	Switching frequency. 3phase Operation				
Туре		l Power W]	2 kHz	4 kHz	8 kHz	16 kHz	2 kHz	4 kHz	8 kHz	16 kHz	
	1phase	3phase									
-01 1	0.09	0.18	0.8 A	0.8 A	0.8 A	0.5 A	1.3	1.3	1.3	0.9A	
-02 1	0.12	0.25	1.0 A	1.0 A	1.0 A	0.7 A	1.5	1.5	1.5	1.0 A	
-03 1	0.18	0.37	1.3 A	1.3 A	1.3 A	0.9 A	2.0	2.0	2.0	1.3 A	
-05 1	0.25	0.55	1.5 A	1.5 A	1.5 A	1.0 A	3.0	3.0	3.0	2.0 A	
-07 1	0.37	0.75	2.0 A	2.0 A	2.0 A	1.3 A	3.5	3.5	3.5	2.3 A	
-09 1	0.55	1.1	3.0 A	3.0 A	3.0 A	2.0 A	5.0	5.0	5.0	3.3 A	
-11 1	0.75	1.5	3.5 A	3.5 A	3.5 A	2.3 A	6.0	6.0	6.0	4.0 A	
-13 1	1.1	2.2	5.0 A	5.0 A	5.0 A	3.3 A	9.0	9.0	9.0	6.0 A	
-15 2	1.5	3.0	6.0 A	6.0 A	6.0 A	4.0 A	12.0	12.0	12.0	8.0 A	
-18 2	2.2	4.0	9.0 A	9.0 A	9.0 A	6.0 A	15.0	15.0	15.0	10.0 A	
-19 3	3.0	5.5	12.0 A	12.0 A	12.0 A	8.0 A	21.0	21.0	21.0	14.0 A	
-21 3	3.0	7.5	12.0 A	12.0 A	12.0 A	8.0 A	26.0	26.0	26.0	17.3 A	

400 V devices:

	Output current								
Fr	equency inverter	Switching frequency							
Type	Туре	2 kHz	4 kHz	8 kHz	16 kHz				
-02 1	0.25	0.8 A	0.8 A	0.8 A	0.5 A				
-03 1	0.37	1.2 A	1.2 A	1.2 A	0.8 A				
-05 1	0.55	1.5 A	1.5 A	1.5 A	1.0 A				
-07 1	0.75	2.1 A	2.1 A	2.1 A	1.4 A				
-09 1	1.1	3.0 A	3.0 A	3.0 A ¹⁾	2.0 A ¹⁾				
-11 1	1.5	4.0 A	4.0 A	4.0 A	2.7 A				
-13 1	2.2	5.5 A	5.5 A	5.5 A ¹⁾	3.7 A ¹⁾				
-15 2	3.0	7.5 A	7.5 A	7.5 A	5.0 A				
-18 2	4.0	9.5 A	9.5 A	9.5 A ¹⁾	6.3 A ¹⁾				
-19 2	5.5	12.0 A	12.0 A	12.0 A ¹⁾	8.0 A ¹⁾				
-19 3	5.5	13.0 A	13.0 A	13.0 A	8.7 A				
-21 3	7.5	17.0 A	17.0 A	17.0 A	11.4 A				
-22 3	9.2	20.0 A	20.0 A	20.0 A	13.4 A				
-23 3	11.0	23.0 A	23.0 A	23.0 A ¹⁾	15.4 A ¹⁾				

¹⁾ Reduction of switching frequency in thermal limit range.



11.3 **Control electronics**

Voltage output DC 24 V								
Terminals	X11.1 (DC +24 V), X11.2 (DC 0 V)							
Maximum output current	DC 100 mA							
Voltage output DC 10 V								
Terminal	X13.4							
Maximum output current	DC 8.2 mA							
Minimum output current	DC 2.3 mA ¹							
Voltage input DC 24 V								
Terminal	X13.1 (DC 24 V), X13.2 (DC 0 V)							
Input for external power supply. ²								
Input voltage range	DC 24 V ±10%							
Rated input current	Max. DC 1.0 A (typically DC 0.45 A)							
Input peak current	Typically < DC 15 A (max. 100 μs)							
External fuse	Standard fuse elements for rated current, characteristic: slow							
Safety	Safety extra low voltage SELV according to EN 61800-5-1							
Digital inputs								
Terminals	X11.4, X11.5, X12.1, X12.2							
Cianal laval	PNP High: DC 15 24 30 V Low: DC 05 V							
Signal level	NPN High: DC 05 V Low: DC 15 24 30 V							
Maximum input voltage	DC 30 V (DC 6 mA at DC 24 V)							
Input resistance	3.9 kΩ							
Response time	2 ms							
Other properties	PLC compatible							
Digital inputs for enable and s								
Terminals	X11.3, X13.3							
Signal level	Low: DC 0 3 V							
	High: DC 15 30 V							
Maximum input voltage	DC 30 V (DC 10 mA at DC 24 V)							
Input resistance	1.8 kΩ							
Response time	Enable is activated 10 ms after triggering.							
Digital output								
Terminal	X13.5							
Output voltage	DC 22 V (DC 15 28 V)							
Maximum output current	DC 100 mA ³							
Other properties	Overload and short-circuit proof, overvoltage-protected							

06/2013

 $^{^{1}}$ Depending on value at 24 VDC voltage input. 2 Connect ground (GND) of external power supply to terminal X13.2 (GND). 3 The value is reduced if additional control outputs are used.



Digital input/output								
Terminal	X11.6							
Digital Input								
-	PNP High: DC 15 24 30 V Low: DC 05 V							
Signal level	NPN High: DC 05 V Low: DC 15 24 30 V							
Maximum input voltage	DC 30 V (DC 6 mA at 24 V)							
Input resistance	3.9 kΩ							
Response time	2 ms							
Other properties	PLC compatible							
Digital output								
Output voltage	DC 24 V (DC 15 30 V**)							
Maximum output current	DC 100 mA*							
Other properties	Overload and short-circuit proof, overvoltage-protected							
Multifunction inputs (digital/a	analog input)							
Terminal	X12.3, X12.4							
Digital Input								
	PNP High: DC 152430 V Low: DC 05							
Cignal lovel	(digital) V (digital)							
Signal level	NPN High: DC 05 V Low: DC 152430 V							
	(digital) (digital)							
Maximum input voltage	DC 30 V (DC 6 mA at DC 24 V)							
Input resistance	3.9 kΩ							
Response time	2 ms							
Other properties	PLC compatible							
Voltage input (analog)								
Input voltage	DC 0 10 V							
Input resistance	78 kΩ							
Resolution	10 Bit							
Current input (analog)								
Input current	DC 0 20 mA							
Input resistance	250 Ω							
Resolution	9 Bit							
Multifunction output (digital/	analog/frequency/pulse train output)							
Terminal	X13.6							
Digital output								
Output voltage	DC 24 V (DC 15 30 V**)							
Maximum output current	DC 100 mA							
Other properties	Overload and short-circuit proof, overvoltage-protected							
Analog output (PWM)	· · · • • · · · · · · · · · · · · · · ·							
Output voltage	DC 24 V (DC 15 30 V**)							
Maximum output current	DC 100 mA*							
Other properties	Pulse-width modulated signal f _{PWM} = 126 Hz							
Frequency output								
Output voltage	DC 24 V (15 30 V**)							
Maximum output current	DC 100 mA							
Maximum output frequency	150 kHz							
Other properties								
Pulse train output								
Output voltage	DC 24 V							
Maximum output current	DC 100 mA*							
Maximum output frequency	150 kHz							

- * The maximum output current of an output of 100 mA is reduced if additional control outputs are used.
- ** Dependent on the voltage supply of the control unit and the connected load on the different outputs. Maximum guaranteed value: 15 VDC.



Relay output (floating changeover contact)					
Terminal	X10				
Contact load capacity	make	AC 240 V/5 A, DC 24 V/5 A (ohmic)			
	contact:	AC 240 V/3 A, DC 24 V/3 A (Offilia)			
	break	AC 240 V/3 A, DC 24 V/1 A (ohmic)			
	contact:	AC 240 V/3 A, DC 24 V/1 A (OIIIIIC)			
Response time	40 ms				

11.4 Operation diagrams

Installation height


The nominal values of the frequency inverter apply to installation altitudes up to 1000 meters above sea level¹. If the installation altitude exceeds 1000 meters, the output power and cooling agent temperature (ambient temperature) must be reduced.

Reduction of output current

Power reduction (derating).

Above 1000 m: Reduction by 5%/1000 m.


Maximum altitude 3000 m.



Reduction of output current I depending on installation altitude H.

Reduction of cooling agent temperature

Above 1000 m: Reduction by 3.3°C/1000 m. Maximum cooling agent temperature 55 °C.



Reduction of cooling agent temperature T depending on installation altitude H.

¹ NN: sea level




Temperature

The nominal values of the frequency inverter apply to a cooling agent temperature between 0 and 40 °C (ambient temperature).

Reduction of output current


Power reduction (derating). Above 40 °C: Reduction by 2.5%/K; $T_{max} = 55$ °C



Reduction of output current I depending on cooling agent temperature T.

Mains voltage

Reduction of output current (Derating) at constant output power Above 400 V: 0.22%/V, U_{max} = 480 V



Reduction of output current I depending on output voltage U (= mains voltage).



12 Options

BONFIGLIOLI provides optional components for mechanical and electrical installation, commissioning and communication.

12.1 Safety

⚠ WARNING



To avoid serious physical injury or considerable damage to property, only qualified staff may work on the device.


The electrical installation must be carried out by qualified electricians according to the general and regional safety and installation directives.

12.2 Shield sheets


With an optional shield sheet an EMC conform cabling can be effected. Shield sheets for control cables and shield sheets for motor cables are available for each construction size.

12.2.1 Shield sheet for control cables

With an optional shield sheet, the shields of control and communication cables can be connected to PE potential. The shield sheet offers three ways of shielding the cables: by means of shielding clamp, shielding connector or shielding connection clamp.




Assembly



Fix the shield sheet:

Remove the lower cover.





Loosen the lower screw slightly (don't turn out completely).




- Push the shield sheet from the bottom into the frequency inverter housing completely.
- Tighten the screw. Maximum tightening torque: 3 Nm.



• Fix the lower cover.



12.2.1.1 Dimensions






12.2.2 Shield sheet for motor cables

With an optional shield sheet, the shield of the motor cable can be connected to PE potential.

12.2.2.1 Size 1 and 2 (3~: 0.18 kW to 5.5 kW; 1~: 0.09 kW to 2.2 kW)


Valid for the following devices

Frequency inverter								
Type	Agile	202	<i>Agile</i> 402					
Mains supply	1ph.	3ph.	3ph.					
Power	kW	kW	kW					
-01 1	0.09	0.18						
-02 1	0.12	0.25	0.25					
-03 1	0.18	0.37	0.37					
-05 1	0.25	0.55	0.55					
-07 1	0.37	0.75	0.75					
-09 1	0.55	1.1	1.1					
-11 1	0.75	1.5	1.5					
-13 1	1.1	2.2	2.2					
-15 2	1.5	3.0	3.0					
-18 2	2.2	4.0	4.0					
-19 2			5.5					



 Assemble the shield sheet (1) together with the fixing bracket (2) onto the mounting plate (3).






12.2.2.2 Size 3 (3~: 5.5 kW to 11.0 kW; 1~: 3kW)


Valid for the following devices


Frequency inverter									
Type	Agile	202	Agile 402						
Mains supply	1ph.	3ph.	3ph.						
Power	kW	kW	kW						
-19 3	3	5.5	5.5						
-21 3	3	7.5	7.5						
-22 3			9.2						
-23 3			11						



Assemble the shield sheet (1) together with the fixing bracket (2) onto the mounting plate (3).







12.3 Brake resistor

The brake resistors convert the regenerative energy into heat when the drive is braking. The resistor must be selected according to the duty cycle and braking power.

Mains	Тур3	Resistor		Continu-	Maximum	Integrated
volt- age		Value	Rated power	ous power	permissi- ble oper- ating voltage	thermal protec- tion
V		Ω	kW	W	V	
230	BR 160/100	100	1,6	160	900	Optional
230	BR 432/37	37	4,3	432	900	Optional
230	BR 667/24	24	6,6	667	900	Ja
230	BR 1332/12	12	13,3	1332	900	Ja
400	BR 213/300	300	2,1	213	900	Optional
400	BR 471/136	136	4,7	471	900	Optional
400	BR 696/92	92	6,9	696	900	Ja
400	BR 1330/48	48	13,3	1330	900	Ja
400	BR 2000/32	32	20	2000	900	Ja
400	BR 4000/16	16	40	4000	900	Ja
400	BR 8000/7	7,5	80	8000	900	Ja



12.3.1 230 V devices

The following table shows the cross reference of brake resistors, that can be used for a majority of applications.

The column "Percentage duty cycle" shows, how long inside a duty cycle the brake resistor can be operated with nominal power.

Frequency inverter		Recommended brake resistor	Power at percenta cycle time 120 s	age duty cycle,	
Type	1ph.	3ph.	Type	Percentage	e duty cycle
Agile 202	kW	kW		% (1ph.)	% (3ph.)
-01 1	0,09	0,18	BR 160/100	100	89
-02 1	0,12	0,25	BR 160/100	100	64
-03 1	0,18	0,37	BR 160/100	89	43
-05 1	0,25	0,55	BR 160/100	64	29
-07 1	0,37	0,75	BR 160/100	43	21
-09 1	0,55	1,1	BR 160/100	29	15
-11 1	0,75	1,5	BR 432/37	57	29
-13 1	1,1		BR 432/37	39	
-13 1		2,2	BR 432/37		20
-15 2	1,5	3,0	BR 432/37	29	14
-18 2	2,2	4,0	BR 432/37	20	11
-19 3	3,0	5,5	BR 667/24	22	12
21.2	3,0		BR 667/24	22	
-21 3		7,5	2x BR 432/37 ¹⁾		11

1) 2x BR432/37 parallel

For the connection of a brake resistor refer to chapter 5.6.5 "Brake resistor".

12.3.2 400 V devices

The following table shows the cross reference of brake resistors, that can be used for a majority of applications.

The column "Percentage duty cycle" shows, how long inside a duty cycle the brake resistor can be operated with nominal power.

Frequency i	nverter	Recommended brake resistor	Power at percentage duty cycle, cycle time 120 s
Type		Type	Percentage duty cycle
Agile 402	kW	BR 213/300	%
-02 2	0,25	BR 213/300	85
-03 2	0,37	BR 213/300	58
-05 2	0,55	BR 213/300	39
-07 2	0,75	BR 213/300	28
-09 2	1,1	BR 213/300	19
-11 2	1,5	BR 213/300	14
-13 2	2,2	BR 213/300	10
-15 2	3,0	BR 471/136	16
-18 2	4,0	BR 471/136	12
-19 2	5,5	BR 471/136 ¹⁾	9
-19 2	5,5	BR 1330/48	24
-21 2	7,5	BR 1330/48	18
-22 2	9,2	BR 1330/48	14
-23 2	11	BR 1330/48	12

1) the maximum breaking power of this combination is limited to 4,4kW

For the connection of a brake resistor refer to chapter 5.6.5 "Brake resistor".




12.4 Line choke

Line chokes reduce mains harmonics and reactive power.

The line choke must be installed between mains connection and input filter.

In chapter 11.2 "Device data" the devices, that require a line choke, are marked.



- 1: Line choke
- 2: Input filter

12.4.1 1x230 V connection

Frequency inverter 1phase operation		Recommend- ed line choke	Rated cur- rent	Power dissipa- tion		
Type		Type				
Agile 202	kW		Α	W		
-01	0.09					
-02	0.12					
-03	0.18	LCVS006	6	8		
-05	0.25	LCV3000	U			
-07	0.37					
-09	0.55					
-11	0.75	LCVS008	8	8		
-13	1.1	LCVC01E	1.	12		
-15	1.5	LCVS015	15	12		
-18	2.2	LCVS018 (*)	18	15		
-19	3.0	On request				
-21	3.0	On request				

(*) Usage allowed using the maximum continous line current of 18 A.



12.4.2 230 V connection

Frequency inverter 3phase operation Typ		Recommend- ed line choke Typ	Rated cur- rent	Inductance	Power dissipa- tion	
Agile 202	kW	тур	Α	mH	W	
-01 1	0.18					
-02 1	0.25					
-03 1	0.37	LCVT004	4	7.32	20	
-05 1	0.55					
-07 1	0.75					
-09 1	1.1	LCVT006	6	4.88	25	
-11 1	1.5	LCVT008	8	3.66	30	
-13 1	2.2	LCVT010	10	2.93	30	
-15 2	3.0	LCVT015	15	1.95	45	
-18 2	4.0	LCVT018	18	1.63	70	
-19 3	5.5	LCVT025	25	1.17	70	
-21 3	7.5	LCVT034	34	0.86	85	


12.4.3 3x400 V connection


Frequency inverter		Recommend- ed line choke	Rated cur- rent	Inductance	Power dissipa- tion
Тур		Тур			
Agile 402	kW		Α	mH	W
-02 1	0.25				
-03 1	0.37				
-05 1	0.55	LCVT004	4	7.32	20
-07 1	0.75	LCV1004	4	7.32	20
-09 1	1.1				
-11 1	1.5				
-13 1	2.2	LCVT006	6	4.88	25
-15 2	3.0	LCVT008	8	3.66	30
-18 2	4.0	LCVT010	10	2.93	30
-19 2	5.5	LCVT015	15	1.95	45
-19 3	5.5	LCVT015	15	1.95	45
-21 3	7.5	LCVT018	18	1.63	70
-22 3	9.2	LCVT025	25	1.17	70
-23 3	11	LCVT034	34	0.86	85



12.4.4 Dimensions

LCVS006 ... LCVS018







Type	Dimensions			Assembly		Weight	Connection			
	a	b	С	n ₂	n ₁	d				
	mm	mm	mm	mm	mm	mm	kg	mm	Nm	PE
LCVS006	60	62	75	44	38	3,6	0,5	0,75 2,5	1,0 1,2	2,5 mm ²
LCVS008	60	67	75	44	43	3,6	0,6	0,75 2,5	1,0 1,2	2,5 mm ²
LCVS010	66	80	70	50	51	4,8	0,8	0,75 2,5	1,0 1,2	M4
LCVS015	78	78	80	56	49	4,8	1,1	0,75 4,0	1,5 1,8	M4
LCVS018	85	85	95	64	50	4,8	1,8	0,75 4,0	1,5 1,8	M4

LCVT004..LCVT025








Type	Di	mensio	ns	Α	ssembl	у	Weight	C	Connection	
	a	b	С	n ₂	n ₁	d				
	mm	mm	mm	mm	mm	mm	kg	mm	Nm	PE
LCVT004	80	65	95	55	37	4	0.8	0.75 2.5	1.0 1.2	4 mm ²
LCVT006	100	65	115	60	39	4	1.0	0.75 2.5	1.0 1.2	4 mm ²
LCVT008	100	75	115	60	48	4	1.5	0.75 2.5	1.0 1.2	4 mm ²
LCVT010	100	75	115	60	48	4	1.5	0.75 2.5	1.0 1.2	4 mm ²
LCVT015	125	85	135	100	55	5	3.0	0.75 4.0	1.5 1.8	4 mm ²
LCVT018	155	90	135	130	57	8	4.0	0.75 4.0	1.5 1.8	4 mm ²
LCVT025	155	100	160	130	57	8	4.0	0.75 10	4.0 4.5	4 mm ²
LCVT034	155	100	190	130	57	8	4.5	2.5 16	2.0 4.0	M5



12.5 Input filter


Input filters damp the conducted radio-frequency interference voltage.

The filter must be installed upstream on mains input side of the frequency inverter.



- 1: Line choke
- 2: Input filter

Circuit diagram of input filter (schematic)



12.5.1 Footprint filter

The filter can be installed below the frequency inverter or next to the frequency inverter onto the mounting plate.

Frequenc Agile	y inverter : 402	Recommended Filter			
kW	Size	Type (Order code)	Product Code (Type Plate)		
0.25 2.2	1	FTV001B-AGL	FS28364-8-07		
3.0 4.0	2	FTV002B-AGL	FS28364-10-07		
5.5 11.0	3	FTV003B-AGL	FS28364-26-07		




Filter	Rated current	Rated volt- age	Operating frequency	Operational leakage current	Operational temperature range	Weight
Type	Α	V	Hz	mA	°C	kg
FTV001B-AGL	8	3x480/275	50/60 Hz	3.5	-25 100	0.9
FTV002B-AGL	10	3x480/275	50/60 Hz	3.5	-25 100	1.1
FTV003B-AGL	26	3x480/275	50/60 Hz	3.5	-25 100	1.7


Safety terminal block: Flex wire AWG 10, Flex wire 4 mm², Solid wire 6 mm²

Dimensions

FTV001B-AGL




FTV002B-AGL





FTV003B-AGL



12.5.2 Booktype filter

The filter can be installed next to the frequency inverter onto the mounting plate. The connection terminal consists of a safety terminal block.


Frequency	inverter	Recommended filter	
kW	Size	Type	
0.25 2.2	1	FTV007A	
3.0 4.0	2	FTV016A	
5.5 7.5	3	FTV016A	
9.2 11.0	3	FTV030A	

Filter	Rated current	Rated voltage	Operating frequency	Operational leakage cur- rent	Operational temperature range	Power loss 1)	Weight
Type	Α	V	Hz	mA	°C	W	kg
FTV007A	7	3x480	50/60 Hz	33	-25 100	3.8	0.5
FTV016A	16	3x480	50/60 Hz	33	-25 100	6.1	0.8
FTV030A	30	3x480	50/60 Hz	33	-25 100	11.8	1.2

¹⁾ At 25 °C, 50 Hz.



Dimensions



	Α	В	С	D	E	F	G	Н	I^1	l ²	J	Κ	L^1	L^2
FTV007A	190	40	70	160	180	20	4.5	1	10.6	22	M5	20	31	29.5
FTV016A	250	45	70	220	235	25	5.4	1	10.6	22	M5	22.5	31	29.5
FTV030A	270	50	85	240	255	30	5.4	1	12.6	25	M5	25	40	39.5

Filter input/output connector cross sections

	-33	-44
Solid wire	16 mm ²	10 mm ²
Flex wire	10 mm ²	6 mm ²
AWG type wire	AWG 6	AWG 8
Recommended torque	1.5 – 1.8 Nm	1.5 – 1.8 Nm

12.5.3 Interference suppression class

The emitted interference of the Agile devices was measured with typical setups. With the complied limit values, the Agile devices can be used with shielded motor cables in industrial and residential environments. Using main chokes or filters reduce the emitted interference of the devices.

12.5.3.1 AC 3x400 V

Interference suppression class Agile size 1

Installation measure	Agile 1
Without EMC input filter, without line choke	Class C3
Without EMC input filter, with line choke	Class C3
With footprint filter FS28364-8-07	Class C1
With footprint filter FS28364-8-07 and line choke upstream on mains input side	Class C1
With booktype filter FTV007A	Class C1
With booktype filter FTV007A and line choke upstream on mains input side	Class C1

Interference suppression class Agile size 2

Installation measure	Agile 2
Without EMC input filter, without line choke	Class C3
Without EMC input filter, with line choke 10 A	Class C3
With footprint filter FS28364-10-44	Class C1
With footprint filter FS28364-10-44 and line choke 10 A upstream on mains input side	Class C1
With booktype filter FTV016A	Class C1
With booktype filter FTV016A and line choke 10 A upstream on mains input side	Class C1



Interference suppression class Agile size 3, AGL 402-19 (5.5 kW), AGL 402-21 (7.5 kW) Installation measure Agile 3 AGL402-19 (5.5 kW) AGL402-21 (7.5 kW) Without EMC input filter, without line choke Without EMC input filter, with line choke 15 A or 25 A Class C3 With footprint filter FTV003B-AGL Class C1 With footprint filter FTV003B-AGL and line choke 25 A upstream on Class C1 mains input side Class C1 With booktype filter FTV016A Class C1 With booktype filter FTV016A and line choke 15 A upstream on mains input side

Interference suppression class Agile size 3, AGL 402-22 (9.2 kW)

Installation measure	Agile 3 AGL402-22 (9.2 kW)
Without EMC input filter, without line choke	-
Without EMC input filter, with line choke 15 A or 25 A	Class C3
With footprint filter FTV003B-AGL	Class C1
With footprint filter FTV003B-AGL and line choke 25 A upstream on mains input side	Class C1
With booktype filter FTV016A	Class C1
With booktype filter FTV016A und Netzdrossel vor dem Filter	Class C1

Interference suppression class *Agile* size 3, AGL 402-23 (11 kW)

Installation measure	Agile 3 AGL402-23 (11 kW)
Without EMC input filter, without line choke	-
Without EMC input filter, with line choke 15 A or 25 A	Class C3
With footprint filter FTV003B-AGL	Class C1
With footprint filter FTV003B-AGL and line choke 25 A upstream on mains input side	Class C1
With booktype filter FTV030A	Class C1
With booktype filter FTV030A and line choke 25 A upstream on mains input side	Class C1



12.5.3.2 AC 3x230 V

Interference suppression class *Agile* size 1

Installation measure	Agile 1
Without EMC input filter, without line choke	Class C3
Without EMC input filter, with line choke	Class C3
With footprint filter FS28364-8-07	Class C1
With footprint filter FS28364-8-07 and line choke upstream on mains input side	Class C1
With booktype filter FTV007A	Class C1
With booktype filter FTV007A and line choke upstream on mains input side	Class C1

Interference suppression class *Agile* size 2

Installation measure	Agile 2
Without EMC input filter, without line choke	Class C3
Without EMC input filter, with line choke 10 A	
With footprint filter FS28364-10-44	
With footprint filter FS28364-10-44 and line choke 10 A upstream on mains input side	On request
With booktype filter FTV016A	
With booktype filter FTV016A and line choke 10 A upstream on mains input side $$	

Interference suppression class Agile size 3, AGL 202-19 (5.5 kW), AGL 202-21 (7.5 kW)

Titler let elice suppliession class Agile size 3, AGL 202-19 (5.5 kW)), AGL 202-21 (7.3 KW)
Installation measure	Agile 3
	AGL202-19 (5.5 kW)
	AGL202-21 (7.5 kW)
Without EMC input filter, without line choke	-
Without EMC input filter, with line choke 15 A or 25 A	Class C3
With footprint filter FTV003B-AGL	Class C1
With footprint filter FTV003B-AGL and line choke 25 A upstream on mains input side	Class C1
With booktype filter FTV016A	Class C1
With booktype filter FTV016A and line choke 15 A upstream on mains input side	Class C1



12.5.3.3 AC 1x230 V

Interference suppression class *Agile* size 1

Installation measure	Agile 1
Without EMC input filter, without line choke	Class C3
Without EMC input filter, with line choke	
With footprint filter FS28364-8-07	
With footprint filter FS28364-8-07 and line choke upstream on mains input side	On request
With booktype filter FTV007A	•
With booktype filter FTV007A and line choke upstream on mains input side	

Interference suppression class *Agile* size 2


Installation measure	Agile 2
Without EMC input filter, without line choke	Class C3
Without EMC input filter, with line choke	
With footprint filter	
With footprint filter and line choke upstream on mains input side	On request
With booktype filter	
With booktype filter and line choke upstream on mains input side	

Interference suppression class Agile size 3, AGL 202-19 (5.5 kW), AGL 202-21 (7.5 kW)

Title lielelice suppliession class Aylle size 3, AGL 202-19 (3.3 kW)	, AGL 202-21 (1.5 KW)
Installation measure	Agile 3
	AGL202-19 (3.0 kW)
	AGL202-21 (3.0 kW)
Without EMC input filter, without line choke	-
Without EMC input filter, with line choke 15 A or 25 A	
With footprint filter	
With footprint filter and line choke upstream on mains input side	On request
With booktype filter	
With booktype filter and line choke upstream on mains input side	



12.6 Communication module




Further communications modules are listed in chapter 3.1 "Inverter type and warning signs on the device". The VABus protocol is used for communication with the PC software VPlus for parameter settings, monitoring and diagnosis.

Installation and commissioning of a communication module are described in the separate instruction manuals of the communication protocols.

12.7 USB adaptor

Via an optional USB adaptor the communication interface X21 can be connected to the USB interface of a PC. It enables parameter settings, monitoring and diagnosis via PC software VPlus.



12.8 Resource pack

The frequency inverter can be extended by an optional resource pack (memory card).

Resource pack

- Capacity = 2 GB
- SPI protocol
- Parameter copy function
- Integrated documentation

Parameter values of a frequency inverter can be saved on standard digital memory cards and uploaded on another frequency inverter. Refer to chapter 7.10.11 "Copy parameters".

Note:

To use the copy function, use the Resource pack offered by Bonfiglioli Vectron.

Bonfiglioli Vectron doesn't take any responsibility for the malfunctioning of the memory cards of other manufacturers.




12.9 Assembly variants

Assembly variants of the Agile device series:

Standard (included in the scope of supply, see chapter 4.2 "Installation")

Feed-through (This assembly set is not included in delivery.)
 Cold Plate (This assembly set is not included in delivery.)
 Vibration-proof (This assembly set is not included in delivery.)
 DIN rail for size 1 (This assembly set is not included in delivery.)



- 1: Mounting plate
- 2: Mounting plate as external heat sink
- 3: DIN rail



12.9.1 Feed-through assembly (This assembly set is not included in delivery.)

The feed-through assembly facilitates the thermal separation.

The heat sink of the frequency inverter can be fed through the mounting plate. The power dissipation can be passed on to an external cooling cycle.


12.9.1.1 Cooling air flow rate required and energy dissipation

The required cooling air flow rate and the device-specific energy dissipation P_d of the heat sink are listed in the following table. Additionally, the thermal radiation (energy dissipation, interior) of the frequency inverter is indicated.

Туре										
<i>Agile</i> 202 / 402			-01	-02	-03	-05	-07	-09	-11	-13
Size							1			
Cooling air										
Cooling air flow rate, required		m ³ /h	-	-	-	•	-	-	30	30
Influencing factors										
Energy dissipation, heat sink [2 kHz]	P_d	W	12	19	29	42	53	70	89	122
Energy dissipation, interior	P _{d interior}	W	10	10	11	12	15	18	21	25

		_							
Туре									
Agile 402			-15	-18	-19	-19	-21	-22	-23
Size				2			(-)	3	
Cooling air									
Cooling air flow rate, required		m³/ h	60	60	100	100	100	100	100
Influencing factors									
Energy dissipation, heat sink [2 kHz]	P_d	W	133	167	230	235	321	393	470
Energy dissipation, interior	P _{d interior}	W	31	35	45	48	61	68	81

Separation of energy dissipation:



P_{d interior} Energy dissipation, interior
 P_d Energy dissipation, heat sink
 Mounting plate


2 Heat sink




12.9.1.2 Size 1 (3~: 0.18 kW to 2.2 kW; 1~: 0.09 kW to 1.1 kW)

Valid for the following devices

Frequency inverter						
Type	Agile	202	Agile 402			
Mains supply	1ph.	3ph.	3ph.			
Power	kW	kW	kW			
-01 1	0.09	0.18	0.18			
-02 1	0.12	0.25	0.25			
-03 1	0.18	0.37	0.37			
-05 1	0.25	0.55	0.55			
-07 1	0.37	0.75	0.75			
-09 1	0.55	1.1	1.1			
-11 1	0.75	1.5	1.5			
-13 1	1.1	2.2	2.2			









12.9.1.3 Size 2 (3~: 3.0 kW to 5.5 kW; 1~: 1.5 kW to 2.2 kW)

Valid for the following devices

Frequency inverter							
Type	Agile	202	<i>Agile</i> 402				
Mains supply	1ph.	1ph. 3ph.					
Power	kW kW		kW				
-15 2	1.5	3.0	3.0				
-18 2	2.2	4.0	4.0				
-19 2			5.5				









12.9.1.4 Size 3 (5.5 kW to 11.0 kW)

12.9.1.4.1 With heat sink fan

Valid for the following devices

Frequency inverter						
Type	Agile	<i>Agile</i> 202				
Mains supply	1ph.	3ph.	3ph.			
Power	kW	kW	kW			
-19 3	3 5.5		5.5			
	_	0.0	0.0			
-21 3	3	7.5	7.5			
-21 3 -22 3	3					









12.9.1.4.2 Without heat sink fan

Valid for the following devices

Frequency inverter						
Type	Agile	<i>Agile</i> 202				
Mains supply	1ph.	1ph. 3ph.				
Power	kW	kW kW				
-19 3	3	5.5	5.5			
-21 3	3	7.5	7.5			
-22 3			9.2			
-23 3			11			







12.9.2 Cold Plate (This assembly set is not included in delivery.)

The "Cold Plate" variant enables installation of the frequency inverter on suitable surfaces which have sufficient thermal conductivity to dissipate the heat developing during the operation of the frequency inverter.

Cooling is realized by means of a sufficient cooling area of the mounting plate or via an additional cooler.

12.9.2.1 Range of application

The "Cold Plate" variant enables the use of the frequency inverter in the following applications:

- Installation in a housing, where a high type of protection is required but the volume of the housing limits thermal compensation.
- Use in highly polluted cooling air affecting the function and service life of the fan.
- Use of several frequency inverters in limited space conditions, e.g. installation of frequency inverters on a liquid-cooled plate (sum cooler).
- Direct assembly on (or in) a machine case, with parts of the machine constructions taking over the cooling function.

12.9.2.2 Required thermal properties of the external heat sink

The heat in the frequency inverter due to the energy dissipation of the electronic components (rectifier and IGBT) must be dissipated to a heat sink via the cold plate of the frequency inverter.

The capacity to dissipate this heat mainly depends on

- the size of the heat sink surface,
- the ambient temperature and
- the heat transmission resistance.

An increase of the heat transmission rate can only be realized to a certain extent by increasing the surface of the heat sink. An additional increase of the heat dissipation by increasing the heat sink is not possible.

The frequency inverter must be mounted with the cold plate on an external heat sink with the lowest thermal resistance possible.

Thermal resistance

The thermal resistance R_{th} is calculated from the difference between the maximum heat sink temperature and the ambient temperature, referred to the energy dissipation of the frequency inverter. The ambient temperature to be considered refers to the immediate environment of the frequency inverter.

$$Rth = \frac{Th \, max - Ta}{Pd}$$

Max. permissible heat sink temperature of the frequency inverter	$T_{h max} = 75 ^{\circ}C$
Ambient temperature of the heat sink	T _a = 35 °C
Difference between the maximum heat sink temperature and the ambient temperature $(T_{h \text{ max}} - T_a)$	ΔT = 40 K
Energy to be dissipated by the heat sink	P _d : device-specific

Typo



The following tables list the maximum permissible thermal resistance R_{th} of the external heat sink and the device-specific energy dissipation P_d of the external heat sink. The thermal resistance R_{th} is given in the unit Kelvin per Watt (K/W). The value of R_{th} can typically be taken from the data sheet of the external heat sink. Additionally, the thermal radiation (energy dissipation, interior) of the frequency inverter is indicated in the table.


Type										
Agile 402/ Agile 202			-01	-02	-03	-05	-07	-09	-11	-13
Size							1			
Influencing factors										
Energy dissipation, heat sink [2 kHz]	P_{d}	W	12	19	29	42	53	70	89	122
Energy dissipation, interior	$P_{d\ interior}$	W	10	10	11	12	15	18	21	25
Thermal resistance										
$T_{h max} - T_{a}$	ΔΤ	K					40			
Thermal resistance	R_{th}	K/W	3.33	2.11	1,38	0.9	5 0.7!	5 0.57	0.45	0.33
Mechanics										
Cooling surface of Cold Plate	НхВ	mm				19	90 x 83	3		
Weight (approx.)	m	kg					1.1			
Туре										
Agile 402/ Agile 202			-15	5 -	18	-19	-19	-21	-22	-23
Size					2			3	3	
Influencing factors										
Energy dissipation, heat sink [2 kHz]] P _d	W	133	3 1	.67		235	321	393	470
Energy dissipation, interior	P _{d interior}	or W	31		35		48	61	68	81
Thermal resistance										
$T_{h max} - T_{a}$	ΔΤ	K					40			
Thermal resistance	R _{th}	K/ W	0.3	0 0	.24	0.17	0.17	0.12	0,10	0.09
Mechanics										
Cooling surface of Cold Plate	HxB	3 mm	ı	190	x 103	3		190	x 148	
Weight (approx.)	m	kg		1	.35			2	.6	

The thermal resistance values and the technical data apply in the following conditions:

- No airflow.
- Clearance of approx. 300 mm above and below as well as 100 mm on both the left and right side of the frequency inverter.

The energy dissipation values are also valid for the switching frequencies of 4, 8, 12 and 16 kHz, as at these operating points, the output current is reduced.

Separation of energy dissipation:



$P_{d\ interior}$	Energy dissipation, interior
P_d	Energy dissipation, heat sink
1	Cold Plate of frequency inverter
2	Mounting plate as external heat sink



12.9.2.3 Additional fan or liquid cooling

The size of the heat sink can be reduced if fans are installed or a liquid cooling system is used in addition to the "Cold Plate" assembly.

The size of the external heat sink can be reduced proportionally to the increase in the flow rate of the cooling medium.

In the following a fan cooling system is described as an example. For calculating the maximum permissible heat resistance $R_{th\ enforced}$ for cooling by means of a fan, a proportionality factor is introduced. This factor describes the increase of the maximum permissible thermal resistance at increasing flow rate of the cooling air.

The maximum permissible thermal resistance $R_{th\ enforced}$ for enforced air cooling can be calculated as follows:

$$R_{th \, enforced} = \frac{R_{th}}{\alpha}$$

 R_{th} : Maximum permissible thermal resistance with free circulation of air. Calculate according to the formula for R_{th} in the previous chapter or use the value indicated in the table.

 α : Proportionality factor.

The relation is shown, as an example, in the following table for the *Agile* 402-23 frequency inverter.

Thermal resistance for enforced air cooling						
R _{th} [K/W]	V _{air} [m/s]	α	R _{th enforced} [K/W]			
0.09	0	1	0.09			
0.09	1	0.65	0.14			
0.09	2	0.45	0.20			
0.09	4	0.28	0.32			
0.09	6	0.20	0.45			

12.9.2.4 Application notes

- Comply with the operation diagrams for power reductions (derating).
- Comply with the thermal limiting values of the frequency inverter. Refer to chapter 11 "Technical data" and 12.9.2.4.1 "Temperature monitoring".
- Additional power losses P_{d interior} are dissipated as heat into the interior of a control cabinet. These losses may amount to 30% of the total energy dissipation and must be considered in the calculation of the volume of the control cabinet. The values are listed in the tables in chapter 12.9.2.2 "Required thermal properties of the external heat sink".
- If several frequency inverters or other heat-producing devices are mounted on a common heat sink (sum cooler), the losses of all devices must be added up. Calculate the maximum permissible thermal resistance R_{th} using the formula (chapter 12.9.2.2 "Required thermal properties of the external heat sink").
- The contact surface of the external heat sink must have a sufficient thermal conductivity.

12.9.2.4.1 Temperature monitoring

The heat sink temperature and the interior temperature can be monitored:

06/2013

- The temperatures can be displayed in the actual value menu. Refer to chapter 9.1 "Actual values of frequency inverter".
- When the maximum permitted temperatures are reached error-switch-off is effected and an error message is triggered.
- Before the maximum permitted temperatures are reached a warning message is triggered. An error-switch-off can be avoided. The temperature values for the warnings can be set via parameter. Refer to chapter 7.4.2 "Temperature".



Error-switch-off is effected at:

- Maximum heat sink temperature
- Maximum interior temperature

In the factory setting a warning message is triggered when

- the maximum heat sink temperature is reached (minus 5 °C)
- the maximum interior temperature is reached (minus 5 °C)

The warning messages can be output via digital outputs.

12.9.2.5 Assembly

12.9.2.5.1 Safety

⚠ WARNING



To avoid serious physical injury or considerable damage to property, only qualified staff may work on the devices.

During operation, the heat sink can reach a temperature of up to 75 $^{\circ}$ C. Do not touch the heat sink during operation.

The heat sink may be hot even some time after the frequency inverter was switched off.

Comply with the following requirements:

- The installation surface of the external heat sink must at least be as large as the cold plate surface.
- The contact surfaces of the external heat sink and cold plate must be plane.
- The contact surfaces must be clean and degreased.
- For fixing the frequency inverter, drill 6 threaded holes M6 in the installation surface. For the installation dimensions, refer to the following chapters.
- Deburr the threaded holes.
- Clean the contact surfaces of the external heat sink and cold plate.
- Apply a thin and uniform film of heat conducting paste on the cold plate.



The heat conducting paste compensates the roughness of the contact surfaces and thus the heat transmission resistance between the cold plate and the heat sink. In this way, the cooling efficiency is increased.

• Mount the frequency inverter vertically on the heat sink using six M6 bolts. The bolts must have a minimum length of 30 mm. Tighten all bolts uniformly.




The maximum tightening torque of the fixing bolts in a typical construction is 3.4 Nm.


After the mechanical installation continue with the electrical installation according to chapter 5 "Electrical Installation". Comply with the safety instructions provided there.



12.9.2.5.2 Size 1 (3~: 0.18 kW to 2.2 kW; 1~: 0.09 kW to 1.1 kW)

Frequency inverter				
Type	Agile 202		<i>Agile</i> 402	
Mains supply	1ph.	3ph.	3ph.	
Power	kW	kW	kW	
-01 1	0.09	0.18	0.18	
-02 1	0.12	0.25	0.25	
-03 1	0.18	0.37	0.37	
-05 1	0.25	0.55	0.55	
-07 1	0.37	0.75	0.75	
-09 1	0.55	1.1	1.1	
-11 1	0.75	1.5	1.5	
-13 1	1.1	2.2	2.2	









12.9.2.5.3 Size 2 (3.0 kW to 5.5 kW)

Frequency inverter				
Type	<i>Agile</i> 202		<i>Agile</i> 402	
Mains supply	1ph.	3ph.	3ph.	
Power	kW	kW	kW	
-15 2	1.5	3.0	3.0	
-18 2	2.2	4.0	4.0	
-19 2			5.5	









12.9.2.5.4 Size 3 (5.5 kW to 11.0 kW)

Frequency inverter				
Type	<i>Agile</i> 202		Agile 402	
Mains supply	1ph.	3ph.	3ph.	
Power	kW	kW	kW	
-19 3	3	5.5	5.5	
-19 3 -21 3	3	5.5 7.5	5.5 7.5	
	3 3			









12.9.3 Vibration-proof (This assembly set is not included in delivery.)

12.9.3.1 Size 1 (3~: 0.18 kW to 2.2 kW; 1~: 0.09 kW to 1.1 kW)

Frequency inverter				
Type	Agile 202		<i>Agile</i> 402	
Mains supply	1ph.	3ph.	3ph.	
Power	kW	kW	kW	
-01 1	0.09	0.18	0.18	
-02 1	0.12	0.25	0.25	
-03 1	0.18	0.37	0.37	
-05 1	0.25	0.55	0.55	
-07 1	0.37	0.75	0.75	
-09 1	0.55	1.1	1.1	
-11 1	0.75	1.5	1.5	
-13 1	1.1	2.2	2.2	










12.9.3.2 Size 2 (3~: 3.0 kW to 5.5 kW; 1.5 kW to 2.2 kW)

Frequency inverter				
Type	<i>Agile</i> 202		Agile 402	
Mains supply	1ph.	3ph.	3ph.	
Power	kW	kW	kW	
-15 2	1.5	3.0	3.0	
-18 2	2.2	4.0	4.0	
-19 2			5.5	











12.9.3.3 Size 3 (3~: 5.5 kW to 11.0 kW)

Frequency inverter				
Type	<i>Agile</i> 202		Agile 402	
Mains supply	1ph.	3ph.	3ph.	
Power	kW	kW	kW	
-19 3	3	5.5	5.5	
			0.0	
-21 3	3	7.5	7.5	
-21 3 -22 3	3			








12.9.4 DIN rail (This assembly set is not included in delivery.)

Size 1 can be assembled on a DIN rail.

12.9.4.1 Size 1 (3~: 0.18 kW to 2.2 kW; 1~: 0.09 kW to 1.1 kW)

Valid for the following devices

Frequency inverter				
Type	Agile 202		<i>Agile</i> 402	
Mains supply	1ph.	3ph.	3ph.	
Power	kW	kW	kW	
-01 1	0.09	0.18	0.18	
-02 1	0.12	0.25	0.25	
-03 1	0.18	0.37	0.37	
-05 1	0.25	0.55	0.55	
-07 1	0.37	0.75	0.75	
-09 1	0.55	1.1	1.1	
-11 1	0.75	1.5	1.5	
-13 1	1.1	2.2	2.2	



During the assembly a good contacting of the frequency inverter to the DIN rail must be assured. A good PE-connection of the frequency inverter to the assembly material and the DIN rail requires metallic conducting contact.



13 Error protocol

The various control methods and the hardware of the frequency inverter include functions which continuously monitor the application. The operational and error diagnosis is facilitated by the information stored in the error protocol.

13.1 Error list

Last errors

The last 16 fault messages are stored in chronological order and the *No. of errors* **362** shows the number of errors which have occurred since initial commissioning of the frequency inverter. On the operator panel, the error code FXXXX is displayed. The meaning of the error key is described in the following chapter "13.1.1 "Error messages". Via the PC user interface, the number of operation hours (h), operation minutes (m) and the fault message can additionally be read out. The current operating hours are shown by parameter *Operating hours counter* **245**. The error message can be acknowledged via the operator panel buttons or according to the link *Error acknowledgement* **103**.

	Error list			
No. Description		Function		
310	Last Error	hhhhh:mm ; FXXXX fault message.		
311	Last Error but one	hhhhh:mm ; FXXXX fault message.		
312 to 325		Error 3 to error 16.		
362	No. of Errors	Number of errors occurred after the initial commissioning of the frequency inverter.		

363 No. of self acknowledged errors

Automatic error acknowledgment enables acknowledgment of errors Overcurrent F0507 and Overvoltage F0700 without intervention by an overriding control system or the user. The *No. of self acknowledged errors* **363** shows the total number of automatic error acknowledgments.

	Error list		
No.	o. Description Function		
363	No. of self acknowledged	Total number of automatic error acknowledg-ment with syn-	
Errors chronization.		chronization.	



13.1.1 Error messages

259 Actual Error

Parameter Actual Error 259 shows the error code.

Error code

Error messages					
Code		Meaning			
F00					
100		Overload			
	00	Frequency inverter overloaded, check load behaviour. Reduce ramps and speed.			
	01	Frequency inverter overloaded in low output frequency range.			
F01	02	Frequency inverter overloaded (60 s), check load behaviour.			
	03	Short-term overload (1 s), check motor and application parameters.			
	05	Heat Sink			
	00	Heat sink temperature too high, check cooling and ventilator.			
F02	01	Heat sink temperature too cold, check allowed ambient temperature.			
		Inside			
	00	Inside temperature too high, check cooling and ventilator.			
F03	01	Inside temperature too cold, check allowed ambient temperature.			
	03	Capacitor temperature too high, check cooling and ventilator.			
		Motor connection			
	00	Motor temperature too high or sensor defective, check connection at terminal X12.4.			
	01	Motor circuit breaker tripped, check drive.			
F04	02	V-belt monitoring reports no load on the drive.			
	03	Phase failure, check motor and wiring.			
	03	Output current			
	00	Overloaded, check load situation and ramps.			
	06	Motor phase current too high, check motor and wiring.			
	07	Message from phase monitoring, check motor and wiring.			
	08	Message from phase monitoring, check motor and wiring.			
F05	09	Message from phase monitoring, check motor and wiring.			
	05	Motor still rotates. The motor is still excited and rotates and			
	11	drive start command applies and the flying start function is deactivated or			
	11	a device test is tried to start			
F06	\ \\	Internal Error Places contact your Ponfigliali office			
FU0	XX	Internal Error. Please contact your Bonfiglioli office. DC-link voltage			
	00	DC link voltage too high, check deceleration ramps and connected brake resistor.			
	01	DC link voltage too riigh, check deceleration ramps and connected brake resistor. DC link voltage too small, check mains voltage.			
	02	Power failure, check mains voltage and circuit.			
F07					
F07	03	Phase failure mains, check mains fuses and circuit.			
	04	Reference DC-Link Limitation 680 too small, check mains voltage.			
	05	Overvoltage brake chopper. Refer to chapter 13.3 "Troubleshooting" (Shut-down).			
06 Overvoltage motor chopper. Refer to chapter 13.3 "Troubleshooting" (Shut-down).					
	01	Electronics voltage			
	01	Electronics voltage DC 24 V too low, check control terminal.			
F08	04	Electronics voltage too high, check wiring of control terminals.			
	05	Fault in the the A/D converter. Remove all external connections (signal terminals etc.) and check if the fault remains			
1	<u> </u>	and check if the fault femalis			



Error messages					
Code		Meaning			
		Voltage supply for optional communication module too low. Communication via bus system faulty.			
	0.6	Disconnect bus system wiring and acknowledge the error message. Check connections and wiring of the bus system.			
	06	Replace the communication module if the error occurs, even if the bus system is disconnected.			
		If the communication module is replaced and the error occurs, contact the service of BONFIGLIOLI.			
		Brake chopper			
F10	10	Brake chopper overcurrent. Also refer to chapter 7.10.4 "Brake chopper and brake resist".			
		Output frequency			
	00	Output frequency too high, check control signals and settings.			
F11	01	Maximum frequency achieved by control. Check deceleration ramps and connected brake resistor.			
		Enable			
		The STO Diagnosis software recognized a fault in the STO switch-off paths. Check			
	01	wiring, connect screens. Check the EMC environment. If the fault remains, exchange the device.			
	02	Fault of the STO diagnosis function. If the device remains after a new start up, exchange the device.			
	04	Internal Fault. Contact the BONFILGLIOLI customer service.			
	05	Enable signals STOA and STOB were not actuated at the same time, but with a high time offset. Check the circuitry of the enable input signals.			
F12	06	The voltage of the STO signals is too low. Check the dimensioning of the DC 24 V supply, that supplies the STO inputs.			
	07	The STO diagnosis software was not able to detect a clear defined STO level. Check the wiring and STO triggering device. Ensure, that clear signal levels can be received (DC 0 V / DC 24 V). If the fault persists, check if the fault persists with another drive.			
	08	The STO diagnosis software has recognized that the STO signal levels of the device don't correlate to each other at different measurement points. Check the wiring, put the screens on correctly. If the fault persists, exchange the device.			
	09	The STO diagnosis software recognized that an STO signal is too high inside the device. Check the wiring; apply a clear defined signal level (0V / 24 V). If the fault persists, exchange the device.			
	ı	Motor connection			
F13	00	Earth fault on output, check motor and wiring.			
113	10	Minimum current monitoring, check motor and wiring.			
		Control connection			
	01	Reference value on multifunctional input 1 faulty, check signal.			
	02	Reference value on multifunctional input 2 faulty, check signal.			
	07	Overcurrent on multifunctional input 1, check signal.			
	80	Overcurrent on multifunctional input 2, check signal.			
F14	09	No actual value for technology controller. Missing actual value was reported according to setting for <i>Operation mode actual value failure</i> 440 .			
	50	Temperature measurement with KTY measuring resistor defective. Check signal and measuring resistor.			
		External error; drive responded according to parameter setting for <i>Operation mode ext</i> .			
	54	error 535 . Error was triggered via the logic signal or digital input signal assigned to			
		parameter External error 183.			
	10	Modbus and VABus Communication array according to parameter V21: VABus Watahdag Timer 1502			
F20	10	Communication error according to parameter X21: VABus Watchdog-Timer 1502.			
	11	Communication error according to parameter CM: VABus Watchdog Timer 413.			



	 				
Error messages					
Code		Meaning			
CANopen					
	21	CAN Bus OFF			
	22	CAN Guarding			
	23	Error state			
	24	SYNC error (SYNC timing)			
	25	CAN error state			
F20	26	RxPDO1 length error			
	27	RxPDO2 length error	Number of received bytes differs from mapping.		
	28	RxPDO3 length error			
	2A	RxPDO1 Timeout	RxPDO was not received in expected time.		
	2B	RxPDO2 Timeout	Ensure, that the RxPDO can be received in the set up "Event		
	2C	RxPDO3 Timeout	time" (Subindex 5).		
			DeviceNet		
F20	5x	DeviceNet Fault. Please	check DeviceNet manual.		
			Profibus		
F20	6x	Profibus Fault. Please c			
	1	T	Internal Error.		
F20	7	Internal Error. Please co	ontact your Bonfiglioli office.		
	1	Foult manage an averte	System bus		
F21	nn	Fault message on system bus master when a fault at system bus slave occurs, nn = node-ID of slave (hex)			
	00		ystem bus, timeout sync-telegram		
	01	Communication fault, system bus, timeout RxPDO1			
F22	02	Communication fault, system bus, timeout RxPDO2			
1 22	03	Communication fault, system bus, timeout RxPDO3			
	10	Communication fault, system bus, bus-off			
	10	Communication radicy 5	CANopen		
F23	nn	Heartbeat error, nn = t			
. 23		II.	CM module recognition		
F24	00		Check compatibility firmware and CM module.		
			Industrial Ethernet		
F27	nn	Industrial Ethernet Faul	t. Please check manual of used Ethernet module.		
			EtherCAT		
F28	nn	EtherCAT fault.			
			User Error		
F30	3n	User triggered Error of	Internal PLC. Please check the application manual VPLC.		
			Optional components		
FOB 13 Assembly of communication module was done without disconnect					
Disconnect mains supply. Internal monitoring					
After 6 warm starts in less than 3 minutes this fault is triggered, due to the expectation					
F0C	40	that a faulty programmi	ing of the PLC or the function table is at hand. Additionally the		
		PLC / Function table is	stopped (P. 1399 = 0 only in RAM).		



Output signals in the case of error messages

Errors are signaled via digital signals.

Error Signal
$$\begin{vmatrix} 1 \\ 2 \end{vmatrix}$$
 A monitoring function signals an error with indication via parameter *Actual* $error$ **259**.

In addition to fault messages mentioned, there are further fault messages. However these messages are only used for internal purposes and are not listed here. If you receive fault mes-sages which are not listed here, please contact the BONFILGLIOLI customer service.

13.2 Error environment

Actual values at the event of a failure

The parameters of the error environment help troubleshooting both in the settings of the frequency inverter and also in the complete application. The error environment documents the operational behavior of the frequency inverter at the time of the last four faults.

	Error environment			
No.	Description	Function		
330	DC-link voltage	Direct voltage in DC-link.		
331	Output voltage	Calculated output voltage (motor voltage) of the frequency inverter.		
332	Stator frequency	The output voltage (motor voltage) of the frequency inverter.		
335	Phase current Ia	Measured current in motor phase U.		
336	Phase current Ib	Measured current in motor phase V.		
337	Phase current Ic	Measured current in motor phase W.		
338	rms Current	Calculated effective output current (motor current) of the frequency inverter.		
339	Isd/reactive current	Current component forming the magnetic flux or the calculated reactive current.		
340	Isq/active current	Sq/active current Current component forming the torque or the calculated active current.		
341	Rotor magnetizing cur- rent	Magnetizing current relative to the rated motor parameters and the operating point.		
342	Torque	Torque calculated from the voltage, the current and the control variables.		
343	Analog input MFI1A	Input signal at multifunction input 1 (terminal X12.3) in analog Operation mode MFI1 452 (voltage or current).		
344	Analog input MFI2A	Input signal at multifunction input 2 (terminal X12.4) in analog Operation mode MFI2 562 (voltage or current).		
346	Analog output MFO1A	Output signal at multifunction output 1 (terminal X13.6) in setting "10 - Analog (PWM) MFO1A" of parameter <i>Operation mode MFO1</i> (X13.6) 550 .		
348	DC-link Cap. Temperature	Measured capacitor temperature.		
349	Repetition frequency output	Signal at multifunction output 1 in setting "20 - repetition frequency (FF) MFO1F" for <i>Operation mode MFO1 (X13.6)</i> 550 and according to selection for <i>RF/PT: Output Value MFO1F</i> 555 .		

¹⁾ For linking to frequency inverter functions.

²⁾ For output via a digital output. Select the signal source for one of the parameters 531, 532, 533, 554. See chapter 7.6.5 "Digital outputs".



	Error environment			
No.	Description	Function		
350	Status of digital inputs	Decimally encoded status of the enable signal (STOA AND STOB) of the six digital inputs and of multifunction input 1 (if Operation mode MFII 452 = "3 -		
		digital NPN (active: 0 V)" or "4 - digital PNP (active: 24 V))" and of multifunction input 2 (if <i>Operation mode MFI2</i> 562 = "3 - digital NPN (active: 0 V)" or "4 - digital PNP (active: 24 V))".		
351	Status of digital outputs	 Decimally encoded status of digital output at terminal X12.5. of multifunction output at terminal X13.6 (if <i>Operation mode MFO1</i> (X13.6) 550 = "1 - Digital MFO1D" of digital input/output at terminal X11.6 (if <i>Operation mode terminal X11.6</i> 558 = "1 - output OUT3D") of relay output at terminal X10 		
352	Time since release	Time of the error in hours (h), minutes (m) and seconds (s) after enable signal: hhhhh:mm:ss .sec/10 sec/100.		
353	Heat sink temperature	Measured heat sink temperature.		
354	Inside temperature	Measured inside temperature.		
355	Controller status	The reference value signal is limited by the controller coded in the controller status.		
356	Warning status	The warning messages coded in warning status.		
357	Int. value 1	Software service parameter.		
358	Int. value 2	Software service parameter.		
359	Long value 1	Software service parameter.		
360	Long value 2	Software service parameter.		
367	Application Warning State	The application warnings coded in warning status.		

361 Checksum

The Checksum 361 parameter shows whether the storage of the error environment was free of errors (OK) or incomplete (NOK).

	Error environment		
No.	Description	Function	
361	Checksum	Check protocol of the error environment.	



13.3 Troubleshooting

The list shows a selection of possible measures if problems occur. Not all problems listed will result in an error message.

an error message.		
Problem	Cause	Possible remedy
Error message		See chapter 13.1.1 "Error messages".
Shut-down	Brake resistor connection	Check.
	Brake resistance	Check value. Reduce value if necessary.
	High generator power	Reduce deceleration value.
	High DC-link voltage	Check brake resistance.
		Check brake resistor connection.
		Reduce deceleration value.
		Check DC-link voltage limitation (P680).
		DC-link voltage higher than brake chopper trigger
		threshold (P506). Check value. Increase value if nec-
		essary.
		DC-link voltage higher than motor chopper trigger
		threshold (P507). Check value. Increase value if nec-
		essary.
	Main phase failure	Check mains connection.
	Overcurrent	Check motor data.
		Check motor connection.
	Short-circuit or overload	The parameterizable motor circuit breaker (P571) has
		been triggered. Short-circuit at motor connection or
		overload.
	Earth fault	Check load for earth fault.
	Overtemperature	Overload. Reduce load and ensure sufficient cooling.
		Comply with permissible ambient conditions.
		Reduce output power or switching frequency.
	Electromagnetic inter- ference	Check EMC.
	Overfrequency	Switch-off limit (P417) exceeded. Increase value if necessary.
		Maximum frequency increase (P681) of DC-link volt-
		age limitation exceeded. Increase value if necessary.
Parameter setting	Enable is switched on	Most parameters cannot be written during operation.
not possible.	and motor is running.	Switch off enable and select "Para" menu on opera-
	Access limited.	tor panel. Select higher control level (P38)
	Setup is active.	Select higher control level (P28). Wait until setup is finished and the message "ready"
	octub is active.	is displayed.
	Changes disabled by	Entry must correspond to password (P27).
	password.	End y music correspond to password (127).
	passivoral	
Motor does not	Parameter setting	For P412, select "3 - Control via keypad" or "4 - Con-
turn after press-		trol via keypad or contacts" (factory setting).
ing of RUN.		Check P418 (Minimum frequency) and P419 (Maxi-
J		mum frequency).
	No enable	Switch on both enable inputs STOA and STOB.
	Error in control cables	Check control cable connections.
		100 100 100 100 100 100 100 100 100 100



Problem	Cause	Possible remedy
Motor does not turn after a start command at digi- tal input.	Parameter setting	Select correct source for reference value. For example, for speed setting via a multifunction input, set at least one of parameters P475 or P492 to "1 - analog input 1" (terminal X12.3) or "2 - analog input 2" (terminal X12.4). For P452 (terminal X12.3) and P562 (terminal X12.4), select the correct signal to set the reference value ("1 - voltage" or "2 - current"). For P68 (Start clockwise) or P69 (Start anticlockwise), select the required digital input. Check P418 (Minimum frequency). Set digital input for the start command to the required evaluation ("0 - NPN" or "1 - PNP").
	Reference value too low.	Check actual value P228 (internal reference frequency). Check voltage or current value at reference value input.
	No enable	Switch on both enable inputs STOA and STOB.
	Error in control cables Motor does not produce enough torque.	Check control cable connections. Carry out setup (again). Long cables will reduce the torque. V/f characteristic: Check start-up behavior (P620), flux-formation (P780 and P781) and starting current (P623). Field-orientated control: Check start-up behavior (flux-formation P780 and P781) and torque limit (P730), reset to factory settings if necessary.
Motor does not turn after a start	Parameter setting	Via P412 set the controller to "1 - state machine" or "2 - remote contacts".
command via a communication interface	No enable	Switch on both enable inputs STOA and STOB.
Motor turning in wrong direction.	Incorrect connection of motor phases.	Check motor cables. Exchange two motor phases (e.g. U and V) at the frequency inverter terminals. Connect terminals U, V and W of the frequency inverter to the corresponding terminals U, V and W of the motor.
	Parameter setting	Check if P493 or P495 is set to "3 - Inverted". The reference value will be inverted. Check if for P68 (Start clockwise) and P69 (Start anticlockwise) the required digital inputs are selected. Check the characteristic parameters if the reference value is defined via MFI1 or MFI2 and "6 - voltage characteristic" or "7 - current characteristic" is selected.
Motor turning in one direction only.	Parameter setting	Check if P493 or P495 is set to "2 - positive only". In this case, the reference value can only be positive. Factory setting: "1 - (+/- reference value)". Check values for P420 (acceleration clockwise) and P422 (acceleration anticlockwise). The value 0.00 Hz/s blocks the corresponding direction of rotation.



Problem	Cause	Possible remedy
The motor is very hot.	Load too high.	Reduce load. Reduce acceleration and deceleration values. Check rated current. Use larger motor.
	Motor temperature mon- itoring connection	Check connection of thermal contact or measuring resistance at MFI2. Check setting of P570 (temperature evaluation). Check setting of P617 (for KTY or PT1000).
	Ambient temperature too high.	Comply with permissible ambient conditions. Ensure sufficient cooling.
	Setup not carried out.	Carry out setup. For an asynchronous motor, switch to control according to V/f characteristic (set P30 to 110).
Time until motor starts seems quite long	Flying Start is used.	Switch off Flying Start (if possible, not recommended for synchronous motors). Use P.645 = 20 (if possible).
Motor stops during start-up.	Load torque too high.	Reduce load torque. Reduce acceleration values. Use larger motor.
Motor does not accelerate or motor accelerates very slowly.	Reference value too low.	Check P418 (Maximum frequency). Check acceleration and deceleration values. Set P475 and P492 to the appropriate reference frequency source. For definition of reference value via multifunction input: For P452 (terminal X12.3) and P562 (terminal X12.4), select the correct signal to set the reference value ("1 - voltage" or "2 - current").
	Ramps too smooth. Setup not carried out.	Check values for P420 (acceleration clockwise) and P422 (acceleration anticlockwise). Carry out setup.
	Control according to V/f characteristic not suitable.	For high torques at low speed, field-orientated control (DMC) may be suitable. Set P30 to 410 (asynchronous motor) or 610 (synchronous motor).
	Mechanical brake	Check if a mechanical brake is effective.
Speed vibrations	High load torques in the case of field-orientated control (DMC)	Check amplification and integral time settings of control functions.
	High load torques in the case of sensor-less control (V/f characteristic)	Switch on slip compensation (P660). Check parameters of V/f characteristic.
	PID controller	If the PID controller is used, check amplification, integral time and derivative time.
	The reference value is defined via an external source.	Avoid electromagnetic interference on the control cables. Install mains and motor cables separately from the control cables. Use shielded control cables. If an analog reference value is defined: Select a filter time constant P451 for MFI1 or P561 for MFI2.
	The motor cables are too long.	Carry out setup. Shorten cables.



Problem	Cause	Possible remedy
Overvoltage	High load torques in the case of field-orientated	High load torques may cause error messages due to overvoltage.
	control (DMC)	For an asynchronous motor, switch to sensor-less control according to V/f characteristic (set P30 to 110).
Noise from drive	Motor noise or switching noise in frequency inverter	Reduce switching frequency (P400). Install input filter. Install output filter.
	verter	Connect motor and frequency inverter to PE potential.
		Install mains and motor cables separately from the control cables. Avoid motor vibration.
	Output frequency is resonant frequency of system	Set blocking frequencies (P447, P448) and hysteresis (P449) to disable output frequency ranges.
PID controller output signal defective	Parameter setting	Set P475 or P492 to "30 - Technology controller". Set P476 or P494 to the source for the reference value.
		Set P478 to the source for the actual value.
		Start signal (P68 or P69) starts the PID controller.
	Connection	Check connection for actual value signal.
Digital inputs have 0 V instead	Energy saving function	Caused by functionality (see chapter 8.3).
of a voltage of		If undesired: Deactivate Energy saving function
approx. 20 V		(P1511) or select an operation mode, that doesn't
		switch off the I/O's.




14 Operational and error diagnosis

Operation of the frequency inverter and the connected load are monitored continuously. Various functions document the operational behavior and facilitate the operational and error diagnosis.

14.1 Status of digital signals

The status display of the digital input and output signals enables checking of the vari-ous control signals and their assignment to the corresponding software functions, in particular during commissioning. Parameters *Status digital inputs* **350** and *Status digital outputs* **351** show decimal values which must be converted to binary values in order to obtain the status information.



A decimal value is displayed, indicating the status of the digital signals in bits after conversion into a binary figure.


Example:

Decimal figure 33 is displayed. Converted into the binary system, the number reads 00100001. Thus, the following contact inputs or outputs are active:

Digital input or output 1 Digital input or output 6

14.2 Controller status

The controller status can be used to establish which of the control functions are active. If a several controllers are active at the time, a controller code com-posed of the sum total of the individual codes is displayed. Display of the controller status via the operator panel can be parameterized via parameter *Controller status message* **409**.



Code	Controller status
C 00 00 -	No controller active.
C 00 01 UDdyn	Voltage controller is in the rise phase according to <i>Operation Mode</i> 670 .
C 00 02 UDstop	The output frequency in the case of a power failure is below the <i>Shutdown Threshold</i> 675 .
C 00 04 UDctr	Failure of the mains voltage and power regulation active according to <i>Operation Mode</i> 670 of the voltage controller.
C 00 08 UDlim	The DC link voltage has exceeded the <i>Reference DC-Link Limitation</i> 680 .



		Co	de	Controller status
С	00	10	Boost	The Dyn. Voltage Pre-Control 605 accelerates the control characteristics.
С	00	20	Ilim	The output current is limited by the current limit value controller or the speed controller.
С	00	40	Tlim	The output power or the torque is limited by the speed controller.
С	00	80	Tctr	Switch-over of field-orientated control between speed and torque-controlled control method.
С	01	00	Rstp	The <i>Operation Mode</i> 620 selected in starting behavior limits the output current
С	02	00	IxtLtLim	Overload limit of the long-term Ixt (60 s) reached, intelligent current limits active
С	04	00	IxtStLim	Overload limit of the short-term Ixt (1 s) reached, intelligent current limits active.
С	08	00	Tclim	Max. heat sink temperature T_K reached, intelligent current limits of $Operation$ $Mode~ 573~ active.$
С	10	00	PTClim	Max. motor temperature T_{PTC} reached, intelligent current limits of $Operation$ $Mode~ 573~ active.$
С	20	00	Flim	Reference frequency reached the <i>Maximum Frequency</i> 419 . The frequency limitation is active.

Example:

The controller status is displayed:


C0024 UDctr Ilim

The controller status results from the hexadecimal sum of the controller codes (0004+0020 = 0024). At the same, the power failure regulation and also the current limita-tion of the speed controller are active.

14.3 Warning status and warning status application

The current warning is displayed by a message in the warning status and can be used for an early message of a critical operational condition. Warnings are also displayed on the operator panel. If several warnings are present, the warning status is displayed as the sum of the individual warning codes.

Via the actual value parameters *Warning* **269**, *Application Warnings* **273**, *Warning status* **356** (in error environment) and *Application warning status* **367** (in error environment), all warnings present at the time of the error are displayed.



The warning masks created through parameters *Create warning mask* **536** and *Create warning mask application* **626** have no influence on the warnings displayed.

356 Warning Status

The parameter displays the warning at failure switch-off.

Meaning of code displayed by parameter Warning Status **356**:

Code			le	Warning status
Α	00	00	-	No warning message present.
Α	00	01	Ixt	Frequency inverter overloaded (A0002 or A0004)
Α	00	02	IxtSt	Overload for 60 s relative to the nominal output of the frequen-cy inverter
Α	00	04	IxtLt	Short-time overload for 1 s relative to the nominal output of the frequency inverter.



	Code			Warning status
Α	00	08	Тс	Maximum heat sink temperature T_K minus the Warning Limit Heat Sink Temp. 407 reached.
Α	00	10	Ti	Maximum inside temperature T_i minus the $\textit{Warning Limit Inside Temp.}$ 408 reached.
Α	00	20	Lim	The controller stated in <i>Controller Status</i> 275 limits the reference value.
Α	00	40	INIT	Frequency inverter is being initialized
Α	00	80	PTC	Warning behavior according to parameterized <i>Operation Mode Motor Temp</i> . 570 at maximum motor temperature T _{Motor} .
Α	01	00	Mains	Phase Supervision 576 reports a phase failure.
Α	02	00	PMS	Motor circuit breaker parameterized in <i>Operation Mode</i> 571 tripped.
Α	04	00	Flim	The <i>Maximum Frequency</i> 419 was exceeded. The frequency limitation is active.
Α	08	00	A1	The input signal MFI1A is lower than 1 V / 2 mA according to the operation mode for the <i>Error/Warning Behaviour</i> 453 .
Α	10	00	A2	The input signal MFI2A is lower than 1 V / 2 mA according to the operation mode for the <i>Error/Warning Behaviour</i> 563 .
Α	20	00	SYS	A slave on the system bus signals an error.
Α	40	00	UDC	The DC link voltage has reached the type-dependent minimum value.
Α	80	00	WARN2	In Application Warning State 367 , a warning is present.

Example:

The following warning status is displayed:

A008D Ixt IxtLt Tc PTC

The warning status results from the hexadecimal sum of the warning codes (0001+0004+0008+0080 = 008D).

The short-term overload (1 s), warning limit heat sink temperature and warning limit motor temperature warnings are present.

Output signals

Warnings are signaled via digital signals.

169 -	general warning	1)	Cianal if a massage is output via Warrings 240
11 -	General warning	2)	Signal if a message is output via Warnings 269 .

¹⁾ For linking to frequency inverter functions

²⁾For output via a digital output. Select the signal source for one of the parameters 531, 532, 533, 554. See chapter 7.6.5 "Digital outputs".



273 Application Warnings 367 Application warning status

Parameter Application Warnings 273 displays the current warning.

Parameter Application warning status **367** displays the warning at failure switch-off.

Meaning of code displayed by parameters *Application Warnings* **273** and *Application Warning State* **367**:

		Code	Warning status
A 00	00	NO WARNING	No warning message present.
A 00	01	BELT	Warning V-belt by Operation Mode 581.
A 00	40	SERVICE	 Service of DC link or fan required. The time remaining until next service has expired. At least for one of the parameters <i>Operation Mode Service Interval DC-link</i> 1534 or <i>Operation Mode Service Interval Fan</i> 1535 the setting "2 - Warning" is selected. Service of DC-link required. The value of <i>Service Interval DC-link</i> 1530 has reached the value 0%. Service of fan required. The value of <i>Service Interval Fan</i> 1531 has reached the value 0%.
A 00	80	User 1	The signal set on digital input <i>User Warning 1</i> 1363 is active.
A 01	00	User 2	The signal set on digital input <i>User Warning 2</i> 1364 is active.

Output signals

Application Warnings are signaled via digital signals.

216 - Wayning application	Signal if a message is output <i>Application Warnings</i> 273 .
26 - Warning, application	2) Signal if a message is output <i>Application warnings</i> 273 .

¹⁾For linking to frequency inverter functions

²⁾For output via a digital output. Select the signal source for one of the parameters 531, 532, 533, 554. See chapter 7.6.5 "Digital outputs".



15 Parameter list

The parameter list is structured according to the menu branches of the control software. The parameters are listed in ascending numerical order. A headline (shaded) can appear several times, i.e. a subject area may be listed at different places in the table.

- The parameter is available in the four data sets.
- ✓ The parameter value is set by the SETUP routine.
- The parameter cannot be written when the frequency inverter is in operation.

I_{FIN}, U_{FIN}, P_{FIN}: Nominal values of frequency inverter, o_c: Overload capacity of frequency inverter

15.1 Actual values (Menu Actual)

Actual value parameter							
No.	Description	Unit	Display range	Chapter			
	RS485/R	S232		1			
11	VABus SST Error Register	-	0 15	CM			
Actual values of machine							
<u>210</u>	Stator Frequency	Hz	0.00 999.99	9.2			
<u>211</u>	rms Current	Α	0.0 I _{max}	9.2			
<u>212</u>	Output Voltage	V	0.0 U _{FIN}	9.2			
<u>213</u>	Active Power	kW	0.0 P _{max}	9.2			
<u>214</u>	Active Current	Α	0.0 I _{max}	9.2			
<u>215</u>	<u>Isd</u>	Α	0.0 I _{max}	9.2			
<u>216</u>	<u>Isq</u>	Α	0.0 I _{max}	9.2			
<u>221</u>	Slip Frequency	Hz	0.0 999.99	9.2			
	Actual values of fre	quency in	verter				
<u>222</u>	DC-Link Voltage	V	0.0 U _{dmax} -25	9.1			
<u>223</u>	<u>Modulation</u>	%	0 100	9.1			
	Actual values	of machin	e	1			
<u>224</u>	<u>Torque</u>	Nm	± 9999.9	9.2			
<u>225</u>	Rotor Flux	%	0.0 100.0	9.2			
<u>226</u>	Winding Temperature	deg.C	0 999	9.2			
<u>227</u>	Act. Rotor Time Constant	ms	0 τ _{max}	9.2			
	Actual values of fre	quency in	verter	1			
<u>228</u>	Internal Reference Frequency	Hz	0.00 f _{max}	9.1			
<u>229</u>	Reference Percentage Value	%	± 300.00	9.1			
<u>230</u>	Actual Percentage Value	%	± 300.00	9.1			
	Actual value	memory					
<u>231</u>	Peak Value Long Term Ixt	%	0.00 100.00	9.4			
<u>232</u>	Peak Value Short Term Ixt	%	0.00 100.00	9.4			
	Actual values	of machin		1			
<u>235</u>	Flux-Forming Voltage	V	0.0 U _{FIN}	9.2			
<u>236</u>	<u>Torque-Forming Voltage</u>	V	0.0 U _{FIN}	9.2			
<u>238</u>	Absolute Flux Value	%	0.0 100.0	9.2			
<u>239</u>	Reactive Current	Α	0.0 I _{max}	9.2			
<u>240</u>	Actual Speed	1/min	0 60000	9.2			
<u>241</u>	Actual Frequency	Hz	0.0 999.99	9.2			
	Actual values of	f the syste					
<u>242</u>	Actual System Value	Hz	0.0 999.99	9.3.1			
	Actual values of fre	quency in	verter				
<u>243</u>	<u>Digital Inputs (Hardware)</u>	-	00 255	9.1			



	Actual value parameter					
No.	Description	Unit	Display range	Chapter		
<u>244</u>	Working Hours Counter	h	99999	9.1		
<u>245</u>	Operation Hours Counter	h	99999	9.1		
<u>246</u>	Capacitor Temperature	deg.C	0 T _{emax}	9.1		
<u>249</u>	Active Data Set	-	1 4	9.1		
<u>250</u>	<u>Digital Inputs</u>	-	00 255	9.1		
<u>251</u>	Analog Input MFI1A	%	± 100.00	9.1		
<u>252</u>	Repetition Frequency Input	Hz	0.0 999.99	9.1		
<u>253</u>	Analog Input MFI2A	%	± 100.00	9.1		
<u>254</u>	<u>Digital Outputs</u>	-	00 255	9.1		
<u>255</u>	Heat Sink Temperature	deg.C	0 T _{kmax}	9.1		
<u>256</u>	<u>Inside Temperature</u>	deg.C	0 T _{imax}	9.1		
<u>257</u>	Analog Output MFO1A	V	0.0 24.0	9.1		
<u>258</u>	PWM-Input	%	0.00 100.00	9.1		
<u>259</u>	Actual error	-	FXXXX	9.1		
260	Actual error	-	0 0xFFFF	CM		
<u>269</u>	Warnings	-	AXXXX	9.1		
270	Warnings	-	0 0xFFFF (bit-coded)	CM		
<u>273</u>	Application Warnings	-	AXXXX	9.1		
274	Application Warnings	-	0 0xFFFF (bit-coded)	CM		
<u>275</u>	Controller Status	-	CXXXX	9.1		
<u>277</u>	STO Status	-	XXXX	9.1		
<u>278</u>	Frequency MFO1F	Hz	0.00 f _{max}	9.1		
<u>282</u>	Reference Bus Frequency	Hz	-1000.00 1000.00	9.1		
<u>283</u>	Reference Ramp Frequency	Hz	0.00 999.99	9.1		

Note:

The parameters *Current error* **260**, *Warnings* **270** and *Application Warnings* **270** are only accessible Fieldbus. They cannot be accessed via the VPlus PC-Software or the Operator Panel.

No.	Description	Unit	Display range	Chapter				
	Actual value memory							
<u>287</u>	Peak Value Vdc	V	0.0 U _{dmax}	9.4				
<u>288</u>	Average Value Vdc	>	0.0 U _{dmax}	9.4				
<u>289</u>	Peak Value Heat Sink Temp.	deg.C	0 T _{kmax}	9.4				
<u>290</u>	Average Value Heat Sink Temp.	deg.C	0 T _{kmax}	9.4				
<u>291</u>	Peak Value Inside Temperature	deg.C	0 T _{imax}	9.4				
<u>292</u>	Average Value Inside Temperature	deg.C	0 T _{imax}	9.4				
<u>293</u>	Peak Value Iabs.	Α	0.0 o _c ·I _{FIN}	9.4				
<u>294</u>	Average Value Iabs	Α	0.0 o _c ·I _{FIN}	9.4				
<u>295</u>	Peak Value Active Power pos.	kW	0.0 o _c ·P _{FIN}	9.4				
<u>296</u>	Peak Value Active Power neg.	kW	0.0 o _c ·P _{FIN}	9.4				
<u>297</u>	Average Value Active Power	kW	0.0 o _c ·P _{FIN}	9.4				
<u>298</u>	Peak Value Capacitor Temp.	deg.C	0 T _{emax}	9.4				
<u>299</u>	Average Value Capacitor Temp.	deg.C	0 T _{emax}	9.4				
<u>301</u>	Energy positive	kWh	0 99999	9.4				
<u>302</u>	Energy negative	kWh	0 99999	9.4				
	Error list							
<u>310</u>	<u>Last error</u>	h:m; F	00000:00; FXXXX	13.1				
<u>311</u>	<u>Last Error but one</u>	h:m; F	00000:00; FXXXX	13.1				



	No.	Description	Unit	Display range	Chapter
	312	Error 3	h:m; F	00000:00; FXXXX	13.1
	313	Error 4	h:m; F	00000:00; FXXXX	13.1
	314	Error 5	h:m; F	00000:00; FXXXX	13.1
	315	Error 6	h:m; F	00000:00; FXXXX	13.1
	316	Error 7	h:m; F	00000:00; FXXXX	13.1
	317	Error 8	h:m; F	00000:00; FXXXX	13.1
	318	Error 9	h:m; F	00000:00; FXXXX	13.1
	319	Error 10	h:m; F	00000:00; FXXXX	13.1
	320	Error 11	h:m; F	00000:00; FXXXX	13.1
	321	Error 12	h:m; F	00000:00; FXXXX	13.1
	322	Error 13	h:m; F	00000:00; FXXXX	13.1
	323	Error 14	h:m; F	00000:00; FXXXX	13.1
	324	Error 15	h:m; F	00000:00; FXXXX	13.1
	325	Error 16	h:m; F	00000:00; FXXXX	13.1
l		Error envir	<u> </u>		
7	330	DC-Link Voltage	V	0.0 U _{dmax}	13.2
	<u>331</u>	Output Voltage	V	0.0 U _{FIN}	13.2
a	<u>332</u>	Stator Frequency	Hz	0.00 999.99	13.2
a	335	Phase current Ia	Α	0.0 I _{max}	13.2
	<u>336</u>	Phase current Ib	Α	0.0 I _{max}	13.2
=	337	Phase current Ic	Α	0.0 I _{max}	13.2
a	<u>338</u>	rms Current	Α	0.0 I _{max}	13.2
\exists	<u>339</u>	Isd / Reactive Current	Α	0.0 I _{max}	13.2
7	<u>340</u>	Isq / Active Current	Α	0.0 I _{max}	13.2
	<u>341</u>	Rotor Magnetizing Current	Α	0.0 I _{max}	13.2
Ħ	<u>342</u>	<u>Torque</u>	Nm	± 9999.9	13.2
8	<u>343</u>	Analog Input MFI1A	%	± 100.00	13.2
\exists	<u>344</u>	Analog Input MFI2A	%	± 100.00	13.2
	<u>346</u>	Analog Output MFO1A	V	0.0 24.0	13.2
	<u>348</u>	DC-link Cap. Temperature	deg.C	0 T _{emax}	13.2
=	<u>349</u>	Repetition Frequency Output	Hz	0.00 999.99	13.2
	<u>350</u>	Status of Digital Inputs	-	00 255	14.1
\blacksquare	<u>351</u>	Status of Digital Outputs	-	00 255	14.1
\blacksquare	<u>352</u>	<u>Time since Release</u>	h:m:s.ms	00000:00:00.000	13.2
7	<u>353</u>	<u>Heat Sink Temperature</u>	deg.C	0 T _{kmax}	13.2
\exists	<u>354</u>	Inside Temperature	deg.C	0 T _{imax}	13.2
7	<u>355</u>	<u>Controller Status</u>	-	C0000 CFFFF	13.2
\blacksquare	<u>356</u>	Warning Status	-	A0000 AFFFF	14.3
Ħ	<u>357</u>	Int. Value 1	-	± 32768	13.2
	<u>358</u>	Int. Value 2	-	± 32768	13.2
=	<u>359</u>	Long Value 1	-	± 2147483647	13.2
=	<u>360</u>	Long Value 2	-	± 2147483647	13.2
7	<u>361</u>	Checksum	-	OK / NOK	13.2
		Error	list		
	<u>362</u>	No. of Errors	-	0 32767	13.1
	<u>363</u>	No. of self acknowledged Errors	-	0 32767	13.1
		Error envir	onment	1.000	
7	<u>367</u>	Application Warning State	-	A0000 AFFFF	14.3



No.	Description	Unit	Display range	Chapter			
	Bus controller						
411	Status Word	-	0 0xFFFF	7.3.1 9.7 CM			
	Position	ning					
<u>470</u>	Revolutions	U	$0.000 \dots 1.10^6$	9.1			
	Digital ou	itputs					
<u>537</u>	Actual Warning Mask	-	AXXXXXXX	7.6.5.8			
<u>627</u>	Actual Appl. Warning Mask	-	AXXXX	7.6.5.9			
	Auto se	t-up					
<u>797</u>	SETUP Status	-	OK/NOK	6.8			
	System	bus					
<u>978</u>	Node-State	-	1 3	9.5 Systemb.			
<u>979</u>	<u>CAN-State</u>	-	1 3	9.5 Systemb.			
	CAN b	us					
<u>1290</u>	Node-State	-	0 127	9.6 CM-CAN			
1291	<u>CAN-State</u>	-	0 4	9.6 CM-CAN			
	CAN b	us					
<u>1431</u>	Module Info	-		9.8 Ethernet			
Service ¹							
<u>1530</u>	Service Interval DC-link	%	0 100	10.3.1			
<u>1531</u>	Service Interval Fan	%	0 100	10.3.2			
<u>1533</u>	Maintenance Note	%	M	10.3.3			
	Device :	test					
<u>1541</u>	Device test status	-	T	7.2.3 9.1			

The column "chapter" refers to the chapter number and/or the corresponding document, that contains a detailed parameter description.

CM: Please refer to the manual of the used communication profile.

CM-CAN: Please refer to the **CAN** communication manual.

CM-PDPV1: Please refer to the **PROFIBUS** communication manual. Please refer to the **VABus** communication manual. Please refer to the **Modbus** communication manual. Systembus: Please refer to the **Systembus** communication manual.

Ethernet: Please refer to the **Ethernet** communication manual (i.e. Profinet, VABus/TCP,

Modbus TCP).

¹ For maintenance work contact the service of BONFIGLIOLI.



15.2 Parameters (Menu PARA)

	Paramete	1		0
No.	Description	Unit	Setting range	Chapter
0	Serial Number	ata -	Characters	7.1
1		 	Characters	7.1
<u></u>	R\$485/R\$	232	Characters	/.1
10	CM: VABus Baud Rate	-	Selection	CM-CAN
	Inverter d	ata		
<u>12</u>	<u>Inverter Software Version</u>	-	Characters	7.1
<u>15</u>	Copyright	-	Characters	7.1
<u>16</u>	Power Module Software Version	-	Characters	7.1
<u>27</u>	<u>Set Password</u>	-	0 999	7.1.3
<u>28</u>	Control Level	-	1 3	7.1.1
<u>29</u>	<u>User Name</u>	-	32 characters	7.1
<u>30</u>	<u>Configuration</u>	-	Selection	7.1.2
<u>34</u>	Program(ming)	-	0 9999	7.1.4
	Fan			
<u>39</u>	Switch-On Temperature	deg.C	0 60	7.10.2
	Traverse fur	nction		
<u>48</u>	<u> </u>	-	Selection	7.10.8
1	Digital inp	uts		
<u>49</u>		-	Selection	7.6.6.12
<u>62</u>		-	Selection	7.5.3.3.1
<u>63</u>	<u>Frequency Motorpoti Down</u>	-	Selection	7.5.3.3.1
<u>66</u>	Fixed Frequency Change-Over 1	-	Selection	7.6.6.5, 7.5.1.3
<u>67</u>	Fixed Frequency Change-Over 2	-	Selection	7.6.6.5, 7.5.1.3
<u>68</u>	Start Clockwise	-	Selection	7.6.6.2
<u>69</u>	Start Anticlockwise	-	Selection	7.6.6.2
<u>70</u>	Data Set Change-Over 1	-	Selection	7.6.6.11
71	Data Set Change-Over 2	-	Selection	7.6.6.11
<u>72</u>		-	Selection	7.5.3.3.2
73	Percent Motorpoti Down	-	Selection	7.5.3.3.2
<u>75</u>	Fixed Percent Change-Over 1	-	Selection	7.6.6.6
<u>76</u>	Fixed Percent Change-Over 2	-	Selection	7.6.6.6
81	JOG Start		Selection	7.5.1.6
87	Start 3-Wire Ctrl.	-	Selection	0
95	Brake Chopper Release	-	Selection	7.6.6.13
103		-	Selection	7.6.6.8
	Electronic	gear		
<u>125</u>	Source Master Reference	-	Selection	7.5.4
	Digital inp	uts		
<u>131</u>	Fixed Frequency Change-Over 3	-	Selection	7.6.6.5, 7.5.1.3
	Digital inp	uts		
<u>164</u>		-	Selection	7.6.6.10
<u>183</u>		-	Selection	7.6.6.15
204	Thermal contact for P570	_	Selection	7.6.6.9



	ı		Paramete	rs		
		No.	Description	Unit	Setting range	Chapter
			Actual value m	emory		
		<u>237</u>	Reset Memory	-	Selection	9.4
			CANopen/CAN sy	stem bu	S	
		276	CAN Interface (CM-CAN/X12)	-	Selection	6.2.10.2
			• • • • • • • • • • • • • • • • • • • •			CM-CAN
		270	Rated motor par			7 2 1
			Rated Voltage	V	0.17·U _{FIN} 2·U _{FIN}	7.2.1 7.2.1
	_	<u>371</u>		A U/min	0.01·I _{FIN} 10· O _C ·I _{FIN}	7.2.1
			Rated Speed	U/IIIII	30 60000	-
\checkmark	8		No. of Pole Pairs Pated Cosine Phi	-	1 24 0.01 1.00	7.2.1
			Rated Cosine Phi			7.2.1 7.2.1
			Rated Frequency	Hz	10.00 1000.00	
	Ħ	3/0	Rated Mech. Power	kW	0.1·P _{FIN} 10·P _{FIN}	7.2.1
. /	a	377	Further motor pa Stator Resistance	mOhm	0 65535	7.2.2
✓ ✓			<u>Leakage Coeff.</u>	%	1.0 20.0	7.2.2
V				mVmin		7.2.2
			Voltage Constant States Industance	mH	0.0 6500.0	7.2.2
		<u> 384</u>	Stator Inductance CAN bus		0.1 500.0	7.2.2
						6.2.10.2
		<u>385</u>	<u>CAN Baud Rate</u>	-	Selection	CM-CAN
		207	CANAN I N I		4 427	6.2.10.2
		<u>387</u>	<u>CAN Node Number</u>	-	-1 127	CM-CAN
		388	Error Behaviour	-	Selection	CM-CAN
			System da	ta		
		<u>389</u>	Factor Actual System Value	-	-100.000 100.000	7.10.9
	Ī		Profibus			
		391	Profibus Node-ID	-	0126	6.2.10.2
			Bus contro	llor		CM-PDPV1
		302	State transition 5	liei _	Selection	CM
		332	R\$485/R\$2	22	Selection	CIT
		394	VABus-CM Node-ID	-	1 30	6.2.10.2
			Protocol (CM/X21)	_	Selection	CM-485
		<u> </u>	Pulse width mod	dulation	Selection	0
		400	Switching Frequency	-	Selection	7.10.1
		401	Min. Switching Frequency	-	Selection	7.10.1
	ı		Error/warning b	ehavior		
		405	Warning Limit Short Term Ixt	%	6 100	7.4.1
		406	Warning Limit Long Term Ixt	%	6 100	7.4.1
		407	Warning Limit Heat Sink Temp.	deg.C	-25 0	7.4.2
		408	Warning Limit Inside Temp.	deg.C	-25 0	7.4.2
		409	Controller-Status Message	-	Selection	7.4.3
			Bus contro	ller		
		410	Control Word	-	0 0xFFFF	7.2.1
		<u>411</u>	Status Word	-	0 0xFFFF	7.3.1 CM
		<u>412</u>	<u>Local/Remote</u>	-	Selection	l CIVI
			RS485/RS2	232		,
		413	VABus-CM Watchdog Timer	S	0 1000	CM-485
			Special functions/data	set chan	Y .	_
		414	Data Set Selection	-	Selection	CM



Parameters						
		No.	Description	Unit	Setting range	Chapter
			Error/warning b	ehavior		
		<u>417</u>	Frequency Switch-off Limit	Hz	0.00 999.99	7.4.4
			Frequency Li	imits		<u> </u>
\checkmark	<i>⊠</i>	<u>418</u>	Minimum Frequency	Hz	0.00 999.99	7.5.1.1
√	<i>∃</i>	<u>419</u>	Maximum Frequency	Hz	0.00 999.99	7.5.1.1
			Frequency ra			
		<u>420</u>	Acceleration (Clockwise)	Hz/s	0.00 9999.99	7.5.1.4
		<u>421</u>	<u>Deceleration (Clockwise)</u>	Hz/s	-0.01 9999.99	7.5.1.4
		<u>422</u>	Acceleration Anticlockwise	Hz/s	-0.01 9999.99	7.5.1.4
		<u>423</u>	<u>Deceleration Anticlockwise</u>	Hz/s	-0.01 9999.99	7.5.1.4
		<u>424</u>	Emergency Stop Clockwise	Hz/s	0.01 9999.99	7.5.1.4
		<u>425</u>	Emergency Stop Anticlockwise	Hz/s	0.01 9999.99	7.5.1.4
		<u>426</u>	<u>Maximum Leading</u>	Hz	0.01 999.99	7.5.1.4
		<u>430</u>	Ramp Rise Time	ms	0 10000	7.5.1.4
		40-	Traverse fun			
		435	Operation Mode	-	Selection	7.10.8
		<u>436</u>	Ramp-up Time	S	0.01 320.00	7.10.8
		437	Ramp-down Time	S	0.01 320.00	7.10.8
			<u>Traverse Amplitude</u>	%	0.01 50.00	7.10.8
		<u>439</u>	<u>Proportional Step</u>	%	0.01 50.00	7.10.8
			PID controller (technol	ogy con	troller)	<u> </u>
	Ħ	<u>440</u>	Operation Mode Actual Value Failure	-	Selection	7.9.3
		<u>441</u>	Max. I-component	Hz	0.00 999.99	7.9.3
		<u>442</u>	<u>Maximum Frequency</u>	Hz	0.00 999.99	7.9.3
		<u>443</u>	Minimum Frequency	Hz	-999.99 0.00	7.9.3
		<u>444</u>	<u>Amplification</u>	-	-15.00 15.00	7.9.3
			<u>Integral Time</u>	ms	0 32767	7.9.3
	\exists	<u>446</u>	<u>Derivative Time</u>	ms	0 1000	7.9.3
		447	Reference frequency channel			7545
		447	1st Blocking Frequency	Hz	0.00 999.99	7.5.1.5
	<u>=</u>		2nd Blocking Frequency	Hz	0.00 999.99	7.5.1.5
		449	<u>Frequency Hysteresis</u>	Hz	0.00 100.00	7.5.1.5
		450	Multifunction inpu			76112
	Ħ	450	Tolerance Band	%	0.00 25.00	7.6.1.1.2
		451	Filter Time Constant Operation Mode MFI1	ms	Selection Selection	7.6.1.1.3 7.6.1
				-		7.6.1.3
	回	453	Characteristic Curve Point V1	- 0/	Selection	+
	8	454		% %	0.00 100.00 -100.00 100.00	7.6.1.1.2
	8	455 456	Characteristic Curve Point Y1	% %	0.00 100.00	7.6.1.1.2
	8					7.6.1.1.2
	Ħ	<u>457</u>	Characteristic Curve Point Y2	%	-100.00 100.00	7.6.1.1.2
		450	Positionir Operation Mode	-	Selection	7.3.7
			Signal Source	_	Selection	7.3.7
		460	Positioning Distance	U	0.000 1 10 ⁶	7.3.7
		461	Signal Correction		-327.68 327.67	7.3.7
		462	Load Correction	ms -	-32768 32767	7.3.7
			Activity after Positioning	-	Selection	7.3.7
			Waiting Time		0 3.6 10 ⁶	7.3.7
		404	<u>waiting rime</u>	ms	0 3.0 10	/.3./



		Paramete	rs		
	No.	Description	Unit	Setting range	Chapter
Ī		Motor potentic		T =	
		Ramp Frequency-Motorpoti	Hz/s	0.01 999.99	7.5.3.3.1
	<u>474</u>	Operation Mode	-	Selection	7.5.3
Г		Frequency referen	ce chanr		
	<u>475</u>	Reference Frequency Source 1	-	Selection	7.5.1
		Reference percenta			
	<u>476</u>	Reference Percentage Source 1	-	Selection	7.5.2
	4	Ref. perc. val. chai			7524
	<u>477</u>	Gradient Percentage Ramp	%/s	0 60000	7.5.2.4
	4-0	PID controller (technol	ogy con		7.00
	4/8	Actual Percentage Source	-	Selection	7.9.3
	400	Fixed frequer		000.00	7542
		Fixed Frequency 1	Hz	-999.99 999.99	7.5.1.3
		<u>Fixed Frequency 2</u>	Hz	-999.99 999.99	7.5.1.3
Ħ		<u>Fixed Frequency 3</u>	Hz	-999.99 999.99	7.5.1.3
		<u>Fixed Frequency 4</u>	Hz	-999.99 999.99	7.5.1.3
	484	Reference Frequency RAM	Hz	-999.99 999.99	CM
7		<u>Fixed Frequency 5</u>	Hz	-999.99 999.99	7.5.1.3
7	<u>486</u>	Fixed Frequency 6	Hz	-999.99 999.99	7.5.1.3
=	<u>487</u>	Fixed Frequency 7	Hz	-999.99 999.99	7.5.1.3
a	<u>488</u>	Fixed Frequency 8	Hz	-999.99 999.99	7.5.1.3
•	489	JOG Frequency	Hz	-999.99 999.99	7.5.1.6
L		Frequency reference	ce chanr	nel	
7	492	Reference Frequency Source 2	-	Selection	7.5.1
a	493	Operation Mode	-	Selection	7.5.1.2
		Reference percenta	ge chan		
a	494	Reference Percentage Source 2	-	Selection	7.5.2
a	495	Operation Mode	-	Selection	7.5.2.2
[PWM input/repetition freque	ncy inpu	it/pulse train	
\otimes	496	Operation mode IN2D	-	Selection	7.6.7
		Repetition freque	ncy inpu	ıt	
\otimes	497	Rep.Freg.: Divider	-	1 8192	7.6.7.2
		Brake Chop	per		
	506	Trigger Threshold	V	AGL202: 225.0 1000.0	7.10.4
	<u>500</u>		-	AGL402: 325.0 1000.0	7.10.1
		Motor chop		AGL202: 225.0 1000.0	
	<u>507</u>	<u>Trigger Threshold</u>	V	AGL402: 325.0 1000.0	7.10.5
		Motor potentic	meter		
	<u>509</u>	Ramp Percentage-Motorpoti	%/s	0.00 600.00	7.5.3.3.2
Ī		Digital outp	uts		
	<u>510</u>	Setting Frequency	Hz	0.00 999.99	7.6.5.2
	517	Setting Frequency Switch Off Del-	Hz	0.00 999.99	7.6.5.2
	517	<u>ta</u>		0.00 555.55	7.0.5.2
		Percentage valu			
a	<u>518</u>	Minimum Reference Percentage	%	0.00 300.00	7.5.2.1
	<u>519</u>	Maximum Reference Percentage	%	0.00 300.00	7.5.2.1
		Fixed percent			
	<u>520</u>	<u>Fixed Percentage 1</u>	%	-300.00 300.00	7.5.2.3
Ħ	<u>521</u>	<u>Fixed Percentage 2</u>	%	-300.00 300.00	7.5.2.3
	<u>522</u>	<u>Fixed Percentage 3</u>	%	-300.00 300.00	7.5.2.3
\blacksquare	<u>523</u>	<u>Fixed Percentage 4</u>	%	-300.00 300.00	7.5.2.3
	524	Reference Percentage RAM	%	-300.00 300.00	CM
L					



	No.	Description	Unit	Setting range	Chapter
	529	Actual Percentage RAM	%	-300.00 300.00	CM
		Digital outp	outs		
	<u>531</u>	Op. Mode OUT1D (X13.5)	-	Selection	7.6.5
	<u>532</u>	Op. Mode OUT2D (X10/Relay)	-	Selection	7.6.5
	533	Op. Mode OUT3D (X11.6)	-	Selection	7.6.5
		Error/warning k	ehavior		
	<u>535</u>	Op. Mode ext. Error	-	Selection	7.4.5
	<u>536</u>	Create Warning Mask	-	Selection	7.6.5.8
		Digital outp	outs		
	<u>549</u>	Reference Value Reached: Toler-	%	0.01 20.00	7.6.5.3
	313	ance Band			7.0.5.5
		Multifunction outpu			
	<u>550</u>	Operation Mode MFO1 (X13.6)	-	Selection	7.6.3
		Analog: Voltage 100%	V	0.0 22.0	7.6.3
	<u>552</u>	Analog: Voltage 0%	V	0.0 22.0	7.6.3
		Analog: Source MFO1A	-	Selection	7.6.3
		Digital: Source MFO1D	-	Selection	7.6.3
		RF/PT: Output Value MFO1F	-	Selection	7.6.3
\otimes		RF: Division Marks	-	30 8192	7.6.3
	<u>557</u>		-	0 32000	7.6.3
ī		Digital input/	output		
		Operation Mode Terminal X11.6	-	Selection	7.6.4
	<u>559</u>	<u>Digital Inputs PNP/NPN</u>	-	Selection	7.6.6
i		Multifunction inpu	it 2 (MFI		
	<u>560</u>	<u>Tolerance Band</u>	%	0.00 25.00	7.6.2.1.2
		Filter Time Constant	-	Selection	7.6.2.1.3
	<u>562</u>	Operation Mode MFI2	-	Selection	7.6.2
	<u>563</u>	Error/Warning Behaviour	-	Selection	7.6.2.1.3
ð	<u>564</u>	Characteristic Curve Point X1	%	0.00 100.00	7.6.2.1.2
	<u>565</u>	<u>Characteristic Curve Point Y1</u>	%	-100.00 100.00	7.6.2.1.2
	<u>566</u>	<u>Characteristic Curve Point X2</u>	%	0.00 100.00	7.6.2.1.2
Ħ	<u>567</u>	Characteristic Curve Point Y2	%	-100.00 100.00	7.6.2.1.2
		Error/warning k	ehavior		
	<u>570</u>	Operation Mode Motor Temp.	-	Selection	7.4.6
		Motor Protection	ction	I = 1 ···	
	<u>571</u>	Operation Mode	-	Selection	7.10.6.1
Ħ	<u>572</u>	<u>Frequency Limit</u>	%	0 300	7.10.6.1
	F72	Intelligent curre	ent limits		701
	<u>573</u>	Operation Mode	- 0/	Selection	7.9.1
		Power Limit	%	40.00 95.00	7.9.1
Ħ	<u>5/5</u>	<u>Limitation Time</u>	min	5 300	7.9.1
	F76	Error/warning k	penavior 	Calaatian	747
a	<u>576</u>	Phase Supervision	-	Selection	7.4.7
	<u>578</u>	Allowed No. of Auto-Acknowl.	-	0 20	7.4.8
	<u>579</u>	-	ms	0 1000	7.4.8
	F00	Pulse width mo	1	25 0	7 10 1
	<u>580</u>	Reduction Limit Ti/Tc	deg.C	-25 0	7.10.1
a	581	V-belt monit	oring -	Selection	7.10.7
	582	Trigger Limit Iactive	%	0.1 100.0	7.10.7
	583	Delay Time		0.1 600.0	7.10.7
	<u>303</u>	Delay Time	S	0.1 000.0	/.10./



			Paramete	rs		
		No.	Description	Unit	Setting range	Chapter
		600	V/f characte		0.0 100.0	77
√			Starting Voltage	V	0.0 100.0	7.7
√			Voltage Rise	%	-100 200	7.7
√	<i>a</i>		Rise Frequency	%	0 100 AGL202: 30.0 280.0	
\checkmark		<u>603</u>	<u>Cut-Off Voltage</u>	V	AGL402: 60.0 560.0	7.7
V		<u>604</u>	<u>Cut-Off Frequency</u>	Hz	0.00 999.99	7.7
		<u>605</u>	Dyn. Voltage Pre-Control	%	0 200	7.8.1
		<u>606</u>	Type V/f characteristic	-	Selection	7.7
			I ² t Monitor	ing		, ,
			<u>Thermal Time Constant Motor</u>	min	1 240	7.10.6.2
		<u>609</u>	<u>Thermal Time Constant Rotor</u>	S	1 600	7.10.6.2
_	_		Current limit value	control		1
\checkmark	<u>=</u>	<u>610</u>		-	Selection	7.9.4.2
	=		Amplification	-	0.01 30.00	7.9.4.2
	=		<u>Integral Time</u>	ms	1 10000	7.9.4.2
		<u>613</u>		Α	0.0 o _c ·I _{FIN}	7.9.4.2
\checkmark		<u>614</u>	Frequency Limit	Hz	0.00 999.99	7.9.4.2
			I ² t Monitor		T	
		615	Warning Limit Motor I ² t	%	6 100	7.10.6.2
		616	PID controller (technol			702
		<u>616</u>	Backlash Motor Power of	-	Selection	7.9.3
		617	Error/warning b Max. Temp. Motor Winding	°C	0 200	7.4.6
		017	PID controller (technol			7.4.0
		618	Backlash	%	0.00 30.00	7.9.3
		010	Starting beh	_	0.00 50.00	7.5.5
✓		620		-	Selection	7.3.2
			Amplification	-	0.01 10.00	7.3.2
			Integral Time	ms	1 30000	7.3.2
√			Starting Current	Α	0.0 o _c ·I _{FIN}	7.3.2
√			Frequency Limit	Hz	0.00 100.00	7.3.2
			Brake Release Time	ms	-5000 5000	7.3.2
		<u> </u>	Warning appli			
		626	Create Appl. Warning Mask	-	Selection	7.6.5.9
			Stopping beh	avior		
	\blacksquare	<u>630</u>	Operation Mode	-	Selection	7.3.3
			Direct current	brake		, ,
V	Ħ	<u>631</u>	Braking Current	Α	0.00 √2·I _{FIN}	7.3.6
	\exists	<u>632</u>	Braking Time	S	0.0 200.0	7.3.6
\checkmark		<u>633</u>	Demagnetizing Time	S	0.1 30.0	7.3.6
	Ħ	<u>634</u>		-	0.00 10.00	7.3.6
		<u>635</u>	<u>Integral Time</u>	ms	0 1000	7.3.6
			Stopping beh	avior		
		<u>637</u>	Switch-Off Threshold Stop Func-	%	0.0 100.0	7.3.3
			tion Holding Time Stop Function		0.0 200.0	
	=	<u>638</u>	Holding Time Stop Function Flying Sta	S	0.0 200.0	7.3.3
		645		-	Selection	7.3.5
		<u>UTJ</u>	Auto star		Jeiection	7.5.5
		651	Operation Mode	-	Selection	7.3.4
			PWM inpu	ut		
		652		%	-100.00 100.00	7.6.7.1
			1	· -		ı



			Paramete	rs		
		No.	Description	Unit	Setting range	Chapter
		<u>653</u>	PWM-Amplification	%	5.0 1000.0	7.6.7.1
			Pulse trai	n		
		<u>654</u>	<u>Pulse Train Scaling Frequency</u>	-	0 32000	7.6.7.3
_	_		Slip compens	ation	T	
\checkmark		<u>660</u>	Operation Mode	-	Selection	7.9.4.1
		<u>661</u>	Amplification	%	0.0 300.0	7.9.4.1
		<u>662</u>	Max. Slip Ramp	Hz/s	0.01 650.00	7.9.4.1
		<u>663</u>		Hz	0.01 999.99	7.9.4.1
		670	Voltage conti	roller	C 1 1:	702
	Ħ	<u>670</u>	Operation Mode	-	Selection	7.9.2
		<u>671</u>	Mains Failure Threshold	V	-200.050.0	7.9.2
		672	Reference Mains Support Value	V	-200.010.0	7.9.2
		673		Hz/s	0.01 9999.99	7.9.2
		<u>674</u>	Acceleration on Mains Resumption	Hz/s	0.00 9999.99	7.9.2
		<u>675</u>	Shutdown Threshold	Hz	0.00 999.99 AGL202: 225.0 387.5	7.9.2
		<u>676</u>	Reference Shutdown Value	V	AGL402: 325.0 775.0	7.9.2
		<u>677</u>	<u>Amplification</u>	-	0.00 30.00	7.9.2
		<u>678</u>	<u>Integral Time</u>	ms	0 10000	7.9.2
		680	Reference DC-Link Limitation	V	AGL202: 225.0 387.5	7.9.2
		681	Max. Frequency Rise	Hz	AGL402: 325.0 775.0 0.00 999.99	7.9.2
		683		A	0.00 o _c ·I _{FIN}	7.9.2
		003	Electronic g		0.0 O _C ·1FIN	7.5.2
		685		-	-300.00 300.00	7.5.4.3.1
		686	Gear Factor Denominator	-	0.01 300.00	7.5.4.3.1
		687	Analog factor at 100%	-	0.00 100.00	7.5.4.3.2
		688		-	0.00 100.00	7.5.4.3.2
		689	Operation Mode	-	Selection	7.5.4.2
			Current conti	roller		-
V		700	Amplification	-	0.00 8.00	7.9.5.1
\checkmark		701	<u>Integral Time</u>	ms	0.00 10.00	7.9.5.1
			Further motor pa			
✓		<u>716</u>	Rated magnetising current	Α	$0.01 \cdot I_{FIN} \dots o_c \cdot I_{FIN}$	7.2.2
			Field contro	ller		
\checkmark	\exists	<u>717</u>		%	0.01 300.00	7.9.5.5
_	_		Further motor pa		•	
\checkmark		<u>718</u>	Rated Slip Correction Factor	%	0.01 300.00	7.2.2
		740	Frequency Li		10000	7544
		<u>/19</u>	Slip Frequency	%	0 10000	7.5.1.1
		720	Speed contro	oller	Coloction	7053
		720 721	Operation Mode Amplification 1(f <p738)< td=""><td>-</td><td>Selection 0.00 200.00</td><td>7.9.5.3 7.9.5.3</td></p738)<>	-	Selection 0.00 200.00	7.9.5.3 7.9.5.3
\checkmark				- mc		7.9.5.3
. /		722	Integral Time 1(f <p738)< td=""><td>ms</td><td>0 60000</td><td> </td></p738)<>	ms	0 60000	
✓			Amplification 2(f >P738)	- mc	0.00 200.00	7.9.5.3 7.9.5.3
	7	<u>/24</u>	Integral Time 2(f >P738) Acceleration pre	ms -control	0 60000	7.3.3.3
		725	Operation Mode		Selection	7.9.5.4
			Minimum Acceleration	Hz/s	0.1 6500.0	7.9.5.4
		727	Mech. Time Constant	ms	1 60000	7.9.5.4
	ائے	121	Speed control		1 III 00000	7.5.5.7
		728		A	0.0 o _c ·I _{FIN}	7.9.5.3.1
			Current Limit Generator Op.	A	-0.01 O _C ·I _{FIN}	7.9.5.3.1
	ت	125	Carrone Entire Generator Opt		1 3131 III OC TFIN	, . , . , . ,



			Paramete	rs		
		No.	Description	Unit	Setting range	Chapter
	\blacksquare	<u>730</u>	<u>Torque Limit</u>	%	0.00 650.00	7.9.5.3.1
		<u>731</u>	Torque Limit Generator Operation	%	0.00 650.00	7.9.5.3.1
		<u>732</u>	P-Comp. Torque Upper Limit	%	0.00 650.00	7.9.5.3.1
	arraycolorginal	<u>733</u>	P-Comp. Torque Lower Limit	%	0.00 650.00	7.9.5.3.1
	arraycolorginal	<u>734</u>	<u>Isq Limit Source Motor Op.</u>	-	Selection	7.9.5.3.2
	\blacksquare	<u>735</u>	<u>Isq Limit Source Generator Op.</u>	-	Selection	7.9.5.3.2
	\blacksquare	<u>736</u>	Torque Limit Source Motor Op.	-	Selection	7.9.5.3.2
	\blacksquare	<u>737</u>	Torque Limit Source Gen. Op.	-	Selection	7.9.5.3.2
✓	\Rightarrow	<u>738</u>	Speed Control Switch-Over Limit	Hz	0.00 999.99	7.9.5.3
	=	<u>739</u>	Power Limit	kW	0.00 2· o _c ·P _{FIN}	7.9.5.3.1
	\exists	<u>740</u>	Power Limit Generator Operation	kW	0.00 2· o _c ·P _{FIN}	7.9.5.3.1
	_		Field contro	ller	Ta a	
_		<u>741</u>	Amplification	-	0.0 100.0	7.9.5.5
✓		<u>742</u>		ms	0.0 1000.0	7.9.5.5
✓		<u>743</u>		Α	0.0 o _c ·I _{FIN}	7.9.5.5.1
✓		<u>744</u>		Α	-I _{FIN} I _{FIN}	7.9.5.5.1
		746	Current conti		0.00 200.00	7051
		<u>/46</u>	Cross-Coupling Factor	%	0.00 300.00	7.9.5.1
	a	7/10	Speed control Backlash Damping	%	0 300	7.9.5.3
		<u>/40</u>	Modulation cor		10 300	7.9.5.5
		750	Reference Modulation	%	3.00 105.00	7.9.5.6
		752	Integral Time	ms	0.0 1000.00	7.9.5.6
		<u>752</u>	Operation Mode	-	Selection	7.9.5.6
		755		Α	0.01·I _{FIN} o _c ·I _{FIN}	7.9.5.6.1
		756		%	0.00 100.00	7.9.5.6.1
		700	Torque contr		0.00 III 100.00	713131011
		<u>767</u>	Frequency Upper Limit	Hz	-999.99 999ohne.99	7.9.5.2
		768	Frequency Lower Limit	Hz	-999.99 999.99	7.9.5.2
			Frequency upper limit source	-	Selection	7.9.5.2.3
		770	Frequency lower limit source	-	Selection	7.9.5.2.3
			Starting beha	avior		
		<u>779</u>	Min. Flux-Formation Time	ms	1 10000	7.3.2
✓		<u>780</u>	Max. Flux-Formation Time	ms	1 10000	7.3.2
✓		<u>781</u>	Current during Flux-Formation	Α	$0.1 \cdot I_{\text{FIN}} \dots o_c \cdot I_{\text{FIN}}$	7.3.2
			Auto set-u	ıp qı		
		<u>796</u>	SETUP Selection	-	Selection	6.8
			System bu	JS		62102
		<u>900</u>	Node-ID	-	-1 63	6.2.10.2 Systemb.
						6.2.10.2
		<u>903</u>	Baud-Rate	-	Selection	Systemb.
		904	Boot-Up Delay	ms	3500 50000	
		918	1 /	-	0 2047	1
			SYNC-Time	ms	0 50000	1
		921	RxSDO1-Identifier	-	0 2047	1 _
		922	TxSD01-Identifier	-	0 2047	Systemb.
		923		-	Selection	1
		924		-	0 2047	1
		925		-	0 2047	1
			= = = =================================	1		ا



No. Description Unit 9 926 RxPDO2 Identifier - 927 TxPDO2 Identifier - 928 RxPDO3 Identifier - 929 TxPDO3 Identifier - 930 TxPDO1 Function - 931 TxPDO1 Time ms 932 TxPDO2 Function -	Setting range Chapter 0 2047 0 2047 0 2047 0 2047 0 2047 Selection 0 50000 0 50000
927 TxPDO2 Identifier - 928 RxPDO3 Identifier - 929 TxPDO3 Identifier - 930 TxPDO1 Function - 931 TxPDO1 Time ms	0 2047 0 2047 0 2047 Selection 0 50000
928 RxPDO3 Identifier - 929 TxPDO3 Identifier - 930 TxPDO1 Function - 931 TxPDO1 Time ms	0 2047 0 2047 Selection 0 50000
929 TxPDO3 Identifier - 930 TxPDO1 Function - 931 TxPDO1 Time ms	0 2047 Selection 0 50000
930 TxPDO1 Function - 931 TxPDO1 Time ms	Selection 0 50000
931 TxPDO1 Time ms	0 50000
932 TxPDO2 Function -	C L II
	Selection
933 TxPDO2 Time ms	0 50000
934 TxPDO3 Function -	Selection
935 TxPDO3 Time ms	0 50000
936 RxPDO1 Function -	Selection
937 RxPDO2 Function -	Selection
938 RxPDO3 Function -	Selection
939 SYNC Timeout ms	0 60000
941 RxPDO1 Timeout ms	0 60000
	0 60000
	0 60000
	Selection
946 TxPDO1 Boolean1 -	Selection
947 TxPDO1 Boolean2 -	
948 TxPDO1 Boolean3 -	Selection
949 TxPDO1 Boolean4 -	Selection
950 TxPDO1 Word1 -	Selection
951 TxPDO1 Word2 -	Selection
952 TxPDO1 Word3 -	Selection
953 TxPDO1 Word4 -	Selection
954 TxPDO1 Long1 -	Selection
955 TxPDO1 Long2 -	Selection
956 TxPDO2 Boolean1 -	Selection
957 TxPDO2 Boolean2 -	Selection
958 TxPDO2 Boolean3 -	Selection
959 TxPDO2 Boolean4 -	Selection
960 TxPDO2 Word1 -	Selection
961 TxPDO2 Word2 -	Selection
962 TxPDO2 Word3 -	Selection
963 TxPDO2 Word4 -	Selection
964 TxPDO2 Long1 -	Selection
965 TxPDO2 Long2 -	Selection
966 TxPDO3 Boolean1 -	Selection
967 TxPDO3 Boolean2 -	Selection
968 TxPDO3 Boolean3 -	Selection
969 TxPDO3 Boolean4 -	Selection
972 TxPDO3 Word1 -	Selection Systemb.
973 TxPDO3 Word2 -	Selection
974 TxPDO3 Word3 -	Selection
975 TxPDO3 Word4 -	Selection
976 TxPDO3 Long1 -	Selection
977 TxPDO3 Long2 -	Selection
989 Emergency Reaction -	Selection
1180 Operation Mode -	Selection
Further motor parameters	
	01 100.000 7.2.2

351



Parameters Description Unit Setting range Chapter No. 0.01% I_{FIN}... Ħ 1192 **Peak Current** Α 7.2.2 100000% oc IFIN 0 ... 16 EEPROM: 1250 7.6.6.17 Mux Input Index (write) 17 ... 33 RAM: EEPROM: 0 ... 16 1251 Mux Input Index (read) 7.6.6.17 RAM: 17 ... 33 1252 **Mux Inputs** Selection 7.6.6.17 7.6.6.17 1253 DeMux Input Selection 7.6.6.14 User warning 1 Selection 1363 1364 User warning 2 Selection 7.6.6.14 Convert PDP/in In-F-PDP-word1 7.10.12 1370 Selection 1371 In-F-PDP-word2 7.10.12 Selection 7.10.12 In-F-intern-long1 1372 Selection _ 1373 In-F-intern-long2 Selection 7.10.12 _ 0.01 Hz...999.99 Hz Convert-Reference 7.10.12 1374 Hz **Modbus Parity** Selection 6.2.10.2 **Modbus Address** 1 ... 247 CM-Modbus 1376 CANopen 0x3008 Perc. Actual 1414 Selection Value Source 1415 CANopen 0x3011 Act. ValueWord 1 -Selection 1416 CANopen 0x3012 Act. ValueWord 2 Selection 1417 CANopen 0x3021 Act. ValueLong 1 Selection 1418 CANopen 0x3022 Act. ValueLong 2 Selection EEPROM: 0 ... 16 1420 CANopen Mux Input Index (write) RAM: 17 ... 33 0 ... 16 EEPROM: 1421 CANopen Mux Input Index (read) RAM: 17 ... 33 CANopen Mux Inputs 1422 Selection CM-CAN CANopen Obj 0x3007 Actual Per-1423 Selection centage Value Source 1451 OS Synctime 700 ... 900 1432 IP Address nnn.nnn.nnn.nnn 1433 Netmask nnn.nnn.nnn.nnn 1434 Gateway nnn.nnn.nnn.nnn 1435 DNS Server nnn.nnn.nnn 1436 DHCP Option Selection 1437 IP Command Ethernet Selection 1438 Reload IP-Settings 0 ... 1 Selection 1440 Email function -1441 Email Text (Body) Text 1500 VABus-X21 Baud rate Selection 6.2.10.2 1501 VABus-X21 Node-ID 1 ... 30 CM-485 1502 VABus-X21 Watchdog Timer 0 ... 1000 CM-485 S Modbus (RTU/ 1503 Modbus Mode Selection 6.2.10.2 1504 Modbus Baud rate Selection CM-Modbus Baud 1505 Modbus Watchdog Timer 0 ... 1000 CM-Modbus S



No.	Description	Unit	Setting range	Chapter			
	Standby						
<u>1510</u>	Time until Keypad Standby	Min	0 60	8.3			
<u>1511</u>	Standby Mode	-	Selection	8.3			
	Real-time tu	ning					
<u>1520</u>	Operation Mode Real-Time Tuning	-	Selection	7.9.6			
	Service ¹⁾			·			
<u>1534</u>	Operation Mode Service Interval DC-link	-	Selection	10.3.1			
<u>1535</u>	Operation Mode Service Interval Fan	-	Selection	10.3.2			
<u>1539</u>	Reset Service Intervals	1	Selection	10.3.3			
	Device te	st					
<u>1540</u>	Start device test manual	-	Selection	7.2.3.4			
<u>1542</u>	Start device test automatic	-	Selection	7.2.3.5			
<u>1543</u>	Base Parameter Actual System Value	1	0 1600	7.10.9			
	Energy saving function						
<u>1550</u>	Operation Mode Energy Saving Function	-	Selection	8.1			
<u>1551</u>	Flux Reduction	%	0 100	8.1			
<u>1552</u>	Energy Saving FunctionOn	-	Selection	8.1			

1) For maintenance work contact the service of BONFIGLIOLI.

The column "chapter" refers to the chapter number and/or the corresponding document, that contains a detailed parameter description.

CM: Please refer to the manual of the used communication profile.

CM-CAN: Please refer to the **CAN** communication manual.

CM-PDPV1: Please refer to the **PROFIBUS** communication manual.

CM-485: Please refer to the **VABus** communication manual.

CM-Modbus: Please refer to the **Modbus** communication manual.

Systembus: Please refer to the **Systembus** communication manual.

Ethernet: Please refer to the **Ethernet** communication manual (i.e. Profinet, VABus/TCP,

Modbus TCP).



Index

A	Communication	98
Acceleration (Ramps)147	modules	. 308
Acceleration pre-control	Setup5	5, 74
Acknowledge error messages 202	Compressor, Application example	. 105
automatic142	Conductor cross-section	34
via keypad 98	Configuration	. 111
via logic signal 201	Connection	32
via Parameter 34 Program(ming) 113	Control	. 122
Actual values	Control functions	
memory 269	Intelligent current limits	. 212
of frequency inverter	PID	
of machine 268	Power failure regulation	
of system 269	Voltage controller	
Adaptor USB	Control level	
Analog inputs84	Control panel	
Analog outputs84	Lock123, 144, 153, 161	. 163
Assembly	Control signals	
Cold Plate	Control terminals	
size 1	Setting options	47
size 2	Standard settings	
size 3	Conveying plant, Application example	
DIN rail	Copy parameter values	
size 1 328	Copying with Memory Card	. 233
Feed-through	Warning message	255
size 1	Copyright	
size 2	Current controller	
	Current limit value controller	
size 3	Current limit value controller	
Standard		. 192
size 1	D Data set	202
size 2	Data set94	
size 3	changeover	
Vibration-proof	Deceleration (Ramps)	
size 1	Decommissioning	
size 2	Demultiplexer	
size 3	Designated use	
Auto set-up	Device test	
Auto start 129	Diagnosis	. 339
B	Digital input 2	
Blocking frequencies	Operation mode	
Blocking Frequencies86	Pulse train	
Brake	PWM	
Control via digital output	Repetition frequency	
Direct current brake	Digital input/output	
Brake chopper241	Digital inputs83	
Release 204	Evaluation logic 48, 186	
Brake resistor241	Logic signal	
connection41	Digital outputs83	
dimensioning 242	Logic signals	
C	Dimensions	27
Cable length39, 40	DIN rail	
CANopen 75	size 1	. 328
CE conformity 278	Direct current brake	
Cold Plate 318	Direction of rotation147	, 155
size 1 322	Check	
size 2 322	Start clockwise, start anticlockwise . 199	, 200
size 3 323	DMC (Direct Moment Control)	
Commissioning51	·	



E	Limits	145
Electrical connection 32	Ramps	147
Electrical connections	Frequency Limit	247
Electrical Installation31	Function table	205
Safety 31	G	
Electronic gear95, 163	Gear factor	165
Actual value 166	fixed	165
Gear factor 165	variable	165
Offset 166	General information about the docu	
Operation modes 163		
EMC32	Group drive	
Emergency stop	Н	
Enable	Hysteresis	150
Status of inputs 268	Frequency hysteresis	
Energy saving97, 258	of analog input signal	
Energy saving function	I	172, 173
Error behavior	Installation	20 27
Error environment	mechanical	
Error list	Intelligent current limits	
Error message	I	212
5	JOG	EO 1EO
Memory card copying	Start	,
Error messages	K K	201
of auto-setup	• •	F2
Error protocol	Keypad	
Error/Warning behaviour	KTY	140
Multifunction input 1	L .	4.40
Multifunction input 2	Leading	149
External error	M	
External fan	Machine data	
External power supply49	Mains Connection	•
F	Maintenance	
Factory reset	DC-link	
Complete reset 113	Fan	
Factory setting	Master drive, Traverse function	
single parameter via keypad60	Maximum frequency	145
Fan	Mechanical installation	
external 192	Safety	27
Switch-On Temperature 240	Memory card	308
Fan, Application example100, 101, 103	Menu	52
Feed-through	Minimum frequency	145
size 1 311	Modbus	
size 2 312	Modulation controller	237
size 3 314	Monitoring	
Feed-through assembly 310	Analog input signal1	73, 174, 180
Field bus98	Controller intervention	136
Field controller 236	Effective current	250
Field-orientated control	Heat sink temperature	136
Asynchronous motor 111	Inside temperature	
Synchronous motor 111	Load behavior	
Filter time constant 179	Motor temperature	
Multifunction input 1	Output frequency	
Multifunction input 2	Overload	
Fixed Frequencies	Phase failure	
Fixed frequency	Warning mask	
Changeover147, 201	Warning mask application	
Fixed percentage	Monitoring functions	
Changeover	Motor chopper	
Flux forming finished	Motor connection	
Flux reduction	Motor data	
Flying Start	Motor potentiometer	
, ,	•	
Frequency	control via digital inputs	



control via operator panel 160	Poti P 58
Motor protection	Power failure regulation 216
motor circuit breaker244	Profibus 75
Motor Protection	Protective functions 96
Motor Protection by I ² t- Monitoring 248	PT1000 141
Mounting	PTC 140
Multifunction input 168	Pulse train
Multifunction input 1	Input 209
Characteristic	Output 185
Error/Warning behaviour 174	Pulse train input87
Filter time constant	Pulse width modulation239
set as analog input	Pump, Application example99, 101
set as digital input	PWM input86, 208
Tolerance band 172	R
Multifunction input 2	Ramp
Characteristic	Frequency 147
Error/Warning behaviour 180	Percentage 155
Filter time constant	Ramp rise time149
set as analog input	Rated motor parameters 113
set as digital input	Reference frequency
Tolerance band	inverted145
Multifunction output	Reference frequency channel 142
Analog 183	Reference percentage
Characteristic	inverted 154
Digital 184	Reference percentage channel 151
Operation mode	Reference torque
Pulse train	Reference value
Repetition frequency	Fixed frequency
Multiplexer	Fixed percentage
N	JOG frequency
NPN 48, 186, 196	Motor potentiometer 156
O	Reached
OC (overload capacity)278	Release brake
Operator panel	Repetition frequency (RF)
Menu	Input
Options	Output
Assembly	Repetition frequency input
Variants 309	Resource pack
Brake resistor	S
Communication module	SA Warning messages auto set-up 68
DIN rail	Safety
Input filter	Electrical Installation
Line choke	General
	mechanical installation
Resource pack	S-curve
Shield sheet	Service
USB adaptor	•
Overload capacity	Setting frequency
-	Setup
Parameter	Asynchronous motor via operator panel 61
Copy	Communication
List	Synchronous motor via operator panel 65
Password	SF Error messages auto-setup
Percentage	Shield sheet
Limits	Slave drive, traverse function
Ramps	Slip compensation
Reference value	Speed control
PID controller	Speed controller
PLC	Switch-over speed/torque control 202
PNP	SS Status messages auto-setup
Positioning	Standby mode
Poti F	Start anticlockwise199, 200



Start clockwise	U	
Starting behavior	UL Approval	278
FOC 89	USB adaptor	
V/f 88	User Name	
Status device test	User warning	204
Stopping behavior 127	V	
Stopping behaviour 89	V/f	111
Storage 20	Characteristic	
Switching frequency	Linear	211
Synchronization	Quadratic	
, System bus	V/f characteristic	
System data	V/f Starting behaviour	
τ [′]	VABus	
TCP/IP 79	Vibration-proof	
Technical data 278	size 1	324
Technology controller 219	size 2	
Thermal time constant motor 249	size 3	326
Thermal time constant rotor	Voltage controller	214
Thermocontact	Voltage input	49
Three-wire control	W	
Tolerance band 172, 178	Warning behavior	135
Multifunction input 1 172	Warning code	
Multifunction input 2 178	of warning mask	194
Torque	of warning mask application	195
Control 230	Warning limit motor I ² t	249
Control, Application example 107	Warning mask	192
Reference value	Warning mask, application	195
Torque control 82	Warning message	
Transport 20	Memory card copying	
Travel application, Application example 106	Warning messages	340
Traverse function	of auto set-up	
Handshake 203	Warning status	
Type designation24	Warranty and liability	12



Bonfiglioli worldwide network.

Bonfiglioli Australia

2, Cox Place Glendenning NSW 2761 Locked Bag 1000 Plumpton NSW 2761 Tel. (+ 61) 2 8811 8000 - Fax (+ 61) 2 9675 6605 www.bonfiglioli.com.au - sales@bonfiglioli.com.au

Bonfiglioli Brazil

Travessa Cláudio Armando 171 - Bloco 3 CEP 09861-730 - Bairro Assunção São Bernardo do Campo - São Paulo Tel. (+55) 11 4344 1900 - Fax (+55) 11 4344 1906 www.bonfigliolidobrasil.com.br bonfigliolidobrasil@bonfiglioli.com

Bonfiglioli Canada

2-7941 Jane Street - Concord, Ontario L4K 4L6 Tel. (+1) 905 7384466 - Fax (+1) 905 7389833 www.bonfigliolicanada.com sales@bonfigliolicanada.com

Bonfiglioli China

19D, No. 360 Pu Dong Nan Road **New Shanghai International Tower** 200120 Shanghai Tel. (+86) 21 5054 3357 - Fax (+86) 21 5970 2957 www.bonfiglioli.cn - bdssales@bonfiglioli.com.cn

Bonfiglioli Deutschland

Sperberweg 12 - 41468 Neuss Tel. (+49) 02131 2988-0 Fax (+49) 02131 2988-100 www.bonfiglioli.de - info@bonfiglioli.de

Bonfiglioli España

TECNOTRANS BONFIGLIOLI S.A. Pol. Ind. Zona Franca sector C, calle F, n°6 08040 Barcelona Tel. (+34) 93 4478400 - Fax (+34) 93 3360402 www.tecnotrans.com - tecnotrans@tecnotrans.com

Bonfiglioli France

14 Rue Eugène Pottier BP 19 Zone Industrielle de Moimont II 95670 Marly la Ville Tel. (+33) 1 34474510 - Fax (+33) 1 34688800 www.bonfiglioli.fr - btf@bonfiglioli.fr

Bonfiglioli India

PLOT AC7-AC11 Sidco Industrial Estate Thirumudiyakkam - Chennai 600 044 Tel. +91(0) 44 24781035 - 24781036 - 24781037 Fax +91(0) 44 24780091 - 24781904 www.bonfiglioliindia.com - bonfig@vsnl.com

Bonfiglioli Italia

Via Sandro Pertini lotto 7b 20080 Carpiano (Milano) Tel. (+39) 02 985081 - Fax (+39) 02 985085817 www.bonfiglioli.it customerservice.italia@bonfiglioli.it

Bonfiglioli New Zealand

88 Hastie Avenue, Mangere Bridge, Auckland 2022, New Zealand - PO Box 11795, Ellerslie Tel. (+64) 09 634 6441 - Fax (+64) 09 634 6445 npollington@bonfiglioli.com.au

Bonfiglioli Österreich

Molkereistr 4 - A-2700 Wiener Neustadt Tel. (+43) 02622 22400 - Fax (+43) 02622 22386 www.bonfiglioli.at info@bonfiglioli.at

Bonfiglioli South East Asia

No 21 Woodlands indusrial park E1 #02-03 Singapore 757720 Tel. (+65) 6893 6346/7 - Fax (+65) 6893 6342 www.bonfiglioli.com.au sales@bonfiglioli.com.sg

Bonfiglioli South Africa

55 Galaxy Avenue, Linbro Business Park - Sandton Tel. (+27) 11 608 2030 OR - Fax (+27) 11 608 2631 www.bonfiglioli.co.za bonfigsales@bonfiglioli.co.za

Bonfiglioli Türkiye

Atatürk Organíze Sanayi Bölgesi, 10015 Sk. No: 17, Çigli - Izmir Tel. +90 (0) 232 328 22 77 (pbx) Fax +90 (0) 232 328 04 14 www.bonfiglioli.com.tr info@bonfiglioli.com.tr

Bonfiglioli United Kingdom

Industrial Solutions

Unit 7, Colemeadow Road North Moons Moat - Redditch, Worcestershire B98 9PB Tel. (+44) 1527 65022 - Fax (+44) 1527 61995 www.bonfiglioli.com uksales@bonfiglioli.com Mobile Solutions

3 - 7 Grosvenor Grange, Woolston Warrington - Cheshire WA1 4SF Tel. (+44) 1925 852667 - Fax (+44) 1925 852668 www.bonfiglioli.co.uk mobilesales@bonfiglioli.co.uk

Bonfiglioli USA

3541 Hargrave Drive Hebron, Kentucky 41048 Tel. (+1) 859 334 3333 - Fax (+1) 859 334 8888 www.bonfiglioliusa.com

Bonfiglioli Vietnam

Lot C-9D-CN My Phuoc Industrial Park 3 Ben Cat - Binh Duong Province Tel. (+84) 650 3577411 - Fax (+84) 650 3577422 www.bonfialioli.vn salesvn@bonfiglioli.com



Bonfiglioli has been designing and developing innovative and reliable power transmission and control solutions for industry, mobile machinery and renewable energy applicacations since 1956.